# DAWSONS HAULAGE TRAILER SERVICE SHEET

| | | | | | |
|---|---|---|---|---|---|
| TRAILER REGO | YB 72CK | | TRAILER NUMBER | Stag 15 (252) | DATE: 23-9-24 |
| KILOMETERS/HUBO | 22376km | | DOLLY NUMBER | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | — | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | — | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect ~~roof~~, walls and doors, including hardware | ✓ | |
| Inspect curtain condition, operation, posts and rollers Taps. | ✓ | |
| Inspect load strap and winder for condition and security | ✓ | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect suzi coils | — | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | ✓ | |
| COMPLIENCE STICKER YES / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check u-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check center bolts | ✓ | |
| Check springs | ✓ | |
| Check rocker bushes and rods | ✓ | |
| Check hangers | ✓ | |
| Check shockers | ✓ | |

| TOWING CONNECTION | A | C |
|---|---|---|
| Inspect turntable jaws - adjust if required | — | |
| Inspect turntable top/turntable inserts | — | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| Inspect all lights and reflectors - refer to NHVIM | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

NOTES:

| NAME | Jacob Murrell | SIGNATURE | | DATE | 23/9/24 |
|---|---|---|---|---|---|

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| TRAILER REGO | YB72CK | TRAILER NUMBER | 252 | DATE: | 12/1/26 |
|---|---|---|---|---|---|
| KILOMETRES/HUBO | | DOLLY NUMBER | | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | NA | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | NA | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect roof, walls and doors, including hardware | ✓ | |
| Inspect curtain condition, operation, posts and rollers | NA | |
| Inspect load strap and winder for condition and security | NA | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect Suzi coils | NA | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | NA | |
| COMPLIANCE STICKER YES / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check U-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check centre bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | | |
|---|---|---|
| Inspect turntable jaws - adjust if required | NA | |
| Inspect turntable top/turntable inserts | NA | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| inspect all lights and reflectors - refer to NHVIM 14.20 | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

**NOTES / OTHER WORK CARRIED OUT:**

| NAME | SIGNATURE | DATE |
|---|---|---|
| Dale | | 12/1/26 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| TRAILER REGO | YB72CK | TRAILER NUMBER | 252 | DATE: | 16/2/26 |
|---|---|---|---|---|---|
| KILOMETRES/HUBO | | DOLLY NUMBER | | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | NA | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | NA | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect roof, walls and doors, including hardware | ✓ | |
| Inspect curtain condition, operation, posts and rollers | NA | |
| Inspect load strap and winder for condition and security | NA | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect Suzi coils | NA | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | NA | |
| COMPLIANCE STICKER YES / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check U-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check centre bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | | |
|---|---|---|
| Inspect turntable jaws - adjust if required | NA | |
| Inspect turntable top/turntable inserts | NA | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| inspect all lights and reflectors - refer to NHVIM 14.20 | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

**NOTES / OTHER WORK CARRIED OUT:**

| NAME | SIGNATURE | DATE |
|---|---|---|
| Dale | | 16/2/26 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| | | | | | |
|---|---|---|---|---|---|
| TRAILER REGO | YB72CK | | TRAILER NUMBER | 252 | DATE: 16/12/25 |
| KILOMETERS/HUBO | | | DOLLY NUMBER | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | — | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | — | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect roof, walls and doors, including hardware | ✓ | |
| Inspect curtain condition, operation, posts and rollers | ~ | |
| Inspect load strap and winder for condition and security | — | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect suzi coils | — | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | ✓ | |
| COMPLIENCE STICKER YES / NO | | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check u-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check center bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | | |
|---|---|---|
| Inspect turntable jaws - adjust if required | — | |
| Inspect turntable top/turntable inserts | — | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| inspect all lights and reflectors - refer to NHVIM 14.20 | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

NOTES:

Repair Top L/H taillight wiring.

| NAME | SIGNATURE | DATE |
|---|---|---|
| Jesse Callaghan | | 16/12/25 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| TRAILER REGO | YB 72.CK | TRAILER NUMBER | 252 | DATE: 17/8/26 |
|---|---|---|---|---|
| KILOMETRES/HUBO | — | DOLLY NUMBER | — | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | ✓ | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | — | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect roof, walls and doors, including hardware | — | |
| Inspect curtain condition, operation, posts and rollers | — | |
| Inspect load strap and winder for condition and security | ✓ | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect Suzi coils | ✓ | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | ✓ | |
| COMPLIANCE STICKER YES / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check U-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check centre bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | A | C |
|---|---|---|
| Inspect turntable jaws - adjust if required | ✓ | |
| Inspect turntable top/turntable inserts | ✓ | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| inspect all lights and reflectors - refer to NHVIM 14.20 | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

**NOTES / OTHER WORK CARRIED OUT:**

Repair air lines for hook up.

Replaced worn king pin

| NAME | SIGNATURE | DATE |
|---|---|---|
| Jacob Murrell | | 17/8/26 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| TRAILER REGO | YB72CIC | TRAILER NUMBER | 252 | DATE: | 18/3/26 |
|---|---|---|---|---|---|
| KILOMETRES/HUBO | | DOLLY NUMBER | | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | N/A | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | N/A | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect roof, walls and doors, including hardware | ✓ | |
| Inspect curtain condition, operation, posts and rollers | N/A | |
| Inspect load strap and winder for condition and security | N/A | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect Suzi coils | N/A | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | N/A | |
| COMPLIANCE STICKER (YES) / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check U-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check centre bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | A | C |
|---|---|---|
| Inspect turntable jaws - adjust if required | N/A | |
| Inspect turntable top/turntable inserts | N/A | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| inspect all lights and reflectors - refer to NHVIM 14.20 | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

**NOTES / OTHER WORK CARRIED OUT:**

| NAME | SIGNATURE | DATE |
|---|---|---|
| Dale Dom | | 18/3/26 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| TRAILER REGO | YB72CK | | TRAILER NUMBER | 252 | DATE: 22/4/25 |
|---|---|---|---|---|---|
| KILOMETERS/HUBO | — | | DOLLY NUMBER | — | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | — | — |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | — | — |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect roof, walls and doors, including hardware | ✓ | |
| Inspect curtain condition, operation, posts and rollers | ✓ | |
| Inspect load strap and winder for condition and security | — | — |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect suzi coils | — | — |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | — | — |
| COMPLIENCE STICKER YES / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check u-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check center bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | | |
|---|---|---|
| Inspect turntable jaws - adjust if required | — | — |
| Inspect turntable top/turntable inserts | — | — |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| Inspect all lights and reflectors - refer to NHVIM | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

NOTES:

| NAME | Sam Fletcher | SIGNATURE | | DATE | 22/4/25 |
|---|---|---|---|---|---|

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| TRAILER REGO | YB72CK | TRAILER NUMBER | 252 | DATE: | 24/2/25 |
|---|---|---|---|---|---|
| KILOMETRES/HUBO | | DOLLY NUMBER | | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | — | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | — | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect roof, walls and doors, including hardware | ✓ | |
| Inspect curtain condition, operation, posts and rollers | ✓ | |
| Inspect load strap and winder for condition and security | — | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect Suzi coils | — | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | — | |
| COMPLIANCE STICKER YES / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check U-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check centre bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | | |
|---|---|---|
| Inspect turntable jaws - adjust if required | — | |
| Inspect turntable top/turntable inserts | — | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| inspect all lights and reflectors - refer to NHVIM 14.20 | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

**NOTES / OTHER WORK CARRIED OUT:**

| NAME | SIGNATURE | DATE |
|---|---|---|
| Dale Dom | Dale Dom | 24/2/25 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| | | | | | |
|---|---|---|---|---|---|
| TRAILER REGO | YD72CK | | TRAILER NUMBER | 252 | DATE: 24/11/25 |
| KILOMETERS/HUBO | | | DOLLY NUMBER | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | | |
| Inspect roof, walls and doors, including hardware | | |
| Inspect curtain condition, operation, posts and rollers | | |
| Inspect load strap and winder for condition and security | | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect suzi coils | ✓ | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | ✓ | |
| COMPLIENCE STICKER YES / NO | | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check u-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check center bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | | |
|---|---|---|
| Inspect turntable jaws - adjust if required | ✓ | |
| Inspect turntable top/turntable inserts | ✓ | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| Inspect all lights and reflectors - refer to NHVIM 14.20 | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

NOTES:

Replaced Rear Axle Tyres

| | | |
|---|---|---|
| NAME Sam Fletcher | SIGNATURE [signature] | DATE 24/11/25 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| | | | |
|---|---|---|---|
| TRAILER REGO | YB 72CK | TRAILER NUMBER | 252 |
| KILOMETERS/HUBO | 115577 | DOLLY NUMBER | |
| | | DATE | 27/5/25 |

| | A | C |
|---|---|---|
| **STRUCTURE** | | |
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | / | |
| Inspect cracks in twist lock beams | — | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | / | |
| Inspect twist locks condition/operation | — | |
| Inspect condition and security of landing legs/bracketry - check operation | / | |
| Inspect floor condition/security | / | |
| Inspect roof, walls and doors, including hardware | / | |
| Inspect curtain condition, operation, posts and rollers | — | |
| Inspect load strap and winder for condition and security | — | |
| **BRAKE COMPONENTS/AIR SYSTEM** | (A) | C |
| Inspect air fittings | / | |
| Test for air leaks - park brake, service brake applied | / | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | / | |
| Inspect brake drums - refer manufacturer's specification | / | |
| Inspect S cam - lubricate | / | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | / | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | / | |
| Inspect air tank mounting points/grain | / | |
| Inspect brake hoses for chaffing | / | |
| Inspect suzi coils | / | |
| Check operation of brakes | / | |
| Inspect brake backing plates - fit where missing | / | |
| Fault Report Repairs | / | |
| **WHEELS, TYRES AND BEARINGS** | (A) | C |
| Inspect wheel bearing adjustment - refer to manufacturer's specification | / | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | / | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | / | |
| Check tyre pressures | / | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |
| **SAFETY SYSTEMS** | A | C |
| Inspect all safety items including retractable stop blocks and lock pin warning flags | | |
| COMPLIENCE STICKER YES / NO | | |

| | A |
|---|---|
| **GENERAL** | (A) |
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | / |
| Check toolbox mount/security | / |
| **AIR SUSPENSION** | (A) |
| Check all shockers | / |
| Check all airbags for leaks/perished | / |
| Check spring saddles and alignment | / |
| Check ride height valve | / |
| Check eye bushes | / |
| Check u-bolt tension | / |
| **MECHANICAL SUSPENSION** | A |
| Check center bolts | |
| Check springs | |
| Check rocker bushes and rods | |
| Check hangers | |
| Check shockers | |
| **TOWING CONNECTION** | |
| Inspect turntable jaws - adjust if required | — |
| Inspect turntable top/turntable inserts | — |
| Inspect skid plate wear - refer NHVIM 14.6 | / |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | / |
| Check mounting bolt tension | / |
| **ELECTRICAL SYSTEM** | (A) |
| Inspect trailer plug - check pin condition | / |
| Inspect all lights and reflectors - refer to NHVIM | / |
| Inspect wiring harness - refer to NHVIM 14.18 | / |
| Inspect condition and security of GPS tracker | / |

NOTES:

fit unit stickers

| | | |
|---|---|---|
| NAME Jesse Callaghan | SIGNATURE | DATE 27/5/25 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| TRAILER REGO | YB72CK | TRAILER NUMBER | 252 | DATE: | 31/3/25 |
|---|---|---|---|---|---|
| KILOMETRES/HUBO | | DOLLY NUMBER | | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | — | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | — | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | / | |
| Inspect roof, walls and doors, including hardware | / | |
| Inspect curtain condition, operation, posts and rollers | / | |
| Inspect load strap and winder for condition and security | — | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | / | |
| Test for air leaks - park brake, service brake applied | / | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | / | |
| Inspect brake drums - refer manufacturer's specification | / | |
| Inspect S cam - lubricate | / | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | / | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | / | |
| Inspect air tank mounting points/grain | / | |
| Inspect brake hoses for chaffing | / | |
| Inspect Suzi coils | — | |
| Check operation of brakes | / | |
| Inspect brake backing plates - fit where missing | / | |
| Fault Report Repairs | | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | / | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | / | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | / | |
| Check tyre pressures | / | |
| Wash and inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | — | |
| COMPLIANCE STICKER (YES) / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | / | |
| Check toolbox mount/security | / | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | / | |
| Check all airbags for leaks/perished | / | |
| Check spring saddles and alignment | / | |
| Check ride height valve | / | |
| Check eye bushes | / | |
| Check U-bolt tension | / | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check centre bolts | X | |
| Check springs | X | X |
| Check rocker bushes and rods | X | X |
| Check hangers | X | X |
| Check shockers | X | X |

| TOWING CONNECTION | A | C |
|---|---|---|
| Inspect turntable jaws - adjust if required | — | |
| Inspect turntable top/turntable inserts | — | |
| Inspect skid plate wear - refer NHVIM 14.6 | / | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | / | |
| Check mounting bolt tension | / | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | / | |
| inspect all lights and reflectors - refer to NHVIM 14.20 | / | |
| Inspect wiring harness - refer to NHVIM 14.18 | / | |
| Inspect condition and security of GPS tracker | / | |

**NOTES / OTHER WORK CARRIED OUT:**

| NAME | SIGNATURE | DATE |
|---|---|---|
| Dale Chad | | 31/3/25 |

# DAWSONS HAULAGE TRAILER SERVICE SHEET

| TRAILER REGO | YB 72CK | | TRAILER NUMBER | Stag B-252 | DATE: 9/12/24 |
|---|---|---|---|---|---|
| KILOMETERS/HUBO | 62176km | | DOLLY NUMBER | | |

| STRUCTURE | A | C |
|---|---|---|
| Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19 | ✓ | |
| Inspect cracks in twist lock beams | — | |
| Inspect all guards, infills and mudflaps - refer NHVIM 14.15 | ✓ | |
| Inspect twist locks condition/operation | — | |
| Inspect condition and security of landing legs/bracketry - check operation | ✓ | |
| Inspect floor condition/security | ✓ | |
| Inspect roof, walls and doors, including hardware | ✓ | |
| Inspect curtain condition, operation, posts and rollers | ✓ | |
| Inspect load strap and winder for condition and security | — | |

| BRAKE COMPONENTS/AIR SYSTEM | A | C |
|---|---|---|
| Inspect air fittings | ✓ | |
| Test for air leaks - park brake, service brake applied | ✓ | |
| Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1 | ✓ | |
| Inspect brake drums - refer manufacturer's specification | ✓ | |
| Inspect S cam - lubricate | ✓ | |
| Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1 | ✓ | |
| Inspect brake boosters and brake valves - including blanking/vent plugs | ✓ | |
| Inspect air tank mounting points/grain | ✓ | |
| Inspect brake hoses for chaffing | ✓ | |
| Inspect suzi coils | ✓ | |
| Check operation of brakes | ✓ | |
| Inspect brake backing plates - fit where missing | ✓ | |
| Fault Report Repairs | ✓ | |

| WHEELS, TYRES AND BEARINGS | A | C |
|---|---|---|
| Inspect wheel bearing adjustment - refer to manufacturer's specification | ✓ | |
| Inspect all wheel studs and nuts - refer to NHVIM 14.12 | ✓ | |
| Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4 | ✓ | |
| Check tyre pressures | ✓ | |
| Wash and Inspect wheel bearings | N/A | |
| Repack bearing - must use Genuine BPW grease | N/A | |
| Inspect/replace hub seal as required | N/A | |
| Clean all grease from hubs and repack | N/A | |

| SAFETY SYSTEMS | A | C |
|---|---|---|
| Inspect all safety items including retractable stop blocks and lock pin warning flags | ✓ | |
| COMPLIENCE STICKER YES / NO | ✓ | |

| GENERAL | A | C |
|---|---|---|
| Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16 | ✓ | |
| Check toolbox mount/security | ✓ | |

| AIR SUSPENSION | A | C |
|---|---|---|
| Check all shockers | ✓ | |
| Check all airbags for leaks/perished | ✓ | |
| Check spring saddles and alignment | ✓ | |
| Check ride height valve | ✓ | |
| Check eye bushes | ✓ | |
| Check u-bolt tension | ✓ | |

| MECHANICAL SUSPENSION | A | C |
|---|---|---|
| Check center bolts | | |
| Check springs | | |
| Check rocker bushes and rods | | |
| Check hangers | | |
| Check shockers | | |

| TOWING CONNECTION | | |
|---|---|---|
| Inspect turntable jaws - adjust if required | — | |
| Inspect turntable top/turntable inserts | — | |
| Inspect skid plate wear - refer NHVIM 14.6 | ✓ | |
| Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease | ✓ | |
| Check mounting bolt tension | ✓ | |

| ELECTRICAL SYSTEM | A | C |
|---|---|---|
| Inspect trailer plug - check pin condition | ✓ | |
| Inspect all lights and reflectors - refer to NHVIM | ✓ | |
| Inspect wiring harness - refer to NHVIM 14.18 | ✓ | |
| Inspect condition and security of GPS tracker | ✓ | |

NOTES: Zip tied up rubbing air lines.

| NAME | Jacob Murrell | SIGNATURE | | DATE | 9/12/24 |
|---|---|---|---|---|---|