

EOI-41
BLLE

Unit # BTP 70

SKIDSTEER TRAILER

SERIAL # - NONE - HOMEBUILT

Date	Description of Work	Parts Costs	Labour Costs
Feb/13 WO#0018	CVIP (B&D), repair break away, brake switch, repair suspension (new bushings), check all tires, install new tire right rear, put new battery for breakaway, install new bushing & pins on suspension. (GILBERT)		
Feb/14 WO 0105	CVIP, repair LHS equilizer bar, install new one	57.92	
Feb 1/2016 WO#0196	CVIP. Check all wheels, tire pressure. Repair break away. Install new switch. CVIP done by B&D Industrial		
Feb16/17 WO#0230	Remove wheels for CVIP/Check tire pressure/Install new lights on rear/New plug in at front and new splice box		
Feb16/17	CVIP done by B&D Industrial		284.49
Jan18/18 WO#0266	CVIP done. Run charge wire for trailer battery. Repair left side brake broken wire.		
Jan19/18	CVIP done by B & D Industrial: Invoive 24301	324.96	
Dec 18/18	CVIP install new battery for brake away		
Feb2/20 WO#0340	CVIP. Check all lights. Put on flex tape.		
Dec 8/20 WO#0408	CVIP repairs. Repair fenders. Repair spring plate #2 Left side. Adjust all wheel bearings. Sand blast and paint.		
Nov18/21 WO#0448	CVIP. Repair board on deck. Remove wheels for inspection. Repair lights. Install new bearings and seals in all wheels.		
Dec2/22 WO#0541	CVIP. Pull wheels off for brake inspection. Repair brake away cable. Replace spring eye bushings. Repair lights.		
Nov14/23 WO#0562	CVIP. Repair break away. Adjust brakes. Repair cross member. Remove wheels and check brakes. Build new trailer.		
May22/24 WO#0578	Break Away. Right side brake. Chain latch. New Build Trailer		

BTP 70

OCT16/25

WO#0597

INSTALL NEW BATTERY TO E BRAKES. CVIP