

## METCALF CRANE SERVICES PTY LTD

### PRIME MOVER - INSPECTION & SERVICE REPORT

|                     |                      |                             |               |              |                   |
|---------------------|----------------------|-----------------------------|---------------|--------------|-------------------|
| <b>JOB NUMBER:</b>  | <b>H22-11</b>        | <b>UNIT NUMBER:</b>         | <b>UH22</b>   | <b>DATE:</b> | <b>31.03.2026</b> |
| <b>TRUCK MODEL:</b> | <b>Kenworth T909</b> | <b>REGISTRATION NUMBER:</b> | <b>XW56TW</b> | <b>KM'S:</b> | <b>246,697km</b>  |
| <b>HOURS:</b>       | <b>4,979</b>         |                             |               |              |                   |

**\*NOTE: MAKE SURE THAT HOURS AND KILOMETRES ARE RECORDED – MAKE SURE A SERVICE STICKER IS FITTED**

| SERVICE                                     | DONE                                | OK                                  | N/A                      | INITIAL | CHECK FAULT – COMMENTS – PLEASE NOTE ALL FINDINGS |
|---------------------------------------------|-------------------------------------|-------------------------------------|--------------------------|---------|---------------------------------------------------|
| <b>TEST DRIVE</b>                           |                                     |                                     |                          |         |                                                   |
| Drain air pressure, check build up          | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check park brake operation                  | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check braking operation                     | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check transmission operation                | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| <b>ELECTRICAL</b>                           |                                     |                                     |                          |         |                                                   |
| Operation of all lights                     | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check all warning systems:- horns           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check all warning systems:- flashing lights | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check all switch functions                  | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check wiper/washer operation & condition    | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check air conditioning operation            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| <b>CAB &amp; PANEL</b>                      |                                     |                                     |                          |         |                                                   |
| Ensure items in cab are secure              | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Condition of cab glass & interior           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Condition of cab, panels & doors            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check seat belt condition & mounting        | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| <b>STEERING</b>                             |                                     |                                     |                          |         |                                                   |
| Check all linkages & ball joints            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check ball joint rubber condition           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check & report leaks                        | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |

| SERVICE                                            | DONE                                | OK                                  | N/A                                 | INITIAL | CHECK FAULT – COMMENTS – PLEASE NOTE ALL FINDINGS |
|----------------------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|---------|---------------------------------------------------|
| <b>BRAKES</b>                                      |                                     |                                     |                                     |         |                                                   |
| Drain water from air tanks                         | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check condition & thickness of linings             | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>WHEELS</b>                                      |                                     |                                     |                                     |         |                                                   |
| Check tyre condition & pressures                   | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check wheel nuts                                   | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>PLEASE USE ISOLATION PROCEDURES &amp; TAGS</b>  |                                     |                                     |                                     |         |                                                   |
| Change engine oil & fill to level                  | <input checked="" type="checkbox"/> | <input type="checkbox"/>            | <input type="checkbox"/>            |         | Type & Litres: 50ltrs E900                        |
| Change oil filters                                 | <input checked="" type="checkbox"/> | <input type="checkbox"/>            | <input type="checkbox"/>            |         | Filter No: LF14000NN                              |
| Change fuel filters                                | <input checked="" type="checkbox"/> | <input type="checkbox"/>            | <input type="checkbox"/>            |         | Filter No: FF5776                                 |
| Change fuel pre filter                             | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         | Filter No:                                        |
| Check & clean air filter outer                     | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         | Filter No:                                        |
| Check & clean air filter inner                     | <input type="checkbox"/>            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> |         | Filter No:                                        |
| Check coolant level                                | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check & report coolant leaks                       | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check & report oil or fuel leaks                   | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check condition of hose & secure clips             | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check condition of mounts                          | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check exhaust system                               | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check battery levels, clean & lube terminals       | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check washer bottle level                          | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check air intake system                            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>TRANSMISSION</b> <input type="checkbox"/>       |                                     |                                     |                                     |         |                                                   |
| Check & report any oil leaks                       | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>DIFFERENTIAL, FINAL DRIVES &amp; DRIVELINES</b> |                                     |                                     |                                     |         |                                                   |
| Check & report oil leaks                           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Fill oil to level                                  | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check wear & lubricate drive shafts                | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>BRAKES</b>                                      |                                     |                                     |                                     |         |                                                   |
| Adjust all brakes                                  | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Change air dryer filter                            | <input type="checkbox"/>            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> |         |                                                   |

|                                           |
|-------------------------------------------|
| <b>GENERAL COMMENTS</b>                   |
| Replaced 4 Drive tyres (front drive axle) |
|                                           |
|                                           |
|                                           |

| TYRE PRESSURE | AXLE 1 | AXLE 2 | AXLE 3 | AXLE 4 |
|---------------|--------|--------|--------|--------|
| INNER         | 110Psi | 110Psi | 110Psi |        |
| OUTER         | 110psi | 110Psi | 110Psi |        |

|                      |                  |                       |            |
|----------------------|------------------|-----------------------|------------|
| <b>INSPECTED BY:</b> | Will Howden      | <b>QUALIFICATION:</b> | Mechanic   |
| <b>SIGNATURE:</b>    | <i>W. Howden</i> | <b>DATE:</b>          | 31.03.2026 |

|                                                                                                                                                                             |                       |                  |                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|------------------|---------------------|
| <b>Certification by Responsible Person:</b>                                                                                                                                 |                       |                  |                     |
| I certify that the described plant is to the manufacturers specifications and is being serviced and maintained by competent personnel to the manufacturer's recommendations |                       |                  |                     |
| <b>PRINT NAME:</b>                                                                                                                                                          | Bill Duncan           | <b>POSITION:</b> | Workshop Supervisor |
| <b>SIGNATURE:</b>                                                                                                                                                           | <i>William Duncan</i> | <b>DATE:</b>     | 31.03.2026          |

## METCALF CRANE SERVICES PTY LTD

### PRIME MOVER - INSPECTION & SERVICE REPORT

|                     |               |                             |        |              |            |
|---------------------|---------------|-----------------------------|--------|--------------|------------|
| <b>JOB NUMBER:</b>  | H22-12        | <b>UNIT NUMBER:</b>         | UH22   | <b>DATE:</b> | 20.08.2026 |
| <b>TRUCK MODEL:</b> | Kenworth T909 | <b>REGISTRATION NUMBER:</b> | XW56TW | <b>KM'S:</b> | km         |
| <b>HOURS:</b>       | Hrs           |                             |        |              |            |

**\*NOTE: MAKE SURE THAT HOURS AND KILOMETRES ARE RECORDED – MAKE SURE A SERVICE STICKER IS FITTED**

| SERVICE                                     | DONE                                | OK                                  | N/A                      | INITIAL | CHECK FAULT – COMMENTS – PLEASE NOTE ALL FINDINGS |
|---------------------------------------------|-------------------------------------|-------------------------------------|--------------------------|---------|---------------------------------------------------|
| <b>TEST DRIVE</b>                           |                                     |                                     |                          |         |                                                   |
| Drain air pressure, check build up          | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check park brake operation                  | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check braking operation                     | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check transmission operation                | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| <b>ELECTRICAL</b>                           |                                     |                                     |                          |         |                                                   |
| Operation of all lights                     | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check all warning systems:- horns           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check all warning systems:- flashing lights | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check all switch functions                  | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check wiper/washer operation & condition    | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check air conditioning operation            | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| <b>CAB &amp; PANEL</b>                      |                                     |                                     |                          |         |                                                   |
| Ensure items in cab are secure              | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Condition of cab glass & interior           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Condition of cab, panels & doors            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check seat belt condition & mounting        | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| <b>STEERING</b>                             |                                     |                                     |                          |         |                                                   |
| Check all linkages & ball joints            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check ball joint rubber condition           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |
| Check & report leaks                        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |         |                                                   |

| SERVICE                                            | DONE                                | OK                                  | N/A                                 | INITIAL | CHECK FAULT – COMMENTS – PLEASE NOTE ALL FINDINGS |
|----------------------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|---------|---------------------------------------------------|
| <b>BRAKES</b>                                      |                                     |                                     |                                     |         |                                                   |
| Drain water from air tanks                         | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check condition & thickness of linings             | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>WHEELS</b>                                      |                                     |                                     |                                     |         |                                                   |
| Check tyre condition & pressures                   | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check wheel nuts                                   | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>PLEASE USE ISOLATION PROCEDURES &amp; TAGS</b>  |                                     |                                     |                                     |         |                                                   |
| Change engine oil & fill to level                  | <input checked="" type="checkbox"/> | <input type="checkbox"/>            | <input type="checkbox"/>            |         | Type & Litres: 50ltrs E900                        |
| Change oil filters                                 | <input checked="" type="checkbox"/> | <input type="checkbox"/>            | <input type="checkbox"/>            |         | Filter No: LF14000NN                              |
| Change fuel filters                                | <input checked="" type="checkbox"/> | <input type="checkbox"/>            | <input type="checkbox"/>            |         | Filter No: FF5776                                 |
| Change fuel pre filter                             | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         | Filter No FS19764                                 |
| Check & clean air filter outer                     | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         | Filter No: Cleaned                                |
| Check & clean air filter inner                     | <input type="checkbox"/>            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> |         | Filter No:                                        |
| Check coolant level                                | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check & report coolant leaks                       | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check & report oil or fuel leaks                   | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check condition of hose & secure clips             | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check condition of mounts                          | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check exhaust system                               | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check battery levels, clean & lube terminals       | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check washer bottle level                          | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check air intake system                            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>TRANSMISSION</b> <input type="checkbox"/>       |                                     |                                     |                                     |         |                                                   |
| Check & report any oil leaks                       | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>DIFFERENTIAL, FINAL DRIVES &amp; DRIVELINES</b> |                                     |                                     |                                     |         |                                                   |
| Check & report oil leaks                           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Fill oil to level                                  | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Check wear & lubricate drive shafts                | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| <b>BRAKES</b>                                      |                                     |                                     |                                     |         |                                                   |
| Adjust all brakes                                  | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            |         |                                                   |
| Change air dryer filter                            | <input type="checkbox"/>            | <input type="checkbox"/>            | <input checked="" type="checkbox"/> |         |                                                   |

|                                   |
|-----------------------------------|
| <b>GENERAL COMMENTS</b>           |
| Tyre pressures checked ok         |
| Lights ok                         |
| Road test ok                      |
| Due for new belts & idler pullies |

| TYRE PRESSURE | AXLE 1 | AXLE 2 | AXLE 3 | AXLE 4 |
|---------------|--------|--------|--------|--------|
| INNER         | 110Psi | 110Psi | 110Psi |        |
| OUTER         | 110psi | 110Psi | 110Psi |        |

|                      |                  |                       |            |
|----------------------|------------------|-----------------------|------------|
| <b>INSPECTED BY:</b> | Will Howden      | <b>QUALIFICATION:</b> | Mechanic   |
| <b>SIGNATURE:</b>    | <i>W. Howden</i> | <b>DATE:</b>          | 20.08.2026 |

|                                                                                                                                                                             |                       |                  |                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|------------------|---------------------|
| <b>Certification by Responsible Person:</b>                                                                                                                                 |                       |                  |                     |
| I certify that the described plant is to the manufacturers specifications and is being serviced and maintained by competent personnel to the manufacturer's recommendations |                       |                  |                     |
| <b>PRINT NAME:</b>                                                                                                                                                          | Bill Duncan           | <b>POSITION:</b> | Workshop Supervisor |
| <b>SIGNATURE:</b>                                                                                                                                                           | <i>William Duncan</i> | <b>DATE:</b>     | 20.08.2026          |