

CHASSIS DETAIL FOR 679855**Print****Model** 389**Class** 8**Unit Type** Tractor**Stock Type** Customer**Invoice Date** 11/28/2023**Build Date** /**VIN** 1XPXA48X7RD679855**Sleeper Type** NO SLEEPER SELECTED**Intended Service** DUMP**Commodity Hauled** CONSTRUCTION MATERIALS**DEALER TRUCK PURCHASE ORDER (DTPO) INFORMATION****DTPO Order Date** 4/3/2023**DTPO Number** 10063755**MAJOR COMPONENTS**

Type	Make	Model	Serial #
DIESEL PARTICULATE FILTER (DPF)	CUMMINS	DUAL	6D304237312
ENGINE	CUMMINS	X15 500V@1900 GOV@2000 1650@950 PRODUCTIVITY SERIES (2021 EMISSIONS)	80587991
FORWARD REAR AXLE	MERITOR	RS23-161	FOR08836460
STEERING AXLE	DANA SPICER		MY02479220
TRANSMISSION	FULLER	FRO16210C	P1635442

Chassis: 679855 Model: MODEL 389 CONVENTIONAL Build
Date: 11/08/23

0000-A00-000 CHAS WT FRT: 8140 KGS

CHAS WT FRT: 8140 KGS
 CHAS WT REAR: 5040 KGS
 13180

0000-DEN-TRE RELEASE TECH

RELEASE TECH
 REL-RPM REL TECH RYAN MALONEY 1

0000-ZZZ-ZZZ VEHICLE ID NO:1XPXA48X7RD679855

VEHICLE ID NO:1XPXA48X7RD679855
 SK FAIRINGS L3200EY BLUE
 SK FAIRINGS L3200EY BLUE
 CAB/HOOD
 A - L0006EY WHITE
 FRAME L0001EA BLACK
 FENDER L0006EY WHITE
 HOOD TOP L0006EY WHITE
 CAB ROOF L0006EY WHITE
 SK FAIRINGS L0006EY WHITE

0000-111-111 CHASSIS INFORMATION SHEET

CHASSIS INFORMATION SHEET
 DEALER CODE- P400
 DEALER- PETERBILT TRK PTS & EQ.
 OWNER- MDB TRUCKING
 MODEL- 0003891
 WHEELBASE 0004318 MM
 CUTOFF 0000762 MM
 FX/BOC 0002357 MM
 CAB/AXLE 0001960 MM
 CAB/EOF 0002722 MM
 FRAME CUT LENGTH 0005079 MM

0002-300-B04 ENGINE ANGLE - 2 DEGREE

ENGINE ANGLE - 2 DEGREE
 ENGINE ANGLE - 2 DEGREE

0002-300-EAQ REAR AXLE ANGLE - 6 DEGREE

REAR AXLE ANGLE - 6 DEGREE
 REAR AXLE ANGLE - 6 DEGREE

0002-300-W45 SELECTION INFORMATION - SCH WEEK 45

SELECTION INFORMATION - SCH WEEK 45

0160-111-111 REAR OR FIXD SET AHD CL BOGIE 008.0 IN

REAR OR FIXD SET AHD CL BOGIE 008.0 IN

0200-A00-000 FRONT AXLE S/N: MY02479220

FRONT AXLE S/N: MY02479220

0300-A00-000 FWD REAR S/N: FOR08836460

FWD REAR S/N: FOR08836460

0300-306-AAK COMMON PARTS

COMMON PARTS

REYCO SUSPENSION**SK19262 INSTL-SPRING SEAT BLOCKS**

03-00681 STOP-REAR,AXLE SEAT 4

0300-306-G03 TRACKING RODS**TRACKING RODS****SK22649-104 AXLE WELD**

>>>>>>>>> ENGINEERING NOTE <<<<<<<<<<<

= NOTIFY MERITOR APPL ENGR PRIOR TO

CHANGING AXLE WELDING SK S OR PARTS=

= ALSO UPDATE AXLE BRKT WELDING DWG =

C65-6027-000000581 ROD - TRACKING, AIR TRAC 1

K055-405 Bracket, Torque Rod 1

TRACK ROD HDWE FRAME SIDE

W34-1160-120 BOLT-FINISHED HEX, M16 2

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 2

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 2

W34-1162-016 Washer (16MM) 4

TRACK ROD HDWE AXLE SIDE

W34-1160-100 Hex Bolt (M16 x 2.00 x 100mm) 2

K221-5086-9 Suspension Spacer (12.7mm) 2

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 2

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 2

W34-1162-016 Washer (16MM) 4

0300-306-HCA HEIGHT CONTROL VALVE**HEIGHT CONTROL VALVE****HEIGHT CONTROL VALVE - NYLON HOSE****SINGLE HEIGHT CONTROL VALVE****C95-6007 INSTL - REYCO HCV MTG****SK29796-014 DIAG-SUSPENSION PLMB**

90554141 LINK, NEWAY SUSPENSION 1

HCV FASTENERS

27-00312-004 Hex Nut (1/4") 2

27-00562-004 Spring Lock Washer (1/4") 2

C11-6064 BRACKET - MOUNTING, HCV 1

27-00204-006 Thread Rolling Screw (1/4-20 x 3/4") 2

AIR DRYER FITTING

G38-1023-0406 Straight Fitting, Brass (#4 Male NPT to #6 J2494) 1

G90-6131-04D5 Height Control Valve Assembly 1

03-07696 Bracket, HCV, Frame Mounted, Rear Rear, Steel 1

27-00428-004 Flat Washer (1/4") 2

27-00566-004 Lock Nut (1/4") 2

G90-6129-005

Height Control Valve Assembly	1		
G90-6131-04D5ASSY	LABOR-HGT CTRL VLV ASSY	1	
G50-6022-04PURCTL	Purple Nylon Tubing (1/4")	1	
<i>MSB TO DUMP VALVE (3401)</i>			
G50-6022-06PURCTL	Purple Nylon Tubing (3/8")	1	
<i>AIR DRYER TO HCV (1110)</i>			
G50-6022-04PURCTL	Purple Nylon Tubing (1/4")	1	
<i>HCV TO L/H REAR AIR BAG (3402)</i>			
G50-6022-04PURCTL	Purple Nylon Tubing (1/4")	1	
<i>HCV TO R/H REAR AIR BAG (3403)</i>			
G50-6022-04PUR006	TUBING-NYLON AIR BRAKE	1	
<i>HCV EXHAUST TUBE</i>			

0300-306-JAN AIR SUSPENSION HOSES

AIR SUSPENSION HOSES

SK28672-0000GF PLUMBING, AIR BAG

AIR BAG FITTINGS

G38-1021-0404	90° Elbow Fitting (#4 Male NPT to #4 J2494)	2	
G38-1024-040404	FTG-RUN TEE MALE NPT	1	
G50-6022-04PURCTL	Purple Nylon Tubing (1/4")	1	
<i>L/H FWD AIR BAG TO CAB MANIFOLD (3404)</i>			

0300-306-LAL REYCO 102AR SUSP KIT

REYCO 102AR SUSP KIT

03-08477	SPSN 102AR23 REYCO	1	
----------	--------------------	---	--

0300-352-V43 STANDARD AXLE ANGLE

STANDARD AXLE ANGLE

SK19955-06 STD AXLE ANGLE

0300-369-ACF SYNTHETIC OIL LUBE

SYNTHETIC OIL LUBE

*NOTE-ADD 19 QTS OF SYNTHETIC GEAR OIL
TO THE FORWARD DRIVE AXLE.*

*NOTE-QTYS ARE APPROXIMATE AND VARY
DIFFERENT PINION ANGLES. USE*

FILLER HOLE FOR FINAL ADJUSTMENT.

USE THE FWD FILLER HOLE W/ PINION

ANGLES LESS THAN OR EQUAL TO 7

*DEG AND THE RR FILLER HOLE W/
PINION ANGLES GREATER THAN 7 DEG.*

=== ADD 1QT OF SYNTHETIC GEAR

OIL TO EACH DRIVE HUB ===

FE75W90	LUBE-BASF 7106 FE 75W90	21	
E53-6000	DECAL - SYNTHETIC LUBE	1	

0350-300-AAS REAR BRAKE CLOCKING ANGLE

REAR BRAKE CLOCKING ANGLE

SK29190-157 INSTL BRAKE, FWD RR AXLE

0500-A00-000 ENGINE S/N: 80587991

ENGINE S/N: 80587991

UNIT TRANS S/N: P1635442

CILS S/N: 31597058

053P-501-AAE FULLER FRO16210C TRANSMISSION*FULLER FRO16210C TRANSMISSION**INTERNAL OIL PUMP W/ COOLER*

T-A3Y11K6N02F020000 PNG-TRANSMISSION-EATON 1

+++++++ *BASE PART INFORMATION* +++++++=== *BASE PART NUMBER - T-A*=== *BASE PART FORMAT- BBCDEFGHJKLMNPQR*=== *BASE PART I.D. - PTM08* ===**0530-500-F22 INSTRUCTION MANUAL***INSTRUCTION MANUAL*

TRDR0515 "OP INSTR, 10-SPEED" 1

0530-500-KBX SYNTHETIC LUBE*SYNTHETIC LUBE**NOTE-OIL CAPACITIES ARE APPROXIMATE**DEPENDING ON INCLINATION OF**TRANSMISSION. ALWAYS FILL**TRANSMISSION TO LEVEL OF**FILLER OPENING.*

PS386 SYNTHETIC TRANS. OIL 12.50000

0530-700-A36 TRANSMISSION HARDWARE*TRANSMISSION HARDWARE**SK27172 SHIFTER BOOT PLATE INSTL**SK26466 INSTL TRANSMISSION HARDWARE*

S09-6000 Shifter Boot 1

22-01151-010 Cushioned Clamp (5/8") 1

05-17809 Shifter Boot Retainer, 1

Aluminum

27-01426-005 Pan Head Thread Rolling 6

Screw (#10-24 x 5/8")

27-00316-008 Hex Nut, (1/2-13), UNC-2B 1

622715 O-Ring 3

27-01000-008 Lock Nut w/ Nylon Insert (M8 1
x 1.25)**0530-701-D01 FLYWHEEL HOUSING HARDWARE***FLYWHEEL HOUSING HARDWARE*

W34-1155 BOLT-STUD, XMSN 12

0800-300-K01 CHASSIS PIPING TIE STRAPS*CHASSIS PIPING TIE STRAPS*

A62-6084 Cable Tie Mount 24

K231-363YEL STRAP - CABLE TIE (CLAMP) 24

== *BUNDLE CONTAINMENT TIE STRAPS* ==

K231-363YEL STRAP - CABLE TIE (CLAMP) 30

0800-302-KAJ MOUNTING HARDWARE FOR CAB HOSE ASSY*MOUNTING HARDWARE FOR CAB HOSE ASSY**G94-6009-000 PLUMBING UNDER CAB**T95-6007 RTG- FOOT VAVLE HOSES**T95-6007 RTG- FOOT VAVLE HOSES**R95-6011 CAB SILL WINDLACE**G95-6152 RTG: UNDERCAB AIR HOSES**G95-6152 RTG: UNDERCAB AIR HOSES*

G95-6152 RTG: UNDERCAB AIR HOSES**MOUNTING HARDWARE FOR MTG TP-5 VALVE**

27-00269-012	Hex Bolt (5/16-18 x 3")	2
27-00428-005	Flat Washer (5/16")	2
27-00437	Lock Nut (5/16-18)	2

== MNT TP-5 USING 2 BOLTS IN DIAGONAL

PATTERN ==

22-01150-034	Hose Clamp, w/ Liner (2-1/8")	3
D11-6283	BRACKET-STANDOFF, ENGINE	1
22-01151-022	Cushioned Clamp (1-3/8")	1
22-01151-016	Cushioned Clamp (1")	3
29-00930-0050	WINDLACE	1
29-00930-0000	Edge Trim, Rubber, Cut to Length	

INSTL WINDLACE ON CAB SILL TO ENSURE

TP-5 VLV PLUMBING DOES NOT RUB METAL.

HARDWARE FOR MTG ACCELERATOR PLATE

20-04611	J - Nut (1/4-20)	11
27-01429-012	Truss Head Screw, Thread Rolling (1/4-20 x 1-1/2")	11

HARDWARE FOR MTG BULKHEAD BRACKET

27-00268-004	Hex Bolt (1/4-20 x 1")	2
27-00428-004	Flat Washer (1/4")	4
27-00562-004	Spring Lock Washer (1/4")	2
27-00312-004	Hex Nut (1/4")	2

0800-309-SAD AIR DRYER INLET PLUMBING

AIR DRYER INLET PLUMBING

26-01932	Connector, 90 Deg (1/2" MP X #12 Flare)	1
V50-6033-0112CTL	Compressor Discharge Hose Assembly (5/8")	1
05712P-C00	Crimp Shell	2
101-14125	Nut (#12)	2
110-02892	Insert (45 Deg. Flare), Brass	2
H010-12	EPDM Hose w/ Wire Reinforcement & Braided Cover	10

DISCHARGE JUNCTION TO AIR DRYER (1001)

0800-313-ACU REAR BRAKE PIPING - NYLON HOSE

REAR BRAKE PIPING - NYLON HOSE

4 MODULATOR ANTILOCK SYSTEM

G97-6049-001 REAR BRAKE PLMBG W/ ABS

G97-6049-001 REAR BRAKE PLMBG W/ ABS

G97-6049-001 REAR BRAKE PLMBG W/ ABS

BRAKE VALVES

G90-6113-001	Quick Release Valve Assembly	1
08-03119	Quick Release Valve	1
G38-1021-0406	90° Elbow Fitting (#4 Male NPT to #6 J2494)	2

K129-188-0606	45° Male Elbow Fitting (3/8-18 NPTF x 5/8-18 NF)	2
G90-6160-505	Air Traction Relay Valve Assembly	1
G38-1021-0408	90° Fitting (#4 Male NPT to #8 J2494)	1
G38-1021-0812	90° Elbow Fitting (#8 Male NPT to #12 J2494)	1
G38-1023-0806	Straight Fitting, Brass (#8 Male NPT to #6 J2494)	1
K105766	VALVE-RAM, ATR-6	1
K129-186-0808	90° Male Elbow Fitting (1/2-14 NPTF x 3/4-16 NF)	2
K129-194-08	Square Pipe Plug (1/2-14 NPTF)	1
K129-290-0404	Pipe Adapter Fitting (1/4-18 NPTF x 1/4-18 NPTF)	1

HARDWARE VALVE PACKAGE

27-00269-013	Hex Bolt (5/16-18 x 3-1/4")	2
27-00566-005	Lock Nut (5/16")	2
27-00503-005	Flat Washer (5/16")	4

HARDWARE QR-1C VALVE

27-00269-005	Hex Bolt (5/16-18 x 1-1/4")	2
27-00566-005	Lock Nut (5/16")	2
27-00503-005	Flat Washer (5/16")	4

NYLON TUBING REQUIREMENTS

G50-6022-080RNCTL	Orange Nylon Tubing (1/2")	1
<i>FT VLV/BOC BLKHD TO SRV BRK RLY (1501)</i>		
G50-6022-120RNCTL	Orange Nylon Tubing (3/4")	1
<i>REAR DRY TANK TO SERV BRK RELAY (1306)</i>		
G50-6022-06YELCTL	Yellow Nylon Tubing (3/8")	1
<i>PARK CONTROL VLV TO QR1C (1601)</i>		
G50-6022-060RNCTL	Orange Nylon Tubing (3/8")	1
<i>SERVICE BRAKE RELAY TO QR1C(2102)</i>		

0800-313-LAG REAR BRAKE CHAMBER PIPING**REAR BRAKE CHAMBER PIPING**

= USE BUTTERFLY STRAPS AS NEEDED TO

SECURE BRAKE HOSES =

26-03424-031	Air Brake Hose Assy, SAE Flared, Crimped, (#6 x 31")	2
26-03425-023	Air Brake Hose Assembly, Crimped (#8 x 23")	2

0800-351-AAD 1ST AIR TANK APPLICATION-FWD AIR TANK*1ST AIR TANK APPLICATION-FWD AIR TANK**REF B/M TITLE***0800-351-CAV 1ST 9.5 X 24 AIR TANK - PAINTED ALUM***1ST 9.5 X 24 AIR TANK - PAINTED ALUM*

08-02387	Air Tank - Aluminum (9-1/2" X 24")	1
26-01984-004	Plug, Square Head (1/4")	1

0800-352-AAE 2ND AIR TANK APPLICATION-RR AIR TANK

2ND AIR TANK APPLICATION-RR AIR TANK

REF B/M TITLE

0800-352-CAH 2ND 9.5 X 24 AIR TANK - PAINTED ALUM

2ND 9.5 X 24 AIR TANK - PAINTED ALUM

08-02281 Air Tank, Aluminum (9-1/2" x 1
24")

26-01984-004 Plug, Square Head (1/4") 2

0800-353-AAE 3RD AIR TANK APPLICATION-RR AIR TANK

3RD AIR TANK APPLICATION-RR AIR TANK

REF B/M TITLE

0800-353-BAE 3RD 8 X 33 AIR TANK - POLISHED ALUM

3RD 8 X 33 AIR TANK - POLISHED ALUM

08-02392P Air Tank, Aluminum (8" x 1
33"), Polished

26-01984-004 Plug, Square Head (1/4") 1

0800-361-AAC ONE AIR TANK MOUNTING - 9.5 AIR TANK

ONE AIR TANK MOUNTING - 9.5 AIR TANK

MTD HORIZONTAL ON RAIL

WITH STD 001 BRKTS W/O SPACERS

G34-6009 Air Tank U-Bolt, High 2
Strength (9-1/2")08-03116-001 Mounting Bracket, Air Tank, 2
Steel (540mm)

27-00428-005 Flat Washer (5/16") 4

27-00791-005 Lock Nut (5/16-24) 4

0800-362-DAN (1) AIR TANK MOUNTING - 8X33 AIR TANK

(1) AIR TANK MOUNTING - 8X33 AIR TANK

MTD LH U/CAB OVER BATT/TOOL BOX

SK17275 INSTALL AIR TANK

G11-6193 BRACKET-AIR TANK 1

G11-6193R BRACKET-AIR TANK 1

08-02296 U-Bolt - Air Tank (5/16-24 X 2
8")

27-00428-005 Flat Washer (5/16") 4

27-00791-005 Lock Nut (5/16-24) 4

0800-362-HAC (1) AIR TANK MOUNTING - 9X24 AIR TANK

(1) AIR TANK MOUNTING - 9X24 AIR TANK

MTD BACK OF LH U/CAB BATTERY BOX

SK17275 INSTALL AIR TANK

G34-6009 Air Tank U-Bolt, High 2
Strength (9-1/2")

27-00428-005 Flat Washer (5/16") 4

27-00791-005 Lock Nut (5/16-24) 4

0800-366-AAM BERG PULL CORD DRAIN VALVE

BERG PULL CORD DRAIN VALVE

==SECURE PULL CORD FROM MOVING PARTS==

08-02355-0140 Drain Valve, w/ Cable 2
(140mm)**0800-366-BAF BERG PULL CORD ON 1ST AIR TANK**

BERG PULL CORD ON 1ST AIR TANK

SK30099 INSTL DRAIN VALVE LH U/CAB

SK30099 INSTL DRAIN VALVE LH U/CAB

==SECURE PULL CORD FROM MOVING PARTS==

08-02355-0914	Drain Valve, w/ Cable (914mm)	1
27-00268-004	Hex Bolt (1/4-20 x 1")	1
27-00204-005	Thread Rolling Screw (1/4-20 x 5/8")	1
22-01149-008	Cushioned Clamp, (1/2")	1
27-00428-004	Flat Washer (1/4")	2
27-00803-004	Lock Nut (1/4-20), Stainless Steel	1
05-10662	Anchor Bracket	1
22-01151-010	Cushioned Clamp (5/8")	1

0800-702-BCH TRACTOR APPLICATION AIR LINES

TRACTOR APPLICATION AIR LINES

NYLON CHASSIS HOSE

G97-6061 INSTL POGO STICK ASSY

G50-6022-08REDCTL	Red Nylon Tubing (1/2")	1
-------------------	-------------------------	---

TP VALVE TO XMBR

G50-6022-10BLUCTL	TUBING-NYLON AIR BRAKE	1
-------------------	------------------------	---

TP VALVE TO XMBR

0800-702-E01 12 FOOT STANDARD AIR LINES

12 FOOT STANDARD AIR LINES

G50-1085-01-0-144	Trailer Service/Emergency Hose Assembly (144")	1
-------------------	---	---

0800-704-FCZ AIR TANK PLUMBING ARRANGEMENT

AIR TANK PLUMBING ARRANGEMENT

NYLON CHASSIS HOSE

G97-6012-0D0118000 PLMBG FWD DRY TANK

G97-6012-0D0118000 PLMBG FWD DRY TANK

G38-1021-0808	90° Elbow Fitting (#8 Male NPT to #8 J2494)	1
---------------	--	---

G38-1021-0810	90° Fitting (#8 Male NPT to #10 J2494)	1
---------------	---	---

26-01984-004	Plug, Square Head (1/4")	1
--------------	--------------------------	---

26-01984-008	Square Head Plug (1/2")	3
--------------	-------------------------	---

ADDITIONAL PARTS FOR STABILITY CONTROL

G38-1021-0810	90° Fitting (#8 Male NPT to #10 J2494)	1
---------------	---	---

0800-704-GBM AIR TANK PLUMBING ARRANGEMENT

AIR TANK PLUMBING ARRANGEMENT

NYLON CHASSIS HOSE

G97-6011-00188200D PLMBG REAR DRY TANK

G97-6011-00188200D PLMBG REAR DRY TANK

G97-6011-00100000D PLMBG REAR DRY TANK

G97-6011-00100000D PLMBG REAR DRY TANK

FITTINGS FOR 1ST REAR DRY TANK

G38-1021-0808	90° Elbow Fitting (#8 Male NPT to #8 J2494)	1
---------------	--	---

G38-1021-0808

90° Elbow Fitting (#8 Male NPT to #8 J2494)	1	
G38-1021-0812	90° Elbow Fitting (#8 Male NPT to #12 J2494)	1
G38-1021-0810	90° Fitting (#8 Male NPT to #10 J2494)	1
26-01984-004	Plug, Square Head (1/4")	1
26-01984-008	Square Head Plug (1/2")	1
<i>FITTINGS FOR 2ND REAR DRY TANK</i>		
G38-1021-0810	90° Fitting (#8 Male NPT to #10 J2494)	1
26-01984-004	Plug, Square Head (1/4")	1
26-01984-008	Square Head Plug (1/2")	4

0900-300-ADG FRONT TIRES - MICHELIN

FRONT TIRES - MICHELIN

MN 14PLY 275/80R22.5 XZE2

TIRE MANUFACTURE - MICHELIN

MN275/80R225GXZE2	TIRE - MICHELIN	2
-------------------	-----------------	---

0900-301-ADV MICHELIN XDN2 - 275/80R22.5 - 14 PLY

MICHELIN XDN2 - 275/80R22.5 - 14 PLY

DRIVING REAR TIRES

TIRE MANUFACTURER - MICHELIN

MN275/80R225GXDN2	TIRE MICHELIN	4
-------------------	---------------	---

0910-300-A11 OUTER CAPNUTS

OUTER CAPNUTS

SK28916 INSTL WHEEL LUGNUT LABELS

NOTE: INSTL (1) LABEL TO EA FRAME RAIL

BEHIND FRT AXLE. LABEL MUST BE

VISIBLE AFTER WHEEL IS INSTALLED

H20-6000	WHEEL NUT-TWO PIECE M22	20
A53-1001-1	LABEL-CHASSIS,WHL LUGNUTS	2

0910-301-AJS ALCOA FRONT WHEEL

ALCOA FRONT WHEEL

ALCOA ULA187 - HIGH POLISH

= MS0910.005 WHEEL BALANCING =

= USE BALANCE WEIGHTS AS REQUIRED =

ULA187	WHEEL- 22.5X8.25	2
H02-6002-000	WEIGHT-BALANCE	

0910-320-AAC OUTER CAPNUTS

OUTER CAPNUTS

SK28916 INSTL WHELL LUGNUT LABELS

NOTE: INSTL (1) LABEL TO EACH FRAME

RAIL CENTERED ON REAR DR AXLE.

LABEL MUST BE VISIBLE AFTER

WHEEL INSTALLATION

H20-6000	WHEEL NUT-TWO PIECE M22	20
A53-1001-1	LABEL-CHASSIS,WHL LUGNUTS	2

0910-321-AMA ALCOA REAR WHEEL

ALCOA REAR WHEEL*ALCOA ULA187 - HIGH POLISH*

ULA187 WHEEL- 22.5X8.25 4

1100-302-EBM FUEL TANK LABEL*FUEL TANK LABEL**K97-6007 INSTL LABEL FUEL TANK**K97-6007 INSTL LABEL FUEL TANK**NOTE: LOCATE DECAL NEAR FILLER CAP*K53-6008-001 Fuel Tank Warning Label, 2
English**1100-302-FAK NON LOCKING FUEL TANK CAP***NON LOCKING FUEL TANK CAP*11-04859-100P Fuel Fill Cap, Non Locking, w/ 2
Logo, Polished**1100-310-AAC FUEL TANK ARRANGEMENT - 2 TANKS***FUEL TANK ARRANGEMENT - 2 TANKS**SK24935-001 FUEL TANK ARRANGEMENT***1100-310-EAF FUEL SUPPLY AND RETURN LINES***FUEL SUPPLY AND RETURN LINES**DUAL DRAW / DUAL RETURN**K95-6013 ROUTING FUEL HOE SPLITTER TEE**K95-6013 ROUTING FUEL HOE SPLITTER TEE**= W/ SLPR AND CROSS-OVER AFTRTRMNT SYS**ROUTE FUEL TANK HOSES ABOVE RAIL**OTHERWISE, RTE HOSES INSIDE RAIL =**= W/ SLPR AND CROSS-OVER AFTRTRMNT SYS**ROUTE FUEL TANK HOSES ABOVE RAIL**OTHERWISE, RTE HOSES INSIDE RAIL =*V50-1006-110053 45° Flare Fuel Hose Assembly 2
(#10 x 53")*SUPPLY LINES - TANKS TO SPLITTER TEE*V50-1006-108053 45° Flare Fuel Hose Assembly 2
(#8 x 53")*RETURN LINES - SPLITTER TEE TO TANKS***1100-311-CFB PRIMARY FUEL TANK FITTINGS***PRIMARY FUEL TANK FITTINGS**TANK LOCATED L/H BOC**K97-6001-30000 INSTL FUEL TANK FITTING*

26-03159 90 Deg Ball Valve (#8 MNPT) 1

26-01650 Straight Connector (1/2" MP 1
x #10 Flare)**1100-311-DFH PRIMARY FUEL TANK FITTINGS***PRIMARY FUEL TANK FITTINGS**TANK LOCATED R/H BOC**K97-6001-30000 INSTL FUEL TANK FITTING*

26-03159 90 Deg Ball Valve (#8 MNPT) 1

26-01650 Straight Connector (1/2" MP 1
x #10 Flare)**1100-311-JAF FUEL TANK FITTINGS***FUEL TANK FITTINGS*

TANK LOCATED L/H BOC**K97-6001-02000 INSTL FUEL TANK FITTING**

V38-1262	90° Fitting (#8 SAE Flare x #6 NPT Oraface)	1
K25-6000	Fuel Tank Vent	1
G50-6022-06BLK018	Nylon Tubing, Black (3/8" x 18")	1
26-01983-006	Pipe Plug, Flush Socket Head (3/8" NPT)	1

1100-311-KAF FUEL TANK FITTINGS**FUEL TANK FITTINGS****TANK LOCATED R/H BOC****K97-6001-02000 INSTL FUEL TANK FITTING**

V38-1262	90° Fitting (#8 SAE Flare x #6 NPT Oraface)	1
K25-6000	Fuel Tank Vent	1
G50-6022-06BLK018	Nylon Tubing, Black (3/8" x 18")	1
26-01983-006	Pipe Plug, Flush Socket Head (3/8" NPT)	1

1100-320-CBS FUEL LEVEL**FUEL LEVEL****NOTE: LOCATE DECAL NEAR FILLER CAP**

D1ESELULS	ULTRA LOW SULFUR DIESEL	24
-----------	-------------------------	----

1200-111-111 DRIVELINE DATA**DRIVELINE DATA****ENGINE ANGLE: +002.0****1ST MIDSHIP ANGLE: +000.0****1ST MS DRIVESHAFT: 250HH0000F1155****1ST MIDSHIP PLATE: E22-6006-190****1ST MIDSHIP LOCATION: +3475****2ND MIDSHIP ANGLE: +0000.00****2ND MIDSHIP LOCATION: +0000****AUX TRANSMISSION ANGLE: +000.0****AUX TRANSMISSION LOC: +0000****AUX TRANS HGHT FROM FRAME BOT: +0000****REAR DRIVESHAFT: 250HS0000F0685****REAR AXLE ANGLE: +0006.00****1600-300-BAK BATTERIES - (3) PACCAR PREMIUM****BATTERIES - (3) PACCAR PREMIUM****12V 2190CCA BATTERIES****P97-6031 INSTL STACKABLE BATT CABLE****P95-6976 RTG-BATTERY CABLES****SK18003-000 THREE BATTERY LAYOUT**

P27-1284-111	BATTERY EAST PENN PC7T31N	3
K169-111	Battery Terminal Nut (3/8-16)	6
DSWS4	Dual Swivel Saddle Spacer	4
== INSTALL SWIVEL TIE TO SPACE OUT		
MEGAFUSE POSITIVE CABLE FROM		

NEGATIVE BATTERY CABLES PER

P95-6976 ==

== USE ADDITIONAL SWIVEL TIES AS
NEEDED TO STANDOFF ALL CROSSING
LINES IN BATTERY BOX PER CMS0258 ==

W62-6000	Mount - Dual Tie Strap	1
RT255R0H1R	Cable Tie	1
DCT11	Cable Tie, Dual	1
W62-6000	Mount - Dual Tie Strap	1
22-01618-002	Cable Tie, Heavy Duty	1

1600-300-GAC BATTERIES LOCATED IN LH U/CAB BATT BOX

BATTERIES LOCATED IN LH U/CAB BATT BOX

BATTERIES LOCATED IN LH U/CAB BATT BOX

BATTERIES LOCATED IN LH U/CAB BATT BOX

1600-700-SCV CONNECTOR PLATE

CONNECTOR PLATE

R97-6423 INSTL-CONN PLATE, FIREWALL

S22-6202	Plate - Connector, LH	1
R42-6179	Seal - Conn Plate, LH	1
R34-6002-06025RHLZ	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	4

S22-6200	Plate - Connector, Center	1
R42-6171	GASKET - CONNECTOR CENTER	1

R34-6002-06025RHLZ	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	4
--------------------	---	---

1620-700-BBT FIVE BUS MARKER LIGHTS (LED BULLET)

FIVE BUS MARKER LIGHTS (LED BULLET)

SK22311 INSTL-CL LIGHT

SK22311 INSTL-CL LIGHT

SK24635 INSTL-SWITCHES

P54-6020-003	Marker Lamp Assembly, Bullet, Amber, LED	5
27-01209-4191	Rivnut - Closed (1/4-20)	10
R42-6242	ADHESIVE, BLACK, SEALANT	

1620-701-YAU SW/WIRING F/O AUX LTS U/CAB/SLEEPER

SW/WIRING F/O AUX LTS U/CAB/SLEEPER

P97-6058 INSTL-AUX PANEL LIGHT

P97-6058 INSTL-AUX PANEL LIGHT

P97-6058 INSTL-AUX PANEL LIGHT

= AUXILIARY CAB/SLEEPER AND A/C LGT =

= INDICATE FUSE LOC FOR "AUX CL LPS"

UNSWITCHED CAN BE USED IF NEEDED =

S92-6514-0600	HARNESS-LIGHT, AIRCLNR	2
27-01372	Hex Nut, PVC (5/8"-11)	2

1620-702-BBH TWO FLUSH MTD LOADLIGHT - POSITION B

TWO FLUSH MTD LOADLIGHT - POSITION B

CLEAR LENS

SK25909-002 INSTALL LOADLIGHTS CAB

SK25911-000 CAB - LOADLIGHTS & EXHAUST

P97-6068 INSTL LOAD LIGHT**S97-6182 INSTL-BACKWALL DAMPING**

P54-6021-001	Loadlamp Assembly, Flush Mount, Clear	2
--------------	---------------------------------------	---

MGLP-U6E	FASTENER-MAGNA LOK 3/16	6
----------	-------------------------	---

1620-702-PAP ADDL 10 COILED WIRE - ONE**ADDL 10 COILED WIRE - ONE****SK28150 DRILLING SK**

S92-6640-4572	HARNESSES-F/O BEACON LIGHTS	1
---------------	-----------------------------	---

= CONNECT TO RH LAMP OPTN 2 RF HARN ==

18-01130	Grommet - Universal	1
----------	---------------------	---

106356	SEAL-THUM PUTTY	
--------	-----------------	--

1650-700-A16 TRAILER ELECTRIC CABLE**TRAILER ELECTRIC CABLE**

30-2050	HARNESSES-TRAILER (12 FT, 7 WIRE)	1
---------	-----------------------------------	---

1700-700-FAD ADD L 12V POWER OUTLET- DASH**ADD L 12V POWER OUTLET- DASH**

P22-6007	Power Outlet Housing	1
----------	----------------------	---

P22-6006	Power Port Cap	1
----------	----------------	---

1700-713-VAC NEGATIVE QTY GAUGE HARNESS**NEGATIVE QTY GAUGE HARNESS**

= NO PARTS REQUIRED =

P92-2192-0175	CVSG Wiring Harness (175mm)	
---------------	-----------------------------	--

1700-715-AAD CVSG CLOCK ANALOG GAUGE**CVSG CLOCK ANALOG GAUGE****CHROME BEZEL - DASH MOUNTED**

Q43-6004-301C	Analog Clock, w/ Chrome Bezel	1
---------------	-------------------------------	---

Q20-1000	Nut, Gauge Mounting	1
----------	---------------------	---

1700-716-BAC SENSORS, PRI & SEC GAUGE**SENSORS, PRI & SEC GAUGE****P97-6064 INSTL, SENSORS****P97-6441 INSTL TIE STRAPS, AIR BUNDLE**

Q21-1041	Air Pressure Sensor, (0-150 Psi)	2
----------	----------------------------------	---

G38-6018-060604	Union Tee Fitting, Composite (#6 to #6 J2494)	1
-----------------	---	---

G38-1085-0404	Straight Union Fitting (#4 J2494 to #4 J2494)	1
---------------	---	---

200P-701-AAF LH CAB DOOR ASSEMBLY**LH CAB DOOR ASSEMBLY****DUAL DOOR STOPS****ELECTRIC POWER DOOR LOCKS****P95-6205 INSTL-ROUTING DOOR HARNESS****R97-6360 INSTL-CHANNEL RUN SEAL GLUE**

R25-6105-0202070202	LH Cab Door Assembly	1
---------------------	----------------------	---

20-11525M001	Door Stop Clevis	1
--------------	------------------	---

27-00335	Elastic Stop Nut	2
27-00764	Flat Head Screw (#10-24 x 51mm)	2
27-01426-004	Pan Head Thread Rolling Screw (#10-24 x 1/2")	4
27-01436-004	Truss Head Tapping Screw (#10-16 x 1/2")	9
27-01447-012	Truss Head Machine Screw (1/4-20 x 3/4")	9
R20-6011	Lock Rod Retainer Clip	1
R21-6009	Electric Window Regulator	1
R25-6065-100	LH Door Frame & Sill Assembly	1
R42-6210	LH Door Hinge Seal	1
R56-6050	Power Lock System Kit	1
R70-6013-2200	Glass Run Channel	1
R70-6014	Glass Channel Assembly	1
R79-6065	Inner Cab Door Skin Assembly	1
S92-6646	LH Door Harness	1
W34-6006-020	Pan Head Screw (M6 x 1.00 x 10 20mm)	

200P-701-BAF RH CAB DOOR ASSY W/REAR LD MIRROR

RH CAB DOOR ASSY W/REAR LD MIRROR

DUAL DOOR STOPS

ELECTRIC POWER DOOR LOCKS

P95-6205 INSTL-ROUTING DOOR HARNESS

R97-6360 INSTL-CHANNEL RUN SEAL GLUE

R25-6106-0802060202	RH Cab Door Assembly	1
20-11525M001	Door Stop Clevis	1
27-00335	Elastic Stop Nut	2
27-00764	Flat Head Screw (#10-24 x 51mm)	2
27-01426-004	Pan Head Thread Rolling Screw (#10-24 x 1/2")	4
27-01436-004	Truss Head Tapping Screw (#10-16 x 1/2")	9
27-01447-012	Truss Head Machine Screw (1/4-20 x 3/4")	9
R20-6011	Lock Rod Retainer Clip	1
R21-6009R	RH Electric Window Regulator	1
R25-6065-280	RH Cab Door Frame Assembly	1
R42-6210R	RH Door Hinge Seal	1
R56-6050R	RH Power Lock System Kit	1
R70-6013-2200	Glass Run Channel	1
R70-6014	Glass Channel Assembly	1
R79-6067	Cab Door Inner Skin Assembly	1
S92-6647	RH Door Harness	1
W34-6006-020		

Pan Head Screw (M6 x 1.00 x 10
20mm)

200P-702-AAE LOW ROOF CAP

LOW ROOF CAP

R22-6048-0061C21000	ROOF-DRILLED,LOW,PNG	1
R22-6273	ROOF-LOW	1

2000-700-CBF EXTENDED FIXED REAR WINDOW - DARK TINT

EXTENDED FIXED REAR WINDOW - DARK TINT

R44-6027	GLASS-REAR WINDOW,DRK TNT	1
20-16781	Rear Window Seal	1
20-03686-143	Glass/Window Seal/Fillerstrip, Rubber (143")	1

2000-700-E02 EXTERIOR SUNVISOR *STNL STL- POLISHED*

*EXTERIOR SUNVISOR *STNL STL- POLISHED**

SK22747 INSTAL SUNVISOR

18-02813	Bracket, Sun Visor, Center, Aluminum	1
R73-6050	Sunvisor-Ext,Low Roof 2	1
R73-6050R	SUNVISOR-EXT,LOW ROOF 2	1
20-14814	Brace - Sunvisor	2
<i>STD MAT L FOR SUN VISOR</i>		
MGCS-R6U	Huck Collar (3/16")	4
27-00793	Magna Grip Pin (3/16")	4
W20-6019-1173	INSERT-BLIND, 1/4 IN-20 A	2
W20-6019-9533	INSERT-BLIND, 1/4 IN-20 A	2
<i>STD MAT L FOR SUN VISOR</i>		
27-01283-006	Polished Head Bolt (1/4-20 x 4 3/4"), Stainless Steel	4
27-00816-008P	Cross Recess Truss Head Screw (#10-24 x 1/2"), Polished	11
27-00803-003	Lock Nut (#10-24), Stainless Steel	11

2000-700-GCD UNIBILT CAB AIR SUSPENSION

UNIBILT CAB AIR SUSPENSION

R97-6140 INSTALL - SUSPENSION

R97-6140 INSTALL - SUSPENSION

R97-6140 INSTALL - SUSPENSION

R97-6140 INSTALL - SUSPENSION

R97-6140 INSTALL - SUSPENSION

R97-6140 INSTALL - SUSPENSION

R97-6146 INSTL - SUSP, DAYCAB

R62-6008	Cab Suspension Assembly	1
R71-6005	Shock Absorber	1
20-18088	Cab Suspension Link Assembly	1
R11-6279M01	BRACKET-CAB SUSP,UPR 380	1
22-01525	Warning Label, Cab Suspension	2
R11-6278M00	Lateral Control Rod Bracket	1

HDWE LATERAL CNTRL ROD TO BRKT

W34-1160-100	Hex Bolt (M16 x 2.00 x 100mm)	1
W34-1162-016	Washer (16MM)	1

HDWE AIR SPRINGS TO BRACKET

27-00273-004	Hex Bolt (3/8-16 x 1")	2
27-00304-006	Lock Washer (3/8")	2
W34-1162-010	Washer (10MM)	2

*HARDWARE SHOCK TO BRACKET**HARDWARE SHOCK TO BRACKET*

W34-1160-140	BOLT-FINISHED HEX, M16	1
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	1

W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	1
--------------	------------------------------	---

W34-1162-016	Washer (16MM)	2
--------------	---------------	---

W34-1160-140	BOLT-FINISHED HEX, M16	1
--------------	------------------------	---

W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	1
--------------	------------------------------	---

W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	1
--------------	------------------------------	---

W34-1162-016	Washer (16MM)	2
--------------	---------------	---

HARDWARE SUSP ASSY TO CAB XMBR

W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm)	4
--------------	------------------------------	---

W34-1159-130	BOLT-FINISHED,HEX-M12	1
--------------	-----------------------	---

W20-1028-012	Lock Nut (M12 x 1.75)	8
--------------	-----------------------	---

W20-1028-012	Lock Nut (M12 x 1.75)	8
--------------	-----------------------	---

W34-1162-012	Flat Washer	13
--------------	-------------	----

HARDWARE CAB BRKT TO SILL

3LCW120-2R8GAL	Huck Collar, High Strength (M6)	13
----------------	---------------------------------	----

C120LT-R8-12U	Huck Bolt (1/4")	10
---------------	------------------	----

C120LT-R8-9U	Huck Pin (1/4")	3
--------------	-----------------	---

2000-700-KBQ RH CAB FLOOR SHEET*RH CAB FLOOR SHEET*

R40-6088-004	FLOORSHEET-RH	1
--------------	---------------	---

HKLT-R8-06	Truss Head Rivet (1/4")	44
------------	-------------------------	----

***** TWO AVK S FOR THRESHOLD *****

W20-6001-0420A165	NUT-SELF RTNG HEX	2
-------------------	-------------------	---

2000-700-LEK LH CAB FLOOR SHEET*LH CAB FLOOR SHEET*

R40-6089-001	FLOORHSEET-LH	1
--------------	---------------	---

HKLT-R8-06	Truss Head Rivet (1/4")	44
------------	-------------------------	----

***** TWO AVK S FOR THRESHOLD *****

W20-6001-0420A165	NUT-SELF RTNG HEX	2
-------------------	-------------------	---

***** ONE AVK FOR PEDAL PLATE *****

W20-6001-0420A165	NUT-SELF RTNG HEX	1
-------------------	-------------------	---

2000-700-RAF CAB/SLEEPER SUSPENSION PLUMBING*CAB/SLEEPER SUSPENSION PLUMBING**SK29798 DIAGRAM CAB SUSP PLMBG*

SK29798 DIAGRAM CAB SUSP PLMBG
 V95-6032 ROUTING - #4 AIR LINE TO CAB
 AIR DRYER FITTING

G38-1022-0404	45° Elbow Fitting (#4 Male NPT to #4 J2494)	1
G50-6022-04PURCTL	Purple Nylon Tubing (1/4")	1

AIR DRYER TO CAB HCV (1111)

2000-702-AAN CAB STRUCTURE-BACK WALL, EXT REAR WDO

CAB STRUCTURE-BACK WALL, EXT REAR WDO

R93-6000 DAYCAB - ASSEMBLY

R64-6026-110	Rear Wall Subassembly	1
20-16676	Window Frame	1
20-16774	Walk-Thru Spacer	1
20-16783	Window Trim Stiffener	1
27-00793	Magna Grip Pin (3/16")	168
HKLT-R8-06	Truss Head Rivet (1/4")	6
MGCS-R6U	Huck Collar (3/16")	168
R39-6009	Rear Sill	1
R41-6009	Walk-Thru Frame	1
R47-6000	Rear Corner Gusset	2
R79-6043-100	LH Rear Corner Cab Skin	1
R79-6044-100	RH Rear Corner Cab Skin	1
R85-6051	Stiffener	1
20-16542	Stiffener - Vertical	1
27-00793	Magna Grip Pin (3/16")	56
MGCS-R6U	Huck Collar (3/16")	56
27-00799	Magna Grip Pin (1/4")	14
MGCW-R8U	Huck Collar (1/4")	14
HKLT-R8-06	Truss Head Rivet (1/4")	8

2000-702-BBE CAB STRUCTURE-LH SIDE, W/ CUTOUT

CAB STRUCTURE-LH SIDE, W/ CUTOUT

SW/WIRING FOR F/O AUX LIGHTS

DUAL DOOR STOPS

R93-6000 DAYCAB - ASSEMBLY

R64-6054-223111	LH Side Wall Assembly	1
20-10335	Bolting Strip Retainer	2
20-10453	Latch Pin Guard	1
20-10831	Door Wedge	1
20-12066	Clevis Pin, Door Stop	2
20-14974-032	Sealing Tape (1/8")	1
20-16312	Door Jamb Nutplate	1
20-18727	Door Check Strap	2
27-00451-006	Flat Head Cross Recess Screw (5/16-18 x 3/4")	2
27-00793	Magna Grip Pin (3/16")	41
27-01428-008	Phillips Square Truss Head Screw (#10-24 x 1")	2
27-01501-005	Pan Head Screw (1/4-20 x 5/8")	4
3LCW120-2R8	Huck Collar (1/4")	10
C120LT-R8-12U	Huck Bolt (1/4")	6

C120LT-R8-9U	Huck Pin (1/4")	4
HKLT-R8-06	Truss Head Rivet (1/4")	4
L67-6012	LH Hood Roller Receptacle	1
MGCS-R6U	Huck Collar (3/16")	41
R25-6073	LH Door Jamb	1
R39-6031	LH Side Sill	1
R42-6038	Grommet, Door Jamb	1
R52-6004	Front Sill Insert	1
R56-6015	Striker Nutplate	1
R56-6017	Door Latch Striker	1
R65-6019	Door Check Bar	2
R77-6018	LH A-Post Reinforcement Assembly	1
R79-6025-11100	LH Side Skin	1
R85-6042	LH Cab Corner Brace	1
R85-6058	B-Pillar Grab Handle Support	1
27-00799	Magna Grip Pin (1/4")	7
MGCW-R8U	Huck Collar (1/4")	7
HKLT-R8-06	Truss Head Rivet (1/4")	4
27-00793	Magna Grip Pin (3/16")	26
MGCS-R6U	Huck Collar (3/16")	26
C120LT-R8-9U	Huck Pin (1/4")	4
3LCW120-2R8GAL	Huck Collar, High Strength (M6)	4
W01-6036-003	Screw, Flat Head (1/4-20 X 3/4")	5

2000-702-CBE CAB STRUCTURE-RH SIDE,W/ CUTOUT

CAB STRUCTURE-RH SIDE,W/ CUTOUT

CAB HEATER

SW/WIRING FOR F/O AUX LIGHTS

DUAL DOOR STOPS

R93-6000 DAYCAB - ASSEMBLY

R64-6063-243111	RH Side Wall Assembly	1
20-10335	Bolting Strip Retainer	2
20-10453	Latch Pin Guard	1
20-10831	Door Wedge	1
20-12066	Clevis Pin, Door Stop	2
20-14974-032	Sealing Tape (1/8")	1
20-16312	Door Jamb Nutplate	1
20-18727	Door Check Strap	2
27-00451-006	Flat Head Cross Recess Screw (5/16-18 x 3/4")	2
27-00793	Magna Grip Pin (3/16")	41
27-01428-008	Phillips Square Truss Head Screw (#10-24 x 1")	2
27-01501-005	Pan Head Screw (1/4-20 x 5/8")	4
3LCW120-2R8	Huck Collar (1/4")	10
C120LT-R8-12U	Huck Bolt (1/4")	6
C120LT-R8-9U	Huck Pin (1/4")	4
HKLT-R8-06	Truss Head Rivet (1/4")	4

L67-6012R	RH Hood Roller Receptacle	1
MGCS-R6U	Huck Collar (3/16")	41
R25-6073R	RH Cab Door Jamb	1
R39-6031R	RH Side Sill	1
R42-6038	Grommet, Door Jamb	1
R52-6004	Front Sill Insert	1
R56-6015	Striker Nutplate	1
R56-6017	Door Latch Striker	1
R65-6019	Door Check Bar	2
R77-6015	RH A-Post Reinforcement Assembly	1
R79-6064-111100	RH Side Skin	1
R85-6042R	RH Cab Corner Brace	1
R85-6058	B-Pillar Grab Handle Support	1
R85-6057	SUPPORT-A PILLAR GRAB HAN	2
22-01151-022	Cushioned Clamp (1-3/8")	1
27-00799	Magna Grip Pin (1/4")	7
MGCW-R8U	Huck Collar (1/4")	7
HKLT-R8-06	Truss Head Rivet (1/4")	10
27-00793	Magna Grip Pin (3/16")	26
MGCS-R6U	Huck Collar (3/16")	26
C120LT-R8-9U	Huck Pin (1/4")	4
3LCW120-2R8GAL	Huck Collar, High Strength (M6)	4
W01-6036-003	Screw, Flat Head (1/4-20 X 3/4")	5

2000-702-EBF CAB STRUCT-DAYCAB UPPER FRONT

CAB STRUCT-DAYCAB UPPER FRONT

R93-6000 DAYCAB - ASSEMBLY

SK24673 ROUTING CAB ROOF HARNESS

SK24673 ROUTING CAB ROOF HARNESS

R29-6002	Cowl Assembly	1
R25-6158-001	Windshield Mask Assembly	1
15-15988	U-Nut (M5 X 0.80)	2
27-00793	Magna Grip Pin (3/16")	4
27-01378	U-Nut (M6 x 1.00)	6
HKLT-R8-06	Truss Head Rivet (1/4")	16
MGCS-R6U	Huck Collar (3/16")	4
R11-6066	LH Header Bracket Support	1
R11-6066R	RH Header Bracket Support	1
R11-6068	Header Mount Bracket	1
R11-6070	Header Bracket	2
R11-6071	Header Bracket	2
R25-6159-001	Windshield Mask Assembly, Low Roof	1
R44-6022R	Glass - Windshield, RH	1
R42-6205-6007315	SEALANT-BUTYL, TAPE	2
R44-6022	Glass - Windshield, LH	1
*** COWL - FIREWALL ***		
27-00793	Magna Grip Pin (3/16")	21

MGCS-R6U	Huck Collar (3/16")	21
*** COWL - SIDE SKIN / A-POST ***		
MGP55R6-10GP	PIN-MAGNAGRIP 3/16 14MM	8
MGP98T-R6-20G	Huck Bolt, Truss Head	6
MGCS-R6U	Huck Collar (3/16")	6
MGCW-R6U	Huck Collar (3/16"), Wide	8
*** MASK - COWL ***		
27-00793	Magna Grip Pin (3/16")	26
MGCS-R6U	Huck Collar (3/16")	26
*** MASK - A-POST ***		
27-00793	Magna Grip Pin (3/16")	12
MGCS-R6U	Huck Collar (3/16")	12
*** HEADER - A-POST ***		
HKLT-R8-06	Truss Head Rivet (1/4")	8
*** HEADER SUPPORT - DOOR JAMB ***		
MGP90R6-10G	Flush-Head Magna Grip Pin (3/16")	4
MGCS-R6U	Huck Collar (3/16")	4

2000-702-GAE CAB STRUCTURE - SLEEPER FLOOR

CAB STRUCTURE - SLEEPER FLOOR

R93-6001 SLEEPER CAB, LOW ROOF ASSY

R93-6002 SLEEPER CAB, HIGH ROOF ASSY

NOTE: TAPE TO BE INSTALLED OVER CAB

GROUND HOLE IN LH CAB SILL.

*NOTE: REMOVE TAPE AT CAB SET WHEN THE
GROUND CABLE IS INSTALLED ONTO
THE SIDE SILL.*

R85-6065	Seat Support	2
R24-6006	Seat Crossmember Assembly	1
39065005	CLIP - PINE-TREE	4
28-00084-024	HOLE PLUG-BLACK PLASTIC	1
27-00799	Magna Grip Pin (1/4")	4
MGCW-R8U	Huck Collar (1/4")	4

2000-702-HAD ADD L ROOF STRUCTURE - LOW ROOF

ADD L ROOF STRUCTURE - LOW ROOF

R93-6001 SLEEPER CAB LOW ROOF ASSY

R93-6000 DAYCAB ASSEMBLY

20-14322	Spacer - Roof	2
R85-6032	Cab Longeron Brace Assembly, LH	1
R85-6032R	Cab Longeron Brace Assembly, RH	1
R77-6049R	LONGERON-CAB	1
R77-6049	LONGERON-CAB	1
27-00793	Magna Grip Pin (3/16")	30
MGCS-R6U	Huck Collar (3/16")	30
27-00799	Magna Grip Pin (1/4")	43
MGC-R8U	Huck Collar, Locking (6mm)	43
R77-6024	Cab Roofbow Assembly	1

2000-703-AAN CAB DOORS W/ RH VIEW WINDOW

CAB DOORS W/ RH VIEW WINDOW

<i>SK20577 INSTL SECONDARY SEAL</i>		
<i>SK26052 INSTL SEAL PRIMARY</i>		
<i>SK11620 SEAL LATCH PIN GUARD</i>		
<i>R97-6031 INSTL DOOR GROMMET</i>		
<i>P95-6467 ROUTING-DOOR ACTUATOR HARNESS</i>		
<i>R97-6259 INSTL - DOOR-CAB, SUPPLEMENT</i>		
<i>DOOR HARDWARE</i>		
27-01215-008	Torx Washer Head Bolt (5/16-14 18 x 1")	
20-10335	Bolting Strip Retainer	2
MGPT-R8-20G	Huck Pin (1/4")	4
MGC-R8U	Huck Collar, Locking (6mm)	4
<i>INNER PANEL HARDWARE</i>		
R42-6122-0725	Door Belt Line Weatherstrip (725mm), Black Rubber	2
W01-10-06P14N013B	Pan Head Screw (#10-24 x 1/2"), Black	46
27-01447-012	Truss Head Machine Screw (1/4-20 x 3/4")	8
<i>LOWER DOOR GLASS & MTG COMPONENTS</i>		
R44-6038	Window Glass, Lower Door	2
R42-6009-1280	Seal - Window Extrusion (1280mm)	1
R42-6025	Door Glass Seal, Lower, Side, Rubber	1
R42-6091-2285	Door Seal, Secondary	2
R60-6003-0Y4065	Trim Seal, Bulb Type (4065mm)	2
R25-6107-001	LH Door Lockboard Module Assembly	1
28-00240-205U	Foam Sealing Tape (1/16" x 5/8")	
28-00240-212S	Sealing Tape (1-1/2")	
HKLT-R8-06	Truss Head Rivet (1/4")	10
K169-239-6-42	Self Retaining Hex Nut	2
R25-6067	LH Cab Door Lockboard	1
R42-6019-0723	Weatherstrip, Door Belt Line (723mm)	1
R56-6035-001	LH Cab Door Latch	1
R65-6011	Lower Lock Rod	1
R65-6012	Outer Release Rod	1
R65-6016	LH Inner Lock Rod	1
R77-6032	LH Lockboard Stiffener	1
S11-6050	LH Lockboard Bracket	1
S16-6003	Cable Clip (1/4")	1
S22-6020	Vapor Barrier	3
S56-6028-001	LH Inside Release Handle	1
W01-10-04P05N019B	Pan Head Screw (#8-18 x 3/4"), Black	4
R25-6107-001R	RH Door Lockboard Module Assembly	1

28-00240-205U	Foam Sealing Tape (1/16" x 5/8")	
28-00240-212S	Sealing Tape (1-1/2")	
HKLT-R8-06	Truss Head Rivet (1/4")	10
K169-239-6-42	Self Retaining Hex Nut	2
R25-6067R	RH Cab Door Lockboard	1
R42-6019-0723	Weatherstrip, Door Belt Line (723mm)	1
R56-6035-001R	RH Cab Door Latch	1
R65-6011	Lower Lock Rod	1
R65-6012	Outer Release Rod	1
R65-6016R	RH Inner Lock Rod	1
R77-6032R	RH Lockboard Stiffener	1
S11-6049	RH Lockboard Bracket	1
S16-6003	Cable Clip (1/4")	1
S22-6020	Vapor Barrier	3
S56-6028-001R	RH Inside Release Handle	1
W01-10-04P05N019B	Pan Head Screw (#8-18 x 3/4"), Black	4
R44-6037	LH Cab Door Glass Assembly	1
R42-6017	Foam Tape	1
R44-6015	Cab Door Glass	1
R70-6012	Window Lift Channel, LH	1
R44-6037R	RH Cab Door Glass Assembly	1
R42-6017	Foam Tape	1
R44-6015	Cab Door Glass	1
R70-6012R	Window Lift Channel, RH	1
S16-6003	Cable Clip (1/4")	2

2000-703-DAN OUTER RELEASE HANDLE HARDWARE

OUTER RELEASE HANDLE HARDWARE

CAB COMPONENTS

R11-1137	Outside Handle Bracket	2
27-01000-006	Lock Nut (M6 x 1.00)	2
18-03002	Key Ring - Medallion	1

2010-300-AAF HORIZONTAL CONVEX MIRROR OVER RH DOOR

HORIZONTAL CONVEX MIRROR OVER RH DOOR

716858-6	MIRROR-CONVEX,RECT	1
18-04509	Seal, Look Down Mirror	1
27-01480	Rivet Assembly - Blind w/Sleeve (1/4")	2

2010-300-BDE TWO 8IN HEATED CONVEX MIRROR-PRUTSMAN

TWO 8IN HEATED CONVEX MIRROR-PRUTSMAN

R97-6047 INSTALL SPOT MIRROR

P95-6107 WIRING, MIRROR HEAT & LIGHT

R59-6100-0202	RH Heated Mirror Assembly (8.5")	1
R59-6100-0203	LH Heated Mirror Assembly (8.5")	1
16-02455	Connector (3-way)	4

2010-300-JAP REAR VIEW MIRROR YOKE

REAR VIEW MIRROR YOKE

STD 102" WIDTH**R97-6045 INSTALL REAR VIEW MIRROR**

R18-6000	Mirror Yoke, Standard, Stainless Steel	2
K169-154-8	Self Locking Hex Nut (M8 x 1.25)	4
27-01260-025P	Hex Bolt (M8 x 1.25 x 25mm), Polished	4

2010-300-LAF RR VIEW MIRROR BRKT MTG HRDWR-POL COV**RR VIEW MIRROR BRKT MTG HRDWR-POL COV**

R22-6026-001	Mirror Clamp Cover, Polished, 1 Aluminum, LH	
R22-6026-001R	Mirror Clamp Cover, Polished, 1 Aluminum, RH	
R80-6013	Support Block, Cab Mounted 1 Mirror, Steel, LH	
R80-6013R	Support Block, Cab Mounted 1 Mirror, Steel, RH	
R11-6044	Bracket - Mirror, Forward LH	1
R11-6044R	Bracket - Mirror, Forward RH	1
R11-6073	BRACKET-MIRROR REAR	2

HARDWARE FOR FWD BRACKET

R42-6021	Seal - Bracket, Forward 2 Mirror	
27-00413-007P	Huck Pin (3/16"), Polished	4
MGCS-R6U	Huck Collar (3/16")	4

HARDWARE FOR REAR BRACKET

R42-6043	Seal - Accessories, Cab	2
27-00818-009P	Huck Pin (1/4"), Polished	4
MGC-R8U	Huck Collar, Locking (6mm)	4

HARDWARE FOR COVER CLAMP

W01-6038-016	Screw - Hex Cap (M6 X 1.00 X 16mm)	8
--------------	---------------------------------------	---

HARDWARE FOR MAIN ASSEMBLY

27-00803-005	Lock Nut (5/16-18), Stainless Steel	4
27-00801-005	Flat Washer (5/16")	4

2010-300-MBT REAR VIEW MIRROR HEAD & ELECTRIC**REAR VIEW MIRROR HEAD & ELECTRIC****7 X 16 NON-AERO - HEATED & NON-LIGHTED****R97-6045 INSTALL REAR VIEW MIRROR****P97-6066 INSTL MIRROR****** INSTL MIRROR W/ TEMP (OAT) SENSOR****ON DRIVER SIDE ****

R59-6102-009	Non-Motorized Mirror Assembly w/ OAT	1
R59-6102-007	Non-Motorized Mirror Assembly	1

HARDWARE FOR MOUNTING MIRROR HEAD**2010-300-QAL LH REAR VIEW MIRROR - TUBE SUPT****LH REAR VIEW MIRROR - TUBE SUPT**

R97-6045 INSTALL REAR VIEW MIRROR

R88-6007-004	Tube Support, Cab Mounted	1
	Mirror, Stainless Steel, LH	
R88-6010	TUBE-MOUNT MIRROR	1
	CROSS CAB	
R80-6032	TAB-FRICTION,MIRROR	1
28-00200	Grommet, Rubber (7/8" X	2
	3/4" ID X 1/8")	
R42-6007	Grommet - Pass Thru Cab	1

*USE CABLE TIE TO SECURE PASS-THRU**GROMMET TO DASH SUPPORT*

K231-363-172	Tie Strap	1
--------------	-----------	---

2010-300-RAK RH REAR VIEW MIRROR - TUBE SUPT*RH REAR VIEW MIRROR - TUBE SUPT***R97-6045 INSTALL REAR VIEW MIRROR**

R88-6007-003R	Tube Support, Cab Mounted	1
	Mirror, Stainless Steel, RH	
R88-6010	TUBE-MOUNT MIRROR	1
	CROSS CAB	
R80-6032	TAB-FRICTION,MIRROR	1
28-00200	Grommet, Rubber (7/8" X	1
	3/4" ID X 1/8")	
R42-6007	Grommet - Pass Thru Cab	1

*USE CABLE TIE TO SECURE PASS-THRU**GROMMET TO DASH SUPPORT*

K231-363-172	Tie Strap	1
--------------	-----------	---

2010-702-ADC ONE 15" RND AIR HORN PAINTED-RH U/CAB*ONE 15" RND AIR HORN PAINTED-RH U/CAB**REF BM TITLE**R97-6237 INSTL - RH U/CAB AIR HORN**R97-6237 INSTL - RH U/CAB AIR HORN**R97-6237 INSTL - RH U/CAB AIR HORN*

H00293PC	Horn, 249P Series (15")	1
R11-6341	BRACKET-AIR HORN	1
G38-1097-0404	Snap Head Fastener w/	1
	Washer (M4 x 0.70 x 30mm)	
27-00204-008	Thread Rolling Screw (1/4-20	2
	x 1")	
MGCS-R6U	Huck Collar (3/16")	3
27-00793	Magna Grip Pin (3/16")	3

2010-702-C30 AIR HORN PLUMBING*AIR HORN PLUMBING**** AIR HORN MTD UNDER CAB ****SK23280 INSTAL AIR HORNS**SK24159 PLUMB AIR HORN**SK29876-011 DIAG-PLMBG AIR HORN VALVE**= ONE AIR HORN MTD LH UNDER CAB =*

H15686	Valve - Lanyard, Single Horn	1
G38-1085-0404	Straight Union Fitting (#4	2
	J2494 to #4 J2494)	

W01-10-07T08N013B

Truss Head Screw (#10-14 x 2 1/2"), Black		
G50-6022-04GRN072	Green Nylon Tubing (1/4" x 72")	1
G50-6022-04BLK100	Black Nylon Tubing (1/4" x 100")	1
<i>FLOOR TO "A" POST CONNECTOR</i>		
G50-6022-04GRN100	Green Nylon Tubing (1/4" x 100")	1
G50-6022-04BLK020	Black Nylon Tubing (1/4" x 20")	1
<i>"A" POST CONNECTOR TO HORN VALVE</i>		
G50-6022-04BLKCTL	Black Nylon Tubing (1/4")	1
<u>2010-702-D01 AIR HORN PULL CORD- BLACK</u>		
<i>AIR HORN PULL CORD- BLACK</i>		
20-13258-201	Pull Cord, Air Horn, Black	1
<u>2010-703-FPJ ONE 27IN HANDLE MTD LH BOC</u>		
<i>ONE 27IN HANDLE MTD LH BOC</i>		
<i>ONE 44IN HANDLE MTD HORIZONTAL BOC</i>		
<i>BOLTED GRAB HANDLE</i>		
<i>R97-6454-120 INTL-GRAB HANDLES, BOC</i>		
<i>GRAB HANDLES BOLTED</i>		
20-16788	Grab Handle - Vertical, LH & RH BOC (27")	1
20-16787	Handle - Grab, Stainless Steel (1125mm)	1
20-12919	Gasket, Grab Handle (25")	4
<i>HARDWARE FOR MTG CAB GRAB HANDLES</i>		
<i>HARDWARE FOR TOP DRILLINGS</i>		
W20-6019-9533	INSERT-BLIND, 1/4 IN-20 A	6
<i>HARDWARE FOR BOTTOM DRILLINGS</i>		
W20-6019-1173	INSERT-BLIND, 1/4 IN-20 A	2
27-01283-008	Polished Head Bolt (1/4-20 x 1"), Stainless Steel	8
<u>2010-705-C01 RADIO ANTENNA ROOF MTD -STANDARD</u>		
<i>RADIO ANTENNA ROOF MTD -STANDARD</i>		
<i>SK17295 INSTL RADIO ANTENNA</i>		
<i>SK17295 INSTL RADIO ANTENNA</i>		
Q28-6002	Radio Antenna, w/ Cable	1
20-10675	Reinforcement - Roof Antenna	1
<u>2010-708-DBX ONE CB ANTENNA BRACKET MOUNTED</u>		
<i>ONE CB ANTENNA BRACKET MOUNTED</i>		
<i>CENTERLINE BACK OF CAB</i>		
<i>R97-6115-001 INSTL BOC ANTENNA</i>		
18-03496	CB Antenna Cable Kit, w/ Antenna Mount	1
R11-6148	BRACKET-ANTENNA	1
<i>NOTE: REMOVE MASKING ON BRACKET BEFORE ANTENNA INSTALLATION</i>		
1200	Cone Grommet	1

27-00793	Magna Grip Pin (3/16")	2
MGCS-R6U	Huck Collar (3/16")	2
106356	SEAL-THUM PUTTY	

2010-708-EAJ CB SPKER MTD LH RR CORNER OF CAB HDLNR*CB SPKER MTD LH RR CORNER OF CAB HDLNR*

P28-1002	CB Speaker Assembly (3-1/2")	1
W01-10-01P55N025B	Pan Head Screw (M5 x 0.80 x 25mm), Black	

2020-701-KAT ACCUMULATOR/RECEIVER DRYER*ACCUMULATOR/RECEIVER DRYER**F95-6146 RTG-HVAC SYSTEM CONVENTIONAL**F95-6146 RTG-HVAC SYSTEM CONVENTIONAL**F95-6146 RTG-HVAC SYSTEM CONVENTIONAL**F97-6402 INSTL-LINES HVAC HEAVY**F97-6213 RTNG - RECEIVER DRYER**F97-6213 RECEIVER DRYER BRACKET**BRACKET/HARDLINE CLIPS**F97-6211 INSTL - PRESSURE SWITCHES*

F37-6017	RECEIVER-DRYER, DAY CAB,	1
27-01000-006	Lock Nut (M6 x 1.00)	2
05-11700-044	Hose Clamp (2-3/4")	2
P27-6142	Low Pressure Switch	1
18-03835	A/C Switch , High Pressure System Cutout	1

DRYER BRACKET AND MTG HARDWARE

R11-6126	BRACKET-RECEIVER, DRYER	1
3LCW120-2R8	Huck Collar (1/4")	2
C120LT-R8-9U	Huck Pin (1/4")	2

203P-700-BAH NATIONAL AIR SUSP DRIVER SEAT*NATIONAL AIR SUSP DRIVER SEAT*

S78-6013-8300013301	Ultraride Highback Seat Assembly, Black Mordura	1
---------------------	---	---

***** *BASE PART INFORMATION* ******** *BASE PART NUMBER - S78-6013* ****** *BASE PART FORMAT - ABCDEFGHHH* ****** *BASE PART I.D. - PSD63* *****203P-701-BAS NATIONAL NON-AIR PASSENGER SEAT***NATIONAL NON-AIR PASSENGER SEAT*

S78-6014-8300010301	Highback Seat Assembly, Black Mordura	1
---------------------	---------------------------------------	---

***** *BASE PART INFORMATION* ******** *BASE PART NUMBER - S78-6014* ****** *BASE PART FORMAT - ABCDEFGHHH* ****** *BASE PART I.D. - PSP63* *****2030-700-AAP SEAT BELT AND ANCHORS***SEAT BELT AND ANCHORS**BLACK SEAT BELT**S97-6203 INSTL - SEAT BELT**S97-6203 INSTL - SEAT BELT*

S84-6048-001 3-Point Driver Seatbelt, Black 1
 MTS SEAT BELT TETHERS TO CAB FLOOR
 MTS RETRACTOR TO FLOOR
 27-00278-005 Hex Bolt (7/16-20 x 1-1/4") 1
 20-07611 Washer - Flat (7/16" X 1-1/4") 1

2030-700-B01 SEAT MOUNTING

SEAT MOUNTING

27-00273-007 Hex Bolt (3/8-16 x 1-3/4") 4
 K363-175CA Flat Washer (3/8") 4
 *** PLUG FOR UNUSED SEAT MTG HOLES ***
 K376-81 Xmas Tree Fastener 4

2030-700-C30 AIR SEAT PLUMBING - DRIVER S SIDE ONLY

AIR SEAT PLUMBING - DRIVER S SIDE ONLY

SK 20891 INSTL - AIR BULKHEAD

G95-6107 HOSE ROUTING

G95-6107 HOSE ROUTING

G38-1043-0404 Straight Bulkhead Union 1
 Fitting, Brass (#4 J2494 to #4 J2494)
 G38-1097-0404 Snap Head Fastener w/ 1
 Washer (M4 x 0.70 x 30mm)

** PLUG FOR UNUSED AIR FITTING HOLE **

28-00084-009 HOLE PLUG BLK PLASTIC 1

2030-701-AAS SEAT BELT AND ANCHORS

SEAT BELT AND ANCHORS

BLACK SEAT BELT

S97-6203 INSTL - SEAT BELT

S97-6203 INSTL - SEAT BELT

S84-6049-001 3-Point Passenger Seatbelt, 1
 Black

MTS SEAT BELT TETHERS TO CAB FLOOR

MTS RETRACTOR TO FLOOR

27-00278-005 Hex Bolt (7/16-20 x 1-1/4") 1
 20-07611 Washer - Flat (7/16" X 1-1/4") 1

2030-701-B01 SEAT MOUNTING

SEAT MOUNTING

27-00273-007 Hex Bolt (3/8-16 x 1-3/4") 4
 K363-175CA Flat Washer (3/8") 4
 *** PLUG FOR UNUSED SEAT MTG HOLES ***
 K376-81 Xmas Tree Fastener 4

2030-703-BAC PASSENGER NON SUSPENSION SEAT PEDESTAL

PASSENGER NON SUSPENSION SEAT PEDESTAL

20-13001 Seat Pedestal Assembly 1
 27-00437 Lock Nut (5/16-18) 4
 27-00428-005 Flat Washer (5/16") 4

204P-700-NAX LOW ROOF CAB HEADLINER

LOW ROOF CAB HEADLINER

S60-6032-010004H391

Cab Headliner Assembly, 1
Light Gray

+++++++ *BASE PART INFORMATION* +++++
=== *BASE PART NUMBER - S60-6032* ===
=== *BASE PART FORMAT - ABCDEFFGGG* ===
=== *BASE PART I.D. - PHC70* ===

204P-700-SAJ FLOOR CARPET & FLOOR MAT

FLOOR CARPET & FLOOR MAT

S14-6089-110104G201 Floormat - Cab, Cvntl 1

2040-700-AAZ CAB INSULATION

CAB INSULATION

S72-6015-0210 Insulation Kit, Cab 1

2040-700-BAW INTERIOR SUNVISORS

INTERIOR SUNVISORS

S97-6059 INSTL HEADER COVER

S73-6001-343C251 Driver Side Interior Sunvisor, 1
Arctic Gray

S73-6001-413C251 Passenger Side Interior 1
Sunvisor, Arctic Gray

S16-6002-281 CLIP-SUNVISOR GRAY 2

S60-6069-281 TRIM-SUNVISOR, BRKT GRAY 2

W01-10-04T09N019B Truss Head Screw (#10-16 x 6
3/4"), Black

W01-10-01P55N025B Pan Head Screw (M5 x 0.80 x 2
25mm), Black

2040-700-CAC HEADER COVER - LOW ROOF

HEADER COVER - LOW ROOF

S97-6059 INSTL HEADER COVER

S60-6038-281 Cab Header Assembly, Low 1
Roof, Gray

W34-6007-01P57N020B Pan Head Screw (M6 x 1.00 x 2
20mm), Black

2040-700-DCA LH CAB DOOR PAD ASSY - GRAY TRIM

LH CAB DOOR PAD ASSY - GRAY TRIM

S97-6060 INSTALL DOOR PAD

S97-6060 INSTALL DOOR PAD

S63-6016-301581 LH Door Pad Assembly, 1
Charcoal/Dark Gray

S22-6021-501 Door Pull Screw Cover, 1
Charcoal

S42-6000-501 Grommet, Cab Door Lockrod, 1
Charcoal

S18-6032-501 LH Inner Release Bezel, 1
Charcoal

S22-6035-281 Upper Map Pocket Screw 1
Cover, Gray

S22-6036-281 Lower Map Pocket Screw 2
Cover, Gray

LAMP HARNESS HARDWARE

28-00214 Grommet (1/4" ID X 1" OD) 1

2040-700-EBF RH CAB DOOR PAD ASSY - GRAY TRIM*RH CAB DOOR PAD ASSY - GRAY TRIM**S97-6060 INSTALL DOOR PAD**S97-6060 INSTALL DOOR PAD*

S63-6017-31581	RH Door Pad Assembly, Charcoal/Dark Gray	1
S22-6021-501	Door Pull Screw Cover, Charcoal	1
S42-6000-501	Grommet, Cab Door Lockrod, Charcoal	1
S18-6032-501R	RH Inner Release Bezel, Charcoal	1
S22-6035-281	Upper Map Pocket Screw Cover, Gray	1
S22-6036-281	Lower Map Pocket Screw Cover, Gray	1

LAMP HARNESS HARDWARE

28-00214	Grommet (1/4" ID X 1" OD)	1
----------	---------------------------	---

2040-700-GBD KICK PANEL PARTS*KICK PANEL PARTS**GRAY HARD TRIM**S97-6119 INSTL-CLIPS, KICK PANELS**S97-6373 INSTL-CONV BRKT, KICK PANELS*

S60-6023-1281	Center Kick Panel Trim, Gray	1
S52-6019	Insert Clip	3
S60-6342-0281	Trim - Left Kick Panel, A	1
S60-6124-281	RH Kick Panel Trim Assembly, Gray	1
S11-6413	Bracket-Dead Pedal	1
== 4 SCREWS FOR LH KICK PNL/5 FOR RH =		
== 2 SCREWS DEAD PEDAL BRKT TO FLR ==		
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	11

2040-700-HAH A PILLAR TRIM*A PILLAR TRIM**S97-6049 INSTL A-POST & GRABHANDLES**S97-6177 INSTL BLUETOOTH MIC,LH A-PLLR*

S60-6245-281	TRIM-COVER, LEFT A POST	1
S60-6040-281	TRIM-COVER,RT A POST	1
S56-6055-281	GRABHANDLE - OVER MOLDED	3
S60-6044-281	Over Door Cover Trim, Gray	2
PV050024	Nut - Push On (5mm)	1
<i>SCREWS-LONG SCREWS FOR DOOR GRABHANDLE</i>		
W34-6007-01P57N030B	Pan Head Screw (M6 x 1.00 x 4 30mm), Black	
W34-6007-01P57N020B	Pan Head Screw (M6 x 1.00 x 6 20mm), Black	
354-190001-00-0075	Fastener - Christmas Tree, Warning Light	1

2040-700-JAE HEADER TRIM

HEADER TRIM

S60-6074-281 TRIM-HEADER,LOWER 1

2040-700-LAE HOOD NOISE INSULATION KIT*HOOD NOISE INSULATION KIT**L95-6008 INSTL INSULATION*

L72-6007 INSULATION-KIT,388/389 1

2040-700-MAC B PILLAR TRIM*B PILLAR TRIM**S97-6045INSTL HARD TRIM*

S60-6070-281 TRIM-B PILLAR.LWR L W/EXH 1

S60-6066-281 TRIM-B PILLAR,LWR RIGHT 1

16-08976-4201 Grille Assembly, Speaker,
Black 227-01446-008 Screw - Phillips, Thread
Rolling (#10 X 24 X 1") 8

S56-6018 B-Pillar Grabhandle 2

*SCREWS FOR B PILLARS 4 EACH*W01-10-04T09N025B Truss Head Screw (#10-16 x 8
1"), Black 8*SCREWS FOR GRABHANDLE*W34-6007-01P57N020B Pan Head Screw (M6 x 1.00 x 4
20mm), Black 4**2040-700-UAD CUP & THERMOS HOLDER***CUP & THERMOS HOLDER**S97-6310 INSTL-CUP HOLDER, FLOOR*

S06-6046-601 CUPHOLDER-ASSY 1

27-00991-024 BOLT 1/4-20X1-1/2 GR2 LO 4

27-00992-004 Flat Washer (1/4"), Black 4

W20-6001-0420A165 NUT-SELF RTNG HEX 4

2040-700-ZAU DAY CAB BACK WALL TRIM*DAY CAB BACK WALL TRIM**GRAY EXTENDED WIDE REAR WINDOW**S97-6045 INSTL CAB HARD TRIM*S60-6051-281 Extended Rear Window Trim, 1
Gray

S03-6000-281 HOOK-COAT,DAYCAB 2

S63-6015-4B281 PAD-REAR WALL DAYCAB 1
GRAYW01-10-04T09N019B Truss Head Screw (#10-16 x 8
3/4"), Black 827-01441-251 Truss Head Screw & Cap 11
Assembly, Platinum Gray,
(#10-24 x 1")*SCREWS FOR COAT HOOK*W01-10-04T09N025B Truss Head Screw (#10-16 x 2
1"), Black 2**2040-704-CAE FLOORMAT / CARPET HARDWARE***FLOORMAT / CARPET HARDWARE*S60-6097 LH Cab Door Threshold 1
Assembly

S32-6002-001	Threshold Insert, Screw-In (630mm)	1
S60-6097R	RH Cab Door Threshold Assembly	1
S32-6002-002	Threshold Insert, Screw-In (575mm)	1
27-01429-012	Truss Head Screw, Thread Rolling (1/4-20 x 1-1/2")	4
R80-6017-001	SPACER-SEAT	8

2040-704-EAQ CAB UPPER CORNER TRIM

CAB UPPER CORNER TRIM

GRAY HARD TRIM

S97-6045 INSTL CAB HARD TRIM

S60-6063-0281	B Pillar Trim, Upper, Std Cab, LH, Gray	1
S60-6063-0281R	B Pillar Trim, Upper, Std Cab, RH, Gray	1
W01-10-03B11N025A	Screw, Snap Head w/Washer (#10-24 x 1")	4
W01-10-04T09N019B	Truss Head Screw (#10-16 x 2 3/4"), Black	2

2040-704-FAC HEADLINER HARDWARE

HEADLINER HARDWARE

S97-6061 INSTL HEADLINER

S22-6074-291	CAP-PLASTIC RESTRAINT HOL	2
<i>HARDWARE FOR OVER DOORS</i>		
W01-10-04T09N019B	Truss Head Screw (#10-16 x 4 3/4"), Black	4

2040-704-GBA HEADER COVER PLATE AND CB RADIO

HEADER COVER PLATE AND CB RADIO

S28-6003-281	CB/Radio Assembly, Cobra Model 29NW	1
--------------	--	---

2040-704-HAC DOOR PAD HARDWARE FASTENERS

DOOR PAD HARDWARE FASTENERS

S97-6392 INSTL-INSERT CLIP

W01-10-01P55N025B	Pan Head Screw (M5 x 0.80 x 13 25mm), Black	13
27-01442-006	Screw, Self Tapping, Truss Head (#10-12 x 3/4")	4
W34-6007-01P57N020B	Pan Head Screw (M6 x 1.00 x 4 20mm), Black	4
27-00992-003	Flat Washer (3/16"), Black	5
S52-6019	Insert Clip	3

3A00-300-AAC HUCK BOLT ALL ACCESSIBLE FRAME COMPS

HUCK BOLT ALL ACCESSIBLE FRAME COMPS

HUCK BOLT ALL ACCESSIBLE FRAME COMPS

FRAME-HUCK	FRAME HUCK	1
------------	------------	---

3A00-300-BAX 10-5/8 STEEL RAIL

10-5/8 STEEL RAIL

INSTL WINDLACE PER DRAWING

01-47634-07240L RAIL-10 5/8 270,7.94 5/16 1

01-47634-07240R FRAME RAIL 270 (10-5/8) 1

3A00-300-LAD CROSSMEMBER MACHINE SETTINGS*CROSSMEMBER MACHINE SETTINGS*

= USE MACHINE SETTING #2 =

3A00-700-BAG STANDARD TOW HITCHES*STANDARD TOW HITCHES**BOX UP TOW HITCHES & PLACE IN CAB*

A65-6000 PIN-TOW HITCH 2

A65-6008 PIN-HITCH 2

A16-6000 Cotter Pin, Stainless Steel 2

A20-6013 HITCH - SFFA TOW 2

3A00-700-FAT FRONT CAB SUPPORT * ALUM **FRONT CAB SUPPORT * ALUM ***R93-6004 ASSY, FRONT CAB MOUNT*

A85-6009 Support, Cab Front, Aluminum 1

A85-6009 Support, Cab Front, Aluminum 1

HARDWARE FOR CAB SUPPORT

33113 MOUNT-RUBBER, CONV CAB 2

W34-1160-120 BOLT-FINISHED HEX, M16 2

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 2

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 2

W34-1162-016 Washer (16MM) 2

27-00776 Shim (5/8") 2

3A00-700-HAD REAR CAB CROSSMEMBER - ALUM*REAR CAB CROSSMEMBER - ALUM**SK29425 ASSEMBLY, CROSSMEMBER**A97-6123 INSTL, BOC CROSS MEMBER**A24-6259-00000000 XMBR-AL, ASSEMBLY**NOTE: XMBR ASSY BUILT W/ ALUM GUSSETS*

01-51526-002 Midship/Cab Mounting Crossmember 1

A52-6029 Aluminum Crossmember Gusset Liner, LH 2

A52-6029R Aluminum Crossmember Gusset Liner, RH 2

01-51612M000 Crossmember Gusset, Aluminum 2

MBT-DT16-20NP Huck Bobtail Pin (16mm) 10

MBTC-R16BL Huck Collar (16mm), Bobtail 10

3A00-714-AAD AIR & ELEC ROUTING SUPPORT (STD)*AIR & ELEC ROUTING SUPPORT (STD)**A97-6245 INSTL-PRIMARY RTG BRKTS CVNTL*

A11-6376 BRACKET-ROUTING, A & E 2

3A00-714-BAD XMBR MTD ROUTING BRACKET

*XMBR MTD ROUTING BRACKET**A97-6245 INSTL-PRIMARY RTG BRKTS CVNTL**A97-6246 INSTL-RTG BRKTS, 3-PIECE**BOC XMBR (LH SIDE)*

A11-6375R BRACKET-ROUTING, 3-PIECE 1

1ST INTERMEDIATE OR M/S XMBR (LH SIDE)

A11-6375R BRACKET-ROUTING, 3-PIECE 1

A11-6375 BRACKET-ROUTING, 3-PIECE 1

3A00-714-FAC MSB MOUNTING BRACKETS*MSB MOUNTING BRACKETS**G97-6372-000 INSTL-MUX SLND BANK BRKT*

A11-6524 BRACKET-MSB XMBR SINGLE 1

3A10-700-BAD OVERBELL CROSSMEMBER*OVERBELL CROSSMEMBER**A93-6009 OVERBELL ASSEMBLY*

A24-6090 Overbell Crossmember, Steel 1

A80-6033-005 SPACER-OVERBELL, EXTRN 2

3A10-700-CAG CAB MOUNT HARDWARE*CAB MOUNT HARDWARE**L97-6076 INSTL FENDER SKIRT**L97-6076 INSTL FENDER SKIRT**L97-6083 INSTALL QTR FENDER**L97-6083 INSTALL QTR FENDER**L97-6053 INSTL TRIM PANEL**L97-6053 INSTL TRIM PANEL**D97-6106S34 INSTL LH CAB MOUNT ROUTE**D97-6106S34 INSTL LH CAB MOUNT ROUTE**Y95-6000 L/H ROUTING - CONV MODEL**Y95-6000 L/H ROUTING - CONV MODEL**Y97-6006 CAB MOUNT STANDOFF INSTL**Y97-6006 CAB MOUNT STANDOFF INSTL*

W34-1160-230 BOLT-FINISHED HEX, M16 6

W34-1160-230 BOLT-FINISHED HEX, M16 2

W34-1162-016 Washer (16MM) 16

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 8

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 8

05-16856 Bracket, Battery Cable 1

3A30-300-AAL ONE MIDSHIP XMBR - ALUM*ONE MIDSHIP XMBR - ALUM**SK29425 ASSY CROSSMEMBER**A24-6259-00000000 XMBR-AL, ASSEMBLY**NOTE: XMBR ASSY BUILT W/ ALUM GUSSETS*

01-51526-002 Midship/Cab Mounting Crossmember 1

01-51612M000 Crossmember Gusset, Aluminum 2

A52-6029 Aluminum Crossmember Gusset Liner, LH 2

A52-6029R

Aluminum Crossmember	2		
Gusset Liner, RH			
MBT-DT16-25NP	Huck Bobtail Pin (16mm)	20	
MBTC-R16BL	Huck Collar (16mm), Bobtail	10	
W34-1162-016	Washer (16MM)	16	

3A40-304-ADZ STEEL SUSPENSION XMBR*STEEL SUSPENSION XMBR**SK29425 ASSY-THREE PIECE XMBR*

01-51371-001	Crossmember	1	
A47-6127	Crossmember Gusset	2	
MBT-DT16-15NP	Huck Bobtail Pin (16mm)	10	
MBTC-R16BL	Huck Collar (16mm), Bobtail	10	
W34-1162-016	Washer (16MM)	10	

3A50-300-ABT TRACTOR TAPER XMBR*TRACTOR TAPER XMBR*

A24-6377-001	CROSSMEMBER-EOF	1	
--------------	-----------------	---	--

3A50-300-CAC TRACTOR TAPER XMBR HARDWARE*TRACTOR TAPER XMBR HARDWARE**SK20901 TAPER XMBR FASTENER INSTL*

27-00858-006	Screw, Truss Head (1/2-13 x 4 1-1/2")	4	
27-00532-008	Hex Bolt, (1/2-13 x 2 in), Grade 8, Zinc Plate	4	
27-00792-008	Lock Nut (1/2-13)	8	
27-00428-008	Plain Washer (1/2")	12	

3A6B-300-AAC FIFTH WHEEL REWORK*FIFTH WHEEL REWORK*

01-52741	REWORK, 5TH WHEEL	1	
----------	-------------------	---	--

3A6P-300-BAC HOLLAND FWAL 5TH WHEEL*HOLLAND FWAL 5TH WHEEL*

FWALW800GL00	FIFTH WHEEL, HOLLAND	1	
--------------	----------------------	---	--

3A70-300-BAD PETERBILT MUDFLAPS*PETERBILT MUDFLAPS*

18-02336	Mudflap (24" X 26")	2	
----------	---------------------	---	--

3A70-300-CBS MUDFLAP HANGERS*MUDFLAP HANGERS**PAINTED HANGERS**SK08844 MUDFLAP ASSY*

A76-6011	MUDFLAP- HANGER	2	
A11-6143	BRACKET-MUDFLAP, ARM	2	
18-01303	Strip - Backing, Mudflap	2	
<i>MOUNTING HARDWARE</i>			
27-00275-006	Bolt (3/8" x 1-1/2")	8	
27-00791-006	Lock Nut (3/8-24)	8	
W34-1162-010	Washer (10MM)	16	
27-00420-024	Cotter Pin (3/16" x 1-1/2")	2	
18-04258R	Conspicuity Bracket, Mudflap, 1 RH	1	
18-04258L	Conspicuity Bracket, Mudflap, 1 LH	1	

3A8B-300-AAC DECK PLATE LOCATION*DECK PLATE LOCATION**DECK PLATE 1 LOC FROM BOC/BOS PLANE*

335

*DECK PLATE 2 LOC FROM BOC/BOS PLANE***3A80-300-BAU NON-SLIP DECK PLATE * NATURAL ****NON-SLIP DECK PLATE * NATURAL ***SK26001 INSTL DECKPLATE*

01-50900-0712	Aluminum Deckplate Assembly (712mm)	1
01-44267	Lever Assembly, Locking, Deckplate	4
W34-1162-010	Washer (10MM)	4
27-00275-013	Hex Bolt (3/8-24 x 3-1/4")	4

3B0P-300-FAC DANA IADB STEER AXLE*DANA IADB STEER AXLE**D1251IL AXLE*

B05-6041-0C0000000	AXLE SPECIFICATION	1
--------------------	--------------------	---

3B0P-313-AAC LEFT FRONT DISC BRAKE*LEFT FRONT DISC BRAKE*

G4-01201809000000L	Air Disc Brake Assembly, LH	1
--------------------	-----------------------------	---

3B0P-313-BAC RIGHT FRONT DISC BRAKE*RIGHT FRONT DISC BRAKE*

G4-01201809000000R	Air Disc Brake Assembly, RH	1
--------------------	-----------------------------	---

3B00-300-DAC HUB CAPS*HUB CAPS*

CR1612	Hub Cap, 6 Hole, 4-1/2" Bolt Circle, Black, Zytel	2
27-00671-004	Bolt & Washer Assembly (5/16-18 X 1")	12

3B00-301-DAZ HUB/ROTOR ASSEMBLIES*HUB/ROTOR ASSEMBLIES**B97-6030 INSTL-FRONT HUBS*

CM10081101	Preset Front Hub & Rotor Assembly, Aluminum	2
------------	---	---

3B00-301-EAC DISC BRAKE COMMON PARTS*DISC BRAKE COMMON PARTS**H97-6008 INSTL WHEEL LABEL*

A53-1043-1	DECAL-TIRE WARNING ENGL	2
------------	-------------------------	---

3B00-302-BAM BRAKE HARDWARE*BRAKE HARDWARE**FRT AXLE BRAKES**B97-6008 INSTL-DISC BRAKES*

= WSHR TO BE PLCD UNDER HEAD OF BOLT =

TORQUE PLATE HDWR FOR THROUGH BOLTS

TORQUE PLATE HDWR FOR THREADED HOLES

CALIPER HARDWARE

W34-1161-060	Hex Bolt (M20 x 2.50 x 60mm)	12
W34-1162-020	Flat Washer (3/4")	12

3B00-302-CAD ABS HARDWARE*ABS HARDWARE**SK20722 INSTL FRONT SENSOR**B95-6001 ROUTING BRAKE LINES**B95-6001 ROUTING BRAKE LINES**B95-6001 ROUTING BRAKE LINES*

K145016BX	SENSOR- WHEEL SPEED, STR 2	
K152407	SLEEVE- SENSOR, ABS	2
B13-1001	Speed Sensor Sleeve	2
201472000	Cable Clip, ABS Sensor	2
01-100-007	ABS Clip	6

3B00-302-EAK SYNTHETIC OIL - FRONT AXLE*SYNTHETIC OIL - FRONT AXLE*

PS386 SYNTHETIC TRANS. OIL

*LUBE QUANTITY = 0.45 QTS***3B00-700-AAR 1200LB TAPER LEAF FRONT SPRING***1200LB TAPER LEAF FRONT SPRING*

B81-6012-003 Front Spring Assembly, 12K 2

3B00-700-BBT FRONT XMBR ASSY*FRONT XMBR ASSY*

A24-6123-001	Crossmember Assembly, Radiator Support & Drive Brackets	1
08-02975	Standoff Bracket	2
12-0302-001	Low profile Mount	2
15-05301	Support Bracket	2
27-00268-004	Hex Bolt (1/4-20 x 1")	2
27-00312-004	Hex Nut (1/4")	2
27-00428-004	Flat Washer (1/4")	4
27-00562-004	Spring Lock Washer (1/4")	2
27-01378	U-Nut (M6 x 1.00)	4
A11-6103	Recirculation Shield Bracket, LH	1
A11-6103R	Recirculation Shield Bracket, RH	1
A24-6104-002	Radiator Crossmember Assembly, SFFA	1
A24-6116	Crossmember - Lower Radiator	1
B11-6012M01	Bracket, Front Spring, Aluminum, LH	1
B11-6012M01R	Bracket, Front Spring, Aluminum, RH	1
L48-6029	Hood Pivot, Lower Mount, LH	1
L48-6029R	Hood Pivot, Lower Mount, RH	1
W20-1028-012	Lock Nut (M12 x 1.75)	9
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	8
W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm)	2
W34-1159-070	Hex Bolt (M12)	4

W34-1159-090	Hex Bolt (M12 x 1.75 x 90mm)	3
W34-1160-050	Lock Nut w/ Nylon Insert (M16 x 1.75)	2
W34-1160-060	Hex Bolt (M16 x 2.00 x 60mm)	2
W34-1160-100	Hex Bolt (M16 x 2.00 x 100mm)	4
W34-1162-012	Flat Washer	16
W34-1162-016	Washer (16MM)	16

3B00-700-CAU FRONT SPRING MOUNTING HARDWARE

FRONT SPRING MOUNTING HARDWARE

B93-6005 INSTL DRV PIN CAP& LOC TR PIN

SHACKLE AND MOUNTING HARDWARE

B20-1007	SHACKLE - LINK	4
W34-1159-080	Hex Bolt (M12 x 1.75 x 80mm)	8
W34-1162-012	Flat Washer	16
W20-1028-012	Lock Nut (M12 x 1.75)	8
W20-1028-012	Lock Nut (M12 x 1.75)	8

SPRING CAP MOUNTING HARDWARE

B22-6000	Cap, Spring Pin	4
B65-1000	Locator Pin	2
W34-1159-090	Hex Bolt (M12 x 1.75 x 90mm)	8
W20-1028-012	Lock Nut (M12 x 1.75)	8
W20-1028-012	Lock Nut (M12 x 1.75)	8
W34-1162-012	Flat Washer	16

NOTE: INSTL SHORTER SPRING PIN IN

REAR SPRING EYE & SHACKLE BRKT

NOTE: INSTL THREADED SPRING PINS SO

THAT EXTENSION FROM BUSHING IS

EQUAL SIDE-TO-SIDE WITHIN 2MM

B65-1008	Spring Pin, Threaded (199mm)	2
B65-6008	PIN - THREADED SPRING	2
1610B	Grease Fitting	6
B65-6008	PIN - THREADED SPRING	2

3B00-700-DBV FRONT AXLE U-BOLTS & SPACER BLOCKS

FRONT AXLE U-BOLTS & SPACER BLOCKS

B93-6003 ASSY - AXLE INSTALLATION

B80-6021	Shim-Caster	2
B34-6010-192	U-BOLT - 3/4 FRONT AXLE	2
B34-6010-205	U-BOLT - 3/4 FRONT AXLE	2
B63-6009	Saddle, Front Suspension, LH	1
B63-6009R	Saddle, Front Suspension, RH	1
03-01199	Flat Washer (3/4")	8
27-00508-012	Hex Nut (3/4-18)	8
B80-6004	PB8 SHIM-CENTERING	2

NOTE: INSTL SHIM ON LEFT SIDE OF AXLE

W/ THICK END FACING FORWARD

P25783-036 Shim - Caster (1 Deg) 1

3B00-700-EAT FRONT SHOCKS AND BRACKETS

FRONT SHOCKS AND BRACKETS

B97-6011 INSTL-FRONT SHOCKS

B97-6011 INSTL-FRONT SHOCKS

== FRNT SHOCK WASHER FACES AWAY FROM

SHOCK-LWR FRONT SHOCK MTG BOLT

FACES OUTBOARD ==

B71-6009 SHOCK ABSORBER 2

UPPER SHOCK MOUNTING HARDWARE

UPPER SHOCK MOUNTING HARDWARE

B34-6018 STUD-UPPER SHOCK MOUNT 2

27-00790-012 Flat Washer (3/4") 4

W20-1028-020 Lock Nut (M20 x 2.50) 2

27-00616 Washer - Retaining, Outer 2
(33/64" ID X 1-5/8" OD)

27-00886 Washer - Retaining, Inner 2
(25/32" ID X 1-21/32" OD)

W20-1028-012 Lock Nut (M12 x 1.75) 2

W20-1028-012 Lock Nut (M12 x 1.75) 2

LOWER SHOCK MOUNTING HARDWARE

27-00616 Washer - Retaining, Outer 2
(33/64" ID X 1-5/8" OD)

27-00886 Washer - Retaining, Inner 2
(25/32" ID X 1-21/32" OD)

W20-1028-012 Lock Nut (M12 x 1.75) 2

W20-1028-012 Lock Nut (M12 x 1.75) 2

3B00-700-FAE WINDUP BUMPER - RUBBER HELPER SPRING

WINDUP BUMPER - RUBBER HELPER SPRING

A93-6000 ASSY WIND UP BUMPER INSTL

NOTE: INSTALL WINDUP STOP BRACKET

MOUNTING BOLTS W/NUTS ON OUTSIDE

OF THE RAIL.

B11-6094-142R Bracket-Bumper Windup 1

B11-6094-142 BRACKET-BUMPER WINDUP 1

W34-1162-016 Washer (16MM) 8

W34-1160-070 Hex Bolt (M16 x 2.00 x 4
070mm) 4

W20-1028-016 Lock Nut (M16 x 2.00 x 4
16mm) 4

W20-1028-016 Lock Nut (M16 x 2.00 x 4
16mm) 4

13248 Bump Stop, Rubber 2

W34-1163-030 Hex Bolt (M10 x 1.50 x 2
30mm) 2

27-00562-007 Spring Lock Washer (7/16") 2

3B00-700-HAN FRT XMBR ASSY & SHACKLE BRKT HARDWARE

FRT XMBR ASSY & SHACKLE BRKT HARDWARE

HDWE FOR MTG FRONT END ASSY TO RAILS

W34-1160-090 BOLT-FINISHED HEX, M16 9

W34-1160-070

Hex Bolt (M16 x 2.00 x 070mm)	4	
W34-1162-016	Washer (16MM)	26
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	13
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	13
<i>HDWE FOR MTG SHACKLE BRKTS</i>		
W34-1160-060	Hex Bolt (M16 x 2.00 x 60mm)	4
W34-1160-080	Hex Bolt (M16 x 2.00 x 080mm)	2
W34-1162-016	Washer (16MM)	12
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	6
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	6

3B00-700-KAD FRONT SPRING SHACKLE BRACKETS

FRONT SPRING SHACKLE BRACKETS

A97-6160 INSTL REAR SPRING SHACKLE

B11-1034-5 Shackle Bracket Assembly 2

3COP-303-AAD LH FORWARD DRIVE REAR BRAKE

LH FORWARD DRIVE REAR BRAKE

LH FORWARD DRIVE REAR BRAKE

G3-785654G1LA0000B Rear Brake Assembly, ES-X 1
(16.5" x 7")

3COP-303-BAD RH FORWARD DRIVE REAR BRAKE

RH FORWARD DRIVE REAR BRAKE

RH FORWARD DRIVE REAR BRAKE

G3-785654G1KA0000A Rear Brake Assembly, ES-X 1
(16.5" x 7")

3COP-306-CAC MERITOR SINGLE DRIVE AXLE

MERITOR SINGLE DRIVE AXLE

MERITOR RS23-161 AXLE

DIFF LOCK

STANDARD TRACK, 12.7MM HOUSING

REAR AXLE RATIO - 3.73

REAR AXLE RATIO - 3.73

C6-5H24C003A073N40 MERITOR REAR REAR AXLE 1

3C00-300-AAY ALUMINUM HUBS - 1ST DRIVE AXLE

ALUMINUM HUBS - 1ST DRIVE AXLE

C97-6063 INSTL-REAR HUBS

CM10081301 Preset Plus Rear Hub 2
Assembly, Aluminum

CM10033073 Oil Fill Plug 2

3C00-300-DAD AXLE SHAFT HARDWARE - 1ST DRIVE AXLE

AXLE SHAFT HARDWARE - 1ST DRIVE AXLE

03-01568 Axle Shaft Gasket 2

1246V1166 Dowel 16

27-00791-010 Lock Nut (5/8") 16

3C00-300-EAD AXLE BREATHER - 1ST DRIVE AXLE*AXLE BREATHER - 1ST DRIVE AXLE*

A2297C8765	Breather	1
A3196J1336	Tube	1

3C00-300-FAE BRAKE DRUMS*BRAKE DRUMS*

53-123537-002	DRUM - X30 - 16.5X7 10-B	2
---------------	--------------------------	---

3C00-300-LAL BRAKE FASTENERS*BRAKE FASTENERS*

C74-1039-04FL00	Brake Drum Fasteners Kit	1
C74-1039-03FR00	Brake Drum Fasteners Kit	1
W34-1169	WASHER - HARD	16
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	16

3C00-305-AAG AIR SUSPENSION RIDE HEIGHT LABEL*AIR SUSPENSION RIDE HEIGHT LABEL**SK29246 INSTALL DECAL, AIR BAG**NOTE: UNLADEN RIDE HEIGHT:8-1/4"*

A53-6018-005	LABEL-RIDE HEIGHT	1
--------------	-------------------	---

3C00-310-BBZ CAMSHAFT REINFORCEMENTS*CAMSHAFT REINFORCEMENTS**C97-6064-165F34 INSTL-CAM TUBE SUPPORT*

08-02564	Camshaft Reinforced Brake Strap	2
08-02566	Camshaft Reinforced Brake Bracket	2
08-02565	Camshaft Reinforcement Brake Tab	2
27-00269-008	Hex Bolt (5/16-18 x 2")	4
27-00566-005	Lock Nut (5/16")	4
27-00428-005	Flat Washer (5/16")	8

3C00-310-CBB ABS HARDWARE PARTS*ABS HARDWARE PARTS**SK29377 RTG-ABS SENSOR CABLE**P95-6955 RTG - WHEEL SPEED*

K152407	SLEEVE- SENSOR, ABS	2
K144020BX	SENSOR- WHEEL SPEED, 90	2
HM3	MOUNT-H,5/8	4
201472000	Cable Clip, ABS Sensor	2
01-100-007	ABS Clip	6

3C00-310-DAF PRIMARY ABS SENSOR MOUNTING*PRIMARY ABS SENSOR MOUNTING**SK20553-007 INSTL - REAR ABS SENSOR**SK20553-007 INSTL - REAR ABS SENSOR**SK29377 ROUTING - ABS SENSOR CABLE**= INSTL SENSORS ON REAR SIDE**OF DRIVE AXLE =***3D00-S02-DAF IMMERSION TYPE HEATER CORD***IMMERSION TYPE HEATER CORD*

D92-6360-2000N	HARNES-ENGINE HEATER	1
----------------	----------------------	---

3D00-304-AAC CHASSIS TO STARTER GROUNDING*CHASSIS TO STARTER GROUNDING**P97-6271 INSTALL CHASSIS GROUNDING**P97-6271 INSTALL CHASSIS GROUNDING**P97-6271 INSTALL CHASSIS GROUNDING**P95-6032 ROUTING CHASSIS GROUND**P95-6032 ROUTING CHASSIS GROUND*

27-00801-006 Flat Washer (3/8") 2

27-00801-006 Flat Washer (3/8") 1

STARTER TO FRAME RAIL GROUND

N92-6007-2AAAB0060 Battery Cable 1

K041-810-50F BOLT-HEXMETRIC-SST 1

27-02040-010 Hex Nut (M10 x 1.50) 1

K169-154-10 Self Locking Hex Nut (M10 x 1.50) 1

3D00-305-AAD INITIAL FILL ENG OIL AND STICKER*INITIAL FILL ENG OIL AND STICKER**DELO 400 XLE CK4 OIL**SK21913-002 INSTL-MOTOR OIL LABEL**= CHEVRON DELO 10W30 ENGINE OIL =**= OIL QTY IS REQD TO FILL ENG TO FULL**MARK ON ENGINE OIL DIPSTICK =**= OIL QTY IS REQD TO FILL ENG TO FULL**MARK ON ENGINE OIL DIPSTICK =*

10W30XLECK4BULK DELO 400 XLE 10W30 CK-4 1

CVDEDEL0400 LABEL-DELO 400 FACTORY FI 1

3D00-702-AAC HEATER RECEPTACLE MOUNTED LH U/CAB*HEATER RECEPTACLE MOUNTED LH U/CAB**SK17680 INSTL ENG & OIL PAN HEATER**P97-6874 INSTL-HEATER CORD SUPT**USE FWD RECEPTACLE INSTALLATION**P97-6874 INSTL-HEATER CORD SUPT**HEATER RECEPTACLE MOUNTED LH U/CAB**HEATER RECEPTACLE MOUNTED LH U/CAB*

16-04592 Receptacle Housing 1

05-13186 Bracket - Jeb Receptacle 1

27-00680 Rivet - Blind (5/32") 2

27-00204-006 Thread Rolling Screw (1/4-20 2 x 3/4")

A11-2255-001 BRACKET-MD NGR FUEL 1

156-00070 Cable Tie Mount 1

3D1P-306-AAC X15 (2023)*X15 (2023)**500V@1900, GOV@2000, 1650@950**- REAR SUMP OIL PAN (SFFA)**- MANUAL TRANSMISSION**- 37.4 CFM NAT ASPIRTD AIR COMP**- INTERBRAKE*

E8JD4J2H401W6M0817 PNG-CUMMINS ENGINE 1

3D10-302-AAL IMMERSION TYPE WATER HEATER

IMMERSION TYPE WATER HEATER

D97-6115S39 INSTL - ISX ENGINE HEATER

D97-6115S39 INSTL - ISX ENGINE HEATER

D97-6115S39 INSTL - ISX ENGINE HEATER

D97-6115S39 INSTL - ISX ENGINE HEATER

3510474 PACCAR ISX AND MX BLOCK 1
H27-01000-008 Lock Nut w/ Nylon Insert (M8 2
x 1.25)

27-00428-005 Flat Washer (5/16") 2

3D10-325-AAC PORT A FTGS - CAB HEATER

PORT A FTGS - CAB HEATER

V97-6000-000 INSTALL ENGINE FITTINGS

NOTE: INSTALL FTGS IN ENGINE PORT A

NOTE: POINT HARDLINE STRAIGHT UP

D2119-9001 Fitting - Adapter (M27 X 1
2.00)

D2208-2266 Ball Valve, Straight (1/2") 1

26-03467 Hose Fitting, Elbow, 45 Deg 1
(1/2" MP x 5/8")**3D10-325-GAC PORT G FTGS - DRIVE TRAIN COOLER**

PORT G FTGS - DRIVE TRAIN COOLER

V97-6000-000 INSTALL ENGINE FITTINGS

NOTE: INSTALL FTGS IN ENGINE PORT G

D2119-9001 Fitting - Adapter (M27 X 1
2.00)D2006-3211 Elbow Fitting, 45 Deg (1/4" 1
Hose Bead x 1/2" Male NPTF)**3D10-325-JAN ENGINE FITTINGS - PORT J**

ENGINE FITTINGS - PORT J

V38-1347 FTG- 90 DEG 1/2 HB TO M1 1

3D10-700-BAC COWL MTD AIR CLEANER PIPING

COWL MTD AIR CLEANER PIPING

D97-6193 INSTALLATION - AIR INTAKE

D66-6305 Pipe - Y, Air Intake Dual Cowl 1

05-15021-800 Hose Clamp, Constant Torque 2
(8")**3D10-700-CAC ENGINE INLET PIPING - DUAL COWL MTD**

ENGINE INLET PIPING - DUAL COWL MTD

D97-6193 INSTALLATION - AIR INTAKE

05-05646 Hose - Hump, Reducer (6" ID 1
X 5-1/2" ID)

D66-6258-405086265C PIPE - AIR INTAKE 1

05-14901 Elbow, Rubber, 90°, (5-1/2" - 1
4")05-15021-650 Hose Clamp, Constant Torque 1
(6-1/2")05-15021-450 Hose Clamp, Constant 1
Torque, (4-1/2")

05-15021-600

Hose Clamp, Constant 2
Torque, (6")

3D10-700-EAM AIR CLEANER CAB ELBOW

AIR CLEANER CAB ELBOW

DUAL AIR CLEANER

COWL OR FENDER MTD AIR CLEANER

D04-6067	Elbow - Intake	2
05-12030-080	Hose Clamp, High Torque (8")	2
26-01984-002	Plug, Square Head (1/8")	1
R42-6242	ADHESIVE,BLACK, SEALANT	

3D10-700-FAG AIR RESTRICTION INDICATOR

AIR RESTRICTION INDICATOR

INDICATOR MTD ON AIR INTAKE

D97-6236 INSTL-AIR RESTRICT INDICATOR

X002277	Restriction Gauge	1
---------	-------------------	---

NOTE: PLACE ORIFICE END OF FITTING

TOWARD AIR CLEANER

PPP10-0089	Fitting, Brass, w/ Filter	1
------------	---------------------------	---

3D10-700-GAT DUAL PREFERRED FIT 13IN AIR CLEANERS

DUAL PREFERRED FIT 13IN AIR CLEANERS

STAINLESS STEEL - COWL MTD

REFERENCE B/M TITLE

D37-6029	13" Air Cleaner Assembly, Stainless Steel	2
----------	--	---

3D10-700-HAH DUAL COWL MOUNTED AIR CLEANER- 13IN

DUAL COWL MOUNTED AIR CLEANER- 13IN

SK17769 INSTAL AIR CLNR

D11-6095	BRACKET-AIR CLEANER (13)	2
----------	--------------------------	---

R84-6003	STRAP-AIR CLEANER,ASSY,DI	4
----------	---------------------------	---

BRACKET MOUNTING BOLTS

27-00805-010P	Hex Bolt (3/8-16 x 1-1/4"), Polished Stainless Steel	8
---------------	---	---

27-00801-006P	Flat Washer (3/8"), Polished	16
---------------	------------------------------	----

27-00810-006P	Lock Washer (3/8"), Polished	16
---------------	------------------------------	----

STRAP MOUNTING BOLTS

27-00805-012P	Hex Bolt (3/8-16 x 1-1/2"), Polished Stainless Steel	8
---------------	---	---

27-01395-7923	INSERT-BLIND, 3/8 IN.-16	8
---------------	--------------------------	---

3D10-703-ABA ALUM REAR ENGINE MOUNTS

ALUM REAR ENGINE MOUNTS

A97-1172-000 INSTL RER ENGINE SUPPORTS

P97-6763 INSTL- ENG MT RTG BRKT

A97-1297-000 INSTL - REAR ENG MNT

FRAME SIDE MOUNTS

U30027	MOUNT - ENGINE REAR	1
--------	---------------------	---

U30027	MOUNT - ENGINE REAR	1
--------	---------------------	---

P11-6394	Engine Mount Bracket Assembly	1
----------	----------------------------------	---

ENGINE SIDE MOUNTS & HARDWARE

D62-1144M02	LEG - ENGINE REAR	1
-------------	-------------------	---

D62-1144M02R	LEG - ENGINE REAR	1
W34-1158	BOLT - FLANGE HEAD M16X2	8
27-00780-008	Hex Bolt, Self Locking, 3/4	8
	in-10 UNC, 2 in	
27-00790-012	Flat Washer (3/4")	8

3D10-703-BAR REAR ENGINE MOUNT SHIMS

REAR ENGINE MOUNT SHIMS

NOTE: NO SHIMS REQUIRED

3D10-703-CAT FRONT ENGINE MOUNTS

FRONT ENGINE MOUNTS

A97-6062-015 INSTL FRONT ENGINE SUPT

A97-6062-015 INSTL FRONT ENGINE SUPT

D97-6106S04 INSTL - FRONT ENG MOUNTS

D97-6106S04 INSTL - FRONT ENG MOUNTS

NOTE: REMOVE REAR ENGINE LIFTING EYE

FOR FIREWALL CLEARANCE

MOUNT ENG SUPT ON REAR SIDE OF KNEES

A11-2203	BRACKET-FRT ENG SPRT	1
----------	----------------------	---

LH KNEE

A11-2204	BRACKET-FRT ENG SPRT	1
----------	----------------------	---

RH KNEE

A24-1079-3	Front Engine Support Crossmember	1
------------	-------------------------------------	---

FRONT ENGINE SUPT HARDWARE

W34-1160-060	Hex Bolt (M16 x 2.00 x 60mm)	4
--------------	---------------------------------	---

W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	4
--------------	---------------------------------	---

W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	4
--------------	---------------------------------	---

W34-1162-016	Washer (16MM)	8
--------------	---------------	---

FRONT ISOLATORS AND HARDWARE

05-16401	Front Mount, Rubber	2
----------	---------------------	---

A22-1016-001	Snubbing Plate	1
--------------	----------------	---

A22-1016-002	Snubbing Plate	1
--------------	----------------	---

W34-6078-120	BOLT-FLANGE HEAD, M20X2.5	2
--------------	------------------------------	---

W20-6032-020	NUT-FLANGED, METRIC	2
--------------	---------------------	---

3D10-703-DAF FRONT ENGINE MOUNT SHIMS

FRONT ENGINE MOUNT SHIMS

NOTE: NO SHIMS REQUIRED

3E0B-300-BAC M/S (C/B) PLATES

M/S (C/B) PLATES

E22-6006-190	PLATE-MIDSHIP BEARING	1
--------------	-----------------------	---

3E0P-302-AAC DANA 1ST DRIVESHAFT

DANA 1ST DRIVESHAFT

E05D250HH0000F1155	PNG - DANA DRIVESHAFT	1
--------------------	-----------------------	---

3E0P-302-BAC DANA 2ND DRIVESHAFT

DANA 2ND DRIVESHAFT

E05D250HS0000F0685	PNG - DANA DRIVESHAFT	1
--------------------	-----------------------	---

3E00-302-ADL EATON 15.5IN HD CLUTCH*EATON 15.5IN HD CLUTCH**ADVANTAGE SELF-ADJUST*

309701-34	Advantage Clutch Assembly (15-1/2")	1
27-01394-010	HEX BOLT-7/16 ZINC	8
27-00790-007	Flat Washer (7/16")	8

3E00-311-AAF MAIN DRIVESHAFT LOCKING HARDWARE*MAIN DRIVESHAFT LOCKING HARDWARE*

250-70-39	BEARING-CAP,SPL250	2
250-70-39	BEARING-CAP,SPL250	4
5007417	BOLT-SPECIAL, M12 x 25-10	4
5007417	BOLT-SPECIAL, M12 x 25-10	8

3E00-311-BAF MIDSHIP HARDWARE*MIDSHIP HARDWARE**MIDSHIP PLATE MOUNTING HARDWARE*

W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm)	4
W34-1162-012	Flat Washer	8
W20-1028-012	Lock Nut (M12 x 1.75)	4
W20-1028-012	Lock Nut (M12 x 1.75)	4
<i>DRIVELINE BEARING MTG HARDWARE</i>		
W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm)	2
W34-1162-012	Flat Washer	4
W20-1028-012	Lock Nut (M12 x 1.75)	2
W20-1028-012	Lock Nut (M12 x 1.75)	2

3E00-700-GAC SELF-ADJUST CLUTCH W/ MANUAL TRANS*SELF-ADJUST CLUTCH W/ MANUAL TRANS**= SELF-ADJUST CLUTCH - REMOVE ROD**BLOCK BEFORE ADJUSTING HEX ROD,**TIGHTEN JAM NUTS, THEN PRESS CLUTCH**PEDAL 5 TIMES TO SET PEDAL**FREE-PLAY =*

Y84-6000-010	STRAP-TIE	1
--------------	-----------	---

3E00-701-BAC CLUTCH PUSH ROD HARDWARE*CLUTCH PUSH ROD HARDWARE**E97-6059 INSTL CLUTCH LINKAGE**E97-6059 INSTL CLUTCH LINKAGE**E97-6059 INSTL CLUTCH LINKAGE*

06-00984	Rod End, Tie Rod	1
06-01106	Jam Nut (1/2-20)	1
27-00279-010	Hex Bolt (1/2-20 x 2-1/2")	1
27-00428-008	Plain Washer (1/2")	3
27-00791-008	Lock Nut (1/2-20)	1
27-00791-008	Lock Nut (1/2-20)	1
27-00279-011	Hex Bolt (1/2-20 x 2-3/4")	2
27-00428-008	Plain Washer (1/2")	5
27-00791-008	Lock Nut (1/2-20)	1
J21270-14	Rod End - Elastomeric	1

06-01105	Jam Nut (1/2-20)	1
27-00279-010	Hex Bolt (1/2-20 x 2-1/2")	1
27-00428-008	Plain Washer (1/2")	3
27-00791-008	Lock Nut (1/2-20)	1

3E00-701-CAK CLUTCH CONTROL - CAB - FRAME MTD

CLUTCH CONTROL - CAB - FRAME MTD

REMOTE LUBE HOSES - CLUTCH LINKAGE

W/ FIREWALL CONNECTION BRKT

E97-6037 INSTL CLUTCH LINKAGE

E95-6034 INSTL REMOTE CLUTCH LUBE

E95-6034 INSTL REMOTE CLUTCH LUBE

E95-6034 INSTL REMOTE CLUTCH LUBE

E95-6034 INSTL REMOTE CLUTCH LUBE

E95-6078 INSTL-REMOTE LUBE, UNDER CAB

NOTE: DO NOT PAINT THE REMOTE

LUBE HOSE ZERK FITTINGS

E21-6003	Clutch Pedal Linkage Assembly	1
E42-6000	Seal, Clutch Rod	1
E20-6003	Clutch Seal Retainer	1
27-00341-004	Self Threading Screw (#10- 24 x 1/2")	4
E17-6002-003	Clutch Linkage Assembly	1
06-01067	Clutch Return Spring	1
06-01102	Bracket, Clutch Return Spring	1
HKLT-R8-06	Truss Head Rivet (1/4")	6
27-00498-006	Star Washer, Internal Tooth (3/8")	2
W34-6031	Nut (1/8 x 27)	2
V50-6027-01320	HOSE-LUBE LINE 1/8-27	2
E74-6026	Remote Lube Kit, Under Cab	1

3E00-701-DAG CLUTCH CONTROL - TRANSMISSION

CLUTCH CONTROL - TRANSMISSION

E97-6037 ASSY-CLUTCH LINKAGE

06-00530	Clutch Shaft, RH	1
105C137	Clutch Release Yoke	1
330231	Cap Screw, Hex Head	2
K363-359-1-438	Lock Washer, External Tooth (7/16")	2
06-01093	Clutch Release Shaft	1
W34-6058	WASHER - CLUTCH, SHAFT	1
05-11695	Woodruff Key (#18)	1
06-00187	Washer (1-1/2")	1
06-00715	Clutch Shaft Lever	1
06-00910M014	Clutch Adjusting Lever Flange	1
27-00790-012	Flat Washer (3/4")	1
27-00442	Lock Nut (3/4-16)	1
127760	Clutch Brake	1

3E00-701-EAC PILOT BEARING

PILOT BEARING

NOTE: INSTALL PILOT BEARING PER

PETERBILT MFG STD 0520.021

05-18810 BEARING XMSN PILOT 1

3E10-300-DAP WATER TO OIL TRANSMISSION COOLER PLMBG

WATER TO OIL TRANSMISSION COOLER PLMBG

D95-6113 ROUTING - ISX HEATER HOSES

D95-6113 ROUTING - ISX HEATER HOSES

E95-6055 RTG-TRANS OIL LINES

E95-6055 RTG-TRANS OIL LINES

E95-6101-000 RTG-XMSN COOLER, WATER TO

E95-6101-000 RTG-XMSN COOLER, WATER TO

TRANS COOLER SUPPLY HOSE

V50-6008-20350 Heater Hose w/ Convolute 1
Tubing, Blue (3/4" x 350mm)

CLAMPS

933-270-10H Constant Tension Clamp 1
(27mm)

05-11700-012 Hose Clamp (3/4") 1

TRANS OIL RTG HARDWARE

D11-6283 BRACKET-STANDOFF, ENGINE 1

3E10-300-FAE FULLER SHIFT KNOB

FULLER SHIFT KNOB

S2574 Shift Knob & Valve 1

V50-6094 TUBING - AIR SHIFT 1

3E10-701-AAC CLUTCH PUSH ROD

CLUTCH PUSH ROD

06-01150-360 CLUTCH LINK LOWER 1

3E10-720-AAC SHIFT LEVER - PAINTED

SHIFT LEVER - PAINTED

05-19690 LEVER-SHIFT TRANS W/
ISOLATOR 1

3E10-720-CBN REMOTE LUBE HOSES

REMOTE LUBE HOSES

A97-6086 DRLG-FRAME LH U/H COMPONENT

E95-6034 INSTL-REMOTE CLUTCH LUBE

E95-6034 INSTL-REMOTE CLUTCH LUBE

E95-6034 INSTL-REMOTE CLUTCH LUBE

E95-6054 RTG-REMOTE LUBE LINE, ISX

E95-6054 RTG-REMOTE LUBE LINE, ISX

E95-6054 RTG-REMOTE LUBE LINE, ISX

REMOTE LUBE BRACKET

E11-6085 Bracket, Remote Lube, Steel 1

22-01684 "Remote Lube" Decal 1

27-00498-006 Star Washer, Internal Tooth 3
(3/8")

W34-6031 Nut (1/8 x 27) 3

W34-1160-050 Lock Nut w/ Nylon Insert 2
(M16 x 1.75)

W20-1028-016 Lock Nut (M16 x 2.00 x 2
16mm)

W20-1028-016

Lock Nut (M16 x 2.00 x 16mm)	2	
W34-1162-016	Washer (16MM)	4
<i>RELEASE BEARING LUBE HOSE</i>		
V50-6027-01375	Lube Hose Assembly (#4 x 1375mm)	1
16-02814	Grommet	1
26-01643	Fitting - Straight (1/8" MP X #4 Flare)	1
<i>CROSS-SHAFT LUBE HOSES</i>		
<i>RH CROSS-SHAFT LUBE HOSE</i>		
V50-6027-01725	Lube Hose Assembly (#4 x 1725mm)	1
K129-186-0204	90° Male Elbow Fitting (1/8-27 NPTF x 7/16-20 NF)	1
<i>LH CROSS-SHAFT LUBE HOSE</i>		
V50-6027-01200	Lube Hose Assembly (#4 x 1200mm)	1
26-01962	Connector-90 Deg (1/8" MP X 1/8" MP)	1
26-01643	Fitting - Straight (1/8" MP X #4 Flare)	1
<i>STANDOFF BRACKETS MTD ON ENGINE</i>		
E11-6107	90° Ladder Bracket	1
27-01008-008	Lock Nut (M8 x 1.15-6H) Cadmium Plate	1
<u>3F0P-300-AAD CRM & COOLANT HOSE ASSY</u>		
<i>CRM & COOLANT HOSE ASSY</i>		
F50-6554-0668GJF0	Coolant Return Manifold Assembly	1
<u>3F00-300-AAG EXTENDED LIFE COOLANT</u>		
<i>EXTENDED LIFE COOLANT</i>		
*** <i>EXTENDED LIFE COOLANT</i> ***		
<i>F97-6186 INSTL ELC LABELS</i>		
<i>F97-1659-0000 INSTL-BELT ROUTING LABEL</i>		
<i>F97-6461 INSTL-PUMP VENT SEALANT</i>		
F72-1002-001	COOLANT-LLC, BULK	16
<i>ANTIFREEZE PROTECTION LABEL ALREADY AFFIXED TO SURGE TANK</i>		
<i>LABEL EXTENDED LIFE COOLANT</i>		
F53-1066	LABEL-SHELL,EXTENDED LI	1
F53-6026	LABEL-WASHER PUMP	2
<u>3F00-700-CAG RECIRCULATION SHIELD ASSY</u>		
<i>RECIRCULATION SHIELD ASSY</i>		
<i>D97-6106S33 SHT 2,INSTL RECIRC SHLD HD</i>		
<i>D97-6106S33 SHT 2,INSTL RECIRC SHLD HD</i>		
F46-6138	SHIELD- RECIRC 388/9 ASSY	1
27-00428-004	Flat Washer (1/4")	4
27-01040-025	Hex Bolt (M6 X 1.00 X 25mm)	4
F46-6138R	SHIELD-RECIRC 388/9 ASSY	1

3F1P-700-AAQ COOLING MODULE ASSEMBLY*COOLING MODULE ASSEMBLY*

F31-1316-2201711 Cooling Module Assembly 1

3F10-700-AAF RING AND BRACKETS - FAN SHROUD*RING AND BRACKETS - FAN SHROUD**F97-6273 INSTL RING SHROUD & BRKT**D97-6330-000 INSTL-NUT CAPTURE BRKT**RING AND BRACKETS - FAN SHROUD*

F91-1017 Fan Ring 1

F85-6469 Fan Ring Support, Upper Left 1

F85-6468 Fan Ring Support, Upper Right 1

F85-6407 Fan Ring Support, Lower 1

HARDWARE FOR RING

27-01000-008 Lock Nut w/ Nylon Insert (M8 2 x 1.25)

27-00790-005 Flat Washer (5/16") 4

27-00944-030 Hex Bolt (M8 x 1.25 x 30mm) 2

27-01008-008 Lock Nut (M8 x 1.15-6H) 2
Cadmium Plate*10MM HRDWR UPPER BRACKETS ISX**APPLY MEDIUM LOCTITE TO BOLT THREADS*

K041-830-25CA Hex Bolt, Lock (M10 x 1.50 x 4 25mm)

W34-1162-010 Washer (10MM) 4

*10MM HRDWR LOWER BRACKETS ISX**APPLY MEDIUM LOCTITE TO BOLT THREADS*

K041-830-25CA Hex Bolt, Lock (M10 x 1.50 x 3 25mm)

W34-1162-010 Washer (10MM) 3

FRONT ENG MOUNT NUT CAPTURE BRACKET

D11-6383 BRACKET - FRONT ENGINE 1

== *INSTL NUT CAPTURE BRACKET OVER LOWER**FAN RING BRACKET ==***3F10-700-BAC RADIATOR MOUNTING***RADIATOR MOUNTING**F97-6092 INSTL RADIATOR MOUNTS**D97-6106S21 INSTL RADIATOR GROUND**F97-6156 INSTL RING SHROUD*

F13-1016 BUSHING-RADIATOR RUBBER 4

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 2

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 2

27-00776 Shim (5/8") 4

3F10-700-CAC RADIATOR TIE RODS*RADIATOR TIE RODS**F97-1640-004 INSTL RADIATOR TIE ROD**F97-1640-004 INSTL RADIATOR TIE ROD*

F65-1080-696094 ROD-TIE, RADIATOR 2

FRAME END OF RADIATOR TIE ROD

*NOTE: LH SIDE SHARES TOP HOLE OF
POWER STEERING RESERVOIR BRKT*

W34-1160-080	Hex Bolt (M16 x 2.00 x 080mm)	2
W34-1162-016	Washer (16MM)	4
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2
<i>RADIATOR END OF RADIATOR TIE ROD</i>		
W34-1160-070	Hex Bolt (M16 x 2.00 x 070mm)	2
W34-1162-016	Washer (16MM)	4
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2

3F10-700-DAD RADIATOR PIPING

RADIATOR PIPING

F97-1776 INSTALLATION - PIPING

F97-1776 INSTALLATION - PIPING

V95-6046 RTG-HVAC @ COOLING MODULE

V95-6046 RTG-HVAC @ COOLING MODULE

V95-6046 RTG-HVAC @ COOLING MODULE

D95-6155 RTG - CUMMINS 15L HARNESS

NOTE: REMV & DISCARD CUMMINS SUPPLIED

ENG HARN RESTRAINT. RESECURE

USING CUSHION CLAMP PROVIDED.

UPPER CONNECTIONS

UPPER CONNECTIONS

F66-2436-100	PB8 PIPE UPPER WATER	1
CT300LSS	HOSE CLAMP ASSY CONSTANT	2
F04-6006	Hose Elbow, 90°, Silicone (2-1/2" OD)	1
CT9444PFB	CLAMP W/STANDOFF	2
F50-6308	Radiator Hose, Upper, Blue (2-1/2"), Silicone	1
F11-1683	BRACKET - WATER PIPE	1
426-2375	U-Bolt Clamp (5/16-18)	1
K363-338-6-312	Flat Washer (5/16")	2
K041-803-20CA	Hex Bolt (M8 x 1.25 x 20mm)	2
K363-338-3-312	Flat Washer (5/16")	2
D16-6003-7611110	Cushioned Clamp (5/8")	1
<i>LOWER CONNECTIONS</i>		
F66-2300-100	PIPE - LOWER WATER	1
F50-1548	Silicone Hose (2-1/2")	1
CT300LSS	HOSE CLAMP ASSY CONSTANT	3

ENGINE CONNECTION HOSE

F50-6179-2400125

Radiator Hose, Silicone (2- 1
 1/2" ID x 125mm)
 NOTE: INSTL ADDTL CLAMP AT LWR ENG CONN
 CT300LSS HOSE CLAMP ASSY 1
 CONSTANT

3F10-700-EAD CHARGE AIR COOLER PIPING

CHARGE AIR COOLER PIPING

F97-1776 INSTALLATION - PIPING

NOTE: RH ELBOW 0 DEG ROTATION FROM
 VERTICAL-IN LINE W/ TURBO OUTLET

NOTE: LH ELBOW STRAIGHT FORWARD

HOT SIDE CAC PIPE

D66-1963 PIPE - CHARGE AIR, HOT 1

COLD SIDE CAC PIPE

D66-1964 PIPE - CHARGE AIR, COLD 1

F16-6009-031B413RB0 CLAMP-HOSE, T-BOLT 8

D50-6039 Hump Hose 2

D50-1076 HOSE-HUMP, COLD SIDE CAC 2

HOSE-HUMP COLD SIDE CAC (BLUE) TO BE

INSTLD ON DRIVER/COLD SIDE OF CAC ONLY

3F10-700-FAL DRAWDOWN & VENT HOSES

DRAWDOWN & VENT HOSES

F95-6134 ROUTING - HOSE, VENT, ISX15

F95-6134 ROUTING - HOSE, VENT, ISX15

D95-6131 ROUTING - DRAW DOWN

D95-6131 ROUTING - DRAW DOWN

F50-1050-1000 Silicone Coolant Hose w/
 Wire Spring Insert (1100mm) 1

F50-2051-0525 HOSE-SILICONE 5/8 1

V38-1302 FTNG-5/8 Bead to M12x1.5 1

D2119-9014 FITTING - STRAIGHTM27 X 1

26-01693 90° Connector (3/4 MP to
 #16 Clamp) 1

933-350-10H Clamp, Constant Torque 2

933-240-10G Band Clamp Constant Tension 2

WSR01MHSUVH4 Tie Strap, Wide 2

DSWS4 Dual Swivel Saddle Spacer 1

D11-6285 Standoff Bracket 1

DRAWDOWN ROUTING HARDWARE

D11-6285 Standoff Bracket 2

Y84-6000-007 Tie Strap 2

3F10-700-GAE PB FILL LABEL INSTRUCTIONS

PB FILL LABEL INSTRUCTIONS

F97-6332 INSTL RAD FILL PROCEDURE

==ATTACH LABEL TO COOLANT SURGE TANK

HEAT SHIELD AS SHOWN IN REF DRAWING

F53-1055-001 LABEL-RADIATOR FILL 1

3F10-701-ABC FAN CLUTCH

FAN CLUTCH

402MM FAN CENTER

1.3:1 FAN DRIVE RATIO

D97-6106S40 ROUTING - AIR SUPPLY
 D97-6106S39 ROUTING - AIR SUPPLY
 F97-1833-002 INSTL-FAN CLUTCH
 D95-6139 AIR HOSE RTG
 CONV TUBING ON NYL HOSE FROM BASE OF
 FAN CLTCH FTG TO APPROX 3" FROM SOLND.
 APPLY LOCTITE TO FASTENER THREADS

F17-1031-002	CLUTCH - DRIVE FAN, ISX15	1
W34-1159-045	Hex Bolt (M12 x 1.75 x 45mm)	4
W34-1162-012	Flat Washer	4
G50-6022-04BLK092	TUBING-NYLON AIR BRAKE FAN CLUTCH TO SOLENOID	1
K129-231-0204	90° Male Fitting, J844 (1/8- 27 NPTF x 7/16-24 NF)	1

3F10-701-BAF FAN BELT

FAN BELT

402MM FAN CENTER

D97-6115S50 INSTL BELTS 2007 ISX

D84-1000-6122310	BELT POLY ENDURANCE 12K	1
D84-1000-6061620	Engine Belt (6 Rib x 1620mm)	1

3F10-701-CAL FAN

FAN

F97-1731-0000 INSTL - FAN BLADE

F51-6008M06	FAN-HORTON	1
27-00437	Lock Nut (5/16-18)	6
27-00790-005	Flat Washer (5/16")	6

3F10-701-DAD FAN CLUTCH HARDWARE

FAN CLUTCH HARDWARE

D95-6077 INSTL-FAN CLUTCH SOLENOID

G90-6047	Solenoid Valve, Normally Closed	1
R34-6002-06050RF0M	Exterior Threaded Hex Screw (M6 x 1.00 x 50mm)	1
22-01151-022	Cushioned Clamp (1-3/8")	1

3F10-701-EAC BELT ROUTING LABEL - ISX

BELT ROUTING LABEL - ISX

F97-1659-0000 INSTL-BELT ROUTING LABEL

NOTE: INSTL ON RH SIDE CHANNEL
 OF THE COOLING MODULE

F53-1025-001	LABEL-BELT ROUTING	1
--------------	--------------------	---

3G0B-300-AAD POGO LOCATION

POGO LOCATION

POGO LOCATION FROM BOC/BOS PLANE
 260

3G0P-300-AAD POGO STICK BRACKET ASSEMBLY

POGO STICK BRACKET ASSEMBLY

G11-6236-06010102	Pogo Stick Bracket Assembly	1
08-02713C		

Pogo Stick Assembly, Chrome 1
Plated

22-00923	Retaining Clip	2
G11-6075M06	Mounting Bracket, Pogo Stick	1
G38-1022-0808	45° Fitting (#8 Male NPT to #8 J2494)	1
G38-1022-0810	45° Elbow Fitting (#8 Male NPT to #10 J2494)	1
K129-160-08	Anchor Coupling Fitting (1/2-14 NPTF x 1-1/8-14 UNF)	2
K129-194-08	Square Pipe Plug (1/2-14 NPTF)	2
W20-1028-010	Lock Nut (M10 x 1.50)	2
W34-1162-010	Washer (10MM)	4
W34-1163-070	Hex Bolt (M10 x 1.50 x 70mm)	2

3G0P-300-CAC UNDER CAB HOSE HARNESS

UNDER CAB HOSE HARNESS

NOTE:ROUTE FOR AIR SYST CLEARANCE

NOTE:ROUTE FOR AIR SYST CLEARANCE

G21-6024527A55D410	PEDAL-FOOT VLV/PLMB,PNG	1
05-12093M000	Pedal Pad	1
05-18716	Pedal Plate Gasket Kit	1
08-03081-005	Control Valve, TP-5	1
08-03285	Double Check Valve (3/8")	1
26-02197	Tee (3/8" FP x 3/8" FP x 3/8" MP)	2
27-00269-004	Hex Bolt (5/16-18 x 1")	7
27-00335	Elastic Stop Nut	2
27-00428-003	Flat Washer (3/16")	2
27-00428-005	Flat Washer (5/16")	12
27-00437	Lock Nut (5/16-18)	1
27-00503-005	Flat Washer (5/16")	2
27-00566-005	Lock Nut (5/16")	6
5018969	Brake Valve	1
D2031-1258	Fitting - Bulkhead (1/2" PTC)	4
D2031-1260	Fitting - Bulkhead (5/8" PTC)	2
D2031-1308	Fitting - Bulkhead (1/2" PTC To #8 Flare)	1
D21-6024	Electronic Throttle Pedal Assembly	1
D22-6006M01	Accelerator Pedal Plate	1
G11-6059	Double Check Valve Mounting Bracket	1
G11-6199	Air Bracket	1
G38-1021-0606	90° Elbow Fitting (#6 Male NPT to #6 J2494)	3
G38-1021-0608	90° Elbow Fitting (#6 Male NPT to #8 J2494)	3
G38-1021-0610	0° Elbow Fitting (#6 Male NPT to #10 J2494)	1

G38-1021-0808	90° Elbow Fitting (#8 Male NPT to #8 J2494)	1
G38-1021-0810	90° Fitting (#8 Male NPT to #10 J2494)	1
G38-1023-0604	Straight Fitting, Brass (#6 Male NPT to #4 J2494)	2
G38-1023-0608	Straight Fitting, Brass (#6 Male NPT to #8 J2494)	4
G50-6022-040RN040	Orange Nylon Tubing (1/4" x 40")	1
G50-6022-04GRN040	Green Nylon Tubing (1/4" x 40")	1
G50-6022-08BLU026	Blue Nylon Tubing (1/2" x 26")	1
G50-6022-08BLUCTL	Blue Nylon Tubing (1/2")	1
G90-6083	Pressure Protection Valve	1
G92-6168-003	HARNESSTUBING, UNDERCAB	1

3G0P-300-DAE AIR DRYER AUX PORT FITTING

AIR DRYER AUX PORT FITTING

G38-6029014C6C014C	FTG-AIR DRYER, AUX, AD-HF	1
K129-194-04	Square Pipe Plug (1/4-18 NPTF)	2

3G0P-302-AAC MUX SOLENOID BANK (MSB) 1 LABEL

MUX SOLENOID BANK (MSB) 1 LABEL

G5334H1B4G1F100000	LABEL-MUX SOLENOID BANK	1
--------------------	-------------------------	---

G533ABBCCDDEEFFGGH PNG VALUE DECODER

3G00-302-CBA REAR AXLE SHIFT CONTROL CHASSIS PIPING

REAR AXLE SHIFT CONTROL CHASSIS PIPING

G95-6230S11 RTG-DIFF-LOCK CONTROLS

G95-6230S11 RTG-DIFF-LOCK CONTROLS

= MAIN DIFF LOCK HOSES =

G50-6022-04BLKCTL	Black Nylon Tubing (1/4") QRV (3307) TO SOLENOID BANK	1
-------------------	---	---

26-03424-029	Air Brake Hose Assy, SAE Flared, Crimped, (#6 x 29")	1
--------------	--	---

= QRV TO DIFF LOCK SHFTR MAIN DIFF

LOCK FTGS, QR VALVE & HWR =

08-01279	Quick Release Valve (QR-1)	1
----------	----------------------------	---

08-02659	Valve Bracket	1
----------	---------------	---

27-00271-004	Hex Bolt (5/16-24 x 1")	2
--------------	-------------------------	---

27-00311-005	Hex Nut (5/16-24)	2
--------------	-------------------	---

27-00304-005	Lock Washer (5/16")	2
--------------	---------------------	---

27-00428-005	Flat Washer (5/16")	4
--------------	---------------------	---

= QR VALVE FTGS =

G38-1021-0604	90° Elbow Fitting (#6 Male NPT to #4 J2494)	1
---------------	---	---

26-01984-006	Hose/Tube Plug, Square Head (3/8")	1
--------------	------------------------------------	---

K129-186-0606		
---------------	--	--

90° Male Elbow Fitting (3/8- 1
 18 NPTF x 5/8-18 NF)
 = *DIFF LOCK SHIFTER FTG* =
 26-01657 Connector, 90 Deg (1/4" MP 1
 X #6 Flare)

3G00-310-CBZ FRONT BRAKE INNER FRAME HOSES

FRONT BRAKE INNER FRAME HOSES

V97-6023 INSTL-FRONT BRAKE PIPING HDWR

C97-6023 INSTL-FRONT BRAKE PIPING HDWR

PMV TO FRAME BULKHEAD

26-03425-037 Air Brake Hose Assembly, 2
 Crimped (#8 x 37")

3G00-310-EHZ BENDIX AIR DRYER

BENDIX AIR DRYER

*BENDIX AD-HF(EP) AIR DRYER * HEATED **

AIR DRYER MOUNTED UNDER RAIL

G97-1470-0000RL INSTL-AIR DRYER, AD-HF

G97-1470-0000RL INSTL-AIR DRYER, AD-HF

G94-6011-001 DIAG-AIR CHARGING

G94-6011-001 DIAG-AIR CHARGING

K160648 Air Dryer Assembly, AD-HF 1

G11-6325-002 bracket-air dryer 1

G53-6036 Label-Air Dryer Warning 1

== *PLC WARNING LBLs ON OUTSIDE OF FRM*

RAIL IN VISIBLE LOC NEAR THE A/D

MTG LOCATION ==

G38-1023-0408 Straight Fitting, Brass (#4 2
 Male NPT to #8 J2494)

27-00767-004 Hex Bolt (3/8-16 X 1") 4

W34-1162-010 Washer (10MM) 4

27-00562-006 Spring Lock Washer (3/8") 4

G50-6022-04BLKCTL Black Nylon Tubing (1/4") 1

GOVERNOR TO COMPRESSOR (1003)

3G00-310-FAP GOVERNOR UNLOADER PORT

GOVERNOR UNLOADER PORT

G37-1032-00000000 DRYER-FTG KIT AD-HF

G37-1032-00000000 DRYER-FTG KIT AD-HF

G38-1021-0404 90° Elbow Fitting (#4 Male 1
 NPT to #4 J2494)

3G00-310-GAJ CHARGE PORT

CHARGE PORT

CHARGE PORT - REMOTE FILL

G97-1411S01-000 INSTL-A/D PRESS SENSOR

G97-1411S01-000 INSTL-A/D PRESS SENSOR

G37-1032-00000000 DRYER-FTG KIT AD-HF

G37-1032-00000000 DRYER-FTG KIT AD-HF

G38-1023-0406 Straight Fitting, Brass (#4 1
 Male NPT to #6 J2494)

3G00-310-JAC FRONT BRAKE CHAMBER HOSES

FRONT BRAKE CHAMBER HOSES

G97-6370 INSTL-FRONT BRAKE CHAMBER JU
 G97-6370 INSTL-FRONT BRAKE CHAMBER JU
 G97-6370 INSTL-FRONT BRAKE CHAMBER JU
 G97-6370 INSTL-FRONT BRAKE CHAMBER JU
 FRAME BULKHEAD TO BRAKE CHAMBER
 26-03425-017 Air Brake Hose Assembly, 2
 Crimped (#8 x 17")
 26-01679 Connector, Straight (3/8" X 2
 #8 Flare)

3G00-700-AEB FRONT BRAKE PIPING

FRONT BRAKE PIPING

** STABILITY CONTROL **

CUMMINS ISX15 ENGINE

V95-6057 RTG: FRONT BRAKE PIPING

V95-6057 RTG: FRONT BRAKE PIPING

A96-6047 DRILLING-COMMON CHASSIS SFFA

FRONT FRAME

A96-6047 DRILLING-COMMON CHASSIS SFFA

FRONT FRAME

G97-6181 INSTL SUPT STABILITY CNTRL

G97-6181 INSTL SUPT STABILITY CNTRL

G95-6112 RTG STABILITY CNTRL-RH RAIL

G95-6112 RTG STABILITY CNTRL-RH RAIL

V97-6023 INSTL FRONT BRAKE PIPING

V97-6023 INSTL FRONT BRAKE PIPING

NOTE:WITH HD TOW PIN INSTL FRONT BRAKE

VALVE ASSY IN REAR MOST POSITION

G90-6167 Front Modulator Valve 1
 Assembly
 27-00269-024 Hex Bolt (5/16-18 x 6") 2
 27-00428-005 Flat Washer (5/16") 6
 27-00566-005 Lock Nut (5/16") 2
 G11-6062 Bracket, ABS Valve Mount 1
 G11-6063 Bracket - Valve, ABS 1
 K056040 Modulator Valve, M-40HF 2
 K129-188-0808 45° Male Elbow Fitting (1/2- 4
 14 NPTF x 3/4-16 NF)
 K129-388-08 90° Street Elbow Fitting 2
BULKHEAD FOR FRONT PMV S
 26-02911 90° Bulkhead Fitting (#8 2
 Flare x #8 Flare)
 27-00428-012 Flat Washer (3/4") 2
 27-00498-012 Star Washer, Internal Tooth 2
 (3/4")
 27-00710-012 Hex Jam Nut (5/8-18 x 3/4") 2
HARDWARE FOR MOUNTING PMV S
 W34-1162-012 Flat Washer 2
 W20-1028-012 Lock Nut (M12 x 1.75) 2
 W20-1028-012 Lock Nut (M12 x 1.75) 2
 Y84-6000-016 Tie Strap, Button Head 2
 27-00269-003 Hex Bolt (5/16-18 x 3/4") 2

27-00428-005	Flat Washer (5/16")	4
27-00437	Lock Nut (5/16-18)	2
V50-1118-08011-164	Wirebraid Hose Assembly, Extreme Temp (#8 x 164")	2

FRONT BRAKE RELAY TO PMV S**FRONT PMV S TO BULKHEAD**

***** TIE STRAP MNTS *****

HM3	MOUNT-H,5/8	2
3754	Heavy-Duty Tie Mount	3
WSR01MHSUVH4	Tie Strap, Wide	4
Y11-6018	BRACKET-STANDOFF	1
Y84-6000-007	Tie Strap	1
HARDWARE FOR RH U/HOOD HOSE SUPPORT		
V46-1002-050-0250	SHIELD - HEAT	1
22-01154-018	Oval Cushioned Clamp, (1- 1/8")	2
A62-6084	Cable Tie Mount	1
22-01618-001	Cable Tie, Heavy Duty	1
K231-363HTMP	Cable Tie	4

3G00-700-CAD FOOT VALVE PLUMBING**FOOT VALVE PLUMBING**

26-03425CTL	Hose Assembly, Crimped (#8)	1
26-03429	Hose Only (#8)	1
26-03433	Crimp Shell (#8)	2
26-03440	Brass Insert (#8)	2
V38-1246-108	Brass Hose Fitting Nut (45° x 2 3/4-16)	2

BOC BULKHEAD TO LIMITING VALVE**3G00-700-EAC FRONT BRAKE MISC****FRONT BRAKE MISC****G97-6105 INSTL - FRONT ABS GROMMET****A96-6047 DRLG COMMON CHASSIS - SFFA****A97-6085 DRLG COMMON CHASSIS - SBFA****A42-6000 GROMMET - ABS, FRT W/O LI 2****3G00-700-GAF PARKING BRAKE CONTROL****PARKING BRAKE CONTROL****G94-6103 DIAG-DBL VLV PARK CTRL PLMB****G97-6376-100 INSTL-PARK VALVE**

S18-6002-002	Bezel, Dual MV3 Valve	1
G90-6036	Parking Brake Control Valve, MV-3	1
W01-10-01P55N020B	Pan Head Screw (M5 x 0.80 x 4 20mm), Black	1
G50-6022-06GRN042	TUBING-NYLON AIR BRAKE	1
FWD FW MANIF TO MV-3 VLV(SPLY)(1903)		
G50-6022-060RN041	TUBING-NYLON AIR BRAKE	1
RR FW MANIF TO MV-3 VLV(SPLY)(1916)		
G50-6022-06YEL042	TUBING-NYLON AIR BRAKE	1
MV-3 VLV DEL(TRAC) TO FRWL BLKHD(1601)		
G50-6022-06RED042	TUBING-NYLON AIR BRAKE	1

MV-3 VLV DEL(TRLR) TO FRWL BLKHD(1704)
 PLUG EXH FITTING IN FW BLKHD (12)
 26-02917 Fitting - Bulkhead (#8 Comp 1
 X #8 Comp)
 G50-6022-08BLK038 TUBING-NYLON AIR BRAKE 1
 MV-3 VLV EXH TO FIREWALL BULKHEAD

3G00-700-HAG AIR SYSTEM COMMON PARTS

AIR SYSTEM COMMON PARTS

NYLON CHASSIS HOSE

P95-6829 RTG-CHASSIS HARNESS SEP

G94-6099 DIAG-CAB MANIFOLD

G94-6099 DIAG-CAB MANIFOLD

S97-6375 INSTL-CONVENTIONAL,DASH SET

S97-6375 INSTL-CONVENTIONAL,DASH SET

G97-6382 INSTL-LABEL,FIREWALL BULKHEAD

G97-6382 INSTL-LABEL,FIREWALL BULKHEAD

P95-6524 RTG-TRAILER HARNESS GROUND

G95-6304 RTG-CHASSIS BUNDLE W/ DAYCAB

G95-6304 RTG-CHASSIS BUNDLE W/ DAYCAB

G95-6304 RTG-CHASSIS BUNDLE W/ DAYCAB

G95-6304 RTG-CHASSIS BUNDLE W/ DAYCAB

G95-6304 RTG-CHASSIS BUNDLE W/ DAYCAB

G95-6304 RTG-CHASSIS BUNDLE W/ DAYCAB

G58-6051-001 MANIFOLD - AIR CAB 1

R42-6212 GROMMET - MAIN CAB 1

27-00498-012 Star Washer, Internal Tooth 1
 (3/4")

G58-6050 Manifold - Bulkhead,Conv 1

G53-6053 LABEL-FIREWALL BULKHEAD 1

G38-6018-040404 Tee Fitting (#4 to #4) 1

G38-6018-060604 Union Tee Fitting, Composite 1
 (#6 to #6 J2494)

G38-1097-0404 Snap Head Fastener w/ 1
 Washer (M4 x 0.70 x 30mm)

G50-6022-04GRN010 TUBING - NYLON AIR BRAKE 1
 MANIFOLD TO LOW AIR SENSOR

G50-6022-08GRNCTL Green Nylon Tubing (1/2") 1
 AIR DRYER TO FWD DRY TANK (1101)

G50-6022-080RNCTL Orange Nylon Tubing (1/2") 1
 AIR DRYER TO REAR DRY TANK (1102)

G50-6022-10BLKCTL Black Nylon Tubing (5/8") 1
 FWD DRY TANK TO BOC BULKHEAD

G50-6022-08BLKTBM TUBING-NYLON AIR BRAKE 1
 REAR DRY TANK TO BOC BULKHEAD

MTG HDWE FOR FIREWALL BULKHEAD

R34-6002-06025RHLZ Exterior Threaded Hex Screw 10
 (M6 x 1.00 x 25mm)

RDR466565A PLUG 8

R34-6002-06035RF0Z Exterior Threaded Hex Screw 4
 (M6 x 1.00 x 35mm)

A62-6084 Cable Tie Mount 3

FRAME BRKT & MTG HARDWARE

A11-6826	BRACKET-FRAME HOSE	1
W16-6024	Clip	1
V46-1003-1750200	Abrasion Shield (175mm x 200mm)	1
V46-1003-1750200	Abrasion Shield (175mm x 200mm)	1
Y84-6000-014	Tie Strap	3
22-01553-018	Cushioned Clamp, (1-1/8")	1
HDM400B	Cable Tie Mount, High Torque	1
27-00428-005	Flat Washer (5/16")	2
27-00269-006	Hex Bolt (5/16-18 x 1-1/2")	2
27-00809-006	Hex Nut (3/8-16)	1
27-00810-006	Lock Washer (3/8")	1
27-01386-005	Lock Nut (5/16-18)	2

3G00-700-JAD DASH MTD - BRAKE VALVE AND PLUMBING*DASH MTD - BRAKE VALVE AND PLUMBING**G94-6100 INSTL- HOSE, HAND VALVE*

G92-6176-200	HARNESS-VALVE, TRAILER HA	1
26-02566	Fitting - Bulkhead (1/4" X #4 NTA X #4 NTA)	1
G90-1260-011	COMPACT TRLR BRKE VLVE	1

3G00-700-MAG TRANSMISSION AIR PLUMBING*TRANSMISSION AIR PLUMBING*

G38-1021-0604	90° Elbow Fitting (#6 Male NPT to #4 J2494)	1
G50-6022-04GRN043	TUBING-NYLON AIR BRAKE	1
== RT HS ACRS BCK OF ENG TO LH RAIL ==		
== HOT LINE-XMSN TO CAB MANIFLD ==		

3G00-700-QAD PTO CONTROLS*PTO CONTROLS**SINGLE ACTING**G94-6102-100 DIAG-PTO CONTROLS**G94-6102-100 DIAG-PTO CONTROLS**PTO SOLENOID PLUG*

G38-1045-0004	Plug Fitting, Composite (1/4")	1
---------------	--------------------------------	---

3G00-700-SAE AIR MANIFOLD PLUGS*AIR MANIFOLD PLUGS*

G38-1045-0004	Plug Fitting, Composite (1/4")	2
G38-1045-0004	Plug Fitting, Composite (1/4")	1

3G00-702-AAF MUX SOLENOID BANK (MSB) 1*MUX SOLENOID BANK (MSB) 1**G97-6372-000 INSTL-MUX SLND BK BRKT*

G90-1266-141	Solenoid Valve, Bank 1	1
==USE BLACK WRAP AS NEEDED PER CMS0258 FOR ROUTING AROUND MSB ==		

P16-1006-100	Fir Tree Clip	2
VFC99016	CAP-VINYL	1

== INSTALL VINYL CAP OVER MSB ELECT
CONNECTOR FOR PAINT MASK ==

3G00-702-CAC MUX SOLENOID BANK AIR SUPPLY

MUX SOLENOID BANK AIR SUPPLY

AIR DRYER FITTING FOR PORT E

G38-1021-0404	90° Elbow Fitting (#4 Male NPT to #4 J2494)	1
---------------	--	---

AIR DRYER PORT E TO MUX BANK SUPPLY

G50-6022-04GRNCTL	Green Nylon Tubing (1/4")	1
-------------------	---------------------------	---

FTG-90 DEG TO AIR SUPPLY AT EOA

G38-1097-0404	Snap Head Fastener w/ Washer (M4 x 0.70 x 30mm)	1
---------------	--	---

3G10-700-AAL COMPRESSOR PIPING

COMPRESSOR PIPING

G95-6101-000 RTG-COMP DISCHARGE LINE

G95-6101-000 RTG-COMP DISCHARGE LINE

G50-6004-029	Compressor Discharge Hose Assembly (#12 x 29")	1
--------------	---	---

G11-6170-001	BRACKET-AIR LINE	1
--------------	------------------	---

D16-6003-5415116	CLAMP - CUSHIONED	2
------------------	-------------------	---

27-01309-025	Hex Bolt (M6 x 1.00 x 25mm)	2
--------------	-----------------------------	---

27-00428-004	Flat Washer (1/4")	2
--------------	--------------------	---

27-01000-006	Lock Nut (M6 x 1.00)	2
--------------	----------------------	---

3G10-700-BAN COMPRESSOR PIPING HARDWARE

COMPRESSOR PIPING HARDWARE

G95-1115-000 RTG- AIR DRYER

G95-6260-000 RTG- GOV. HOSE

= FLARE TO PTC ADAPTER INCLUDED IN

HOSE ASSY =

D2119-9005	Fitting - Adapter (M10 X 1.00 to 1/8-27)	1
------------	---	---

26-03552	Connector, 45 Deg. #12	1
----------	------------------------	---

G50-1064-04-016	Air Brake Hose Assembly, Wirebraid (#4 x 16")	1
-----------------	--	---

3G10-700-DAC REMOTE AIR FILL/CHECK PORT

REMOTE AIR FILL/CHECK PORT

G97-1416-000 INSTL-REMOTE AIR LEAK

D2224-2406	FTG-Q/C-ISO 7241 B -BLKHD	1
------------	---------------------------	---

G38-1021-0206	90° Elbow Fitting (#2 Male NPT to #6 J2494)	1
---------------	--	---

G50-6022-06S1LCTL	Silver Nylon Tubing (3/8")	1
-------------------	----------------------------	---

K221-5086-5	Suspension Spacer (6.4mm)	1
-------------	---------------------------	---

== ADD SPACER TO OUTSIDE OF RAIL ==

3G10-701-ABN STABILITY CONTROL COMMON PARTS

STABILITY CONTROL COMMON PARTS

W/ LOAD GAUGE

WITH TRAILER HAND VALVE

P97-6431 INSTL YAW RATE SENSOR

G97-6032 INSTL PRESSURE TRANSDUCERS
 G97-6032 INSTL PRESSURE TRANSDUCERS
 G97-6068 INSTL SUSP LOAD TRANSDUCER
 A97-6181 INSTL-STAB CNTRL HOSE SUPTS
 G95-6112 INSTL-ESP VALVES RH RAIL
 G95-6112 INSTL-ESP VALVES RH RAIL
 G97-6181 INSTL-STAB CNTRL WELD STUBS
 G97-6181 INSTL-STAB CNTRL WELD STUBS
 6CP3-17 PRESSURE-TRANSDUCER 3
 G38-6018-040406 FITTING-UNION TEE, J2494 1
 G38-1085-0406 FTG-STR UNION, COMPOSITE 2
 G50-6022-040RN002 TUBING-NYLON AIR BRAKE 1
 F/WALL TO BLKHD TO TRANSDUCER REDUCER
 G50-6022-04GRN002 TUBING-NYLON AIR BRAKE 1
 F/WALL TO BLKHD TO TRANSDUCER REDUCER
 G50-6022-04PUR005 TUBING-NYLON AIR BRAKE 1
 F/WALL TO BLKHD TO TRANSDUCER
 REDUCER
 YAW RATE SENSOR & MOUNTING HARDWARE
 K190676BX SENSOR- YAW 1
 ACCELERATION
 P11-6191 BRACKET-SENSOR, YAW 1
 RATE
 G90-6163-101 Stability Control Valve 1
 Assembly
 27-00269-013 Hex Bolt (5/16-18 x 3-1/4") 1
 27-00566-005 Lock Nut (5/16") 1
 27-00767-003 Hex Bolt (3/8-16 x 3/4") 2
 27-00790-005 Flat Washer (5/16") 2
 G11-6219 Electronic Stability System 1
 Valve Bracket
 G38-1021-0810 90° Fitting (#8 Male NPT to 1
 #10 J2494)
 G38-1022-0808 45° Fitting (#8 Male NPT to 1
 #8 J2494)
 K105769 ATR-6 Valve 1
 K129-183-0808 Straight Male Fitting (1/2-14 1
 NPTF x 3/4-16 NF)
 K129-186-0408 90° Male Elbow Fitting (1/4- 1
 18 NPTF x 3/4-16 NF)
 K129-188-0808 45° Male Elbow Fitting (1/2- 1
 14 NPTF x 3/4-16 NF)
 K129-194-08 Square Pipe Plug (1/2-14 1
 NPTF)
 K129-290-0404 Pipe Adapter Fitting (1/4-18 1
 NPTF x 1/4-18 NPTF)
 W34-1162-010 Washer (10MM) 2
 W34-1163-035 Hex Bolt (M10 x 1.5 x 35mm) 2
 27-00562-007 Spring Lock Washer (7/16") 2
 W34-1159-045 Hex Bolt (M12 x 1.75 x 1
 45mm)

W34-1162-012	Flat Washer	2
W20-1028-012	Lock Nut (M12 x 1.75)	1
W20-1028-012	Lock Nut (M12 x 1.75)	1
G50-6022-08BLUCTL	Blue Nylon Tubing (1/2")	1
<i>TRAILER PMV TO BOC BULKHEAD</i>		
<i>== HDWR STAB CNTRL HOSE SUPPORT ==</i>		
22-01154-018	Oval Cushioned Clamp, (1-1/8")	2
A62-6084	Cable Tie Mount	1
22-01618-001	Cable Tie, Heavy Duty	1
V46-1002-050-0250	SHIELD - HEAT	1
K231-363HTMP	Cable Tie	4

3J0P-700-AAC STEERING COLUMN

STEERING COLUMN

J97-6051 INSTL-CVNTL STEERING COLUMN

BENDIX STEERING ANGLE SENSOR

MULIT-FUNCTIONAL STEERING WHEEL

1.9M CONVENTIONAL CAB

ENGINE BRAKE

W/O AUTOMATED TRANSMISSION

SELF-CANCEL TURN SIGNAL

J19-6032-351312723 COLUMN-STEERING, GLOBAL 1
A

3J00-700-AAH AXLE STEERING - TRW TAS65 OR THP60

AXLE STEERING - TRW TAS65 OR THP60

J97-6010 INSTALL STEERING

J97-6010 INSTALL STEERING

J97-6016 INSTALL PITMAN ARM

== APPLY LOCTITE 243 TO PITMAN ARM

MTG BOLT THREADS ==

J23-6015	Pitman Arm	1
J20-6004-001	Draglink Assembly	1
<i>HARDWARE FOR MOUNTING PITMANN ARM</i>		
27-01109	Hex Bolt, Pitman Arm (3/4-16 x 4-1/2")	1
27-00791-012	Lock Nut (3/4-16)	1
W34-1162-020	Flat Washer (3/4")	2
<i>HARDWARE FOR DRAGLINK MOUNTING</i>		
27-00411-024	Cotter Pin (1/8" X 1-1/2")	2

3J00-700-BAP STEERING GEAR - TRW THP60 NON-LIMITED

STEERING GEAR - TRW THP60 NON-LIMITED

J97-6010 INSTALL STEERING

TRW THP60 STEERING GEAR

THP60013 Steering Gear Assembly, TRW1

HARDWARE FOR MOUNTING STEERING GEAR

W34-1160-090	BOLT-FINISHED HEX, M16	2
W34-1160-120	BOLT-FINISHED HEX, M16	1
W34-1160-150	Hex Bolt (M16 x 2.00 x 150mm)	2
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	5

W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	5
W34-1162-016	Washer (16MM)	10

3J00-700-CAL STEERING INTERMEDIATE SHAFT

STEERING INTERMEDIATE SHAFT

J97-6010 INSTL-STEERING

418235	Intermediate Steering Shaft Assembly	1
--------	--------------------------------------	---

HARDWARE FOR MOUNTING STEERING SHAFT

27-00651	Hex Bolt (7/16-20 X 2")	2
27-00646	Nut (7/16-20)	2

3J00-702-BAD STEERING COLUMN MOUNTING

STEERING COLUMN MOUNTING

J97-6051 INSTL-STEERING COLUMN

HARDWARE FOR COLUMN TO X-CAR BEAM

S34-6003-0830RHLOB	Hex Lock Screw (M8 x 1.25 x 4 30mm), Black	
--------------------	--	--

STEERING SHAFT BEARING TO BULKHEAD

R34-6002-08035RHOK	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	4
--------------------	---	---

3J00-702-CAK STEERING WHEEL

STEERING WHEEL

J97-6037 INSTL-STEERING WHEEL

J91-6011-1050000	Steering Wheel Assembly	1
W20-6023	NUT-FLANGE,STEERING WHEEL	1
S63-6091	Horn Pad Assembly	1

== PUSH CLIP ONTO TOP OF INPUT SHAFT

AFTER FINAL TORQUE OF NUT ==

BN13193	CLIP-EXTERNAL	1
---------	---------------	---

3J10-701-AAM POWER STEERING PUMP

POWER STEERING PUMP

D97-1237-005 INSTL - POWER STRG PUMP

NOTE: USE LOCKTITE 243 W/ POWER

STEERING PUMP HARDWARE

PEV2216-18R101	PUMP-PWR STRG	1
4988280	GASKET-POWER STEERING	1
W34-1163-040	Hex Bolt (M10 x 40mm)	2
W34-1162-010	Washer (10MM)	2

3J10-701-BAR POWER STEERING RESERVOIR

POWER STEERING RESERVOIR

J97-1120-000 RTG-POWER STEERING

P95-7055 RTG-LH FRAME RAIL

J86-1070	Power Steering Reservoir Assembly	1
W34-1160-050	Lock Nut w/ Nylon Insert (M16 x 1.75)	1
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	1
W20-1028-016		

Lock Nut (M16 x 2.00 x 16mm)	1	
W34-1162-016	Washer (16MM)	2
R34-6002-08030RH0M	FASTENER-THREADED,EXT	1
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	1
J11-1217	BRACKET - PS RESERVOIR	1
3754	Heavy-Duty Tie Mount	1

3J10-701-CEG POWER STEERING PIPING

POWER STEERING PIPING

J95-1316-004 RTG-POWER STEERING

J97-6029 P/S PUMP - ISX

J95-1316-004 RTG-POWER STEERING

GEAR FITTINGS

26-02879	45° Connector (3/4" or #8 Hose)	1
26-03339	Connector - Straight (#8 O-Ring X 3/4-16)	1

PUMP FITTINGS AND HOSES

26-02902	Connector-90 Deg (1-1/16" X #12 Barb)	1
26-02085	Connector - 90 Deg (3/4" St X #8 Flare)	1
J50-1007-08-030PT	37° Flare Hose Assembly (#8 x 30")	1

PUMP PRESSURE TO GEAR

J50-6003-08017	Hose - Push On (#8 X 17")	1
----------------	---------------------------	---

GEAR RETURN TO RESERVOIR

J50-1090	HOSE - FORMED PS SUCTION	1
----------	--------------------------	---

RESERVOIR TO PUMP INLET

CLAMPS

16700024	Oetiker Clamp - 21MM	2
933-270-10H	Constant Tension Clamp (27mm)	2

P/S HOSE SUPPORT HARDWARE

DCT11	Cable Tie, Dual	3
A62-6084	Cable Tie Mount	1

3K0P-300-AAD PACCAR FUEL FILTER

PACCAR FUEL FILTER

K37-1010-103100020	Primary Fuel Filter Assembly	1
--------------------	------------------------------	---

3K0P-301-CAC - 26 IN LH BOC FUEL TANKS

- 26 IN LH BOC FUEL TANKS

K1-0C2530A0000001P	26" Fuel Tank Assembly, Polished Aluminum	1
--------------------	---	---

3K0P-301-DAC - 26 IN RH BOC FUEL TANKS

- 26 IN RH BOC FUEL TANKS

K1-0C2530A0000002P	26" Fuel Tank Assembly, Polished Aluminum (60 Gallon)	1
--------------------	---	---

3K00-303-PCP LH BOC FULL WIDTH F/T STEP-POLISHED

LH BOC FULL WIDTH F/T STEP-POLISHED

11-04006-0550P	Fuel Tank Step (550mm x 178mm), Aluminum, Polished	1
11-03942-0550P	Fuel Tank Step (550mm x 121mm), Aluminum, Polished	1
27-00275-005	Hex Bolt (3/8-24 x 1-1/4")	8
27-00791-006	Lock Nut (3/8-24)	8
W34-1162-010	Washer (10MM)	16
R34-6002-10042RH0M	Exterior Threaded Hex Screw (M10 x 1.50 x 42mm)	4
W20-6011-10TDYOZ	Flanged Lock Nut (M10 x 1.50)	4

3K00-303-RAV LH BOC F/TANK STEP SIDEPLATES-POLISHED**LH BOC F/TANK STEP SIDEPLATES-POLISHED****SK13326 INSTL TANK STEP**

11-03679P	Bracket, Fuel Tank Step, Polished	2
28-00237-0560	Windlace (560mm)	2
28-00237-0560DB	WINDLACE-DEBURRED W/BULB	2

3K00-310-CAF 26" ALUM FUEL TANK BRACKETS**26" ALUM FUEL TANK BRACKETS****SK28968 INSTL-TANK STRAPS**

11-04855M000	Bracket, 26" Fuel Tank	4
--------------	------------------------	---

3K00-311-DAX ALUM FUEL TANK STRAPS - 26" TANK**ALUM FUEL TANK STRAPS - 26" TANK****SK28968 INSTL- FUEL TANK HARDWARE**

11-04551-001P	Strap & T-Bolt Assembly, Polished (660mm)	4
11-04517-0580	Strap Liner, Rubber (90mm x 580mm)	4
K65-6000	PIN - FUEL TANK STRAP TO	4
W20-1028-012	Lock Nut (M12 x 1.75)	4
27-01290	Spring Clip	4
W34-1162-016	Washer (16MM)	4
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	4

3K10-300-DBR SPLITTER TEE MOUNTING**SPLITTER TEE MOUNTING****XMBR MTD FUEL SPLITTER TEE****K95-6013 RTG-FUEL HOE SPLITTER TEE****M97-6749 INSTL-DEF/COOLANT RTG, PB**

K20-6018-008	CONNECTOR-FUEL, SPLITTER	1
W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm)	2
W20-1028-012	Lock Nut (M12 x 1.75)	2
W20-1028-012	Lock Nut (M12 x 1.75)	2
W34-1162-012	Flat Washer	4

3K10-302-AGC FUEL TANK GAUGE SENDING UNIT**FUEL TANK GAUGE SENDING UNIT**

PH11-00002 SENDER UNIT TORQUE F/T
 = RTE SENDING UNIT JMPRS TO PRIMARY
 AND SECONDARY FUEL TANKS =
 = RTE SENDING UNIT JMPRS TO PRIMARY
 AND SECONDARY FUEL TANKS =
 = NO GROUND CABLE NEEDED =
 = INSTL SENDING UNIT IN ALL TANKS =

5549-13715-26	Fuel Level Sending Unit Sensor	2
P92-7180-0650	Fuel Sender Jumper Harness (650mm)	2
W01-6037-004	Threaded Rolling Screw (#10-24 x 1/2")	10

3K10-302-EAD ADDITIONAL FUEL TANK FITTINGS

ADDITIONAL FUEL TANK FITTINGS

26-01984-004	Plug, Square Head (1/4")	2
--------------	--------------------------	---

3K10-310-AAG SUPPLY - REAR TO FILTER

SUPPLY - REAR TO FILTER

NOTE: FILTER @ 1040 FOF

V50-1006-110092	45° Flare Fuel Hose Assembly (#10 x 92")	1
-----------------	---	---

3K10-310-BAC SUPPLY - FILTER TO ENGINE

SUPPLY - FILTER TO ENGINE

K97-6056-000 INSTL FUEL FILTER

V50-1006-110016	45° Flare Fuel Hose Assembly (#10 x 16")	1
-----------------	---	---

USE SADDLE W/ TYWRAPS TO
SEPARATE FUEL LINES

DSWS4	Dual Swivel Saddle Spacer	1
-------	---------------------------	---

3K10-310-CCU RETURN - ENGINE TO FILTER

RETURN - ENGINE TO FILTER

K97-6135-000 INSTL-PACCAR FILTER LINES

V50-1005-108018	90° Fuel Hose Assembly (#8 x 18")	1
-----------------	--------------------------------------	---

3K10-310-GAS RETURN - FILTER TO REAR

RETURN - FILTER TO REAR

V50-1006-108092	45° Flare Fuel Hose Assembly (#8 x 92")	1
-----------------	--	---

3K10-700-EAD FITTINGS - PACCAR FUEL FILTER

FITTINGS - PACCAR FUEL FILTER

D97-6268-27310 INSTL FUEL FILTER

D2111-4227	Straight Fitting (#10 SAE Flare x #10 SAE MBO)	1
------------	---	---

D2127-3633	Connector-45 Deg (#10 Straight X #10 Flare)	1
------------	--	---

3K10-700-FAC MOUNTING HARDWARE - PACCAR FUEL FILTER

MOUNTING HARDWARE - PACCAR FUEL FILTER

K97-6056-000 INSTL-PACCAR FILTER

K97-6056-000 INSTL-PACCAR FILTER

FUEL FILTER MOUNTING HARDWARE

W34-1163-050	Hex Bolt (M10 x 1.50 x 50mm)	2
M10CNPTC1M4	NUT-M10X1.5	2
W34-1162-010	Washer (10MM)	2

3L0P-700-AAE 389-123 ALUM HOOD PRE-PAINT ASSY

389-123 ALUM HOOD PRE-PAINT ASSY

L29-6110-1000	Hood Assembly	1
---------------	---------------	---

***** BASE PART INFORMATION *****

BASE PART NUMBER - L29-6110

BASE PART FORMAT - ABCD

BASE PART I.D. - PHD72

3L00-703-AAF CROWN AND GRILLE

CROWN AND GRILLE

BUGSCREEN BEHIND GRILLE

L97-6072 INSTL HOOD TRIM

L29-6082-1210	Crown & Grille Assembly	1
<i>HARDWARE - CROWN TO TOP SKIN</i>		
27-00413-005P	Huck Pin, Polished (5/16")	32
<i>HARDWARE - CROWN TO SIDE SKINS</i>		
27-00413-006P	Huck Pin (3/16"), Polished	16
<i>HARDWARE - CROWN TO CORNER CASTING</i>		
27-00413-010P	Huck Pin (3/16"), Polished	10
MGCW-R6U	Huck Collar (3/16"), Wide	62
<i>HARDWARE - CROWN TO HOOD CROSSMEMBER</i>		
27-00413-009P	Huck Pin (3/16"), Polished	6

3L00-703-BAC HOOD TRIM

HOOD TRIM

L97-6072 INSTL HOOD TRIM

SK09775 LOCATION PACCAR NAMEPLATE

20-19280	Peterbilt Logo Nameplate (8")	2
07-01440	Nameplate Nut (3/16")	4
22-01050	Nameplate, PACCAR	1
L85-6035	SUPPORT-FENDER REAR	1
<i>ALUM CAST LH</i>		
L85-6035R	SUPPORT-FENDER REAR	1
<i>ALUM CAST RH</i>		
L85-6036	Support - Fender, Front LH	1
L85-6036R	Support - Fender, Front RH	1
<i>HARDWARE FOR FENDER SUPPORTS</i>		
W34-6019-025	SEMS Screw (6.3 x 1.8) (25mm)	18
<i>REAR FNDR SUPT THRU LOWER HOOD GUIDE</i>		
W34-6017-025	Flanged Bolt w/ Dog Point (M6 x 1.00 x 25mm)	4
K363-340-3-250	Flat Washer (1/4")	4
<i>FRONT FENDER SUPPORT TO CORNER CASTING</i>		
27-00944-080	Hex Bolt (M8 x 1.25 x 80mm)	2
27-00944-040	Hex Bolt (M8 x 1.25 x 40mm)	2
W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	4
27-00428-005	Flat Washer (5/16")	4

L46-6180	GUARD-SPLASH, HOOD, 389	2
<i>HARDWARE FOR SPLASH GUARD</i>		
27-01212-002	Blind Rivet (3/16")	12
27-00531	Flat Washer (9/32" ID X 1-1/4" OD)	12

3L00-703-CAC HOOD MOUNTING

HOOD MOUNTING

L95-6010 HOOD ADJUSTMENT

L97-6078 INSTL RESTRAINT CABLE/TILT

L97-6079 INSTL PASSIVE RESTRAINT

L97-6079 INSTL PASSIVE RESTRAINT

L97-6076 INSTL FENDER SKIRT RECEPTACLE

L97-6072 INSTL HOOD TRIM

SK28717 INSTL HOOD SUPPORT

SK28717 INSTL HOOD SUPPORT

SK24890 HOOD HOLDDOWN

SK24890 HOOD HOLDDOWN

SK24890 HOOD HOLDDOWN

L97-6091 INSTL LABEL HOOD OPEN/CLOSE

HOOD ADJUST- USE SHIM 13-04195 AS REQD

HOOD PIVOT HARDWARE

L34-6021	Hood Pivot Bolt	2
27-01238	Hex Nut, Flanged, Slotted, (5/8-11)	2
27-00411-016	Cotter Pin, (1/8" X 1")	2
27-00790-012	Flat Washer (3/4")	2
L67-6013	RECEPTACLE-HOOD GUIDE STL LH	1
L67-6013R	RECEPTACLE-HOOD GUIDE STL RH	1
L11-6133	Bracket, Hood Guide, Upper	2
L11-6167	Bracket - Hood Guide, Lower LH	1
L11-6167R	Bracket - Hood Guide, Lower RH	1

HOOD GUIDE BRKT HARDWARE

W34-6017-025	Flanged Bolt w/ Dog Point (M6 x 1.00 x 25mm)	20
13-04470	Bracket	2
13-04339	Hood Latch, Rubber	2
13-04393	Catch Bracket	2

HARDWARE FOR MTG HOOD LATCH

27-00268-008	Hex Bolt (1/4-20 x 2")	2
27-00541	Hex Nut (1/4-20)	2
27-01502-0762	Threaded Insert (1/4-20 x 30.61mm)	2
27-00268-005	Hex Bolt (1/4-20 x 1-1/4")	2
27-00562-004	Spring Lock Washer (1/4")	2

HARDWARE FOR MTG HOOD HOLD DOWN

27-01426-008	Pan Head Thread Rolling Screw (#10-24 x 1")	4
--------------	---	---

27-00335	Elastic Stop Nut	4
27-00428-003	Flat Washer (3/16")	4
L81-6008	Hood Tilt Assist Spring	2
L92-6017-1065	Hood Stop Cable, (1065mm)	2
<i>HARDWARE FOR SPRING AND CABLE</i>		
BN13193	CLIP-EXTERNAL	2
BN13193	CLIP-EXTERNAL	2
5304-62	Retaining Ring, Large	2
5304-62	Retaining Ring, Large	2
27-00428-010	Flat Washer (5/8")	2
27-00428-010	Flat Washer (5/8")	2
L56-6014	Latch - Hood, Hold Open	1
L55-6003	Lever - Hold Open Release	1
L22-6144	Hood Restraint Plate	1
<i>HARDWARE FOR PASSIVE RESTRAINT</i>		
L34-6008	Shoulder Screw (3/8" x 1"), Stainless Steel	1
L65-6001	Clevis Pin	1
L80-6024	Spacer, Nylon	2
822642	Clip - 7/16	1
27-01371	Flat Washer, Nylon (1/2")	2
27-00411-016	Cotter Pin, (1/8" X 1")	1
13-04709L	Upper Hood Support, LH	1
13-04709R	Upper Hood Support, RH	1
13-04711	Upper Hood Support Bumper	2
<i>HARDWARE FOR UPPER SUPPORT</i>		
W20-6008-004	Wide Flange Hex Nut, (1/4"-20)	12
L53-6005-001	Caution Label, Hood Close/Open, English	1
<i>COWL SEAL</i>		
L42-6006-3085	SEAL-COWL	1
<u>3L00-703-DAC PETERBILT FRONT WHEEL MUDFLAPS</u>		
<i>PETERBILT FRONT WHEEL MUDFLAPS</i>		
<i>L97-6072 INSTL HOOD TRIM</i>		
L46-6031	GUARD-FENDER SPLASH RBR	2
L76-6000	MUDFLAP-HOOD 388/389 W/PB LOGO	2
<u>3L00-703-FAC LH FENDER SKIRT</u>		
<i>LH FENDER SKIRT</i>		
<i>L97-6076 INST FENDER SKIRT</i>		
L33-6012	LH Fender Skirt Assembly	1
R34-6002-08125RH0M	Exterior Threaded Hex Screw (M8 x 1.25 x 125mm)	1
W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25)	1
R34-6002-08030RHLZ	FASTENER-THREADED,EXT	1
<u>3L00-703-GAC RH FENDER SKIRT</u>		
<i>RH FENDER SKIRT</i>		
<i>L97-6076 INST FENDER SKIRT</i>		
L33-6012R	RH Fender Skirt Assembly	1
R34-6002-08125RH0M		

Exterior Threaded Hex Screw 1 (M8 x 1.25 x 125mm)	
W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25) 1
27-00428-005	Flat Washer (5/16") 2
27-00944-030	Hex Bolt (M8 x 1.25 x 30mm) 1
27-00562-005	Spring Washer (5/16") 1

3MOP-302-AAH DEF COOLANT BUNDLE

DEF COOLANT BUNDLE

M50-6072-0611B1800	HOSE-DEF BUNDLE ASSY, 1.9 1
--------------------	-----------------------------

3M00-700-EAF FIREWALL HEAT SHIELD

FIREWALL HEAT SHIELD

M97-6125 INSTL FIREWALL HEAT SHIELD

R72-6036	INSULATION-SHLD, FIREWALL 1
----------	-----------------------------

3M1P-300-AAD RH EXHAUST STACK ASSEMBLY

RH EXHAUST STACK ASSEMBLY

M66-6842-1M7100	RH 45° Cut Standpipe Stack Assembly (36") 1
-----------------	--

3M1P-300-BAD LH EXHAUST STACK ASSEMBLY

LH EXHAUST STACK ASSEMBLY

M66-6842-1L7100	LH 45° Cut Standpipe Stack Assembly (36") 1
-----------------	--

3M10-303-ABT DIESEL EXHAUST FLUID

DIESEL EXHAUST FLUID

M99-6000	FLUID-DIESEL EXHAUST (DEF) 5
M99-6000BULK	DEF 5

3M10-303-CCB DEF ROUTING SUPPORT

DEF ROUTING SUPPORT

M97-6749 INSTL-DEF/COOLANT RTG PB 1.9M

M97-6749 INSTL-DEF/COOLANT RTG PB 1.9M

M95-6134 RTG-FUEL TEE HOSES

M97-6650 RTG-DEF LINES CROSSING

P97-6759 INSTL-AFTERTREATMENT HARNESS

W11-6061-11321	BRACKET - HOSE SPRT, ASSY 2
W20-1028-012	Lock Nut (M12 x 1.75) 4
W20-1028-012	Lock Nut (M12 x 1.75) 4
W34-1162-012	Flat Washer 8
W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm) 4

K20-6018-014	CONNECTOR-FUEL, SPLITTER 1
--------------	----------------------------

3M10-305-FCP DPF/SCR - CUMMINS ENGINE

DPF/SCR - CUMMINS ENGINE

M93-6030-000 ASSY-EXH CANISTER PACCAR

A063G421	Exhaust Canister Assembly 1
----------	-----------------------------

3M10-700-ANK DPF/SCR - RH UNDER CAB

DPF/SCR - RH UNDER CAB

M93-6030-000 ASSY-EXHAUST CANISTER

M96-6051-000 DRLG-DPF/SCR RHUC

M97-6470 INSTL-DPF/SCR RHUC BOX

M97-6574 INSTL-MASKING DPF/SCR RHUC

M10-6123-012411102	DPF/SCR Box Assembly	1
<i>HARDWARE</i>		
R34-6002-12100RF0M	Exterior Threaded Hex Screw 4 (M12 x 1.75 x 100mm)	

3M10-700-DAC DPF/SCR - RH U/CAB - FRAME BRACKETS

DPF/SCR - RH U/CAB - FRAME BRACKETS

M97-6470 INSTL-DPF/SCR RHUC BOX

M96-6051-000 DRLG-DPF/SCR RHUC

FRONT FRAME BRACKET

M11-8383M00	Bracket-Exhaust	1
-------------	-----------------	---

REAR FRAME BRACKET

M11-8384M00	Bracket-Exhaust	1
-------------	-----------------	---

3M10-703-EAY DEF COOLANT, INJECTOR SPLY AND RETURN

DEF COOLANT, INJECTOR SPLY AND RETURN

933-160-10G	Clamp, Constant Torque	1
-------------	------------------------	---

3M10-704-AHP TURBO OUTLET PIPING

TURBO OUTLET PIPING

M97-6757-00000 INSTL-FPP ASSY, RHUC

M97-6758-00000 INSTL-FPP ASSY, UNFR

M95-6039 RTG-ISX NOX SENSOR HARNESS

M95-6039 RTG-ISX NOX SENSOR HARNESS

M66-2920	PIPE-EXHAUST	1
----------	--------------	---

M66-9393-0320	PIPE-BELLOWS, 3.5 NTSD	1
---------------	------------------------	---

M66-6729-001	PIPE-	1
--------------	-------	---

EXHAUST,INTERMEDIATE

90-0012	V-Band Clamp (4")	3
---------	-------------------	---

Q312526	Circular Gasket (4")	2
---------	----------------------	---

3M10-704-BDN DPF INLET PIPING

DPF INLET PIPING

M97-6450 INSTL-FRONT PARTIAL PIPE

M97-6450 INSTL-FRONT PARTIAL PIPE

M66-8249-001	PIPE-EXHAUST	1
--------------	--------------	---

LP34216	V-Clamp (5")	1
---------	--------------	---

A029E744	Spherical Gasket (5")	1
----------	-----------------------	---

90-0013	V-Band Clamp (5")	1
---------	-------------------	---

Q312516	Circular Gasket (5")	1
---------	----------------------	---

3M10-705-AEE SUPPORT-FRONT PARTIAL PIPING

SUPPORT-FRONT PARTIAL PIPING

M97-6450 INSTL-FRONT PARTIAL PIPE

M11-7694	BRACKET-EXHAUST,PIPE	1
----------	----------------------	---

R34-6002-10042RH0M	Exterior Threaded Hex Screw 1 (M10 x 1.50 x 42mm)	1
--------------------	--	---

LP55563	CLAMP-5 INCH BAND	1
---------	-------------------	---

3M10-705-BAQ SUPPORT-REAR PARTIAL PIPING

SUPPORT-REAR PARTIAL PIPING

M97-6559 INSTL-EXHAUST DSOC

M96-6010 DRLG-2010 DUAL EXHAUST

BRACKETS

M11-7898	BRACKET-EXHAUST	1
----------	-----------------	---

M11-6479	BRACKET-LH INSIDE DUAL	1
----------	------------------------	---

*USE BOLT FOR UPPER MIDDLE HOLE
OF LH BOC CROSSMEMBER
SUPPORT HARDWARE (3/8)*

W34-1163-060	BOLT-FINISHED HEX M10	2
W34-1163-050	Hex Bolt (M10 x 1.50 x 50mm)	2
W34-1162-010	Washer (10MM)	8
27-00562-006	Spring Lock Washer (3/8")	4
27-02040-010	Hex Nut (M10 x 1.50)	4
M11-6360-208	PIPE-EXHAUST, CLAMP PLATE	1
14-00924	Clamp, Exhaust Pipe, (5- 1/4")	1

3M10-707-BCT REAR PARTIAL PIPING - DUAL EXHAUST

REAR PARTIAL PIPING - DUAL EXHAUST

M97-6559 INSTL-REAR PARTIAL DSOC LEGAC

M97-6811 INSTL-EXHAUST, DRAIN COVER

A50BFE	Accuseal Exhaust Clamp	1
A50BFE	Accuseal Exhaust Clamp	2
M66-9046-002	PIPE-EXHAUST	1
M74-6005-004	Shield-Pipe Drain	1
R34-6002-10042RH0M	Exterior Threaded Hex Screw (M10 x 1.50 x 42mm)	1
M66-8699-002	PIPE-EXHAUST DSOC LH	1

3M10-709-ACD DEF TANK & MOUNTING

DEF TANK & MOUNTING

M97-6803 INSTL-DEF TANK

M86-6300-225105	DEF Tank Assembly, Small	1
M11-8743-004	BRACKET - FRAME	1
M11-8744-004	BRACKET-FRAME	1
R34-6002-12030RHLM	FASTENER-THREADED	2
W20-1028-012	Lock Nut (M12 x 1.75)	2
W34-1162-012	Flat Washer	2

3M10-709-DAC DEF COOLANT FILTER

DEF COOLANT FILTER

M97-6805-000 INSTL-DEF COOLANT FILTER

M96-6228-000 DRLG-DEF COOLANT FILTER

M37-6278-002	DEF Coolant Filter Assembly	1
933-200-10H	Constant Tension Clamp (20mm)	2

3M10-715-AAD CAB MOUNTED MUFFLER BRACKETS

CAB MOUNTED MUFFLER BRACKETS

DUAL CAB MTD EXHAUST

M97-6147 INSTL STACK, CAB MTD

SK25867 INSTL BRKT ON UPPER RH

SIDE OF CAB PER SK

BRACKETS

M11-6327	PB8 BRACK-SOC EXHAUST DA	1
M11-6327R	B32S BRACKET-SOC EXHAUST,	1
14-13441	Pad, Exhaust Bracket	2

HARDWARE FOR MTG BRKT TO CAB

27-00273-004	Hex Bolt (3/8-16 x 1")	8
27-00304-006	Lock Washer (3/8")	8
W34-1162-010	Washer (10MM)	8
27-01395-7923	INSERT-BLIND, 3/8 IN.-16	8

SLIDER/STACK MOUNTING HARDWARE

K041-809-40	Hex Bolt (M8 x 1.25 x 40mm)	4
27-00790-005	Flat Washer (5/16")	4

3N0P-700-CAE DEEP TAPERED - ALUM S/S CLAD**DEEP TAPERED - ALUM S/S CLAD**

N71-6041-15001	Deep Taper Bumper Assembly, Stainless Steel Clad	1
----------------	--	---

3N00-701-CAC BUMPER MTG HARDWARE - DEEP TAPER**BUMPER MTG HARDWARE - DEEP TAPER****N97-6022 INSTL BUMPER SFFA****N97-6025 INSTL BUMPER BRKT**

W34-6013-045P	Hex Bolt, Locking (M16 X 2.00 X 45mm), Stainless Steel, Polished	6
W34-6012	Nylon Washer	6
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2
W34-1162-016	Washer (16MM)	2
K363-340-2-625POL	Flat Washer (5/8"), Stainless Steel, Polished	6

BUMPER BRACES & MTG HARDWARE

N11-6086	Bracket, Bumper/Fog Light, LH	1
N11-6086R	Bracket, Bumper/Fog Light, RH	1
W20-1028-012	Lock Nut (M12 x 1.75)	2
W20-1028-012	Lock Nut (M12 x 1.75)	2
W34-1162-012	Flat Washer	4
W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm)	2

3N10-701-AAG NON-AERO ALUM BATTERY BOX *POLISHED***NON-AERO ALUM BATTERY BOX *POLISHED*****REF BATT BOX LOC LH U/CAB****REF BATT BOX LOC LH U/CAB****SK27342 INSTL BATT BOX BUSHING/PLUG****SK17275 INSTL BATTERY BOX****P93-6017 ASSY MEGA FUSE****INSTALL WINDLACE ON UPPER EDGE OF****BATTERY BOX AND LOWER EDGE OF COVER**

N10-6135-012P	Battery Box Assembly w/ Mega Fuse Bracket, Polished	1
15-06179M003P	Battery Box Cover Assembly, Polished	1

15-06613L	Angle Mounting, Battery Box, 1 LH, Steel	
15-06613R	Angle Mounting, Battery Box, 1 RH, Steel	
28-00013-028DB	Edge Guard, Black (1")	1
28-00013-028DB	Edge Guard, Black (1")	1

3N10-701-HAD BATTERY BOX PLUG*BATTERY BOX PLUG**SK27342 INSTL BATT BOX BUSHING/PL**N97-6213 INSTL-BRACE, BATTERY BOX*

2473 Plug (4") 1

N42-6001 Grommet w/Plastic Nut Jam 1

*HRDWR FOR BATT CABLES AT ENTRY TO BOX**HRDWR FOR BATT CABLES AT ENTRY TO BOX*

K11-6149 Standoff Bracket Assembly 1

WSR01MHSUVH4 Tie Strap, Wide 1

3N10-701-LAJ BATTERY HOLD-DOWNS*BATTERY HOLD-DOWNS**SK17274 INSTAL BATTERIES*

N03-6001 Battery Hold Down Hook 3

15-05609 Hold Down - Battery (3"
Wide) 1

27-00790-005 Flat Washer (5/16") 3

27-00791-005 Lock Nut (5/16-24) 3

680071BLK CAP-STUD BLACK 3

3N10-701-QAC CONV BATTERY BOX REINFORCEMENT*CONV BATTERY BOX REINFORCEMENT**N97-6213 INSTL-BRACE, BATTERY BOX**N95-6005 RTG-BATTERY CBLs W/ GUSSET**N95-6005 RTG-BATTERY CBLs W/ GUSSET**BATTERY BOX GUSSET*

N85-6250 BRACE- BATTERY BOX 2

28-00013-005 Edge Guard, Black (5") 2

28-00013-005DB WINDLACE-BLACK 2
DEBURRED*MOUNTING HARDWARE*W34-1159-040 Hex Bolt (M12 x 1.75 x
40mm) 2

W34-1162-012 Flat Washer 4

W20-1028-012 Lock Nut (M12 x 1.75) 2

3POP-700-AAD MAIN CAB HARNESS*MAIN CAB HARNESS**S96-6550 SCHM-MAIN CAB, 1.9M**S95-6088 RTG-MAIN CAB HARN, 1.9M**P97-6871 INSTL - DD ETHERNET CABLE*

S92V211543561216DB HARNESS-MAIN CAB, 1.9M 1

Y84-6000-003 Tie Strap 2

*== USE TIE-STRAPS TO TIE DD ETHERNET**CABLE TO MAIN CAB HARNESS***3POP-700-BAD CAB ROOF HARNESS**

CAB ROOF HARNESS

S96-6475 SCHM-CAB ROOF, ULTRA, 1.9M

S95-6090 RTG-CAB ROOF, ULTRA, 1.9M

S92-6600-121731 HARNESS-CAB ROOF 1

***** BASE PART INFORMATION *****

BASE PART NUMBER: S92-6600

BASE PART FORMAT: -ABCDEF

BASE PART ID: PCH74

3POP-702-AAG MAIN CHASSIS HARNESS**MAIN CHASSIS HARNESS**

A96-6606 SCHM-CHASSIS, 1.9M VECU

A95-6038 RTG-CHASSIS HARN, 1.9M

P95-7007 RTG-CHASSIS HARNESS, 1.9M

A92-61661015652023 HARNESS - CHASSIS 1.9M 1
VE**3POP-702-CAD MUX SOLENOID HARNESS****MUX SOLENOID HARNESS**

A96-6429 SCHM-MUX SOLENOID BANK 1.9M

A95-6041-000 RTG-MSB HARN, 1.9M

A92-6075-107070000 HARNESS-MUX SOLENOID 1
BANK**3POP-702-DAC REAR CHASSIS HARNESS****REAR CHASSIS HARNESS**

A96-6335 SCHM-REAR CHASSIS

A95-6068 RTG-REAR CHASSIS, 1.9M

A92-6017-31B100000 HARNESS- REAR CHASSIS 1

3P00-700-PAC REAR AXLE TEMP EXTENSION HARNESS**REAR AXLE TEMP EXTENSION HARNESS**

P92-5636-0001 HARN-REAR AXLE SENSOR 1

3P00-700-QAC AXLE DIFF LOCK HARNESS**AXLE DIFF LOCK HARNESS**

P92-5636-1000 HARN-REAR AXLE SENSOR 1

3P00-700-SAC ABS CHASSIS (STBLTY CNTL) W/O HUF**ABS CHASSIS (STBLTY CNTL) W/O HUF**

P95-6475 RTG - ABS CHASSIS HARNESS

P95-6475 RTG - ABS CHASSIS HARNESS

P95-6475 RTG - ABS CHASSIS HARNESS

P95-6475 RTG - ABS CHASSIS HARNESS

P97-6876 INSTL ABS HARN COVERING

A92-6089-210121400 HARNESS-BENDIX ABS 1
CHASSIV46-1003-1751524 SHIELD-ABRASION, NYLON 1
FA**3P00-700-WAC MAIN TRANS TEMP SENSOR JUMPER****MAIN TRANS TEMP SENSOR JUMPER**

E95-6096 RTG-HARN XMSN TEMP SENSOR

= RTE HARNESS ALONG TRANSMISSION.

MATE J531 W/ TRANS TEMP SENSOR

AND MATE CONN P531 TO CONN J096

PRESENT IN CHASSIS HARNESS NEAR

NEUTRAL START SWITCH =

P92-6594-1000 Jumper-Axle Temp 1

3P00-702-EAK BATTERY CABLES - 2 CABLE SYSTEM**BATTERY CABLES - 2 CABLE SYSTEM**

SK18003-001 THREE BATTERY LAYOUT

SK18003-001 THREE BATTERY LAYOUT

PH16-00075 CABLE ROUTING - 3 BATTERY

PH16-00075 CABLE ROUTING - 3 BATTERY

N92-6006-4ABSL0210 CABLE-BATTERY,(POS) ASSY 1

BATTERY TO SOLENOID

N92-6007-4AABS0190 CABLE-BATTERY,(NEG) ASSY 1

BATTERY TO STARTER

3P00-703-AAJ HEADLIGHTS**HEADLIGHTS**

P97-6172 INSTL HEADLAMP

P95-6201-001 RTNG HEADLT HARN 389

P95-6201-002 RTNG HEADLT HARN 389

P54-6166-110 Headlamp Pod Assembly, LH 1

P54-6166-110R Headlamp Pod Assembly, RH 1

HEADLAMP INSTL HARDWARE

27-01008-008 Lock Nut (M8 x 1.15-6H) 12

Cadmium Plate

22-01151-010 Cushioned Clamp (5/8") 2

3P00-703-CAP CAB INTERIOR LIGHTING**CAB INTERIOR LIGHTING**

P95-6061 INSTL CAB INTER LIGHTING

P54-6011-2212 Over Door Lamp Assembly w/2

Clear Lens, Gray

P54-6012-281 LAMP-DOME 1

K301-354 Door Jamb Switch 2

3P00-705-DAF REMOTE DIAGNOSTICS**REMOTE DIAGNOSTICS****EXTERIOR ANTENNA**

R97-6281-100 INSTL-REMOTE DIAGNOSTICS

R97-6281-100 INSTL-REMOTE DIAGNOSTICS

P97-6771 INSTL-DRVR RESOURCE LBL

Q94-6009 CHART-SOFTWARE, REMOTE DIA

== ANTENNA INSTL ON EXTERIOR ROOF SURF

DRILL CAB ROOF FOR ANTENNA ==

= ANTENNA INSTL ON EXTERIOR ROOF SURF=

= APPLY DECAL TO DRIVER SIDE WINDOW =

== HARN INSTL - RTE HARN LH TO DRIVER

SIDE A-PILLAR ==

= INSTL ADAPTER HARNESS BETWEEN

ROOF HARNESS AND TIG =

PP607340 TIG Assembly 1

P11-6256 BRACKET-PMG MOUNT 1

10037180 VECLRO-STRAP 1

27-01450-012 Screw, Self Tapping, Pan 3

Head (#10-12 x 3/4")

PP407083-1500 Antenna - GPS/LTE 1

9771	Adhesive - Anchors, Tie Strap	1
P53-6158	LABEL - DRIVER RESOURCES	1
PP207280	TIG Adapter Harness witho	1

3P00-710-AAX RADIO HEAD UNIT

RADIO HEAD UNIT

CONCERT CLASS AUDIO SYS W/BT, W/O CD

SATELLITE AUDIO - SIRIUS-XM

P97-6173 INSTL-SDARS ANTENNA

P97-6173 INSTL-SDARS ANTENNA

P97-6494 INSTL-BLUETOOTH MIC HARNESS

= GPS CONNECT NOT USED IN THIS APPL =

PP107180-7301131200	RADIO-APTIV, DEA700	1
PP207236	ADAPTER-FAKRA TO MOTOROLA	1
S62-6095	Bluetooth Assembly w/ Microphone	1
Q28-6020-001	ANTENNA-COMBO, SDARS/GPS	1
28040440	HARNESS SDARS 6FT EXT	1
PP603988	PB8 CONTROL-IR REMOTE	1
PPC00452	ANTENNA-6 CABLE	1

3P00-710-BBX CAB SPEAKERS

CAB SPEAKERS

MID LEVEL OR F/O CAB SPEAKERS

PP307007	Speaker (4"x6")	2
S45-6016-1221	Speaker Grille (4" x 6"), Gray	2
S22-6027	Speaker Mounting Plate (4" x 2 6")	
PP302534	6" Speaker (80HM)	2
R34-6002-05027RF0Z	Exterior Threaded Hex Screw 8 (M5 x 0.80 x 27mm)	8

3P00-720-AAC CAB POWER DISTRIBUTION CENTER

CAB POWER DISTRIBUTION CENTER

P97-6775 INSTL-CONV HEAVY DUTY MPDC

P96-6087 SCHEM-LC, 1.9M VECU

S97-6404 INSTL-MPDC LABEL, 1.9M

P27-6230-0301	Main Loadcenter	1
P53-6169-011	LABEL - FUSE CAB MPDC	1
W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25)	4
P11-6389	Bracket-Vert,F/W Harnes	1
12-0375C2	Clip - Antenna Routing	1
S46-6015	Shield - Protective, PDC	1
Q27-1038	Pressure Switch, Normally Close	1

P27-1023-05 FUSE-MINI 5 AMP

*SHOP NOTE: PLUG P27-1023-05 IN THE
FOLLOWING POS ON DASH SIDE CAB PDC:*

POS-J11-"J11 STOP LAMP"

POS-G10-"G10 RMT DIAGNOSTICS"

POS-U13-"U13 MASTER SW MODULE"

POS-Q8-"Q8 VECU IGN POWER"

POS-V6-"V6 VECU/SMARTWHEEL ACC PWR"
POS-L13-"L13 LINE HEAT 3 (SUCTION)"
POS-M7-"M7 ENG ECU WAKE-UP"
P27-1023-10 FUSE-MINI, 10 AMP
SHOP NOTE: PLUG P27-1023-10 IN
THE FOLLOWING POS ON DASH SIDE CAB PDC
POS-L11-"L11 HORN"
POS-C8-"C8 DISPLAY CLUSTER BATT"
POS-C9-"C9 DIAG POWER"
POS-D10-"D10 MISC LOW CURRENT"
POS-J14-"J14 GAUGE CLUSTER BATT"
POS-G9-"G9 VECU BATT PWR 1"
POS-E8-"E8 VECU BATT PWR 2"
POS-V7-"V7 RP1226 2 BATT"
POS-G8-"G8 RP1226 1 BATT"
POS-J10-"J10 MUX SOL BNK 1"
POS-P7-"P7 RP1226 1 IGN"
POS-Q6-"Q6 SUSP/CHASSIS"
POS-N8-"N8 SPLICE FEED IGN"
POS-J7-"J7 QCOM/LDWS/RMT DIAG"
POS-J5-"J5 SCM/OCM/MSB IGN"
POS-P14-"P14 PR1226 2 IGN"
POS-A8-"A8 PWR POINT/CIG LIGHT"
POS-E7-"E7 MIRROR PWR MODULE"
POS-W6-"W6 RADIO ACC PWR"
POS-Q7-"Q7 CAB ABS IGN"
P27-1023-15 FUSE- MINI, 15 AMP
SHOP NOTE: PLUG P27-1023-15 IN THE
FOLLOWING POS ON DASH SIDE CAB PDC
POS-V8-"V8 RADIO PWR"
POS-G12-"G12 DOOR LOCK"
POS-M5-"M5 AIR DRYER"
POS-G3-"G3 LH MIRROR"
POS-G4-"G4 RH MIRROR"
POS-E9-"E9 AC CLUTCH"
POS-L3-"L3 DEF PUMP POWER"
POS-L10-"L10 LINE HEAT 2 (BACKFLOW)"
POS-M12-"M12 LINE HEAT 1 (PRESSURE)"
POS-B3-"B3 AFT POWER"
P27-1023-20 FUSE-MINI, 20 AMP
SHOP NOTE: PLUG P27-1023-20 IN THE
FOLLOWING POS ON DASH SIDE CAB PDC
POS-G13-"G13 CAB MARKER LAMP"
POS-N13-"N13 SCM 1"
POS-N14-"N14 SCM 2"
POS-D7-"D7 SCM 7"
POS-B9-"B9 CAB DOME LAMPS"
P27-1023-25 FUSE-MINI, 25 AMP
SHOP NOTE: PLUG P27-1023-25 IN THE
FOLLOWING POS ON DASH SIDE CAB PDC
POS-M15-"M15 SCM 3"

POS-F17-"F17 SCM 4"
 POS-F18-"F18 SCM 5"
 POS-M11-"M11 SCM 6"
 P27-1023-30 FUSE-MINI 30 AMP
 SHOP NOTE: PLUG P27-1023-30 IN THE
 FOLLOWING POS ON DASH SIDE CAB PDC
 POS-F15-"F15 CAB ABS BATT"
 POS-W8-"W8 WIPER PARK"
 POS-K1-"K1 ENG ECU CONST PWR"
 16-09185 DIOD
 SHOP NOTE: PLUG 16-09185 IN THE
 FOLLOWING POS ON DASH SIDE CAB PDC
 POS-R8-"R8 DIODE"
 POS-R7-"R7 DIODE"

3P00-720-BAC AUX POWER DISTRIBUTION CENTER

AUX POWER DISTRIBUTION CENTER

P96-6088 SCHM-AUX LC
 P97-6776 INSTL-AUXILIARY, LC
 P97-6776 INSTL-AUXILIARY, LC
 P27-6232-020 LOADCENTER- 1
 AUXILIARY,1.9M
 P53-6163-011 LABEL-CAB AUX PDC,1.9M 1
 S11-6420 Bracket - Auxiliary PDC 1
 M36-0630-07 Christmas Tree Fastener 4
 R42-6031 Grommet - Split 1
 P27-6090-070 FUSE-MIDI 1
 == INSTL MIDI FUSE ON MTA FUSE MODULE,
 FUSE MODULE IS PART OF CHARGE/START
 HARNESS ==
 W20-6011-05TDY0Z Flanged Lock Nut (M5 x 0.80) 2

3P00-722-AAC TRAILER FUSES AND RELAYS

TRAILER FUSES AND RELAYS

P27-1150 Relay, Micro 280 4
 SHOP NOTE: PLUG P27-1150 IN THE
 FOLLOWING POS ON DASH SIDE CAB PDC:
 POS-V9-"CK V9 TRAILER STOP RELAY"
 POS-R15-"CK R15 MARKER LP TRLR RELAY"
 POS-M19-"CK M19 TRAILER ABS RELAY"
 POS-R12-"CK R12 TRAILER PARK LP RELAY"
 P27-1023-10 Mini Fuse (10 AMP) 1
 SHOP NOTE: PLUG P27-1023-10 IN THE
 FOLLOWING POS DASH SIDE CAB PDC:
 POS-Q12-"Q12 PARK LP-TRLR 10A"
 P27-1023-30 Mini Fuse (30 AMP) 2
 SHOP NOTE: PLUG P27-1023-30 IN THE
 FOLLOWING POS ON DASH SIDE CAB PDC:
 POS-W11-"W11 TRLR STOP 30A"
 POS-S17-"S17 TRLR MARKER LP 30A"
 P27-1023-25 Mini Fuse, Clear (25 AMP) 1
 SHOP NOTE: PLUG P27-1023-25 IN THE
 FOLLOWING POS ON DASH SIDE CAB PDC:

POS-N10-"N10 TRLR ABS 25A"

3P00-722-FAG RKE/ADDL 12V OUTLET FUSES

RKE/ADDL 12V OUTLET FUSES

P27-1023-05 Mini Fuse (5 AMP) 1

SHOP NOTE: PLUG P27-1023-05 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-D9-"D9 CLOCK"

P27-1023-20 Mini Fuse, Yellow (20 AMP) 1

SHOP NOTE: PLUG P27-1023-20 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-C10-"C10 ADDL POWER POINT"

PD BOX IMPACT! VERIFY ID & FORMAT

3P00-722-JAJ LOAD/BEACON LIGHT FUSES

LOAD/BEACON LIGHT FUSES

P27-1253 Relay, Micro 2

SHOP NOTE: PLUG P27-1253 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-C6-"CK C6 FLOOD LP2 RELAY"

POS-D6-"CK D6 FLOOD LP1 RELAY"

P27-1023-15 Mini Fuse, Blue (15 AMP) 2

SHOP NOTE: PLUG P27-1023-15 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-B5-"B5 FLOOD LP2 15A"

POS-C7-"C7 FLOOD LP1 15A"

3P00-722-KAC PTO/DUAL STATION FUSES

PTO/DUAL STATION FUSES

P27-1023-10 Mini Fuse (10 AMP) 1

SHOP NOTE: PLUG P27-1023-10 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-Q5-"Q5 BODY IGNITION"

3P00-722-LAC AUX LAMP FUSES

AUX LAMP FUSES

P27-1023-30 Mini Fuse (30 AMP) 1

SHOP NOTE: PLUG P27-1023-30 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-B10-"B10 AUX LAMPS"

3P00-722-MAG TRANSMISSION FUSES

TRANSMISSION FUSES

P27-1023-05 Mini Fuse (5 AMP) 1

SHOP NOTE: PLUG P27-1023-05 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-P8-"P8 RH STALK 5A IGN"

3P00-722-NAC DIFF LOCK FUSES

DIFF LOCK FUSES

P27-1023-10 Mini Fuse (10 AMP) 1

SHOP NOTE: PLUG P27-1023-10 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-L7-"L7 AXLE LOCK IND"

3P00-722-QAF ENGINE FUSES AND RELAYS

ENGINE FUSES AND RELAYS

== NO FUSES OR RELAYS TO BE ADDED

3P00-722-RAC OPTIONAL POLYSWITCH FUSES

OPTIONAL POLYSWITCH FUSES

P27-1022-25 Switch-Auto Reset Cb Mini 4

SHOP NOTE: PLUG P27-1022-25 IN

FOLLOWING POS ON DASH SIDE CAB PDC:

POS-N9-"N9 LH WINDOW CKT BRKR"

POS-J9-"J9 RH WINDOW CKT BRKR"

POS-D8-"D8 CAB HVAC BLOWER CKT BRKR"

POS-T7-"T7 WIPER CKT BRKR"

P27-1022-20 Switch-Auto Reset Cb Mini 1

SHOP NOTE: PLUG P27-1022-20 IN

FOLLOWING POS ON DASH SIDE CAB PDC:

POS-M16-"M16 KEY PWR SW CKT BRKR"

3P00-724-FAC AUX - OPTIONAL CHASSIS MODULE FUSES

AUX - OPTIONAL CHASSIS MODULE FUSES

P27-1023-15 Mini Fuse, Blue (15 AMP) 1

SHOP NOTE: PLUG P27-1023-15 IN THE

FOLLOWING POS ON ENGINE SIDE CAB PDC:

POS-B7-"B7 OCM 2 15A BATT"

P27-1023-25 Mini Fuse, Clear (25 AMP) 1

SHOP NOTE: PLUG P27-1023-25 IN THE

FOLLOWING POS ON ENGINE SIDE CAB PDC:

POS-A3-"A3 OCM 6 25A BATT"

P27-1023-20 Mini Fuse, Yellow (20 AMP) 4

SHOP NOTE: PLUG P27-1023-20 IN THE

FOLLOWING POS ON ENGINE SIDE CAB PDC:

POS-A4-"A4 OCM 4 20A BATT"

POS-B1-"B1 OCM 5 20A BATT"

POS-B8-"B8 OCM 1 20A BATT"

POS-A7-"A7 OCM 3 20A BATT"

3P10-300-AAZ ALTERNATOR

ALTERNATOR

D97-1458 INSTL-ENG ACC PX9/L9N

D97-1286-003 INSTL MX-13 ENG ACC

D27-1016-0160P ALTERNATOR - PACCAR 160A 1

LOCK WASHER FOR POSITIVE TERMINAL

27-00562-005 Spring Washer (5/16") 1

LOCK WASHER FOR GROUND BOLT

27-00562-004 Spring Lock Washer (1/4") 1

3P10-300-BAC ALTERNATOR MOUNTING HARDWARE

ALTERNATOR MOUNTING HARDWARE

D97-1299 INSTL - NGP ENG ACCESS

NOTE: PULLEY IS INCLUDED W/CUM ISX ENG

W34-1163-150 BOLT-FINISHED HEX M10 1

W34-1163-100 Hex Bolt (M10 x 1.50 x
100mm) 3

W34-1162-010 Washer (10MM) 4

3P10-300-CAC STARTER

STARTER

D61-6005-003 STARTER-PACCAR 1

3P10-300-DAC STARTER MOUNTING HARDWARE

STARTER MOUNTING HARDWARE

P42-6000 PREVENTATIVE CORRORION

3P10-315-AAD CORROSION PREVENTION - COMMON

CORROSION PREVENTION - COMMON

P97-6709 INSTL-CORROSION PREVENTATIVE

P97-6709 INSTL-CORROSION PREVENTATIVE

P97-6710 INSTL-CORROSION PREVENTATIVE

== APPLY CPC TO BOTH ALTERNATOR

CONNECTIONS ==

== APPLY CPC TO ALL STARTER

CONNECTIONS ==

== APPLY CPC TO ENGINE GROUND ==

== APPLY CPC TO FRAME GROUND ==

== APPLY CPC INSIDE MEGA FUSE HOLDER

AND TO ALL MEGA FUSE CONNECTIONS ==

== APPLY CPC TO ALL CAB GROUND

CONNECTIONS ==

== APPLY CPC TO PDC CONNECTIONS ==

== APPLY CPC TO ALL BATTERY NUTS ==

P42-6000 PREVENTATIVE CORRORION

P42-6000 PREVENTATIVE CORRORION

3P10-315-CAC CORROSION PREVENTION - BATTERY BOX

CORROSION PREVENTION - BATTERY BOX

P97-6709 INSTL-CORROSION PREVENTATIVE

== APPLY CPC TO ALL BATTERY NUTS ==

P42-6000 PREVENTATIVE CORRORION

3P10-700-ACY TAIL & LICENSE LAMPS

TAIL & LICENSE LAMPS

SK22557-002 INSTL-TAIL LIGHTS

SK22557-002 INSTL-TAIL LIGHTS

P95-6971 RTG - TAILLIGHT HARNESS

P95-6971 RTG - TAILLIGHT HARNESS

P95-6039 INSTL-LICENSE PLATE LIGHT

P95-6039 INSTL-LICENSE PLATE LIGHT

== INSTL STANDOFF IN MIDDLE HOLE

OF TAIL LIGHT BRKT FACING DOWN ==

P11-6339R BRACKET-TAIL LIGHT 1

P11-6339 BRACKET-TAIL LIGHT 1

P11-6019 Bracket, License Plate 1

27-00412-004 Lock Washer, External Tooth 2
(1/4")

P54-6130 LAMP - S/T/T, 4 LED 2

P54-6135 LAMP - BACK UP, 4 LED 2

P54-6141 LAMP- LED LICENSE 1

== TIE STRAP CAN USED IPO CPA LOCK ON

TAIL LAMP HARNESS CONNECTOR ==

P92-9425-003 Harness- Tail Lights 1

27-00219-014 Screw - Tapping (7/8) 2

HDWR TO INSTL LICENSE LIGHT & BRACKET

REFLECTOR & MOUNTING HARDWARE

98003R	Reflector	2
354-190001-00-0075	Fastener - Christmas Tree, Warning Light	4

HDWR TO INSTL LICENSE BRKT TO FRM XMBR

27-00671-004	Bolt & Washer Assembly (5/16-18 X 1")	2
27-01386-005	Lock Nut (5/16-18)	2
K11-1153	Standoff Bracket Assembly	2

3P10-701-ATH ENGINE HARNESS**ENGINE HARNESS***D96-6244 SCHM-ENG CUMMINS X15**D96-6244 SCHM-ENG CUMMINS X15**D95-6253 RTG-ENG CUMMINS X15**D95-6282 RTG-X15 ENG HARNESS SHIELD**== ENG BLOCK GROUND - PLACE SS**WASHER ON ENG GROUND STUD. INSTL**ENG GROUND TERM ON STUD. PLACE**2ND SS WASHER ON ENG GROUND STUD ==**== HARDWARE ON A/C COMP BOLT FOR**ENGINE HARNESS ROUTING ==**= SECURE SHIELD TO BRACKET USING**ADDITIONAL ZIP TIES =*

D92-6369-1100	HARNESS - ENG CUMMINS X15	1
---------------	------------------------------	---

27-00801-006	Flat Washer (3/8")	2
--------------	--------------------	---

05-17791	Support Bracket	1
----------	-----------------	---

A62-6084	Cable Tie Mount	1
----------	-----------------	---

27-00428-004	Flat Washer (1/4")	4
--------------	--------------------	---

27-00562-004	Spring Lock Washer (1/4")	2
--------------	---------------------------	---

27-00312-004	Hex Nut (1/4")	2
--------------	----------------	---

ENGINE HARNESS ROUTING HARDWARE

D11-6404	BRACKET - HARNESS, X15 EN	1
----------	------------------------------	---

D11-6285	Standoff Bracket	2
----------	------------------	---

D11-6283	BRACKET-STANDOFF, ENGINE3	3
----------	---------------------------	---

27-00562-005	Spring Washer (5/16")	3
--------------	-----------------------	---

27-00944-020	Hex Bolt (M8 x 1.25 x 20mm)	3
--------------	-----------------------------	---

27-00790-005	Flat Washer (5/16")	4
--------------	---------------------	---

W34-1159-020	BOLT-FINISHED,HEX-M12	4
--------------	-----------------------	---

27-00304-008	Lock Washer (1/2")	4
--------------	--------------------	---

3P10-701-BCU CHARGE/START HARNES**CHARGE/START HARNES***D95-6265 RTG-CHARGE AND START, X15**D95-6265 RTG-CHARGE AND START, X15**D96-6208 SCHM-CHARGE AND START, X15**R97-6425 INSTL-BRACKET, CHARGE START**P97-6387_2 INSTL-ENGINE HARNESS**P97-6387_2 INSTL-ENGINE HARNESS**P97-6387_3 INSTL-ENGINE HARNESS**P97-6387_3 INSTL-ENGINE HARNESS*

P97-6387_1 INSTL-ENGINE HARNESS
 D95-6210 RTG-CAB PWR FEED, 1.9M
 D92-6313-1000 HARNESS-CHARGE AND 1
 START
 P92-2200-0800 HARN - AMMETER SENSOR 1
 MAIN CAB POWER INSTALLATION HARDWARE
 W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25) 1
 PDC BRACKET INSTALLATION HARDWARE
 W34-6075-008 SCREW, THD ROLLING 1/4-2 2
 AUX CAB POWER INSTALLATION HARDWARE
 W20-6011-05TDY0Z Flanged Lock Nut (M5 x 0.80) 1
 R34-6002-08045RHLK Exterior Threaded Hex Screw 2
 (M8 x 1.25 x 45mm)

== INSTL HARDWARE FOR FUSE MODULE
 BRKT TO FIREWALL ==

3P10-701-CEA ENGINE PROTECTION SYSTEM

ENGINE PROTECTION SYSTEM
 P95-6494 ROUTING CHASSIS GROUND JUMPER
 D95-6209 RTG-CONSTANT PWR, 1.9M
 D95-6209 RTG-CONSTANT PWR, 1.9M
 N97-6217 INSTL-MEGA FUSE PLATE
 A96-6428 SCHM-CONSTANT PWR FEED, 1.9M
 MEGA FUSE & MOUNTING HARDWARE
 P27-6180-060 FUSE-HOLDER, MEGA 1
 K041-813-25 Hex Bolt, Locking (M6 x 1.00 2
 x 25mm)
 27-01000-006 Lock Nut (M6 x 1.00) 2
 K363-340-1-250 Flat Washer (1/4") 4
 NOTE: RING TERMINAL CONN OF MEGA FUSE
 JUMPER SHOULD BE MADE AT B/S 22
 AFTER MEGA FUSE HOLDER IS
 INSTALLED IN THE BATTERY BOX
 A92-6074-02400 HARNESS-CONSTANT PWR 1
 FEED

CHASSIS GROUND JUMPER
 CUSHIONED CLAMP
 22-01153-008 Cushioned Clamp (1/2") 1
 MEGA-FUSE BACKING PLATE
 P27-6236 FUSE-BACKING PLATE 1

3P10-701-KAS ELECTRONIC ENGINE CONTROLS

ELECTRONIC ENGINE CONTROLS
 SK29992 PROGRAM, CUMMINS, ISM02/ISX02
 SK28835 INSTL-FIREWALL/CONNECTIONS
 SK28835 INSTL-FIREWALL/CONNECTIONS
 SK17333 INSTL-CLUTCH SWITCH MTG
 P97-6317 INSTL-CUMMINS ENIGNE CONTROL
 PH16-00007 RTG-FIREWALL HARNESS
 PH16-00007 RTG-FIREWALL HARNESS
 PH16-00007 RTG-FIREWALL HARNESS
 SK29331 CONNECTIONS, FIREWALL HARNESS
 SK29331 CONNECTIONS, FIREWALL HARNESS

SK29331 CONNECTIONS, FIREWALL HARNESS

16-04996	Clutch Switch, Gold	1
20-05288-004	Edge Guard, Black (4")	1
CLUTCH SW BRKT TO CLUTCH BRKT HARDWARE		
W01-10-01P04N025Z	Pan Head Screw (#6-32 x 1")	2
W20-6020	NUT-#6-32 Hex Flange	2

3P10-701-MAC CUMMINS ENGINE PROTECTION SHUTDOWN**CUMMINS ENGINE PROTECTION SHUTDOWN**

Y97-6047 INSTL-LABEL, ENG SHTDWN 1.9M		
22-01635	LABEL-SHUTDOWN	1

3P10-702-CAP HOOD HARNESS**HOOD HARNESS**

L95-6030 RTG-HOO HARN, 1.9M
P95-6675 RTG-HARNESS, HEADLIGHT
P95-6675 RTG-HARNESS, HEADLIGHT
P95-6675 RTG-HARNESS, HEADLIGHT
P95-6675 RTG-HARN,HEADLIGHT,388/389
P95-6883 RTG-HEADLIGHT HARNESS
P95-6883 RTG-HEADLIGHT HARNESS
A95-6038 RTG-CHASSIS HARN,1.9M
A95-6038 RTG-CHASSIS HARN,1.9M
HOOD HARNESS & MTG HARDWARE

P92-8482-12101100	HARNESS-HOOD	1
Y84-6000-016	Tie Strap, Button Head	3
== INSTALL BUTTON TIE IN HOLE FWD OF ENGINE MOUNT TO SECURE HOSE BUNDLE FROM STARTER ==		
Y84-6000-016	Tie Strap, Button Head	1
P16-1001-031	Edge Clip, Two-Piece	2

3P10-702-DBA FIREWALL HARNESS**FIREWALL HARNESS**

P95-6957 INSTL-FIREWALL HARNESS, 1.9M		
P92-8523-100	HARNESS-FW,CVNTL NODE	1
A62-6084	Cable Tie Mount	2
R34-6002-06025RHLZ	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	3

3P10-702-GCJ CAB DOOR ELECTRICAL**CAB DOOR ELECTRICAL****LH POWER WINDOW**

P92-6539	JUMPER MIRROR CTL MODULE	1
P27-6224-040501	LH Door Armrest Switch Assembly, Charcoal	1
P27-6225-10501	RH Door Armrest Switch Assembly, Charcoal	1

3P10-702-MCE BENDIX ABS CAB HARNESS**BENDIX ABS CAB HARNESS**

Q27-1040-301	EC-80 ESP CAB ECU	1
S11-6408	Bracket - Center Console	1
S34-6003-0525TP00B		

PSD Screw, Black (M5 x 0.80 4
x 25mm)

3P10-702-QAE ELECTRICAL SYSTEM SCHEMATICS

ELECTRICAL SYSTEM SCHEMATICS

P94-6501 SCHM-EXTERIOR LIGHTING

P94-6502 SCHM-INTERIOR LIGHTING

P94-6503 SCHM-WIPER, WASHER

P94-6504 SCHM-HVAC SYSTEM, 1.9M

P94-6505 SCHM-AUDIO SYSTEM, 1.9M

P94-6506 SCHM-DOOR, CONTROL

P94-6507 SCHM-ABS SYSTEM, 1.9M

P94-6508 SCHM-INSTRUMENTATION

P94-6509 SCHM-CAB/SLEEPER SYSTEM

P94-6510 SCHM-CAB ENG CONTROL

P94-6511 SCHM-2010 MX ENG

P94-6512 SCHM-ALLISON TOWER

P94-6513 SCHM-EATON XMSN, 1.9M

P94-6514 SCHM-EOAS SYSTEM, 1.9M

P94-6516 SCHM-ALLISON DASH

P94-6517 SCHM-AUX PDC SYSTEM

P94-6518 SCHM-TRAILER CONNECTION

P94-6519 SCHM-EOF KILL SWITCH

P94-6520 SCHM-PTO CONNECTION

3P10-702-VAC PRIMARY CHASSIS MODULE

PRIMARY CHASSIS MODULE

Q21-1142-001-001 Primary Chassis Module 1

3P10-702-WAC SECONDARY CHASSIS MODULE

SECONDARY CHASSIS MODULE

Q21-1143-001-001 Secondary Chassis Module 1

3P10-702-YAD CAB GROUND FEED

CAB GROUND FEED

SK30378 INSTL-CAB GROUNDING

SK30383 INSTL-CAB GROUNDING

S96-6370 SCHM-CAB GROUND, 1.9M

P95-6257 RTG-CAB GROUND

S92-6480-1100 HARNESS-CAB GROUND 1

HDWE FOR CAB GROUNDING

W34-6001-038 Hex Bolt (3/8" x 1-1/2"),
Stainless Steel 1

27-00803-006 Lock Nut (3/8-16), Stainless
Steel 1

27-00801-006 Flat Washer (3/8") 3

3P10-703-RAC DASH MTD HAND VALVE ADAPTER HARNESS

DASH MTD HAND VALVE ADAPTER HARNESS

S96-6497 SCHM-PRESSURE, SW ADAPTER

= ON PRESSURE SW ADAPTER HARNESS

CONNECT J001 TO THE PRESSURE SWITCH

FOR TRAILER BRAKE. CONNECT J002 TO

EDITABLE TELLTALE #1 (J1001) ON IP

HARNESS. CONNECT P001 TO P022423

IN IP HARNESS =

S92-6622 HARN-PRESSURE SW 1
ADAPTER

3P10-703-SAL AIR DRYER JUMPERS

AIR DRYER JUMPERS

A95-6070-000 RTG-AIR DRYER, 1.9M

P92-1129-1000 JUMPER- AIR DRYER 1

3P10-703-TAC MERITOR DIFF LOCK EXTENSION HARNESS

MERITOR DIFF LOCK EXTENSION HARNESS

= CONN FROM REAR CHASSIS EXT HARNESS

TO MERITOR AXLE W/ DIFF LOCK =

16-10095-0150 HARNESS-JUMPER, NEUT SW 1

3P10-703-VAG BACK-UP ALARM

BACK-UP ALARM

A97-6075-0000 FRM DRLG-BACKUP ALARM

P97-6603 INSTL-BACKUP ALARM

S97-6092 INSTL-LABEL PLACEMENT

= ALARM WITHOUT THE YELLOW STICKER =

P49-1003 ALARM - FIXED BACKUP 1

16-03337 Label - Backup Alarm 1

3P10-703-WAF BACK-UP ALARM HARNESS

BACK-UP ALARM HARNESS

A96-1531 SCHM-WIRE JUMPER

P97-6603 INSTL BACKUP ALARM

A92-1004-01500 HARNESS- WIRE-JUMPER 1

3P10-705-FDU AFTERTREATMENT CHASSIS HARNESS

AFTERTREATMENT CHASSIS HARNESS

M96-6203 SCHM-AFT, 2021 1.9M

P95-7017 RTG-AFT, 2021 1.9M

M92-6104-0011306 HARNESS-AFT,2021 1.9M 1

3P10-708-GAC CUMMINS PTO ENGAGE DIODE JUMPER

CUMMINS PTO ENGAGE DIODE JUMPER

= CONN J110 IN JMPR TO P110 IN MAIN

CHASSIS HARNESS. CONN P110 IN JMPR

TO J110 IN MAIN CHASSIS HARNESS =

A92-6190 JUMPER-PTO ENGAGE DIODE 1

3P10-710-DAG BATTERY TO BATTERY JUMPERS

BATTERY TO BATTERY JUMPERS

P97-6031 INSTALLATION - BATTERY CABLES

P97-6031 INSTALLATION - BATTERY CABLES

P92-8059-10550 JUMPER - MEGA FUSE 1

N92-6006-2AMSSB020 Battery Cable (POS) 1

N92-6006-2AASS0020 Battery Cable (POS) 1

N92-6007-2AASS0020 Battery Cable (NEG) 1

N92-6007-2AWSSB020 CABLE-BATTERY,(NEG) ASSY 1

3P10-710-PAF BATTERY CABLE RTG HDWR AT ENGINE

BATTERY CABLE RTG HDWR AT ENGINE

P95-6723-001 ROUTING-BATT CABLE,ISX

BATTERY CABLE CRADLE

P11-6328-001

Battery Cable Bracket Assembly <i>HARDWARE</i>	1		
27-01008-008	Lock Nut (M8 x 1.15-6H)	3	
	Cadmium Plate		
Y84-6000-014	Tie Strap	4	

3P10-710-QAC BATTERY CABLE RTG HDWR AT TRANSMISSION

BATTERY CABLE RTG HDWR AT TRANSMISSION

P95-6963-001 RTG-BATT CABLES, MANUAL

P97-6814 INSTL-SECUREMENT BOC BATT CAB

BATT CABLE RTG HDWR AT PTO AREA

W11-6072	BRACKET - STANDOFF, ASSY	1	
----------	--------------------------	---	--

Y84-6000-014	Tie Strap	2	
--------------	-----------	---	--

DUAL TIE STRAPS BETWEEN HARD MOUNTS

Y84-6000-021	Tie Strap, Dual Loop	3	
--------------	----------------------	---	--

3P10-711-AGD TRAILER ELECTRIC CABLE W/ SOCKET

TRAILER ELECTRIC CABLE W/ SOCKET

SK29780-001 ABS TRLR HARN CONNECTIONS

P95-6285 CHASSIS TRLR ABS LABEL PLCMNT

P95-6524 ROUTING - TRAILER HARN GROUND

P95-6524 ROUTING - TRAILER HARN GROUND

P95-6462 RTG TRAILER HARNESS

P92-4835-006001	HARN-TRLR J560 NGP	1	
-----------------	--------------------	---	--

MTG HDWE FOR TRLR ELEC SOCKET

27-00271-005	Hex Bolt (5/16-24 x 1-1/4")	2	
--------------	-----------------------------	---	--

27-00801-005P	Washer, Polished (5/16")	4	
---------------	--------------------------	---	--

27-00791-005	Lock Nut (5/16-24)	2	
--------------	--------------------	---	--

27-00204-006	Thread Rolling Screw (1/4-20 x 3/4")	1	
--------------	---	---	--

NOTE: APPLY LABEL TO A&E BRKT OR ON

RAIL NEAR A&E LOCATION.

A53-1001-4	Caution Label, Trailer ABS	1	
------------	----------------------------	---	--

3P10-711-FAD TRAILER 4-WAY

TRAILER 4-WAY

P92-9461-10300	HARNESS-TRLR,ADDL RECEP	1	
----------------	-------------------------	---	--

P92-9459-0900	HARNESS - 4 WAY SCKT	1	
---------------	----------------------	---	--

ADPT

3P21-700-AAC STANDARD DASH

STANDARD DASH

P97-6778 INSTL-MODULE, MASTER SWITCH

Q21-1136-002-003	CTRL-Master Switch Module	1	
------------------	---------------------------	---	--

S92-1127-0125	HARNESS - LIN JUMPER	5	
---------------	----------------------	---	--

P27-6241-010-01	SWITCH-DIMMER	1	
-----------------	---------------	---	--

P27-6253-032-01	SWITCH-ELST ON/OFF	1	
-----------------	--------------------	---	--

P27-6253-152-01	SWITCH-CLEARANCE LAMP	1	
-----------------	-----------------------	---	--

P27-6253-156-01	SWITCH-HEADLAMP	1	
-----------------	-----------------	---	--

P27-1250-026-01	SWITCH-HAZARD	1	
-----------------	---------------	---	--

3P21-700-DAC DPF START/STOP

DPF START/STOP

P27-6241-012-01	SWITCH-DPF START/STOP	1	
-----------------	-----------------------	---	--

3P21-700-KAE DASH SWITCH WHOLE WIRE GUARD*DASH SWITCH WHOLE WIRE GUARD*

S46-1006 SHIELD-SWITCH DUAL 3

3P21-700-LAD DASH SWITCH HALF WIRE GUARD*DASH SWITCH HALF WIRE GUARD*

S46-1007 SHIELD-SWITCH SINGLE 2

3P21-700-NAC C-PANEL LIN JUMPER NEG QTY*C-PANEL LIN JUMPER NEG QTY*

= BOM REMOVES (1) JUMPER FROM TOTAL =

S92-1127-0125 HARNESS - LIN JUMPER

3P21-700-PAE D-PANEL LIN JUMPER NEG QTY*D-PANEL LIN JUMPER NEG QTY*

= BOM REMOVES (0) JUMPER FROM TOTAL =

3P21-703-BAC SPARE EOA GUARDED SWITCHES*SPARE EOA GUARDED SWITCHES*

P27-6253-050-01 SWITCH-AIR ACCESSORY 1 1

S92-1127-0125 HARNESS - LIN JUMPER 1

3P21-703-DAC AIR SUSP DUMP SWITCHES*AIR SUSP DUMP SWITCHES*

P27-6253-053-01 SWITCH-AIR SUSP DUMP 1 1

S92-1127-0125 HARNESS - LIN JUMPER 1

3P21-703-ZAC TRAILER DUMP FRT/REAR SWITCHES*TRAILER DUMP FRT/REAR SWITCHES*P27-6253-074-01 SWITCH-TRLR DUMP GATE 1
FWDP27-6253-076-01 SWITCH-TLR DUMP GATE 1
REAR

S92-1127-0125 HARNESS - LIN JUMPER 2

3P21-704-LAC PTO SWITCH*PTO SWITCH*

P27-6253-058-01 SWITCH-PTO 1 1

S92-1127-0125 HARNESS - LIN JUMPER 1

3P21-704-QAD WHL DIFF LOCK FWD REAR AXL SWITCH*WHL DIFF LOCK FWD REAR AXL SWITCH*

P27-6253-091-01 SWITCH-DIFF LOCK SGL RA 1

S92-1127-0125 HARNESS - LIN JUMPER 1

3P21-709-CAC AUTO TRACTION CTRL SWITCH*AUTO TRACTION CTRL SWITCH*P27-6253-002-01 SWITCH-AUTO TRACTION 1
CTRL

S92-1127-0125 HARNESS - LIN JUMPER 1

3P21-709-EAC AUX SIDE LIGHTS SWITCH*AUX SIDE LIGHTS SWITCH*

P27-6253-003-01 SWITCH-AUX LIGHTS 1

S92-1127-0125 HARNESS - LIN JUMPER 1

3P21-709-QAC ENGINE FAN OVERRIDE SWITCH*ENGINE FAN OVERRIDE SWITCH*

P27-6253-018-01 SWITCH-ENG FAN OVERRIDE 1

S92-1127-0125 HARNESS - LIN JUMPER 1

3P21-720-CAC LOADLIGHT SWITCH*LOADLIGHT SWITCH*

P27-6253-020-01	SWITCH-FLOODLIGHT 1ST	1
S92-1127-0125	HARNES - LIN JUMPER	1

3P21-720-DAC LOADLIGHT 2ND SWITCH*LOADLIGHT 2ND SWITCH*

P27-6253-021-01	SWITCH-FLOODLIGHT 2ND	1
S92-1127-0125	HARNES - LIN JUMPER	1

3Q00-S10-A10 PARAMETER FOR VEHICLE MODEL*PARAMETER FOR VEHICLE MODEL***3Q00-S10-B40 PARAMETER FOR COMMODITY HAULED***PARAMETER FOR COMMODITY HAULED***3Q00-S10-C01 PARAMETER FOR VEHICLE TYPE***PARAMETER FOR VEHICLE TYPE***3Q00-S10-D99 PARAMETER FOR BODY TYPE***PARAMETER FOR BODY TYPE***3Q00-S10-E06 PARAMETER FOR TRAILER TYPE***PARAMETER FOR TRAILER TYPE***3Q00-S10-F01 PARAMETER FOR ABS CONFIGURATION***PARAMETER FOR ABS CONFIGURATION***3Q00-S10-G01 PARAMETER FOR REAR DRIVE AXLE CONFIG***PARAMETER FOR REAR DRIVE AXLE CONFIG***3Q00-S10-H01 PARAMETERS FOR DISTANCE TO PUSHER 1***PARAMETERS FOR DISTANCE TO PUSHER 1*

* ANY DIMENSION IN HUNDREDS 0XX

* ANY DIMENSION IN TENS X0X

3Q00-S10-J01 PARAMETERS FOR DISTANCE TO PUSHER 2*PARAMETERS FOR DISTANCE TO PUSHER 2*

* ANY DIMENSION IN HUNDREDS 0XX

* ANY DIMENSION IN TENS X0X

3Q00-S10-K01 PARAMETERS FOR DISTANCE TO PUSHER 3*PARAMETERS FOR DISTANCE TO PUSHER 3*

* ANY DIMENSION IN HUNDREDS 0XX

* ANY DIMENSION IN TENS X0X

3Q00-S10-L01 PARAMETERS FOR DISTANCE TO PUSHER 4*PARAMETERS FOR DISTANCE TO PUSHER 4*

* ANY DIMENSION IN HUNDREDS 0XX

* ANY DIMENSION IN TENS X0X

3Q00-S10-M01 PARAMETERS FOR DISTANCE TO TAG 1*PARAMETERS FOR DISTANCE TO TAG 1*

* ANY DIMENSION IN HUNDREDS 0XX

* ANY DIMENSION IN TENS X0X

3Q00-S10-N01 PARAMETER FOR DISTANCE TO TAG 2*PARAMETER FOR DISTANCE TO TAG 2***3Q00-S10-P01 PARAMETER FOR PUSHER 1 TYPE***PARAMETER FOR PUSHER 1 TYPE***3Q00-S10-Q01 PARAMETER FOR PUSHER 2 TYPE***PARAMETER FOR PUSHER 2 TYPE*

3Q00-S10-R01 PARAMETER FOR PUSHER 3 TYPE*PARAMETER FOR PUSHER 3 TYPE***3Q00-S10-S01 PARAMETER FOR PUSHER 4 TYPE***PARAMETER FOR PUSHER 4 TYPE***3Q00-S10-T01 PARAMETER FOR TAG 1 TYPE***PARAMETER FOR TAG 1 TYPE***3Q00-S10-U01 PARAMETER FOR TAG 2 TYPE***PARAMETER FOR TAG 2 TYPE***3Q00-S10-W02 PARAMETER FOR FRONT AXLE TRACK WIDTH***PARAMETER FOR FRONT AXLE TRACK WIDTH***3Q00-S10-X09 PARAMETER FOR GROSS COMBO WEIGHT***PARAMETER FOR GROSS COMBO WEIGHT***3Q00-S10-Y04 PARAMETER FOR GAWR STEER AXLE (LBS).***PARAMETER FOR GAWR STEER AXLE (LBS)***3Q00-S10-Z09 PARAMETER FOR GAWR INDIVIDUAL REAR***PARAMETER FOR GAWR INDIVIDUAL REAR**AXLE (LBS)*

Q30-1003-024000009 GAWR REAR PRMTR - ABS 6 1

3Q00-S11-B10 PARAMETER FOR STEERING GEAR TYPE*PARAMETER FOR STEERING GEAR TYPE*

Q30-1003-026000010 STRNG TYPE PRMTR - ABS 6 1

3Q00-S11-C52 PARAMETER FOR REAR SUSPENSION TYPE*PARAMETER FOR REAR SUSPENSION TYPE***3Q00-S11-D06 PARAMETER FOR STEER AXLE BRAKE SIZE***PARAMETER FOR STEER AXLE BRAKE SIZE*

Q30-1003-028000006 STR BRK PRMTR - ABS 6 1

3Q00-S11-E10 PARAMETER FOR STEER AXLE SUSP TYPE*PARAMETER FOR STEER AXLE SUSP TYPE***3Q00-S11-F01 PARAMETER FOR REAR AXLE BRAKE SIZE***PARAMETER FOR REAR AXLE BRAKE SIZE***3Q00-S11-G99 PARAMETER FOR REAR AXLE SPACING***PARAMETER FOR REAR AXLE SPACING***3Q00-S11-H06 PARAMETER FOR YAW RATE SENSOR ORIENT.***PARAMETER FOR YAW RATE SENSOR ORIENT.*

Q30-1003-032000001 YAW SNSR PRMTR - ABS 6 1

3Q00-S11-J01 PARAMETER FOR STEERING ANGLE SENSOR*PARAMETER FOR STEERING ANGLE SENSOR**ORIENTATION***3Q00-S11-K04 PARAMETER: HIGH RESOLUTION WHEEL SPEED***PARAMETER: HIGH RESOLUTION WHEEL SPEED**WHEEL SPEED ENABLED*

Q30-1003-034000003 PARAMETER- ABS, HRWS 1

3Q00-S11-L02 PARAMETER FOR ATC PRESENT*PARAMETER FOR ATC PRESENT***3Q00-S11-M01 PARAMETER-ENG RETARDER RELAY PRESENT***PARAMETER-ENG RETARDER RELAY PRESENT***3Q00-S11-N02 PARAMETER FOR REAR AXLE RATIO***PARAMETER FOR REAR AXLE RATIO*

3Q00-S11-P04 PARAMETER FOR FRONT AXLE TYPE*PARAMETER FOR FRONT AXLE TYPE***3Q00-S11-Q03 PARAMETER FOR ABS ECU TYPE***PARAMETER FOR ABS ECU TYPE***3Q00-S11-R01 PARAMETER FOR CLUTCH TYPE***PARAMETER FOR CLUTCH TYPE***3Q00-S11-S99 PARAMETER FOR BODY BUILDER***PARAMETER FOR BODY BUILDER***3Q00-S11-T99 PARAMETER FOR BODY INFORMATION***PARAMETER FOR BODY INFORMATION***3Q00-S11-U99 PARAMETER FOR ACB CONFIGURATION***PARAMETER FOR ACB CONFIGURATION***3Q00-S11-VAC SUSP BASED TRACTION SYSTEM PARAMETER***SUSP BASED TRACTION SYSTEM PARAMETER*

Q30-1003-044000000 SUSP BASE TRAC SYS-ABS 6 1

3Q00-S11-WAE ATC MUD/SNOW SWITCH CONFIG PARAMETER*ATC MUD/SNOW SWITCH CONFIG PARAMETER*

Q30-1003-045000002 ATC MUD/SNOW SW-ABS 6 1

3Q00-S11-X99 ACC FOLLOWING DISTANCE ALERTS*ACC FOLLOWING DISTANCE ALERTS*

Q30-1003-046000000 PARAMETER-ABS 6 1

3Q00-S11-YAD VECU*VECU*

Q30-1003-047000002 PARAMETER- ABS, VECU 1

3Q00-S11-ZAC RETARDER*RETARDER*

Q30-1003-048000000 PARAMETER- ABS, RETARDER 1

3Q00-S12-AAE SDP SPEAKER LEFT VOLUME*SDP SPEAKER LEFT VOLUME*

Q30-1003-049999999 PARAMETER-ABS-6 1

3Q00-S12-BAE SDP SPEAKER RIGHT VOLUME*SDP SPEAKER RIGHT VOLUME*

Q30-1003-050999999 PARAMETER-ABS-6 1

3Q00-S12-CBC ENGINE MODEL*ENGINE MODEL*

Q30-1003-051000030 PARAMETER-ABS 6 1

3Q00-S12-EAC PARAMETERS FOR AIR DRYER TYPE*PARAMETERS FOR AIR DRYER TYPE*

Q30-1003-053000000 PARAMETER - ABS 6 1

3Q00-S12-FAC PARAMETER FOR COMPRESSOR TYPE*PARAMETER FOR COMPRESSOR TYPE*

Q30-1003-054000000 PARAMETER - ABS 6 1

3Q00-S12-GAC PARAMETER FOR STEER AXLE TYPE*PARAMETER FOR STEER AXLE TYPE*

Q30-1003-055000000 PARAMETER - ABS 6 1

3Q00-S12-HAE PARAMETER FOR STEER BRAKE CHAMBER SIZE*PARAMETER FOR STEER BRAKE CHAMBER SIZE*

Q30-1003-056000003 PARAMETER-ABS 6 1

3Q00-S12-JAJ PARAMETER FOR REAR BRAKE CHAMBER SIZE*PARAMETER FOR REAR BRAKE CHAMBER SIZE*

Q30-1003-057000007 PARAMETER-ABS 6 1

3Q00-S12-KAC PARAMETER FOR RADAR ALIGNMENT*PARAMETER FOR RADAR ALIGNMENT*

Q30-1003-058000000 Parameter-ABS 6 1

3Q00-S12-LAC PARAMETER FOR RADAR OFFSET FROM CENTER*PARAMETER FOR RADAR OFFSET FROM CENTER*

Q30-1003-059000000 Parameter-ABS 6 1

3Q00-S12-MAC PARAMETER FOR RAIL MODE*PARAMETER FOR RAIL MODE*

Q30-1003-060000000 Parameter-ABS 6 1

3Q00-710-AAD ENGINE OIL TEMPERATURE*ENGINE OIL TEMPERATURE**P95-6079 INSTL-GAUGE WIRING, B-PANEL**Q97-6023 INSTL - LIN GAUGE*

Q43-1176-106C100 LIN-PB ENG OIL TEMP 1

Q20-1002 Gauge Mount Nut 1

P92-2192-0175 CVSG Wiring Harness 1
(175mm)**3Q00-710-BAD MANIFOLD PRESSURE***MANIFOLD PRESSURE**P95-6079 INSTL-GAUGE WIRING, B-PANEL**Q97-6023 INSTL - LIN GAUGE*

Q43-1176-111C100 LIN-PB MANIFOLD PRESS 1

Q20-1002 Gauge Mount Nut 1

P92-2192-0175 CVSG Wiring Harness 1
(175mm)**3Q00-710-CAH FUEL FILTER RESTRICTION***FUEL FILTER RESTRICTION**FRAME MOUNTED FUEL FILTER**D97-6106S45 INSTL-FUEL FLTR,RESTR,SHT3**P95-6079 INSTL-GAUGE WIRING, B-PANEL**Q97-6023 INSTL - LIN GAUGE*

Q43-1176-128C100 LIN-PB FUEL FILT RES 1

Q20-1002 Gauge Mount Nut 1

P92-2192-0175 CVSG Wiring Harness 1
(175mm)*== RMV NIPPLE FRM PCAR FF AND REINSTL**USING TEE PER INSTL-FF RESTR,SHT3==***3Q00-710-FAD FRONT DRIVE AXLE TEMPERATURE***FRONT DRIVE AXLE TEMPERATURE**P95-6079 INSTL-GAUGE WIRING, B-PANEL**Q97-6023 INSTL - LIN GAUGE**SK23145 RTG-REAR AXLE*

Q43-1176-124C100 LIN-PB FRONT AXLE TEMP 1

Q20-1002 Gauge Mount Nut 1

P92-2192-0175 CVSG Wiring Harness 1
(175mm)

P92-6594-2000

Jumper Harness Assembly -	1
Axle Temperature	
22-01151-008	Cushioned Clamp (1/2") 1
<i>FRONT DRIVE AXLE TEMP SENSOR</i>	
Q21-1002	Temperature Sensor 1
27-00273-003	Hex Bolt (3/8-16 x 3/4") 1
20-09700	Retainer - Axle Air Lines 1
27-00562-006	Spring Lock Washer (3/8") 1
08-01498	Clip - Manifold 1

3Q00-710-JAD MAIN TRANSMISSION OIL TEMPERATURE

MAIN TRANSMISSION OIL TEMPERATURE

P95-6079 INSTL-GAUGE WIRING, B-PANEL

Q97-6023 INSTL - LIN GAUGE

Q43-1176-107C100	LIN-PB MAIN TRANS OIL, EN 1
Q20-1002	Gauge Mount Nut 1
P92-2192-0175	CVSG Wiring Harness 1
	(175mm)

MAIN TRANSMISSION SENSOR

Q21-1002	Temperature Sensor 1
----------	----------------------

3Q00-710-KAD AMMETER

AMMETER

P95-6079 INSTL-GAUGE WIRING, B-PANEL

Q97-6023 INSTL - LIN GAUGE

Q43-1176-302C100	LIN-PB AMMETER, CHRM 1
Q20-1002	Gauge Mount Nut 1
P92-2192-0175	CVSG Wiring Harness 1
	(175mm)

3Q00-710-LAD BRAKE APPLICATION PRESSURE

BRAKE APPLICATION PRESSURE

Q97-6023 INSTL - LIN GAUGE

P95-6079 INSTL-GAUGE WIRING, B-PANEL

Q43-1176-103C100	LIN-PB BRAKE APP PRESS 1
Q20-1002	Gauge Mount Nut 1
P92-2192-0175	CVSG Wiring Harness 1
	(175mm)

BRAKE APPLICATION SENSOR

Q21-1040	Air Pressure Sensor, (0-85 Psi) 1
----------	-----------------------------------

G38-6018-040404	Tee Fitting (#4 to #4) 1
-----------------	--------------------------

3Q00-710-MAD AIR FILTER RESTRICTION

AIR FILTER RESTRICTION

COWL MOUNTED AIR CLEANER

P95-6079 INSTL-GAUGE WIRING, B-PANEL

P97-6618 INSTL-AIR FILTER RESTRICTION

Q97-6023 INSTL - LIN GAUGE

Q43-1176-108C100	LIN-PB AIR FLTR RES, CHRM 1
Q20-1002	Gauge Mount Nut 1
P92-2192-0175	CVSG Wiring Harness 1
	(175mm)

116305-25540	FILTERMINDER SENSOR 1
--------------	-----------------------

G38-1085-0404	
---------------	--

Straight Union Fitting (#4 1
 J2494 to #4 J2494)
 G50-6022-04BLK076 TUBING-NYLON AIR BRAKE 1
 == SENSOR TO INTAKE ELBOW ==
 G38-1038-0204 90° Elbow Fitting (#2 FNPT 1
 to #4 J2492)
 == PLACE ORIFICE ED OF FTG TOWARD
 AIR CLEANER ==
 PPP10-0089 Fitting, Brass, w/ Filter 1

3Q00-710-NAD SUSPENSION LOAD GAUGE #1

SUSPENSION LOAD GAUGE #1

BRIGHT BEZEL - ENGLISH GAUGE

NYLON HOSE

Q97-6023 INSTL - LIN GAUGE

CAB HARDWARE

AIR CIRCUIT 305

Q43-6072-103C Air Suspension Pressure 1 1
 Gauge, Chrome

Q20-1002 Gauge Mount Nut 1

P92-2192-0175 CVSG Wiring Harness 1
 (175mm)

G50-6022-04PUR065 TUBING-NYLON AIR BRAKE 1

== SPSN LD GA TO FIREWALL MANIFOLD ==

3Q00-710-VAD TRAILER SUPPLY AIR PRESSURE GAUGE

TRAILER SUPPLY AIR PRESSURE GAUGE

BRIGHT BEZEL - ENGLISH GAUGE

G95-6132 PLMB-TRLR SPLY AIR PRESS

Q97-6023 INSTL - LIN GAUGE

CAB HARDWARE

AIR CIRCUIT 226

Q43-6072-106C Trailer Reservoir Gauge, 1
 Chrome

Q20-1002 Gauge Mount Nut 1

P92-2192-0175 CVSG Wiring Harness 1
 (175mm)

G50-6022-04BLK062 CUT TUBING J844 04-BLK- 1
 062

== TRAILER SUPPLY GAUGE TO MV3 LINE ==

G38-6018-060604 Union Tee Fitting, Composite 1
 (#6 to #6 J2494)

3Q00-715-FAE SENSOR - FUEL FILTER RESTRICTION

SENSOR - FUEL FILTER RESTRICTION

D97-6106S45 INSTL-FUEL FLTR,RESTR,SHT3

Q21-1033 Sensor - Fuel Filter 1
 Restriction

26-02816 Connector - Tee (1/8" MP X 1
 1/8" FP X 1/8" FP) 1

== RMV NIPPLE FROM PCAR FF AND REINSTL

USING TEE PER INSTL-FF RESTR, SHT3=

3Q10-S40-BAP CUMMINS ENGINE BASE CALIBRATION

CUMMINS ENGINE BASE CALIBRATION

D30-6011-0004 SOFTWARE-CUMM, 2021 1
X15,

3Q10-S40-CAD DEF SOFTWARE

DEF SOFTWARE

M30-6003-001 Software - DEF, SSI 1

3Q10-S50-AAK BASE APPLICATION SOFTWARE PARAMETER

BASE APPLICATION SOFTWARE PARAMETER

AASF12202397054N43 VMUX BASE APP SW MY23 1

3Q10-S50-BAK ENGINE CALIBRATION PARAMETER

ENGINE CALIBRATION PARAMETER

AASF12212397055N43 VMUX BASE CALIB MY23 1

3Q10-S50-CAY ENGINE PARAMETER

ENGINE PARAMETER

AASF13122391219N36 VMUX ARCH ENG ISX R19.9+ 1

3Q10-S50-DCM TRUCK MODEL PARAMETER

TRUCK MODEL PARAMETER

AASF13202397241N43 VMUX TRUCK PB 1.9M MY23 1

3Q10-S50-EAH SPARE SOFTWARE PARAMETER

SPARE SOFTWARE PARAMETER

AASF13162158954L05 VMUX SPARE SFTWARE 1
R19.8+

3Q10-S50-FBW VMUX TRANS - MANUAL

VMUX TRANS - MANUAL

AASF13002390935N36 VMUX TRANS MANUAL 1
R19.9+

3Q10-S50-GBK ABS CONFIGURATION PARAMETER

ABS CONFIGURATION PARAMETER

AASF13192397251N43 VMUX BENDIX W/O ACC 1
W/ESP

3Q10-S50-HAR PCC CONFIGURATION PARAMETER

PCC CONFIGURATION PARAMETER

AASF13182346713N09 VMUX - W/O PCC R19.8+ 1

3Q10-S50-JAY AUTO START CONFIGURATION PARAMETER

AUTO START CONFIGURATION PARAMETER

AASF13222314404M09 VMUX W/O AUTO START 1

3Q10-S50-KAJ SPARE SOFTWARE PARAMETER

SPARE SOFTWARE PARAMETER

AASF13152158819L05 VMUX SPARE SFTWARE 1
R19.8+

3Q10-S50-LAV SWITCHES PARAMETER

SWITCHES PARAMETER

AASF13132295791L38 VMUX SM SWITCHES R19.8+ 1

3Q10-S50-MBE ENGINE BRAKE SWITCH CONFIG PARAMETER

ENGINE BRAKE SWITCH CONFIG PARAMETER

AASF13142298234L38 VMUX ENG BRK - CE W/RHS 1

3Q10-S50-NAT SPP VERSION PARAMETER

SPP VERSION PARAMETER

AASF11192391222N36 VMUX CUMMINS SPP R19.9+ 1

3Q10-S50-PBN LIFT AXLE PARAMETER

LIFT AXLE PARAMETER

AASF13402164793L07	VMUX W/O LFT AXLES	1
	R19.8+	

3Q10-S50-QBA DRIVEN AXLE PARAMETER*DRIVEN AXLE PARAMETER*

AASF13422258008L07	VMUX SNGL DRV AXLE	1
	R19.8+	

3Q10-S50-RAX VMUX AUTO START & BRAKE CONFIGURATION*VMUX AUTO START & BRAKE CONFIGURATION*

AASF13432341042M52	W/O AUTO START & W/O ACE 1	
--------------------	----------------------------	--

3Q10-S50-SAH SPARE INSTALLATION PARAMETER*SPARE INSTALLATION PARAMETER*

AASF13462151654L07	VMUX SPARE-INSTALL	1
	R19.8+	

3Q10-S50-TAH SPARE SOFTWARE PARAMETER*SPARE SOFTWARE PARAMETER*

AASF13212158820L05	VMUX SPARE SFTWARE	1
	R17.4+	

3Q10-S50-UAH SPARE SOFTWARE PARAMETER*SPARE SOFTWARE PARAMETER*

AASF13172158821L05	VMUX SPARE SFTWARE	1
	R19.8+	

3Q10-S50-VAH SPARE SOFTWARE PARAMETER*SPARE SOFTWARE PARAMETER*

AASF13302158822L05	VMUX SPARE SFTWARE	1
	R17.4+	

3Q10-S50-WCN CMS AND MSB CONFIGURATION PARAMETER*CMS AND MSB CONFIGURATION PARAMETER*

AASF13412135773L07	VMUX W/CM P&S, MSB 1	1
--------------------	----------------------	---

3Q10-S50-XAN CAN CONFIGURATION*CAN CONFIGURATION*

AASF13662397056N43	VMUX CAN CONFIG MY23	1
--------------------	----------------------	---

3Q10-S50-YAJ FLASH LOADER*FLASH LOADER*

AASF13652304958M30	VMUX FLASH LOADER	1
	R19.8+	

3Q10-S51-AAG SPARE SOFTWARE PARAMETER*SPARE SOFTWARE PARAMETER*

AASF10262346324N06	VMUX SPARE SW R19.8+	1
--------------------	----------------------	---

3Q10-S51-BAG SPARE SOFTWARE PARAMETER*SPARE SOFTWARE PARAMETER*

AASF10512271594L05	VMUX SPARE SFTWARE	1
	R19.8+	

3Q10-S51-CAG SPARE SOFTWARE PARAMETER*SPARE SOFTWARE PARAMETER*

AASF10522271595L05	VMUX SPARE SFTWARE	1
	R19.8+	

3Q10-S51-DAG SPARE SOFTWARE PARAMETER*SPARE SOFTWARE PARAMETER*

AASF10532271596L05	VMUX SPARE SFTWARE R19.8+	1
<u>3Q10-S51-EAG SPARE SOFTWARE PARAMETER</u>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF10552271597L05	VMUX SPARE SFTWARE R19.8+	1
<u>3Q10-S51-FAG SPARE SOFTWARE PARAMETER</u>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF10562271598L05	VMUX SPARE SFTWARE R19.8+	1
<u>3Q10-S51-GAH SPARE SOFTWARE PARAMETER</u>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF15982397057N43	1598 - DEM FILE MY23	1
<u>3Q10-S51-HAG SPARE SOFTWARE PARAMETER</u>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF17762258021L07	VMUX SPARE-INSTALL R17.4+	1
<u>3Q10-S51-JAT SPARE SOFTWARE PARAMETER</u>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF17772258025L07	VMUX PB 1.9M R19.8+	1
<u>3Q10-S51-KAG SPARE SOFTWARE PARAMETER</u>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF12452257979L05	VMUX SPARE SFTWARE R19.8+	1
<u>3Q10-S51-LAG SPARE SOFTWARE PARAMETER</u>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF12442257978L05	VMUX SPARE SFTWARE R19.8+	1
<u>3Q10-S52-AAD BASE APPLICATION SOFTWARE</u>		
<i>BASE APPLICATION SOFTWARE</i>		
ACSA12222204147L12	CMP - VMUX - BASE APP SW	1
<u>3Q10-S52-BAF BASE CONFIGURATION</u>		
<i>BASE CONFIGURATION</i>		
ACSA13232324532N30	CMP - VMUX - BASE CONFIG	1
<u>3Q10-S52-CAQ SPARE SOFTWARE</u>		
<i>SPARE SOFTWARE</i>		
ACSA13242324528N30	CMP - VMUX -W/O CITY HORN	1
<u>3Q10-S54-AAH CHASSIS MODULE SECONDARY</u>		
<i>CHASSIS MODULE SECONDARY</i>		
ADSA12232204148L12	CMS - VMUX - Base App SW	1
<u>3Q10-S54-BAP CHASSIS MODULE SECONDARY</u>		
<i>CHASSIS MODULE SECONDARY</i>		
ADSA13252387050N30	CMS - VMUX - SPARE SOFTWA	1
<u>3Q10-S54-CAJ CHASSIS MODULE SECONDARY</u>		
<i>CHASSIS MODULE SECONDARY</i>		
ADSA13262387051N30	CMS - VMUX - BASE CONFIG	1
<u>3Q10-S56-AAD MSM APPLICATION SOFTWARE</u>		

MSM APPLICATION SOFTWARE

AGSA12242266560L16 MSM APP SW - VMUX 1

3Q10-S56-BAD MSM PARAMETER FILE*MSM PARAMETER FILE*

AGSA13272135781L12 MSM PAR FILE - VMUX 1

3Q10-S56-CAD MSM PARAMETER FILE*MSM PARAMETER FILE*

AGSA13472135782L12 MSM INSTALL VAR - VMUX 1

3Q10-S58-AAK INSTALLATION VARIANT - RH STALK*INSTALLATION VARIANT - RH STALK*AHSA13942153933L12 RHS W/ ENG BRK W/O PAT- 1
VM**3Q10-S58-BAD RHS APPLICATION SOFTWARE***RHS APPLICATION SOFTWARE*

AHSA13972277283M15 RHS BASE SOFTWARE DNRP 1

3Q10-S58-CAD RHS FLASH/BOOT LOADER -VMUX*RHS FLASH/BOOT LOADER -VMUX*

AHSA13932204801L12 RHS FLASH LOADER - VMUX 1

3Q10-S58-HAF (1291) INSTALLATION VARIANTS SWS*(1291) INSTALLATION VARIANTS SWS*APSB12912257983M40 W/O TOGGLE SWITCH W/O 1
VRS**3Q10-S60-AAK VEHICLE CONTROLLER SW***VEHICLE CONTROLLER SW*

AQSG10272395936N40 DD 15 VEH CONTROLLER SW 1

3Q10-S60-BAK APPLICATION CONTROLLER SW*APPLICATION CONTROLLER SW*

AQSG10282395938N40 DD 15 APP CONTROLLER SW 1

3Q10-S60-CAK EVENT & SOUND DATABASE*EVENT & SOUND DATABASE*

AQSG10292395940N40 DD 15 EVENT & SOUND SW 1

3Q10-S60-DAP CONTROL SWITCH IV*CONTROL SWITCH IV*

AQSG10012264322N40 DD 15 STEERING SWITCH 1

3Q10-S60-EAP DISPLAY CONFIG IV*DISPLAY CONFIG IV*

AQSG10022264323N40 DD 15 SNGL DISPLAY CONFG 1

3Q10-S60-FAK SPARE IV*SPARE IV*

AQSG10032273282N40 DD 15 SPARE IV (1003) 1

3Q10-S60-GAK SPARE IV*SPARE IV*

AQSG10042273283N40 DD 15 SPARE IV (1004) 1

3Q10-S60-HAK SPARE IV*SPARE IV*

AQSG10052273284N40 DD 15 SPARE IV (1005) 1

3Q10-S60-JAK SPARE IV*SPARE IV*

AQSG10062273285N40 DD 15 SPARE IV (1006) 1

3Q10-S60-KDF DIV & ENG CONFIG*DIV & ENG CONFIG*

AQSG10502330351N40 DD 15 X15 X1 PRODUCTIVIT 1

3Q10-S60-LAK PARAMETER IMG FILE*PARAMETER IMG FILE*

AQSG10572395942N40 DD 15 PARAMETER IMG FILE 1

3Q10-S60-MAK SPP VER / REV*SPP VER / REV*

AQSG12322318688N40 DD 15 SPP VER / REV 1

3Q10-S60-NBL TRANS SW CONFIG*TRANS SW CONFIG*

AQSG12872330357N40 DD 15 MANUAL TRANS 1

3Q10-S60-PAK FLASH LOADER*FLASH LOADER*

AQSG15742298998N40 DD 15 FLASHLOADER 1

3Q10-S60-QAK HARDWARE SECURITY MODULE*HARDWARE SECURITY MODULE*AQSG15772273286N40 DD 15 HW SECURITY 1
MODULE**3Q10-S60-RAK APP BOOT LOADER***APP BOOT LOADER*

AQSG15782389685N40 DD 15 APPL BOOT LOADER 1

3Q10-S60-SAK VEH BOOT LOADER*VEH BOOT LOADER*

AQSG15792298997N40 DD 15 VHCL BOOT LOADER 1

3Q10-716-GAD VMUX-INSTRUMENTATION CONTROL*VMUX-INSTRUMENTATION CONTROL**P97-6779 INSTL - VECU MODULE*

Q21-1139-019-019 CONTROL -VECU 1

S34-6003-0555TP00B PSD Screw (M5 x 0.80 x 3
55mm), Black**3Q10-716-HAC DRIVER INFO DIGITAL DISPLAY***DRIVER INFO DIGITAL DISPLAY**Q97-6022 INSTL-DIGITAL DISPLAY*

Q43-6104-100-100 Display-Driv Info 15 PB 1

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 4
x 25mm)**3Q10-716-JAC INSTRUMENT CONTROL SWITCH JUMPER***INSTRUMENT CONTROL SWITCH JUMPER**= CONNECT JUMPER FROM LH SIDE OF**D-PANEL TO C-PANEL. DO NOT USE**CONNECTOR JOGA ON D-PANEL,**(TIE BACK) =*

S92-1127-1350 HARNESS - LIN JUMPER 1

3Q20-S21-CAD SOFTWARE - RH STALK*SOFTWARE - RH STALK**= REFERENCE ONLY =*

Q30-6013-0B00 SOFTWARE-RH STALK,CNTRL 1

3Q20-S21-HAC SOFTWARE - BENDIX ABS - ESP MODULE

SOFTWARE - BENDIX ABS - ESP MODULE

P30-1061-0003 SOFTWARE- BENDIX ABS ESP1

3Q21-700-AAD CHASSIS MODULE MOUNTING**CHASSIS MODULE MOUNTING**

A97-6290-100 INSTL-CHASSIS MODL, PRMRY

A97-6290-100 INSTL-CHASSIS MODL, PRMRY

A97-6290-100 INSTL-CHASSIS MODL, PRMRY

A97-6291-100 INSTL-CHASSIS MODL, SECDR

A97-6291-100 INSTL-CHASSIS MODL, SECDR

A97-6291-100 INSTL-CHASSIS MODL, SECDR

PRIMARY CHASSIS MODULE MTG BRACKET

P11-6613 BRACKET- PRIMARY MODULE 1

156-00070 Cable Tie Mount 2

PRIMARY CHASSIS MODULE MTG HARDWARE

W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25)4

SEC CHASSIS MODULE MTG BRACKET

P11-6615 BRACKET- CHAS MOD SEC 1

SEC PRIMARY MODULE BRACKET MTG HDWARE

W34-1159-040 Hex Bolt (M12 x 1.75 x 40mm) 3

W34-1162-012 Flat Washer 6

W20-1028-012 Lock Nut (M12 x 1.75) 3

W20-1028-012 Lock Nut (M12 x 1.75) 3

SEC CHASSIS MODULE MTG HARDWARE

W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25)4

A11-2278-002 Under Rail Bracket 2

156-00070 Cable Tie Mount 2

3R0P-300-AAC CAB KEY KIT**CAB KEY KIT**

R56-6030-000032G000 Cab Release Handle & Ignition Key Kit 1

3R00-701-AAC ELECTRIC WINDSHIELD WIPER -**ELECTRIC WINDSHIELD WIPER -****INTERMITTENT CONTROL**

D95-1035 RTG-WASHER FLUID HOSE

SK17139 INSTAL WIPER

P97-6377 INSTL FIREWALL GROMMET

D95-1035 RTG-WASHER FLUID HOSE

NOTE: WATER BOTTLE MTD ON

COOLING MODULE

E006-246 MOTOR-WIPER ASSY 1.9M FAM 1

R74-6007 Wiper Linkage Kit 1

R23-6002 Wiper Arm Assembly, LH 2

W000024652 Wiper Blade (450mm) 2

18-02864 Tee Fitting, Hose 1

GW249 Wet Arm Adapter Assy 2

Y84-6000-016 Tie Strap, Button Head 2

28-00194 Grommet - Firewall 1

28-00096-004 Windshield Washer Fluid 1

28-00096 ANTI FREEZE WINDSHIELD 1

22-01149-008	Cushioned Clamp, (1/2")	4
26-01773-140	Hose, Low Pressure, (5/32" x 1 140")	
<i>WASHER BOTTLE TO TEE</i>		
28-00114-3325	TUBING-CONVOLUTED	1
28-00114-0000	TUBING CONVOLUTED NYLON	10.90870
26-01773-032	Hose, Low Pressure, (5/32" x 1 32")	
<i>TEE TO WASHER - LH</i>		
26-01773-003	HOSE, LOW PRESSURE	1
<i>TEE TO WASHER - RH</i>		
<i>HARDWARE FOR WIPER SHAFT TO COWL</i>		
27-00800-006	Screw, Hex Head w/ Washer (1/4-20 x 3/4"), Stainless Steel	4
18-03739	Washer, Wiper Arm, Stainless Steel	2
<i>HARDWARE FOR WIPER MOTOR TO BRKT</i>		
27-00268-003	Bolt (6.35mm x 3/4")	4
27-00428-004	Flat Washer (1/4")	4

3R00-701-BAG ELECTRIC HORN*ELECTRIC HORN**= MOUNT HORN W/ ELECT CONNECTION**ON TOP & OPENING TOWARDS LH SIDE =*

P49-1001-100	HORN - ELECTRIC FIAMM	1
R34-6002-06025RHLZ	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	1

3R00-701-FAC DOOR DEFLECTOR SEAL*DOOR DEFLECTOR SEAL**R97-6461 INSTL-CAB DOOR FOAM*

R42-6203	SEAL-DOOR, DEFLECTOR	2
R42-6203R	SEAL-DOOR, DEFELCTOR	2

3R01-700-ABA CAB HVAC UNIT AND CONTROLS*CAB HVAC UNIT AND CONTROLS**** PETERBILT COMFORT CONTROL ****SK25477 INSTL-AIR COND LABELS**F95-6146 RTG-HVAC SYSTEM CONVENTIONAL**F95-6146 RTG-HVAC SYSTEM CONVENTIONAL**F95-6146 RTG-HVAC SYSTEM CONVENTIONAL**S97-6058 INSTL-HVAC CONTROL HEAD**S97-6375 INSTL-DASH SET, CONVENTION**S97-6372 INSTL-HVAC, CONV DASH**F95-6100 RTG-DRAIN TUBE**P95-6343 RTG-HVAC ACTUATOR HARN**V95-6046 RTG-HVAC AT COOL MODULE**V95-6046 RTG-HVAC AT COOL MODULE**V95-6046 RTG-HVAC AT COOL MODULE**HVAC UNIT & CONTROLS*

S31-6085	Cab HVAC Unit	1
Q21-6119	CONTROL - CAB HVAC, 1.9M	1

Q27-6015	Sensor & Harness Assembly	1
<i>LABELS & DECALS</i>		
F53-6011	Decal, Heater Core Water Supply	1
9771	Adhesive - Anchors, Tie Strap	1
<i>MTG HDWE FOR HTR TO L-BRACKET</i>		
S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black	2
<i>MTG HDWE FOR HVAC TO CROSSCAR</i>		
S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black	2
<i>MTG HDWE FOR FLOOR DUCT</i>		
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	2
<i>MTG HDWE FOR DEFROST DUCTING</i>		
W01-10-07P08N019B	Pan Head Screw (#10-14 x 3/4"), Black	3
<i>MTG HDWE FOR HTR/AC TO FIREWALL</i>		
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	5
W20-1027	NUT - NGP DOOR HINGE	1
<i>MTG HDWE FOR INLET DUCT ON CAB</i>		
27-01426-006	Pan Head Thread Rolling Screw (#10-24 x 3/4")	8
<i>HVAC UNIT DRAIN ELBOW & DUCKBILLS</i>		
F04-6012	ELBOW-DRAIN TUBE	2
<i>ADHESIVE ANCHOR FOR WIRE ROUTING</i>		
9771	Adhesive - Anchors, Tie Strap	1
== USE ANCHOR TO ATTACH FRESH RECIRC WIRES TO A/C CASE, AWAY FROM FILTER. ==		

3R01-700-BAJ FIREWALL MOUNTED HARDLINES

<i>FIREWALL MOUNTED HARDLINES</i>		
<i>F95-6146 RTG-HVAC SYSTEM CONVENTIONAL</i>		
<i>F97-6402 INSTL-LINES HVAC HEAVY</i>		
<i>F97-6402 INSTL-LINES HVAC HEAVY</i>		
<i>F95-6122 RTG-HVAC FIREWALL LOW PRESS</i>		
F50-6530-20225	HVAC Suction Hardline Assembly (#12 x 225mm)	1
== TXV TO DRIVER SIDE COMPRESSOR ==		
F50-6546-0235	Hardline Assembly (#6 x 235mm)	1
== RECEIVER DRIER TO CAB TXV ==		
W34-6027-020	Cap Screw, Socket Head (M6 x 1 x 20mm)	1
<i>HARDWARE FOR MTG HARDLINE TO FIREWALL</i>		
R34-6002-06025RHLZ	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	1
K077-123-10	Cushioned Clamp (5/8")	1
D16-6003-7611110	Cushioned Clamp (5/8")	1

3R01-700-CAJ RADIATOR REFRIGERANT HOSES

RADIATOR REFRIGERANT HOSES**SK27355 INSTALL COMPRESSOR FITTINGS**

F97-6402 INSTL-LINES HVAC HEAVY

F97-6402 INSTL-LINES HVAC HEAVY

F97-6402 INSTL-LINES HVAC HEAVY

F97-6402 INSTL-LINES HVAC HEAVY

F95-6146 RTG-HVAC SYSTEM CONVENTIONAL

F95-6146 RTG-HVAC SYSTEM CONVENTIONAL

F95-6146 RTG-HVAC SYSTEM CONVENTIONAL

F95-6146 RTG-HVAC SYSTEM CONVENTIONAL

F50-6527-050000	HVAC Liquid Hardline	1
	Assembly (#6)	

HARDLINE CONDENSER TO RECEIVER DRIER**CONDENSER HARDLINE SUPPORT BRKT**

K028-2489-18	90° Standoff Bracket	1
--------------	----------------------	---

HARDWARE - HARDLINE TO RECEIVER DRIER

W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25)	1
------------------	------------------------------	---

MOUNTING - LIQUID LINE TO FRAME HDWE

22-01150-006	Hose Clamp, w/ Liner (3/8")	4
--------------	-----------------------------	---

27-00269-005	Hex Bolt (5/16-18 x 1-1/4")	4
--------------	-----------------------------	---

27-00566-005	Lock Nut (5/16")	4
--------------	------------------	---

27-00428-005	Flat Washer (5/16")	8
--------------	---------------------	---

Y84-6000-021	Tie Strap, Dual Loop	3
--------------	----------------------	---

MOUNTING - LIQUID LINE TO RAD SUPPORT

22-01150-006	Hose Clamp, w/ Liner (3/8")	2
--------------	-----------------------------	---

K206-34-15	Hex Screw, Self-Tapping (M6 x 1.00 x 15mm)	2
------------	---	---

22-01150-010	Cushioned Clamp (5/8")	1
--------------	------------------------	---

27-01155	Lock Bolt, w/ Large Flange (1/4-20 x 3/4")	1
----------	--	---

27-00984	U-Nut (1/4-20)	1
----------	----------------	---

HARDWARE - LIQUID LINE TO RAD FITTING

W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	1
------------------	---	---

3R01-700-EAM ENGINE REFRIGERANT HOSES**ENGINE REFRIGERANT HOSES**

F97-6251 INSTL-ISX15 HVAC SUCT

F97-6251 INSTL-ISX15 HVAC SUCT

F50-6472-0300	HVAC Suction Hose Assembly (300mm)	1
---------------	---------------------------------------	---

D16-6003-5412110	Cushioned Clamp (1-1/2")	3
------------------	--------------------------	---

27-01000-006	Lock Nut (M6 x 1.00)	1
--------------	----------------------	---

27-01309-020	Hex Bolt (M6 x 1.00 x 20mm)	1
--------------	-----------------------------	---

27-00428-004	Flat Washer (1/4")	2
--------------	--------------------	---

F11-6482	Bracket - Suction Line	2
----------	------------------------	---

27-00268-004	Hex Bolt (1/4-20 x 1")	2
--------------	------------------------	---

27-00984	U-Nut (1/4-20)	2
----------	----------------	---

27-00562-004	Spring Lock Washer (1/4")	2
--------------	---------------------------	---

27-00428-004	Flat Washer (1/4")	2
--------------	--------------------	---

F11-1687	PB8 BRACKET HVAC SUCT LI	1
----------	--------------------------	---

K041-805-20CA		
---------------	--	--

Locking Hex Bolt (M6 x 1.00 x 20mm)		1
W34-1162-010	Washer (10MM)	1
W34-1163-030	Hex Bolt (M10 x 1.50 x 30mm)	1
27-00428-008	Plain Washer (1/2")	2
K041-833-30CA	Hex Bolt, Lock (M12 x 1.75 x 30mm)	2
K363-338-2-250	Flat Washer (1/4")	1
K169-163-6CA	Hex Nut, Steel (M3)	1

3R10-S01-AAC COMPRESSOR AND MOUNTING

COMPRESSOR AND MOUNTING

D97-1244 INSTL 2010 ISX ENG ACC

F69-6007-122	COMPRESSOR-A/C, O-RING	1
27-00944-100	Hex Bolt (M8 x 1.25 x 100mm)	4
27-00790-005	Flat Washer (5/16")	4

3R10-700-DGC CAB STRUCT-LWR FRT,DUAL COWL MTD CLNR,

CAB STRUCT-LWR FRT,DUAL COWL MTD CLNR,

ALUMINUM FIREWALL

R93-6002 ASSY-SLEEPER CAB, HIGH ROOF

SK24742 INSTL-HOOD SUPPORT SHIM

R64-6193-105	Cab Firewall Assembly	1
27-00793	Magna Grip Pin (3/16")	67
K169-244-6-42	Closed End Hex Nut (M6 x 1.00)	21
MGCS-R6U	Huck Collar (3/16")	67
R22-6020	Wiper Motor Recess	1
R22-6342-200	Firewall Recess Cover	1
R40-6040-100	Front Floorsheet, Aluminum	1
R64-6194-105	Cab Firewall	1
20-15322	Dash Support Gasket	2
20-16303R	Dash Support Bracket, RH	1
20-16303L	Dash Support Bracket, LH	1
13-04386	Shim, Hood Support	2
27-00799	Magna Grip Pin (1/4")	8
MGCW-R8U	Huck Collar (1/4")	8

3R10-701-BAC HEATER HOSES

HEATER HOSES

D95-6113 ROUTING-ISX HEATER HOSES

D95-6113 ROUTING-ISX HEATER HOSES

D95-6113 ROUTING-ISX HEATER HOSES

F95-6121 RTG ISX HTR HOSE ELBOW FIREWL

D95-6113 RTG ISX HTR HOSES

F97-6306 INSTL-COMMON RETURN MANIFOLD

F97-6306 INSTL-COMMON RETURN MANIFOLD

D97-6232 INSTL-CRM FITTING

D95-6194 RTG-HOSE, HEATER, CAB

D95-6194 RTG-HOSE, HEATER, CAB

G97-6372-000 INSTL-MUX SOLENOID BRKT

F50-1016-2-0225

Silicone Heater Hose, Blue 1
(225mm)
ENGINE TO CAB
CLAMPS AND MISC
F50-6561 Coolant Hose Elbow Assembly 2
05-11700-024 Hose Clamp (1-1/2") 1
933-240-10G Band Clamp Constant Tension 1
933-240-10G Band Clamp Constant Tension 1
933-240-10G Band Clamp Constant Tension 1
CAB HEATER RETURN SUPPORT HARDWARE
HDM400B Cable Tie Mount, High Torque 1
W34-1159-020 BOLT-FINISHED,HEX-M12 1
27-00304-008 Lock Washer (1/2") 1
W34-1162-012 Flat Washer 1
CRM RETURN HOSE
Y84-6000-016 Tie Strap, Button Head 1
COOLANT RETURN FITTING
D2006-6247 FITTING-90 DEGREE 1 1/4 1
CAB HEATER HOSE SUPT-BACK OF ENG HEAD
09-033-012A-M0 CLIP-BEAM, OUT 5/16-1/2 1
27-01340-020 Hex Bolt, Lock (M10 x 1.50 x 1
20mm)
27-00562-007 Spring Lock Washer (7/16") 1
D11-6285 Standoff Bracket 1

== RTE CAB HTR RTRN PER HOSE HTR RTG ==

== RTE CAB HTR RTRN PER HOSE HTR RTG ==

3R10-701-CCL HEATER HOSES - SILICONE HOSE

HEATER HOSES - SILICONE HOSE

F97-6306 INSTL- COMMON RETURN MANIFOLD

F97-6306 INSTL- COMMON RETURN MANIFOLD

F95-6133 RTG-HTR HOSE, SLPR/APU RETN

TRANS OIL COOLER RETURN HOSE

05-11700-012 Hose Clamp (3/4") 1

CRM ROUTING

09-033-012A-M0 CLIP-BEAM, OUT 5/16-1/2 1

3S0P-750-AAC DASH ASSY

DASH ASSY

= *WITHOUT CB MOUNT* =

= *WITHOUT ELEC ACCESORY BRKT* =

= *STANDARD NAME PLATE* =

= *STANDARD BLACK* =

= *WITH LIGHTER/POWER PORT* =

= *GRAY & ASHTRAY* =

S62-6205-000112111 DASH-ASSEMBLY,PNG 1

3S00-750-AAC GLOVE BOX ASSEMBLY

GLOVE BOX ASSEMBLY

S10-6013-11281 Glovebox Assembly, Dark 1
Gray

HDWE FOR MTG GLOVE BOX TO ASSY TO DASH

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 4
x 25mm)

3S00-750-BAC DASH SECONDARY STRUCTURE*DASH SECONDARY STRUCTURE**S97-6372 INSTL-HVAC, CVNTL DASH**S97-6378 INSTL-DASH WINDLACE**S97-6375 INSTL-DASH SET, CONV**R97-6425 INSTL-BRKT, CHARGE START**SECONDARY STRUCTURE*

S85-6039	SUPPORT - STEERING COLUMN	1
S85-6040	BRACE - HVAC & STEERING	1
S07-6027	Beam-Cross Car,Assy	1
S46-6014	GUARD-WIPER MOTOR, CAB HA	1
R64-6217	BULKHEAD NUT AND GASKET	1

CHARGE START BRKT TO FIREWALL HDWR

R34-6002-08045RHKL	Exterior Threaded Hex Screw (M8 x 1.25 x 45mm)	2
--------------------	--	---

COLUMN SUPT TO L-BRKT HARDWARE

S34-6003-0830RHLOB	Hex Lock Screw (M8 x 1.25 x 230mm), Black	
--------------------	---	--

L-BRKT TO CROSS CAR BEAM HARDWARE

S34-6003-0830RHLOB	Hex Lock Screw (M8 x 1.25 x 130mm), Black	
--------------------	---	--

COLUMN SUPT TO CROSS BEAM HDWR

S34-6003-0830RHLOB	Hex Lock Screw (M8 x 1.25 x 230mm), Black	
--------------------	---	--

DASH TO CROSS CAR BEAM HARDWARE

S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black	6
--------------------	-------------------------------------	---

DASH TO CTR CONSOLE BRKT HARDWARE

S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black	2
--------------------	-------------------------------------	---

DASH TO BEAM BRKTS HARDWARE

S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	1
--------------------	-------------------------------------	---

DASH TO DOGHOUSE HARDWARE

W34-6004-025	Screw - Machine (M5 X 0.80 X 25mm)	3
--------------	------------------------------------	---

DASH TO STRUCTURE HARDWARE

R34-6002-10042RH0M	Exterior Threaded Hex Screw (M10 x 1.50 x 42mm)	4
--------------------	---	---

DASH TO COWL HARDWARE

S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	10
--------------------	-------------------------------------	----

DASH WINDLACE

28-00013-013	Edge Guard, Black (1")	2
28-00013-010	WINDLACE BLACK 10IN	1
28-00013-010DB	WINDLACE-BEBURRED	1

DASH WRG SHIELD TO L-BRKT HARDWARE

S34-6003-0630TP00B		
--------------------	--	--

PSD Screw (M6 x 1.00 x 30mm), Black	2
<i>HARNESS SUPPORT</i>	
S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black 3
A62-6084	Cable Tie Mount 1
S11-6446	BRACKET-HARNESS SUPPORT 2

3S00-750-CAC DASH TRIM*DASH TRIM*

S18-6059-281	Bezel Lower Dash, 1.9VMUX 1
S60-6106-281	RH Dash Trim Strip, Dark Gray 1
S60-6350-300	Trim-Strip , A-B Joint 1
P22-6036-281	CAP-DIAGNOSTIC CONNECTOR 1

3S00-752-AAC A-PANEL*A-PANEL*

<i>S97-6376 PANEL INSTALL - A, B, C, D</i>	
S64-6324-100	Panel-A, Assy Charcoal 1

3S00-752-BAC B-PANEL*B-PANEL*

<i>S97-6376 INSTL-PANEL, A, B, C, D</i>	
S64-6308-100	Panel-B,Charcoal 1

3S00-752-CAD C-PANEL*C-PANEL*

<i>S97-6376 INSTL-PANEL, A, B, C, D</i>	
<i>S97-6374 INSTL-SWITCH PLATE</i>	
S64-6342-200	C-Panel Assembly, Gray 1
S64-6296	Panel-C,Switch Plate 1

3S00-752-DBE D-PANEL*D-PANEL*

<i>S97-6374 INSTL-SWITCH PLATE</i>	
<i>S97-6376 INSTL-A,B,C,D</i>	
S64-6309-200	Panel-D, Gray 1
S64-6328	Panel-D,L Switch Plate 1

3S00-752-EAC COMMON PARTS/HARDWARE*COMMON PARTS/HARDWARE**A PANEL HARDWARE*

W01-10-01P55N025B	Pan Head Screw (M5 x 0.80 x 1 25mm), Black
W01-10-01F55N025B	SCREW-PSD, FLAT HD, M5X25 1
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm) 2

B PANEL HARDWARE

S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm) 3
W01-10-01F55N025B	SCREW-PSD, FLAT HD, M5X25 1

C PANEL HARDWARE

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 5
x 25mm)

D PANEL HARDWARE

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 9
x 25mm)

3S00-756-AAD DASH SWITCH POCKET

DASH SWITCH POCKET

S97-6377 INSTL-SWITCH POCKET

S18-6068 Bezel-Tilted Switch,4 2

3S00-756-BAE DASH SWITCH PLUGS

DASH SWITCH PLUGS

S97-6377 INSTL-SWITCH POCKET

S67-6007 Plug - Switch, PB Dash 3

3S10-701-AAF SHIFTER PLATE

SHIFTER PLATE

S22-6041M01-218 COVER-SHIFTER,PLATE 1

05-17811-238 PLATE-SHIFTER ALUM 1

05-17812-196 INSULATOR-FOAM SHIFTER
PLATE 1

27-01429-012 Truss Head Screw, Thread 12

Rolling (1/4-20 x 1-1/2")

27-00984 U-Nut (1/4-20) 12

3S10-701-BAS CAB FIREWALL INSULATION

CAB FIREWALL INSULATION

S72-6019-009 Kit-Insulation, Firewall 1

3Y00-300-AAW CARB IDLE LABEL

CARB IDLE LABEL

R97-6133 INSTL EMISSIONS LABEL

5259894 DECAL-CLEAN IDLE, CARB 1

NOTE: INSTALL LABEL THEN SCAN

LABEL SERIAL NUMBER

3Y00-300-BAC FLAG & FLARE KIT W/ TRIANGULAR RFLTR

FLAG & FLARE KIT W/ TRIANGULAR RFLTR

S74-1008 REFLECTOR - KIT, WITH HOL 1

3Y00-300-CBH FIRE EXTINGUISHER

FIRE EXTINGUISHER

5LB FIRE EXTINGUISHER

= FIRE EXTINGUISHER TO BE SHIPPED

LOOSE IN CAB =

= LEAVE FIRE EXTINGUISHER IN BOX =

S86-6000 EXTINGUISHER-FIRE,5.5 LB 1

3Y00-300-DUR OPERATION MANUAL

OPERATION MANUAL

Y53-6076-1D1 Manual - Operator Conv, E 1

3Y00-300-EAC WELDING & DO NOT STEP WARNING LABELS

WELDING & DO NOT STEP WARNING LABELS

A95-6013 INSTL DECALS EOF & BOC/BOS

A95-6013 INSTL - DECALS EOF & BOC/BOS

A53-1001-10 LABEL-CHASSIS 2

COMBINATION

3Y00-300-FAM REFRIGERANT*REFRIGERANT**SK25477 INSTL A/C LABELS*

R134A	REFRIGERANT	2.90000
18-04467-290	LABEL-AIR	1
	CONDITIONER,R13	
F53-1001	Decal Plate, R134a	1
	Fluorescent Dye	

*NOTE: PLATE TO BE PLACED ON FIREWALL
OR IN CLOSE PROXIMITY TO
CHARGE LABEL.*

BARCODE

*R134A 46.4 OZ
(2.90 LBS)*

3Y00-300-HAG MICHELIN FRONT TIRE WARRANTY PAMPHLET*MICHELIN FRONT TIRE WARRANTY PAMPHLET*

NOTE - PLACE PAMPHLET IN GLOVE BOX

9152	PAMPHLET-WARRANTY	1
	MICHELI	

3Y00-300-VAC GHG COMPLIANCE LABEL*GHG COMPLIANCE LABEL**S97-6179-000 INSTL-LABEL GHG**S97-6185 INSTL-GHG LABEL*

S53-6198	LABEL- GREEN HOUSE GAS	1
----------	------------------------	---

3Y00-300-YAC STABILITY CONTROL MANUAL*STABILITY CONTROL MANUAL*

BENDIX ABS MANUAL - INSTL IN GLOVE BOX

BW2489	ABS 6 Bendix Manual	1
--------	---------------------	---

3Y00-300-ZAC STABILITY CONTROL LABEL*STABILITY CONTROL LABEL**G97-6277 DASH LABEL INSTL**G97-6078 CHASSIS LABEL INSTL**G97-6190 STRG COLUMN LABEL INSTL**G97-6058 VISOR LABEL INSTL*

S53-6208-100	LABEL-DASH, ESP - ENGLISH	1
--------------	---------------------------	---

A53-6025-100	LABEL-CHASSIS, STABILITY	2
--------------	--------------------------	---

J53-6003-100	Steering Column Label,	1
--------------	------------------------	---

English

G53-6029-100	Stability Control Label,	1
--------------	--------------------------	---

English

3Y00-301-AAD REFERENCE CARD-WARNING ICONS*REFERENCE CARD-WARNING ICONS*

= NO SUPPLEMENT NEEDED =

3Y00-301-CAC QR CODE LABEL*QR CODE LABEL**S97-6067 INSTL-LABELS, CAB*

S53-1330	LABEL - SERV MGMT QR	1
	CODE	

3Y00-301-EAC OPERATORS MANUAL - WHEELS*OPERATORS MANUAL - WHEELS*

ALCOA WHEELS
GAXLT0RG1 WHEEL SERVICE & OP 1
MANUAL

3Y00-301-JCE ENGINE MANUAL

ENGINE MANUAL
5504581 OWNERS MANUAL - 2020 1
X15

3Y00-301-KAW AFTERTREATMENT MANUAL

AFTERTREATMENT MANUAL
Y53-6091-1E1 MANUAL-AFTERTREATMENT 1
ENG

3Y00-301-PAD DIESEL EXHAUST LABEL

DIESEL EXHAUST LABEL
S97-6323 INSTL-CB MOUNT
= INSTL DIESEL EXH LABEL ABOVE DPF/SCR
LABEL ON DRIVER SUNVISOR =
S53-6190-100 LABEL-DIESEL EXHAUST 1

3Y00-301-TAC GHG SUPPLEMENT

GHG SUPPLEMENT
Y53-6128-1A1 GHG Compliance Requiremen 1

3Y00-301-VAC RP1226 LABEL

RP1226 LABEL
= PLACE LABEL LOOSE W/ OWNERS MANUAL =
S53-6205 LABEL - GLOVE BOX, RP1226 1

3Y00-310-CAD CLEAR RH OUTSIDE FRAME ENG LABOR

CLEAR RH OUTSIDE FRAME ENG LABOR

3Y00-311-MAC ADDITIONAL SENDING UNIT ENG LABOR

ADDITIONAL SENDING UNIT ENG LABOR

3Y00-312-HAC FIXED 5TH WHEEL ENG LABOR

FIXED 5TH WHEEL ENG LABOR

3Y00-312-XAC SYMMETRICAL FUEL TANK ENG LABOR

SYMMETRICAL FUEL TANK ENG LABOR

3Y00-700-BCP LABELS AND DECALS

LABELS AND DECALS
S97-6253 INSTL-WEIGHT LABEL
SK22720 INSTL ACRYLIC
S97-6067 INSTALL CAB LABELS
S97-6067 INSTALL CAB LABELS
NOTE:DO NOT INSTALL BRASS VIN PLATE
ON THE DASH
REFERENCE:FRAME ACCESS LABEL-MFG
0180.002 FOR INSTL
SK13025 LOCATION OF PATENT LABEL
ASSISTANCE
SK09775 GLOVE BOX PACCAR NAME PLATE
S97-6067 INSTL-LABELS, CAB
22-01050 Nameplate, PACCAR 1
S53-1269 LABEL-PB CHASSIS WT 1
22-01616 PLATE SERIAL NUMBER 1
250052YL YELLOW ADHESIVE LABEL 1

S53-1270	LABEL-CLEAR	1
<i>USE AT CHASSIS LUBE STATION</i>		
<i>LABELS INSTALLED ON VEHICLE</i>		
22-01478	LABEL-PAINT DATA	1
22-01540	LABEL BLANK	1
22-01467	LABEL-COMplete VEH FMVSS	1
22-01644	LABEL-CLEAR,SHEET	1
S53-6167	Label-EPA Noise Emission	1
22-01593	DECAL - ROADSIDE	1
	ASSISTAN	
22-01050	Nameplate, PACCAR	1
S53-6140	LABEL-STOCK BLANK	1

3Y00-700-CAC CONSPICUITY SHEETING

CONSPICUITY SHEETING

SK28174 DAY CAB CONSPICUITY

R59-1011	TAPE-RETROREFLECTIVE	4
----------	----------------------	---

3Y00-700-EAC MERCURY WARNING LABEL

MERCURY WARNING LABEL

S97-6067 INSTALL CAB LABELS

S53-1162-100	LABEL-WARN, MERCURY, EN	1
--------------	-------------------------	---

8000-720-AAC ROBOTIC PAINT PROGRAM: 389 CAB

ROBOTIC PAINT PROGRAM: 389 CAB

JOB NAME: 389DAYBASE

BASE CAB ONLY

8000-720-FAU ROBOTIC PAINT PROGRAM 389-123 HOOD

ROBOTIC PAINT PROGRAM 389-123 HOOD

JOB NAME: 389-123 HOOD

BASE HOOD

8100-300-AAC FINAL BOM FOR PAINT

FINAL BOM FOR PAINT

9999-A00-000 VEHICLE PLATE WEIGHT: 0013003 LBS

VEHICLE PLATE WEIGHT: 0013003 LBS

KEY NUMBER: G371