DYNAPAC

Part of the Atlas Copco Group

Dealer No. Händlernummer	Dealer Händler
213010	*ATLAS COPCO FORAGE*
Order No. Auftragsnummer	**Delivery Date Lieferdatum**
0000026937	*05.06.2012*
Paver Type Fertiger Typ	**Paver PIN Fertiger PIN**
SD 2500 C	*10002116K0G000841* *
Screed Type Bohle Typ	**Screed Serial No. Bohle Seriennummer**
V 5100 TV	*3100856*
Engine Verbrennungsmotor	**Engine Serial No. Motor-Seriennummer**
CUMMINS QSB6.7 129KW TIER3 PB	*22024976*

= PC Sequence number
(To be used to find the machine in PartsBase system / Bitte verwenden zur Identifikation der Maschine im PartsBase - System)

Please take care of the following hints:
Bitte beachten Sie folgende Hinweise:

When ordering spares, please clearly state the following details:

1. Serial number of the machine.
2. Type and number of the screed (for finishers).
3. Number and description of the spares.
4. Quantity of each spare.
5. Method of despatch desired.
6. Adress, destination and railway station.

- Please use only original spare parts on Dynapac equipment. If other spare parts are used, no warrenty will be accepted.
- Please check the options mounted on your machine before placing an order.
- If there are further questions please contact us by phone +49 44 07 97 2-0.

Bei Bestellungen bitten wir um folgende Angaben:

1. Die Seriennummer der Maschine.
2. Typ und Nummer der Bohle bei Fertigern.
3. Nummer und Bezeichnung der Ersatzteile.
4. Anzahl der Ersatzteile.
5. Gewünschte Versandart.
6. Anschrift, Bestimmungsort und Bahnstation

- Bitte verwenden Sie nur Originalteile. Bei Verwendung anderer Ersatzteile erlischt jeglicher Garantieanspruch.
- Bitte vor Bestellung unbedingt beachten, welche Optionen Ihre Maschine beinhaltet.
- Bei Fragen erreichen Sie uns unter Tel.: +49 44 07 97 2-0.