

JEFTOMSON TRAILER SERVICEChassis No: Kilometres: 937959 Date Inspected: 22-01-24Rego: 0131-S6TOTAL H2 410165FRONT MOTOR ENGINE H2 #10032

Mechanic to inspect, make adjustments, tighten, on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

		Tech Init.																			
1.	Grease and check condition of all grease points	☒	☒																		
2.	Check operation and condition of all lights, reflectors and safety signals	☒	☒																		
3.	Check condition of all brake components	☒	☒																		
4.	Check and adjust brakes <u>AUTO</u>	☒	☒																		
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th>%</th> <th>R</th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td>Middle</td> <td>L</td> <td><u>75</u></td> <td>%</td> <td><u>75</u></td> </tr> <tr> <td></td> <td>Rear</td> <td>L</td> <td>%</td> <td>R</td> <td>%</td> </tr> </tbody> </table>				Brake % Report	Front	L	%	R	%		Middle	L	<u>75</u>	%	<u>75</u>		Rear	L	%	R	%
Brake % Report	Front	L	%	R	%																
	Middle	L	<u>75</u>	%	<u>75</u>																
	Rear	L	%	R	%																
5.	Check all air hoses & fittings	☒	☒																		
6.	Drain all air tanks	☒	☒																		
7.	Check turntable and King Pin for movement	☒	☒																		
8.	Grease and check landing legs	☒	☒																		
9.	Inspect all suspension components	☒	☒																		
10.	Check chassis for cracks and fatigue	☒	☒																		
11.	Check wheel bearings for movement	☒	☒																		
12.	Check condition of tyres rims and hubs	☒	☒																		
13.	Check and report on condition of safety signs	☒	☒																		
Please list any faults found																					
<u>NEED TO PERFORMS WATER AUGMENT</u>																					
<u>NEED TO REPAIR AN SHOCKERS</u>																					

Leading Hand / Mechanic: JOFFAY Date: 22-01-24

Chassis No:..... Kilometres: 924271 Date Inspected: 20-11-23
 Rego: 0131-S6 total HZ \$10000 new
FRING MOTOR ENGINE HZ \$9800 SLX 5400
 Mechanic to inspect, make adjustments, tighten, on all operations listed.
 Consult applicable service information for adjustments and specification.

								Tech Init.																						
1.	Grease and check condition of all grease points						—	✓																						
2.	Check operation and condition of all lights, reflectors and safety signals						—	✓																						
3.	Check condition of all brake components						—	✓																						
4.	Check and adjust brakes						—	✓																						
<table border="1"> <tr> <td rowspan="3">Brake % Report</td> <td>Front</td> <td>L</td> <td>85</td> <td>%</td> <td>R</td> <td>85</td> <td>%</td> </tr> <tr> <td>Middle</td> <td>L</td> <td></td> <td>%</td> <td>R</td> <td></td> <td>%</td> </tr> <tr> <td>Rear</td> <td>L</td> <td></td> <td>%</td> <td>R</td> <td></td> <td>%</td> </tr> </table>									Brake % Report	Front	L	85	%	R	85	%	Middle	L		%	R		%	Rear	L		%	R		%
Brake % Report	Front	L	85	%	R	85	%																							
	Middle	L		%	R		%																							
	Rear	L		%	R		%																							
5.	Check all air hoses & fittings						—	✓																						
6.	Drain all air tanks						—	✓																						
7.	Check turntable and King Pin for movement						—	✓																						
8.	Grease and check landing legs						—	✓																						
9.	Inspect all suspension components						—	✓																						
10.	Check chassis for cracks and fatigue						—	✓																						
11.	Check wheel bearings for movement						—	✓																						
12.	Check condition of tyres rims and hubs						—	✓																						
13.	Check and report on condition of safety signs						—	✓																						
Please list any faults found broken front door (VH) front motor over drive																														

loading Hand / Mechanic: Date: 24-11-23

JEFTOMSON TRAILER SERVICE

Chassis No: Kilometres: **896759** Date Inspected: **12-7-23**

Rego: **0131-SG** TOTAL HR # **9640**

FRIDGE MOTOR ENGINE HR # 9508
 Mechanic to inspect, make adjustments, tighten, on all operations listed.
 Consult applicable service information for adjustments and specification.
 Tick = OK A = Adjust R = Repair

		Tech Init.
1.	Grease and check condition of all grease points	JP
2.	Check operation and condition of all lights, reflectors and safety signals	JB
3.	Check condition of all brake components	JB
4.	Check and adjust brakes ADJ	JB

Brake % Report	Front	L	%	R	%
	Middle	L	90	90	%
	Rear	L	90	90	%

5.	Check all air hoses & fittings	JB
6.	Drain all air tanks	JB
7.	Check turntable and King Pin for movement	JB
8.	Grease and check landing legs	JB
9.	Inspect all suspension components	JB
10.	Check chassis for cracks and fatigue	JB
11.	Check wheel bearings for movement	JB
12.	Check condition of tyres rims and hubs	JB
13.	Check and report on condition of safety signs	JB

FRIDGE MOTOR AND INSIDE VAN HAVE CHECK.

Please list any faults found

SIDE LIGHT NOT WORKING
14 INDICATOR NOT WORKING.

Copy

12-7-23

JEFTOMSON TRAILER SERVICEChassis No: Kilometres: 889757 Date Inspected: 17-5-23Rego: 0131-S6 TOTAL # 9560
FRONT ENG. # 9428

Mechanic to inspect, make adjustments, tighten, on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

		Tech Init.																									
1.	Grease and check condition of all grease points	-	JB																								
2.	Check operation and condition of all lights, reflectors and safety signals	-	JB																								
3.	Check condition of all brake components	-	JB																								
4.	Check and adjust brakes	-	JB																								
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th>%</th> <th>R</th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td>90</td> <td>90</td> <td>%</td> </tr> <tr> <td></td> <td>Middle</td> <td>L</td> <td>90</td> <td>90</td> <td>%</td> </tr> <tr> <td></td> <td>Rear</td> <td>L</td> <td>90</td> <td>90</td> <td>%</td> </tr> </tbody> </table>				Brake % Report	Front	L	%	R	%				90	90	%		Middle	L	90	90	%		Rear	L	90	90	%
Brake % Report	Front	L	%	R	%																						
			90	90	%																						
	Middle	L	90	90	%																						
	Rear	L	90	90	%																						
5.	Check all air hoses & fittings	-	JB																								
6.	Drain all air tanks	-	JB																								
7.	Check turntable and King Pin for movement	-	JB																								
8.	Grease and check landing legs	-	JB																								
9.	Inspect all suspension components	-	JB																								
10.	Check chassis for cracks and fatigue	-	JB																								
11.	Check wheel bearings for movement	-	JB																								
12.	Check condition of tyres rims and hubs	-	JB																								
13.	Check and report on condition of safety signs	-	JB																								
Please list any faults found																											
NOTE: NOT RUNNING																											
NO TAIL LIGHT (MISSING) BAR																											

Leading Hand / Mechanic: Jeffery Date: 17-5-23

Der- 07-0506-20/1118 (R42)

1995, 1996, 1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 26

SPORTS

877023

Date inserted _____

13-1-23

1997:

0131-56

70772 NR # 9411

FLIDGE MOTOR ENGINE # 9279

Mechanic to inspect, make adjustments, tighten, on all open...

Consult applicable service information for adjustments and torque values.

— Tick = OK — A = Adjust R = Repair

				Tech int.									
1	Grease and check condition of all grease points			✓	VB								
2	Check operation and condition of all lights, reflectors and safety signals			✓	VB								
3	Check condition of all brake components			✓	VB								
4	Check and adjust brakes			✓	VB								
Brake % Report <table border="1"> <thead> <tr> <th></th> <th>Front</th> <th>Middle</th> <th>Rear</th> </tr> </thead> <tbody> <tr> <td>95</td> <td>95</td> <td>95</td> <td>95</td> </tr> </tbody> </table>							Front	Middle	Rear	95	95	95	95
	Front	Middle	Rear										
95	95	95	95										
5	Check all air hoses & fittings			✓	VB								
6	Drain all air tanks			✓	VB								
7	Check turntable and King Pin for movement			✓	VB								
8	Grease and check landing legs			✓	VB								
9	Inspect all suspension components			✓	VB								
10	Check chassis for cracks and damage			✓	VB								
11	Check wheel bearings for movement			✓	VB								
12	Check condition of tyres rims and hubs			✓	VB								
13	Check and report on condition of safety signs			✓	VB								

Page 4 of 4

FROM SUZ1 COMPANY IS WORK OUT
BIG CUT ON THE MIDDLE TAKE OUTER

~~Electronics~~ **Mechanics**

JOFFRY

Date _____

13-1-23

OUTSIDE INSIDE OF - TEARER

Check Fluids Motion

JEFTOMSON TRAILER SERVICE

Chassis No:

Kilometres:

Date Inspected:

Rego:

0131-SL

PRIMO MOTOR

TOTAL HR # 9030

PRIMO HR 8952

Mechanic to inspect, make adjustments, tighten, on all operations listed.
Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

		Tech Init.																													
1.	Grease and check condition of all grease points	✓	VB																												
2.	Check operation and condition of all lights, reflectors and safety signals	✓	VB																												
3.	Check condition of all brake components	✓	VB																												
4.	Check and adjust brakes	✓	VB																												
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th>R</th> <th>%</th> <th>R</th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td>70</td> <td></td> <td>70</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>60</td> <td></td> <td>60</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>65</td> <td></td> <td>65</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>				Brake % Report	Front	L	R	%	R	%		70		70					60		60					65		65			
Brake % Report	Front	L	R	%	R	%																									
	70		70																												
	60		60																												
	65		65																												
5.	Check all air hoses & fittings	✓	VB																												
6.	Drain all air tanks	✓	VB																												
7.	Check turntable and King Pin for movement	✓	VB																												
8.	Grease and check landing legs	✓	VB																												
9.	Inspect all suspension components	✓	VB																												
10.	Check chassis for cracks and fatigue	✓	VB																												
11.	Check wheel bearings for movement	✓	VB																												
12.	Check condition of tyres rims and hubs	✓	VB																												
13.	Check and report on condition of safety signs	✓	VB																												
Please list any faults found KING PIN IS WORN OUT - REPAIRS DONE																															

Leading Hand / Mechanic:

J. Saffery

Date:

7-9-22

PRIMO MOTOR CHECK
CHECK INSIDE OF TRAILER



GRAHAM THOMSON MOTORS



Trailer Service Sheet

RO

521837

Chassis No:

B088631

Kilometres:

Date:

12/05/2022

Customer:

JEFF TOMSONS TRANSPORT P/L

Fleet no:

Rego:

013156

Mechanic to inspect, make adjustment, tighten, correct or add fluids on all operations listed

Consult applicable service information for adjustment specification

Tick = OK A = Adjust R = Repair

Chassis & General

Grease & check All grease points

Check All lights, reflectors & safety signage

Check All brake components

Check & adjust Brakes

Front	L	20	%	R	20	%
Middle	LF	20	%	RF	20	%
Rear	LR	20	%	RR	20	%

Check All air hoses & fittings

Drain All air tanks

Check Turntable and king pin for movement

Grease & check Landing legs

Inspect All suspension components

Check Chassis - cracks and fatigue

Check Wheel bearings for movement

Check Condition of tyre rims and hubs

Tech

✓ Init

Notes

✓ AS	L.H.R Shocker mount has small crack
✓ AS	Turntable refion top have wear
✓ AS	Turntable front bushes 1/2"
✓ AS	Turntable needs to be
✓ AS	snapped and loose bolt on
✓ AS	spare tyre carrier
✓ AS	snapped welds on front crossmember
✓ AS	1/2" M10 x 1.5 x 100mm steel screw
✓ AS	1/2" M10 x 1.5 x 100mm steel screw
✓ AS	2 front axle grease nipples 1/2"
✓ AS	multiple cracks in rear crossmember
✓ AS	safety signs damaged
✓ AS	1/2" brake light missing
✓ AS	
✓ AS	

Job Comments

Technician:

5198

Signature:

Am1

Chassis No. Kilometres: 793,400 Date inspected: 01-03-22
 Rego. 0131-S6 8255 HRS

Mechanic to inspect, make adjustments, tighten, on all operations listed.
Consult applicable service information for adjustments and specifications.
Tick = OK A = Adjust R = Repair

1.	Grease and check condition of all grease points	Technician																					
2.	Check operation and condition of all lights, reflectors and safety signals	CL																					
3.	Check condition of all brake components	CL																					
4.	Check and adjust brakes	CL																					
		autos																					
<table border="1"> <tr> <td rowspan="4">Brake % Report</td> <td>Front</td> <td>L</td> <td>70 %</td> <td>R</td> <td>70 %</td> </tr> <tr> <td>Middle</td> <td>L</td> <td>70 %</td> <td>R</td> <td>70 %</td> </tr> <tr> <td>Rear</td> <td>L</td> <td>70 %</td> <td>R</td> <td>70 %</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table>			Brake % Report	Front	L	70 %	R	70 %	Middle	L	70 %	R	70 %	Rear	L	70 %	R	70 %					
Brake % Report	Front	L		70 %	R	70 %																	
	Middle	L		70 %	R	70 %																	
	Rear	L		70 %	R	70 %																	
5.	Check of air hoses & fittings	CL																					
6.	Drain brake tanks	CL																					
7.	Check swivel and King Pin for movement	CL																					
8.	Grease and check landing legs	CL																					
9.	Inspect all suspension components	CL																					
10.	Check chassis for cracks and fatigue	CL																					
11.	Check wheel bearings for movement	CL																					
12.	Check condition of tyres rims and hubs	CL																					
13.	Check and report on condition of safety signs	CL																					

Please list any faults found:

chassis cracks, shocks loose, left side rear side machine

Leading Hand / Mechanic: W Date: 1/3/22

JEFTOMSON TRAILER SERVICE

Chassis No: Kilometres: ~~8090~~ ⁸⁰¹⁵ Date inspected: 21-01-22
 Rego: 0131-SG

Mechanic to inspect, make adjustments, tighten, on all operations listed.
 Consult applicable service information for adjustments and specification.
 Tick = OK A = Adjust R = Repair

1.	Grease and check condition of all grease points	Technic
2.	Check operation and condition of all lights, reflectors and safety signals	CL
3.	Check condition of all brake components	CL
4.	Check and adjust brakes	CL

Brake % Report	Front	L	R	%	R	%
	Middle	L	R	75	75	%
	Rear	L	R	75	75	%

5.	Check all air hoses & fittings	
6.	Drain all air tanks	CL
7.	Check turntable and King Pin for movement	CL
8.	Grease and check landing legs	CL
9.	Inspect all suspension components	CL
10.	Check chassis for cracks and fatigue	CL
11.	Check wheel bearings for movement	CL
12.	Check condition of tyres rims and hubs	CL
13.	Check and report on condition of safety signs	CL

Please list any faults found

hwb mepa
 rear left indicator
 brake light first left light bar
 cracked light bar housing
 front left air hose slight wear
 weeping middle air hub seal
 cross member cracked

Leading Hand / Mechanic: [Signature] Date: 31/01/22

Chassis No: Kilometres: 743,055 Date Inspected: 9-11-21
 Rego: 0131-SG T-7848
 E-7775

Mechanic to inspect, make adjustments, tighten, on all operations listed.
Consult applicable service information for adjustments and specification.
Tick = OK A = Adjust R = Repair

Leading Hand / Mechanic: Date:

JEFTOMSON TRAILER SERVICE

Chassis No: Kilometres: 721,411 Date Inspected: 6/9/21
 Rego: 0131-56 Total - 7538
 Engine - 7466

Mechanic to inspect, make adjustments, tighten, on all operations listed.
 Consult applicable service information for adjustments and specification.
 Tick = OK A = Adjust R = Repair

		Tech Init.																								
1.	Grease and check condition of all grease points	✓																								
2.	Check operation and condition of all lights, reflectors and safety signals	✓																								
3.	Check condition of all brake components	✓																								
4.	Check and adjust brakes <u>auto sticks</u>	✓																								
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th></th> <th>%</th> <th>R</th> <th></th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td>Middle</td> <td>L</td> <td></td> <td>80</td> <td>R</td> <td></td> <td>80</td> </tr> <tr> <td></td> <td>Rear</td> <td>L</td> <td></td> <td>85</td> <td>R</td> <td></td> <td>85</td> </tr> </tbody> </table>			Brake % Report	Front	L		%	R		%		Middle	L		80	R		80		Rear	L		85	R		85
Brake % Report	Front	L		%	R		%																			
	Middle	L		80	R		80																			
	Rear	L		85	R		85																			
5.	Check all air hoses & fittings	✓																								
6.	Drain all air tanks	✓																								
7.	Check turntable and King Pin for movement	✓																								
8.	Grease and check landing legs	✓																								
9.	Inspect all suspension components	✓																								
10.	Check chassis for cracks and fatigue	✓																								
11.	Check wheel bearings for movement	✓																								
12.	Check condition of tyres rims and hubs	✓																								
13.	Check and report on condition of safety signs	✓																								
Please list any faults found <u>new left indicator - ✓</u> <u>new electrical plug - ✓</u> <u>Door pole's bent - ✓</u> <u>right side light has broken - ✓</u> <u>wheeling middle left hub seal - ✓</u> <u>cross member welds cracked - ✓</u> <u>turntable bushes worn - ✓</u> <u>turntable pin - ✓</u> <u>swivel couplings - ✓</u> <u>turntable stop - ✓</u>																										

Leading Hand / Mechanic: Allen Date: 6/9/21

Chassis No: N/A Kilometres: 711,865 km Date Inspected: 1/7/2021
 Rego: 0131-S6 TH: 7339 EH: 7288

Mechanic to inspect, make adjustments, tighten, on all operations listed. Consult applicable service information for adjustments and specification.
Tick = OK A = Adjust R = Repair

Leading Hand / Mechanic: _____ Date: 1/7/2021

JEFTOMSON TRAILER SERVICE

Chassis No: Kilometres: 653609 Date Inspected: 24-3-21Rego 0131-SG 1-7015
E-6944Mechanic to inspect, make adjustments, tighten, on all operations listed.
Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

							Tech Init.																																
1.	Grease and check condition of all grease points						CL																																
2.	Check operation and condition of all lights, reflectors and safety signals						CL																																
3.	Check condition of all brake components						CL																																
4.	Check and adjust brakes <i>auto slack</i>						CL																																
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th></th> <th>%</th> <th>R</th> <th></th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td>90</td> <td>%</td> <td>90</td> <td>%</td> <td></td> </tr> <tr> <td></td> <td>Middle</td> <td>L</td> <td>90</td> <td>%</td> <td>90</td> <td>%</td> <td></td> </tr> <tr> <td></td> <td>Rear</td> <td>L</td> <td>90</td> <td>%</td> <td>90</td> <td>%</td> <td></td> </tr> </tbody> </table>							Brake % Report	Front	L		%	R		%				90	%	90	%			Middle	L	90	%	90	%			Rear	L	90	%	90	%		
Brake % Report	Front	L		%	R		%																																
			90	%	90	%																																	
	Middle	L	90	%	90	%																																	
	Rear	L	90	%	90	%																																	
5.	Check all air hoses & fittings						CL																																
6.	Drain all air tanks						CL																																
7.	Check turntable and King Pin for movement						CL																																
8.	Grease and check landing legs						CL																																
9.	Inspect all suspension components						CL																																
10.	Check chassis for cracks and fatigue						CL																																
11.	Check wheel bearings for movement						CL																																
12.	Check condition of tyres rims and hubs						CL																																
13.	Check and report on condition of safety signs						CL																																
<i>tyre pressure & check inside, fridge</i>							CL																																
Please list any faults found																																							
<i>SL21 couplings ✓</i>																																							
<i>cracked cross member</i>																																							
<i>air leak - booster line ✓</i>																																							
<i>booster rear right</i>																																							
<i>turntable bushes ✓</i>																																							
<i>rear wheel bearing slight movement ✓</i>																																							
<i>water pump belt</i>																																							

Leading Hand / Mechanic: *[Signature]* Date: 26-3-21

JEFTOMSON TRAILER SERVICE

Chassis No: Kilometres: 667,621KM Date Inspected: 4/1/21Rego: 0131-S66737 ENGINE HOURS6807 TOTAL HOURS

Mechanic to inspect, make adjustments, tighten, on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

							Tech Init.																								
1.	Grease and check condition of all grease points						DN																								
2.	Check operation and condition of all lights, reflectors and safety signals						DN																								
3.	Check condition of all brake components						DN																								
4.	Check and adjust brakes						DN																								
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th>%</th> <th>R</th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td>90</td> <td></td> <td>90</td> </tr> <tr> <td></td> <td>Middle</td> <td>L</td> <td>90</td> <td>R</td> <td>90</td> </tr> <tr> <td></td> <td>Rear</td> <td>L</td> <td>90</td> <td>R</td> <td>90</td> </tr> </tbody> </table>							Brake % Report	Front	L	%	R	%				90		90		Middle	L	90	R	90		Rear	L	90	R	90	
Brake % Report	Front	L	%	R	%																										
			90		90																										
	Middle	L	90	R	90																										
	Rear	L	90	R	90																										
5.	Check all air hoses & fittings						DN																								
6.	Drain all air tanks						DN																								
7.	Check turntable and King Pin for movement						DN																								
8.	Grease and check landing legs						DN																								
9.	Inspect all suspension components						DN																								
10.	Check chassis for cracks and fatigue						DN																								
11.	Check wheel bearings for movement						DN																								
12.	Check condition of tyres rims and hubs						DN																								
13.	Check and report on condition of safety signs						DN																								
Please list any faults found																															
- REPAIRED FRONT R/H AIR BAG																															
- ADJUSTED TYRE PRESSURES																															
- HUB OIL LEVELS GOOD																															
- ADJUSTED L/H REAR GUARD																															
- REPLACED TOP L/H FRIDGE MOTOR PANEL																															
- REPLACED TRAILER PLUG SURT LEAD																															
- GREASED LOCKING PIN																															
FAULTS																															
• INSIDE VAN DIRTY																															

Leading Hand / Mechanic: [Signature] Date: 4/1/21


JEFTOMSON TRAILER SERVICE

Chassis No: Kilometres: **643,906** Date Inspected: **13/11/20**
 Rego: **0131-SG** — **E-6433**
T-6502

Mechanic to inspect, make adjustments, tighten, on all operations listed.
 Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

								Tech init.
1.	Grease and check condition of all grease points							ck
2.	Check operation and condition of all lights, reflectors and safety signals							ck
3.	Check condition of all brake components							ck
4.	Check and adjust brakes							ck
Brake % Report		Front	L	95	%	R	95	%
		Middle	L	95	%	R	95	%
		Rear	L	95	%	R	95	%
5.	Check all air hoses & fittings							ck
6.	Drain all air tanks							ck
7.	Check turntable and King Pin for movement							ck
8.	Grease and check landing legs							ck
9.	Inspect all suspension components							ck
10.	Check chassis for cracks and fatigue							ck
11.	Check wheel bearings for movement							ck
12.	Check condition of tyres rims and hubs							ck
13.	Check and report on condition of safety signs							ck
Please list any faults found								
Brake lights Not Working - Fixed								
3 cracked cross members - rewelded								
4 cracks above air bags - rewelded								
loose front right shock - tightened								
loose rear right shock - replaced Bolt								
2 more cracks on last cross member - rewelded								
end of pogopole rail missing								
rivet 1/2 inch below in front of bridge motor								
door handle stiff & bent								

Leading Hand / Mechanic: 

Date: **13/11/20**

Leftomson Transport

Date of Issue: 29/11/18 (R41)

JEFTOMSON TRAILER SERVICE

Chassis No:..

Kilometres:

Date Inspected: 09/10/20

Rego: 0131-SC

form 112 6407

Mechanic to inspect, make adjustments, tighten, on all operations listed.
Consult applicable service information for adjustments and specification.
Tick = OK A = Adjust R = Repair

Tick = OK A = Adjust R = Repair

								Tech Init.
1.	Grease and check condition of all grease points							V07A
2.	Check operation and condition of all lights, reflectors and safety signals	OK						JOPPRY
3.	Check condition of all brake components	OK						bppny
4.	Check and adjust brakes	OK						JOPPRY
Brake % Report		Front	L A	100	%	R A	100	%
		Middle	L A	100	%	R A	100	%
		Rear	L A	100	%	R A	100	%
5.	Check all air hoses & fittings							JOPPRY
6.	Drain all air tanks							JOPPRY
7.	Check turntable and King Pin for movement	OK						JOPPRY
8.	Grease and check landing legs	OK						JOPPRY
9.	Inspect all suspension components	OK						JOPPRY
10.	Check chassis for cracks and fatigue	OK						JOPPRY
11.	Check wheel bearings for movement	OK						JOPPRY
12.	Check condition of tyres rims and hubs	OK						JOPPRY
13.	Check and report on condition of safety signs	OK						JOPPRY
Please list any faults found ▲ 								

Leading Hand / Mechanic:

Date: 04/10/20

JEFTOMSON TRAILER SERVICE

Chassis No: Kilometres: 702009 Date Inspected: 19/05/21Rego: 0131-SGENGINE HR = 7131
TOTAL HR = 7202Mechanic to inspect, make adjustments, tighten, on all operations listed.
Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

		Tech Init.																													
1.	Grease and check condition of all grease points	✓	JB																												
2.	Check operation and condition of all lights, reflectors and safety signals	✓	JB																												
3.	Check condition of all brake components	✓	JB																												
4.	Check and adjust brakes	✓	JB																												
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th>R</th> <th>%</th> <th>R</th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td>L</td> <td>85</td> <td>%</td> <td>R</td> <td>85</td> </tr> <tr> <td></td> <td>Middle</td> <td>L</td> <td>85</td> <td>%</td> <td>R</td> <td>85</td> </tr> <tr> <td></td> <td>Rear</td> <td>L</td> <td>85</td> <td>%</td> <td>R</td> <td>85</td> </tr> </tbody> </table>				Brake % Report	Front	L	R	%	R	%			L	85	%	R	85		Middle	L	85	%	R	85		Rear	L	85	%	R	85
Brake % Report	Front	L	R	%	R	%																									
		L	85	%	R	85																									
	Middle	L	85	%	R	85																									
	Rear	L	85	%	R	85																									
5.	Check all air hoses & fittings	✓	JB																												
6.	Drain all air tanks	✓	JB																												
7.	Check turntable and King Pin for movement	✓	JB																												
8.	Grease and check landing legs	✓	JB																												
9.	Inspect all suspension components	✓	JB																												
10.	Check chassis for cracks and fatigue	✓	JB																												
11.	Check wheel bearings for movement	✓	JB																												
12.	Check condition of tyres rims and hubs	✓	JB																												
13.	Check and report on condition of safety signs	✓	JB																												
Please list any faults found LA RR SIGNAL LIGHT N/W - DATE LA RR AXLE HUB BEARING TOO LOOSE - DATE LA RR GUARD IS BROKEN RR SUZI COIL COUPLERS IS WORN																															

Leading Hand / Mechanic: JeffreyDate: 20/05/21

JEFTOMSON TRAILER SERVICE

Kilometreš:

Date Inspected:

Rego:

0131-56

636,318

Date Inspected:

6467 TOTAL HOURS

6338 ENG HOURS

Mechanic to inspect, make adjustments, tighten, on all operations listed. Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

							Tech Init.																		
1.	Grease and check condition of all grease points						DN																		
2.	Check operation and condition of all lights, reflectors and safety signals						DN																		
3.	Check condition of all brake components						DN																		
4.	Check and adjust brakes						DN																		
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th>%</th> <th>R</th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td>Middle</td> <td>L</td> <td>5</td> <td>R</td> <td>5</td> </tr> <tr> <td></td> <td>Rear</td> <td>L</td> <td>20</td> <td>R</td> <td>20</td> </tr> </tbody> </table>							Brake % Report	Front	L	%	R	%		Middle	L	5	R	5		Rear	L	20	R	20	
Brake % Report	Front	L	%	R	%																				
	Middle	L	5	R	5																				
	Rear	L	20	R	20																				
5.	Check all air hoses & fittings						DN																		
6.	Drain all air tanks						DN																		
7.	Check turntable and King Pin for movement						DN																		
8.	Grease and check landing legs						DN																		
9.	Inspect all suspension components						DN																		
10.	Check chassis for cracks and fatigue						DN																		
11.	Check wheel bearings for movement						DN																		
12.	Check condition of tyres rims and hubs						DN																		
13.	Check and report on condition of safety signs						DN																		
Please list any faults found REPLACED L/H REAR CLEARANCE LIGHT TOPPED UP FRIDGE MOTOR COOLANT AND ENGINE OIL.																									
FAULTS BRAKES LOW NEED REPLACING. R/H SHOCKER BOTTOM BOLT BROKEN FRIDGE MOTOR DUE FOR SERVICE. FRIDGE MOTOR COMPRESSOR BELT SMALL CRACKS. TURN TABLE FOOT CRUSHES MOVEMENT																									

Leading Hand / Mechanic:

Date _____

24/8/20

JEFTOMSON TRAILER SERVICE

Chassis No: Kilometres: 614,172km Date Inspected: 24/6/20Rego: 0131-S6 6131 ENG HOURS.6200 TOTAL HOURS

Mechanic to inspect, make adjustments, tighten, on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

								Tech Init.																								
1.	Grease and check condition of all grease points							DN																								
2.	Check operation and condition of all lights, reflectors and safety signals							DN																								
3.	Check condition of all brake components							DN																								
4.	Check and adjust brakes <u>AUTO'S</u>							DN																								
<table border="1"> <thead> <tr> <th>Brake % Report</th> <th>Front</th> <th>L</th> <th></th> <th>%</th> <th>R</th> <th></th> <th>%</th> </tr> </thead> <tbody> <tr> <td></td> <td>Middle</td> <td>L</td> <td></td> <td>30</td> <td>%</td> <td>R</td> <td>30 %</td> </tr> <tr> <td></td> <td>Rear</td> <td>L</td> <td></td> <td>30</td> <td>%</td> <td>R</td> <td>30 %</td> </tr> </tbody> </table>									Brake % Report	Front	L		%	R		%		Middle	L		30	%	R	30 %		Rear	L		30	%	R	30 %
Brake % Report	Front	L		%	R		%																									
	Middle	L		30	%	R	30 %																									
	Rear	L		30	%	R	30 %																									
5.	Check all air hoses & fittings							DN																								
6.	Drain all air tanks							DN																								
7.	Check turntable and King Pin for movement							DN																								
8.	Grease and check landing legs							DN																								
9.	Inspect all suspension components							DN																								
10.	Check chassis for cracks and fatigue							DN																								
11.	Check wheel bearings for movement							DN																								
12.	Check condition of tyres rims and hubs							DN																								
13.	Check and report on condition of safety signs							DN																								
Please list any faults found																																
- FRIIDGE MOTOR WATER PUMP BELT CRACKED																																
- RESET ROLL BACK BATTERY FUSE																																
- L/H DOOR POLE SMALL BEND.																																
- NO ABS LEAD.																																
• HUB OIL LEVELS OK.																																
• REPLACED SUZI FITTINGS.																																
• LUBED LOCKING PIN																																
• LUBED ROLL BACK SLIDES																																

Leading Hand / Mechanic: [Signature]Date: 24/6/20