

Class: 40.

Kilometres:

Date inspected:

7950

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.
Consult applicable service information for adjustments and specification.
Tick = OK A = Adjust R = Repair

OFF

022

sec
155

1. Change	Engine oil
2. Change	Oil filters
3. Change	Fuel filters
4. Check	Cooling system & test condition & record
5. Change	Coolant filter
6. Inspect	Engine for oil leaks
7. Check &/or replace	Air cleaner element
8. Inspect	All bolts

CHASSIS & GENERAL

- | 9. Grease | Chassis and turntable, top up auto greaser | | | | | | | | | |
|-----------------------|---|---------|-----|---|----------|------|---|----------|------|---|
| 10. Check | Turntable adjustment & condition | | | | | | | | | |
| 11. Inspect | All uni joints | | | | | | | | | |
| 12. Check | Centre bearings | | | | | | | | | |
| 13. Adjust | Brakes - check for air leaks | | | | | | | | | |
| 14. Brakes P. | <table border="1"> <thead> <tr> <th>Steer L</th> <th>% R</th> <th>%</th> </tr> </thead> <tbody> <tr> <td>Drive LF</td> <td>% RF</td> <td>%</td> </tr> <tr> <td>Drive LR</td> <td>% RR</td> <td>%</td> </tr> </tbody> </table> | Steer L | % R | % | Drive LF | % RF | % | Drive LR | % RR | % |
| Steer L | % R | % | | | | | | | | |
| Drive LF | % RF | % | | | | | | | | |
| Drive LR | % RR | % | | | | | | | | |
| 15. Drain | Air tanks | | | | | | | | | |
| 16. Check | Suspension for condition | | | | | | | | | |
| 17. Visual inspection | Over unit and report | | | | | | | | | |
| 18. Check | Oil level front hubs | | | | | | | | | |
| 19. Check | Freeplay in steering and all components | | | | | | | | | |
| 20. Check | Condition of king pins & ball joints | | | | | | | | | |
| 21. Inspect | Steering and oil level and for leaks | | | | | | | | | |
| 22. Check | Batteries - level and terminals | | | | | | | | | |
| 23. Check | Clutch operation and adjust as required | | | | | | | | | |
| 24. Check | All lights | | | | | | | | | |
| 25. Check | Wiper, washer operation, level and blades | | | | | | | | | |
| TRANSMISSION | | | | | | | | | | |
| 26. Check | Oil levels | | | | | | | | | |
| 27. Inspect | For leaks | | | | | | | | | |
| DIFFERENTIAL | | | | | | | | | | |
| 28. Check | Oil levels | | | | | | | | | |
| 29. Inspect | For leaks | | | | | | | | | |
| 30. Road Test | Vehicle and check for leaks | | | | | | | | | |

oil leak on
engine

~~Cat~~ Grill
loose.

Leading Hand / Mechanic

2000

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: Kilometres: 988787 Date Inspected: 4/8/23 Rego: YXP412

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

FUEL ECONOMY

OFE

DFE

Tech
Init.**ENGINE**

- | | | | | |
|--------------------------|--|-------------------------------------|----|--|
| 1. Change | Engine oil | ☒ | DC | <i>Power steering pump
leaking</i> |
| 2. Change | Oil filters | ☒ | DC | |
| 3. Change | Fuel filters | ☒ | DC | |
| 4. Check | Cooling system & test condition & record | ☒ | DC | |
| 5. Change | Coolant filter | ☒ | DC | |
| 6. Inspect | Engine for oil leaks | R | DC | |
| 7. Check &/or
replace | Air cleaner element | ☒ | DC | |
| 8. Inspect | All belts | ☒ | DC | <i>Belly bar loose</i> |

CHASSIS & GENERAL

- | | | | | |
|-----------------------|--|-------------------------------------|----|---|
| 9. Grease | Chassis and turntable, top up auto greaser | ☒ | DC | <i>Steering box leaking
oil.</i> |
| 10. Check | Turntable adjustment & condition | ☒ | DC | |
| 11. Inspect | All uni joints | ☒ | DC | |
| 12. Check | Centre bearings | ☒ | DC | |
| 13. Adjust | Brakes – check for air leaks | ☒ | DC | |
| 14. Brakes % | Steer L <u>20</u> % R <u>50</u> % | ☒ | DC | <i>Left hand front steer
brake low need done
at next service.</i> |
| | Drive LF <u>70</u> % RF <u>70</u> % | ☒ | DC | |
| | Drive LR <u>70</u> % RR <u>70</u> % | ☒ | DC | |
| 15. Drain | Air tanks | ☒ | DC | |
| 16. Check | Suspension for condition | ☒ | DC | |
| 17. Visual Inspection | Over unit and report | ☒ | DC | |
| 18. Check | Oil level front hubs | ☒ | DC | |
| 19. Check | Freeplay in steering and all components | ☒ | DC | |
| 20. Check | Condition of king pins & ball joints | ☒ | DC | |
| 21. Inspect | Steering and oil level and for leaks | ☒ | DC | |
| 22. Check | Batteries – level and terminals | ☒ | DC | |
| 23. Check | Clutch operation and adjust as required | ☒ | DC | |
| 24. Check | All lights | ☒ | DC | <i>lights out = Dash</i> |
| 25. Check | Wiper, washer operation, level and blades | ☒ | DC | |

TRANSMISSION

- | | | | |
|-------------|------------|-------------------------------------|----|
| 26. Check | Oil levels | ☒ | DC |
| 27. Inspect | For leaks | ☒ | DC |

DIFFERENTIAL

- | | | | |
|-------------|------------|-------------------------------------|----|
| 28. Check | Oil levels | ☒ | DC |
| 29. Inspect | For leaks | ☒ | DC |

- | | | | |
|---------------|-----------------------------|--------------------------|--------------------------|
| 30. Road Test | Vehicle and check for leaks | ☐ | ☐ |
|---------------|-----------------------------|--------------------------|--------------------------|

Leading Hand / Mechanic: David Cox

Date: 4/8/23

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: Kilometres: 938 222 Date Inspected: 7-3-23 Rego: YXP 417

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

FUEL ECONOMY

OFE

2.50

DFE

2.57Tech
Init.**ENGINE**

1. Change Engine oil
2. Change Oil filters
3. Change Fuel filters
4. Check Cooling system & test condition & record
5. Change Coolant filter N/A
6. Inspect Engine for oil leaks
7. Check &/or replace Air cleaner element
8. Inspect All belts

92um

✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB

43.5% 6H1000 PropyleneDUS - FRONT CRANKSHAFTSEAL IS LEAKING.OIL WEEP ONENG. FRONT COVEROIL WEEP ON ENG. Sump**CHASSIS & GENERAL**

9. Grease Chassis and turntable, top up auto greaser
10. Check Turntable adjustment & condition
11. Inspect All uni joints
12. Check Centre bearings
13. Adjust Brakes - check for air leaks
14. Brakes %
Steer L 55 % R 65 %
Drive LF 70 % RF 70 %
Drive LR 75 % RR 75 %
15. Drain Air tanks
16. Check Suspension for condition
17. Visual Inspection Over-unit and report
18. Check Oil level front hubs
19. Check Freeplay in steering and all components
20. Check Condition of king pins & ball joints
21. Inspect Steering and oil level and for leaks
22. Check Batteries - level and terminals
23. Check Clutch operation and adjust as required
24. Check All lights
25. Check Wiper, washer operation, level and blades

✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB

DASH GLOBS NOTWORKINGWIPER BLADES REPAIR**TRANSMISSION**

26. Check Oil levels
27. Inspect For leaks

✓	JB
✓	JB

DIFFERENTIAL

28. Check Oil levels
29. Inspect For leaks

✓	JB
✓	JB

30. Road Test Vehicle and check for leaks

✓	JB
---	----

Leading Hand / Mechanic: JOPPA

Date: 7-3-23

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: 21A Kilometres: 916,283km Date Inspected: 4-1-23 Rego: YXP-417

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.
Consult applicable service information for adjustments and specification.
Tick = OK A = Adjust R = Repair

FUEL ECONOMY		OFE	DFE	Tech Init.
ENGINE				
1. Change	Engine oil			✓ MG
2. Change	Oil filters			✓ MG
3. Change	Fuel filters			✓ MG
4. Check	Cooling system & test condition & record			✓ MG
5. Change	Coolant filter			✓ MG
6. Inspect	Engine for oil leaks			✓ MG
7. Check &/or replace	Air cleaner element			✓ MG
8. Inspect	All belts			✓ MG
CHASSIS & GENERAL				
9. Grease	Chassis and turntable, top up auto greaser			✓ MG
10. Check	Turntable adjustment & condition			✓ MG
11. Inspect	All uni joints			✓ MG
12. Check	Centre bearings			✓ MG
13. Adjust	Brakes – check for air leaks			✓ MG
14. Brakes %	Steer L 20 % R 40 %			✓ MG
	Drive LF 80 % RF 80 %			✓ MG
	Drive LR 80 % RR 80 %			✓ MG
15. Drain	Air tanks			✓ MG
16. Check	Suspension for condition			✓ MG
17. Visual Inspection	Over unit and report			✓ MG
18. Check	Oil level front hubs			✓ MG
19. Check	Freeplay in steering and all components			✓ MG
20. Check	Condition of king pins & ball joints			✓ MG
21. Inspect	Steering and oil level and for leaks			✓ MG
22. Check	Batteries – level and terminals			✓ MG
23. Check	Clutch operation and adjust as required			✓ MG
24. Check	All lights			✓ MG
25. Check	Wiper, washer operation, level and blades			✓ MG
TRANSMISSION				
26. Check	Oil levels			✓ MG
27. Inspect	For leaks			✓ MG
DIFFERENTIAL				
28. Check	Oil levels			✓ MG
29. Inspect	For leaks			✓ MG
30. Road Test	Vehicle and check for leaks			✓ MG

Leading Hand / Mechanic: [Signature]

Date: 4-1-23

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: Kilometres: 874,051 KM Date Inspected: 28-9-22 Rego: XP 917

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

FUEL ECONOMY		OFE	DFE	Tech
ENGINE				Init.
1. Change	Engine oil	✓	DN	
2. Change	Oil filters	✓	DN	
3. Change	Fuel filters	✓	DN	
4. Check	Cooling system & test condition & record	✓	DN	
5. Change	Coolant filter	✓	DN	
6. Inspect	Engine for oil leaks	✓	DN	
7. Check &/or replace	Air cleaner element	✓	DN	
8. Inspect	All belts	✓	DN	
CHASSIS & GENERAL				
9. Grease	Chassis and turntable, top up auto greaser	✓	DN	
10. Check	Turntable adjustment & condition	✓	DN	
11. Inspect	All uni joints	✓	DN	
12. Check	Centre bearings	✓	DN	
13. Adjust	Brakes – check for air leaks	✓	DN	
14. Brakes %	Steer L <u>55</u> % R <u>60</u> %	✓	DN	
	Drive LF <u>75</u> % RF <u>75</u> %	✓	DN	
	Drive LR <u>75</u> % RR <u>75</u> %	✓	DN	
15. Drain	Air tanks	✓	DN	
16. Check	Suspension for condition	✓	DN	
17. Visual Inspection	Over unit and report	✓	DN	
18. Check	Oil level front hubs	✓	DN	
19. Check	Freeplay in steering and all components	✓	DN	
20. Check	Condition of king pins & ball joints	✓	DN	
21. Inspect	Steering and oil level and for leaks	✓	DN	
22. Check	Batteries – level and terminals	✓	DN	
23. Check	Clutch operation and adjust as required	✓	DN	
24. Check	All lights	✓	DN	
25. Check	Wiper, washer operation, level and blades	✓	DN	
TRANSMISSION				
26. Check	Oil levels	✓	DN	
27. Inspect	For leaks	✓	DN	
DIFFERENTIAL				
28. Check	Oil levels	✓	DN	
29. Inspect	For leaks	✓	DN	
30. Road Test	Vehicle and check for leaks	✓	DN	

Leading Hand / Mechanic: [Signature]

Date: 28/9/22

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: Kilometres: 854,339 Date Inspected: 5/8/22 Rego: YXP417

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.
Consult applicable service information for adjustments and specification.
Tick = OK A = Adjust R = Repair

FUEL ECONOMY

OFE

DFE

Tech
Init.**ENGINE**

- | | | | | |
|-------------------------------------|--|-------------------------------------|----|-------|
| 1. Change | Engine oil | ☒ | DN | |
| 2. Change | Oil filters | ☒ | DN | |
| 3. Change | Fuel filters | ☒ | DN | |
| 4. Check | Cooling system & test condition & record | ☒ | DN | |
| 5. Change | Coolant filter | ☒ | DN | |
| 6. Inspect | Engine for oil leaks | ☒ | DN | |
| 7. <u>Check &/or</u>
replace | Air cleaner element | ☒ | DN | |
| 8. Inspect | All belts | ☒ | DN | |

REPLACED ALL BELTS
REPLACED IDLER PULLEY
BEARINGS

CHASSIS & GENERAL

- | | | | | |
|-----------------------|--|-------------------------------------|----|-------|
| 9. Grease | Chassis and turntable, top up auto greaser | ☒ | DN | |
| 10. Check | Turntable adjustment & condition | ☒ | DN | |
| 11. Inspect | All uni joints | ☒ | DN | |
| 12. Check | Centre bearings | ☒ | DN | |
| 13. Adjust | Brakes - check for air leaks | ☒ | DN | |
| 14. Brakes % | Steer L <u>60</u> % R <u>60</u> % | ☒ | DN | |
| | Drive LF <u>80</u> % RF <u>80</u> % | ☒ | DN | |
| | Drive LR <u>80</u> % RR <u>80</u> % | ☒ | DN | |
| 15. Drain | Air tanks | ☒ | DN | |
| 16. Check | Suspension for condition | ☒ | DN | |
| 17. Visual Inspection | Over unit and report | ☒ | DN | |
| 18. Check | Oil level front hubs | ☒ | DN | |
| 19. Check | Freeplay in steering and all components | ☒ | DN | |
| 20. Check | Condition of king pins & ball joints | ☒ | DN | |
| 21. Inspect | Steering and oil level and for leaks | ☒ | DN | |
| 22. Check | Batteries - level and terminals | ☒ | DN | |
| 23. Check | Clutch operation and adjust as required | ☒ | DN | |
| 24. Check | All lights | ☒ | DN | |
| 25. Check | Wiper, washer operation, level and blades | ☒ | DN | |

REPLACED BLADES

TRANSMISSION

- | | | | | |
|-------------|------------|-------------------------------------|----|-------|
| 26. Check | Oil levels | ☒ | DN | |
| 27. Inspect | For leaks | ☒ | DN | |

DIFFERENTIAL

- | | | | | |
|-------------|------------|-------------------------------------|----|-------|
| 28. Check | Oil levels | ☒ | DN | |
| 29. Inspect | For leaks | ☒ | DN | |

REAR HOUSING ON
FRONT DIFF LEAKING

- | | | | | |
|---------------|-----------------------------|-------------------------------------|----|-------|
| 30. Road Test | Vehicle and check for leaks | ☒ | MU | |
|---------------|-----------------------------|-------------------------------------|----|-------|

Leading Hand / Mechanic: [Signature]

Date: 5/8/22

- REPLACED BOTH LAC AND TURBO OUTLET BOOST HOSES AND CLAMPS
- REPLACED L/H MIRROR.

Chassis No.:

Kilometres: 0

Date Inspected:

Rego:

Tick = OK A = Adjust R = Repair

FUEL ECONOMY		OFE	2.49	DFE	2.51
ENGINE				Tech Init.	
1. Change	Engine oil	42UM	✓	JB	
2. Change	Oil filters		✓	JB	
3. Change	Fuel filters		✓	JB	
4. Check	Cooling system & test condition & record		✓	JB	
5. Change	Coolant filter		✓	N/A	
6. Inspect	Engine for oil leaks		✓	JB	
7. Check &/or replace	Air cleaner element		✓	JB	
8. Inspect	All belts		✓	JB	
CHASSIS & GENERAL					
9. Grease	Chassis and turntable, top up auto greaser		✓	JB	
10. Check	Turntable adjustment & condition		✓	JB	
11. Inspect	All uni joints		✓	JB	
12. Check	Centre bearings	N/A	✓	JB	
13. Adjust	Brakes - check for air leaks		✓	JB	
14. Brakes %	Steer L % R 70 % 70		✓	JB	
	Drive LF % RF 85 % 85		✓	JB	
	Drive LR % RR 85 % 85		✓	JB	
15. Drain	Air tanks		✓	JB	
16. Check	Suspension for condition		✓	JB	
17. Visual Inspection	Over unit and report		✓	JB	
18. Check	Oil level front hubs		✓	JB	
19. Check	Freeplay in steering and all components		✓	JB	
20. Check	Condition of king pins & ball joints		✓	JB	
21. Inspect	Steering and oil level and for leaks		✓	JB	
22. Check	Batteries - level and terminals		✓	JB	
23. Check	Clutch operation and adjust as required		✓	JB	
24. Check	All lights		✓	JB	
25. Check	Wiper, washer operation, level and blades		✓	JB	
TRANSMISSION					
26. Check	Oil levels		✓	JB	
27. Inspect	For leaks		✓	JB	
DIFFERENTIAL					
28. Check	Oil levels		✓	JB	
29. Inspect	For leaks		✓	JB	
30. Road Test	Vehicle and check for leaks				

49% GYLCOOL
COOLANT TANK PRESENT
WITH CARBON
OIL LEAK ON INS. MANIFOLD
OIL LEAK ON PUMP COVER
OIL LEAK ON
ENG. OIL SUMP

SIGN OF WEAR ON
LEAF SPRING BUSH
TORNALIS NO. 2 BUSH
IS SPLIT

FRT DRIVE DIFF. HOUSING
OIL LEAK

~~Reading Hand~~ / Mechanic:

Date:

ROTATE STORE TIME

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No:

Kilometres: **776466**Date Inspected: **05-01-22**Rego: **YXP417**

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

FUEL ECONOMY

OFE

2.49

DFE

2.50Tech
Init.**ENGINE**

1. Change Engine oil **45Lm**
2. Change Oil filters
3. Change Fuel filters
4. Check Cooling system & test condition & record
5. ~~Change~~ Coolant filter **N/A**
6. Inspect Engine for oil leaks
7. Check &/or replace Air cleaner element
8. Inspect All belts

✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB

6.5 PA / 3.2 PA / 3.5 / PP / BP**OIL LEAK ON INJECTOR LOOMS****FRONT COVER OIL LEAK****ENGINE OIL SUMP LEAKING
OIL WEEP ON FILLER PIPE****CHASSIS & GENERAL**

9. Grease Chassis and turntable, top up auto greaser
10. Check Turntable adjustment & condition
11. Inspect All uni joints
12. ~~Check~~ Centre bearings **N/A**
13. Adjust Brakes - check for air leaks
14. Brakes %
- | | | | |
|----------|-------------|----|-------------|
| Steer L | 55 % | R | 55 % |
| Drive LF | 70 % | RF | 70 % |
| Drive LR | 70 % | RR | 70 % |

✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB

15. Drain Air tanks
16. Check Suspension for condition
17. Visual Inspection Over unit and report
18. Check Oil level front hubs
19. Check Freeplay in steering and all components
20. Check Condition of king pins & ball joints
21. Inspect Steering and oil level and for leaks
22. Check Batteries - level and terminals
23. Check Clutch operation and adjust as required
24. Check All lights
25. Check Wiper, washer operation, level and blades

✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB
✓	JB

SPROCKET BRUSH & PIN**PRESENT OF RUST****SHOWING SIGN OF WEAR****TRANSMISSION**

26. Check Oil levels
27. Inspect For leaks

✓	JB
✓	JB

DIFFERENTIAL

28. Check Oil levels
29. Inspect For leaks

✓	JB
✓	JB

OIL WEEP ON BOTH DIFF.

30. Road Test Vehicle and check for leaks

✓	JB
---	----

Leading Hand / Mechanic: **JOFFRY**Date: **06-01-22****CHECK ALL ROOST HOSE CLAMP**

\\FILESVR01\CompanyData\Quality\Quality Manual\Transport\HACCP Transport\Records\R39 JT 20,000 km B Service 2018-11-29.docx

Performe Tyre Rotation

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: N/A Kilometres: 755,137km Date Inspected: 22/10/21 Rego: 4XP417

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

FUEL ECONOMY

OFE

2.48 km/L

DFE

2.49 km/LTech
Init.

ENGINE

1. Change Engine oil
2. Change Oil filters
3. Change Fuel filters
4. Check Cooling system & test condition & record
5. Change Coolant filter
6. Inspect Engine for oil leaks
7. Check &/or replace Air cleaner element
8. Inspect All belts

✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML

TIGHTENED BOOST
CLAMPS + PYRO
DIPSTICK/FILL TUBE
OIL LEAK
INJECTOR/JAKE LOOM
BYPASSING OIL
45% GYCOL LEVEL
WHEN COOLANT TESTED
FRONT COVER OIL
LEAK
FRONT DIFF REAR
HOUSING OIL LEAK

CHASSIS & GENERAL

9. Grease Chassis and turntable, top up auto greaser
10. Check Turntable adjustment & condition
11. Inspect All uni joints
12. Check Centre bearings
13. Adjust Brakes - check for air leaks
14. Brakes %
Steer L 80 % R 80 %
Drive LF 90 % RF 90 %
Drive LR 90 % RR 90 %
15. Drain Air tanks
16. Check Suspension for condition
17. Visual Inspection Over unit and report
18. Check Oil level front hubs
19. Check Freeplay in steering and all components
20. Check Condition of king pins & ball joints
21. Inspect Steering and oil level and for leaks
22. Check Batteries - level and terminals
23. Check Switch operation and adjust as required
24. Check All lights
25. Check Wiper, washer operation, level and blades

✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML
✓	ML

SUMP PLUG
STRIPPED OUT - REPAIRED
TORQUE ROD BUSHES
STARTING TO WEAR
DRIVE SHOCK BUSHES
STARTING TO WEAR
FRONT DIFF OUTLET
MORE SLIGHT MOVEMENT

TRANSMISSION

26. Check Oil levels
27. Inspect For leaks

✓	ML
✓	ML

DIFFERENTIAL

28. Check Oil levels
29. Inspect For leaks

✓	ML
✓	ML

30. Road Test Vehicle and check for leaks

✓	ML
---	----

Leading Hand / Mechanic: MLDate: 22/10/21

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: Kilometres: 732063 Date Inspected: 10-8-21 Rego: YXP 917

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.
Consult applicable service information for adjustments and specification.
Tick = OK A = Adjust R = Repair

FUEL ECONOMY		OFE	DFE	Tech Init.
		2.42	2.43	
ENGINE				
1. Change	Engine oil	450ml	JB	
2. Change	Oil filters		JB	
3. Change	Fuel filters		JB	
4. Check	Cooling system & test condition & record		JB	
5. Change	Coolant filter N/A			
6. Inspect	Engine for oil leaks		JB	
7. Check &/or replace	Air cleaner element		JB	
8. Inspect	All belts		JB	
CHASSIS & GENERAL				
9. Grease	Chassis and turntable, top up auto greaser		JB	
10. Check	Turntable adjustment & condition		JB	
11. Inspect	All uni joints		JB	
12. Check	Centre bearings			
13. Adjust	Brakes - check for air leaks		JB	
14. Brakes %	Steer L 75 % R 75 %		JB	
	Drive LF 80 % RF 80 %		JB	
	Drive LR 80 % RR 80 %		JB	
15. Drain	Air tanks		JB	
16. Check	Suspension for condition		JB	
17. Visual Inspection	Over unit and report		JB	
18. Check	Oil level front hubs		JB	
19. Check	Freeplay in steering and all components		JB	
20. Check	Condition of king pins & ball joints		JB	
21. Inspect	Steering and oil level and for leaks		JB	
22. Check	Batteries - level and terminals		JB	
23. Check	Clutch operation and adjust as required		JB	
24. Check	All lights		JB	
25. Check	Wiper, washer operation, level and blades			
TRANSMISSION				
26. Check	Oil levels		JB	
27. Inspect	For leaks		JB	
DIFFERENTIAL				
28. Check	Oil levels		JB	
29. Inspect	For leaks		JB	
30. Road Test	Vehicle and check for leaks		JB	

Leading Hand / Mechanic: JOFFRYDate: 16-8-21

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: N/A Kilometres: 710,406 km Date Inspected: 8/6/21 Rego: 4XP-417

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.

Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

FUEL ECONOMY		OFE	2.38 km/L	DFE	2.39 km/L
ENGINE					
1. Change	Engine oil	✓	ML	✓	ML
2. Change	Oil filters	✓	ML	✓	ML
3. Change	Fuel filters	✓	ML	✓	ML
4. Check	Cooling system & test condition & record	✓	ML	✓	ML
5. Change	Coolant filter	✓	ML	✓	ML
6. Inspect	Engine for oil leaks	✓	ML	✓	ML
7. Check &/or replace	Air cleaner element	✓	ML	✓	ML
8. Inspect	All belts	✓	ML	✓	ML
CHASSIS & GENERAL					
9. Grease	Chassis and turntable, top up auto greaser	✓	ML	✓	ML
10. Check	Turntable adjustment & condition	✓	ML	✓	ML
11. Inspect	All uni joints	✓	ML	✓	ML
12. Check	Centre bearings	-	-	-	-
13. Adjust	Brakes - check for air leaks	✓	ML	✓	ML
14. Brakes %	Steer L 70 % R 70 %	✓	ML	✓	ML
	Drive LF 90 % RF 90 %	✓	ML	✓	ML
	Drive LR 90 % RR 90 %	✓	ML	✓	ML
15. Drain	Air tanks	✓	ML	✓	ML
16. Check	Suspension for condition	✓	ML	✓	ML
17. Visual Inspection	Over unit and report	✓	ML	✓	ML
18. Check	Oil level front hubs	✓	ML	✓	ML
19. Check	Freeplay in steering and all components	✓	ML	✓	ML
20. Check	Condition of king pins & ball joints	✓	ML	✓	ML
21. Inspect	Steering and oil level and for leaks	✓	ML	✓	ML
22. Check	Batteries - level and terminals	✓	ML	✓	ML
23. Check	Clutch operation and adjust as required	✓	ML	✓	ML
24. Check	All lights	✓	ML	✓	ML
25. Check	Wiper, washer operation, level and blades	✓	ML	✓	ML
TRANSMISSION					
26. Check	Oil levels	✓	ML	✓	ML
27. Inspect	For leaks	✓	ML	✓	ML
DIFFERENTIAL					
28. Check	Oil levels	✓	ML	✓	ML
29. Inspect	For leaks	✓	ML	✓	ML
30. Road Test	Vehicle and check for leaks	✓	ML	✓	ML

Tech
Init.

- COMPRESSOR MOUNT
 GASKET LEAKING
 - BREATHER HOSE
 WEEPING - TIGHTENED
 - INJECTOR LOOM PASSING
 OIL
 - BATTERY BOX
 CRACKED L/H SIDE
 - COOLING SYSTEM
 TESTED OKAY - RUBBER
 FOUND BUILT UP IN
 SPOUT OF RADIATOR
 - COMPRESSOR INLET
 GASKET WEEPING OIL
 - UNBLOCKED L/H WIPER
 WASHER
 - REAR RM SHOCK
 MINOR WEEP
 - TIGHTENED BOOST
 CLAMPS
 - OIL PRESSURE SENSORS
 LEAKING OIL - REPLACED
 - TORQUE ROD
 BUSHES WORN
 - FRONT DIFF OIL
 LEAK - REAR HOUSING
 - FRONT DIFF TIE
 SHAFT MOVEMENT
 - REAR ENGINE MOUNTS
 CRACKED
 - LEAK ON FILL
 HOSES R/H SIDE -
 TIGHTENED CLAMPS

Leading Hand / Mechanic: MLDate: 8/6/21

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: Kilometres: 2,673,046 Date Inspected: 22/2/21 Rego: YXP417

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.
Consult applicable service information for adjustments and specification.
Tick = OK A = Adjust R = Repair

FUEL ECONOMY		OFE	DFE	Tech	Init:
ENGINE					
1. Change	Engine oil			✓	DN
2. Change	Oil filters			✓	DN
3. Change	Fuel filters			✓	DN
4. Check	Cooling system & test condition & record			✓	DN
5. Change	Coolant filter			✓	DN
6. Inspect	Engine for oil leaks			✓	DN
7. Check &/or replace	Air cleaner element			✓	DN
8. Inspect	All belts			✓	DN
CHASSIS & GENERAL					
9. Grease	Chassis and turntable, top up auto greaser			✓	DN
10. Check	Turntable adjustment & condition			✓	DN
11. Inspect	All uni joints			✓	DN
12. Check	Centre bearings			✓	DN
13. Adjust	Brakes – check for air leaks			✓	DN
14. Brakes %	Steer L <u>70</u> % R <u>70</u> %			✓	DN
	Drive LF <u>80</u> % RF <u>80</u> %			✓	DN
	Drive LR <u>80</u> % RR <u>80</u> %			✓	DN
15. Drain	Air tanks			✓	DN
16. Check	Suspension for condition			✓	DN
17. Visual Inspection	Over unit and report			✓	DN
18. Check	Oil level front hubs			✓	DN
19. Check	Freeplay in steering and all components			✓	DN
20. Check	Condition of king pins & ball joints			✓	DN
21. Inspect	Steering and oil level and for leaks			✓	DN
22. Check	Batteries – level and terminals			✓	DN
23. Check	Clutch operation and adjust as required			✓	DN
24. Check	All lights			✓	DN
25. Check	Wiper, washer operation, level and blades			✓	DN
TRANSMISSION					
26. Check	Oil levels			✓	DN
27. Inspect	For leaks			✓	DN
DIFFERENTIAL					
28. Check	Oil levels			✓	DN
29. Inspect	For leaks			✓	DN
30. Road Test	Vehicle and check for leaks				

Handwritten notes on the right side of the form:

- FRONT COVER LEAK
- BATTERY BOX CRACKED
- ADJUSTED CLUTCH
- REPLACED WIPERS
- UNBLOCKED WASHERS
- TIGHTENED UP
- PRESSURE SENSOR REPLACED

Leading Hand / Mechanic: [Signature]

Date: 22/2/21

TIGHTENED EXHAUST CLAMPS.

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: Kilometres: 2652834 Date Inspected: 5/1/21 Rego: YXP417

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.
Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

FUEL ECONOMY

OFE

DFE

Tech
Init.**ENGINE**

- | | | | | |
|--------------------------|--|---|----|-------------------|
| 1. Change | Engine oil | ✓ | DN | |
| 2. Change | Oil filters | ✓ | DN | |
| 3. Change | Fuel filters | ✓ | DN | |
| 4. Check | Cooling system & test condition & record | ✓ | DN | REPLACED RAD CAP. |
| 5. Change | Coolant filter | ✓ | DN | COMPRESSOR MOUNT |
| 6. Inspect | Engine for oil leaks | ✓ | DN | LASKET. |
| 7. Check &/or
replace | Air cleaner element | ✓ | DN | ADJUSTED BELTS |
| 8. Inspect | All belts | ✓ | DN | |

CHASSIS & GENERAL

- | | | | | |
|-----------------------|--|---|---------|--|
| 9. Grease | Chassis and turntable, top up auto greaser | ✓ | DN | |
| 10. Check | Turntable adjustment & condition | ✓ | DN | |
| 11. Inspect | All uni joints | ✓ | DN/JOFF | |
| 12. Check | Centre bearings | ✓ | JOFF | |
| 13. Adjust | Brakes - check for air leaks | ✓ | JOFF | |
| 14. Brakes % | Steer L 75 % R 75 % | ✓ | JOFF | |
| | Drive LF 80 % RF 80 % | ✓ | JOFF | |
| | Drive LR 80 % RR 80 % | ✓ | JOFF | |
| 15. Drain | Air tanks | ✓ | DN | |
| 16. Check | Suspension for condition | ✓ | DN | |
| 17. Visual Inspection | Over unit and report | ✓ | JOFF | |
| 18. Check | Oil level front hubs | ✓ | JOFF | |
| 19. Check | Freeplay in steering and all components | ✓ | JOFF | |
| 20. Check | Condition of king pins & ball joints | ✓ | JOFF | |
| 21. Inspect | Steering and oil level and for leaks | ✓ | DN | |
| 22. Check | Batteries - level and terminals | ✓ | DN | |
| 23. Check | Clutch operation and adjust as required | ✓ | DN | |
| 24. Check | All lights | ✓ | DN | |
| 25. Check | Wiper, washer operation, level and blades | ✓ | DN | |

TRANSMISSION

- | | | | | |
|-------------|------------|---|----|--|
| 26. Check | Oil levels | ✓ | DN | |
| 27. Inspect | For leaks | ✓ | DN | |

DIFFERENTIAL

- | | | | | |
|-------------|------------|---|------|--|
| 28. Check | Oil levels | ✓ | JOFF | |
| 29. Inspect | For leaks | ✓ | JOFF | |

- | | | | | |
|---------------|-----------------------------|--|--|--|
| 30. Road Test | Vehicle and check for leaks | | | |
|---------------|-----------------------------|--|--|--|

Leading Hand / Mechanic: DN / JOFF

Date: 06/01/21

JEFTOMSON TRANSPORT 20,000 Km 'B' SERVICE

Chassis No: Kilometres: 612,926 Date Inspected: 17/9/20 Rego: YXP417

Mechanic to inspect, make adjustments, tighten, correct or add fluids on all operations listed.
Consult applicable service information for adjustments and specification.

Tick = OK A = Adjust R = Repair

FUEL ECONOMY

OFE

2.11

DFE

2.13Tech
Init.

ENGINE

- | | | | |
|-------------------------------------|--|---|----|
| 1. Change | Engine oil | ✓ | DN |
| 2. Change | Oil filters | ✓ | DN |
| 3. Change | Fuel filters | ✓ | DN |
| 4. Check | Cooling system & test condition & record | ✓ | DN |
| 5. Change | Coolant filter | ✓ | DN |
| 6. Inspect | Engine for oil leaks | ✓ | DN |
| 7. <u>Check &/or</u>
replace | Air cleaner element | ✓ | DN |
| 8. Inspect | All belts | ✓ | DN |

PASSED TEST

CHASSIS & GENERAL

- | | | | |
|-----------------------|--|---|----|
| 9. Grease | Chassis and turntable, top up auto greaser | ✓ | DN |
| 10. Check | Turntable adjustment & condition | ✓ | DN |
| 11. Inspect | All uni joints | ✓ | DN |
| 12. Check | Centre bearings | ✓ | DN |
| 13. Adjust | Brakes - check for air leaks | ✓ | DN |
| 14. Brakes % | Steer L <u>76</u> % R <u>70</u> % | ✓ | DN |
| | Drive LF <u>75</u> % RF <u>75</u> % | ✓ | DN |
| | Drive LR <u>75</u> % RR <u>75</u> % | ✓ | DN |
| 15. Drain | Air tanks | ✓ | DN |
| 16. Check | Suspension for condition | ✓ | DN |
| 17. Visual Inspection | Over unit and report | ✓ | DN |
| 18. Check | Oil level front hubs | ✓ | DN |
| 19. Check | Freeplay in steering and all components | ✓ | DN |
| 20. Check | Condition of king pins & ball joints | ✓ | DN |
| 21. Inspect | Steering and oil level and for leaks | ✓ | DN |
| 22. Check | Batteries - level and terminals | ✓ | DN |
| 23. Check | Clutch operation and adjust as required | ✓ | DN |
| 24. Check | All lights | ✓ | DN |
| 25. Check | Wiper, washer operation, level and blades | ✓ | DN |

REPLACED GROUSELINE
FITTEDREPLACED STEER
SLACK ADJUSTERSREPLACED VOLT CABLE CLOVE
REPLACED BLADES

TRANSMISSION

- | | | | |
|-------------|------------|---|----|
| 26. Check | Oil levels | ✓ | DN |
| 27. Inspect | For leaks | ✓ | DN |


REPLACED TRANS
PRESSURE SENSOR

DIFFERENTIAL

- | | | | |
|-------------|------------|---|----|
| 28. Check | Oil levels | ✓ | DN |
| 29. Inspect | For leaks | ✓ | DN |

30. Road Test

Vehicle and check for leaks

Leading Hand / Mechanic: Date: 17/9/20