

EA30-5

<u>Work Order</u>	<u>Request</u>	<u>Request Type</u>	<u>Description</u>
54263	72544	Running Repair	ACH - DECALS REMOVED & BENT PANEL ...
54263	72543	Running Repair	ACH - GPS, SENSORS & 2 WAY RADIO RE...
54263	74803	Running Repair	ACH - REPAIR BUCKET CYLINDER
54263	72541	Running Repair	ACH - INSPECTION FOR FAULTS & DEFEC...
53929	71307	Preventative Maintenance...	KL - RESAMPLE LEFT FINAL
32492	44699	Preventative Maintenance...	G.E.T.
38853	53309	Preventative Maintenance...	DET - SOS (ENGINE)
37705	51845	Preventative Maintenance...	DET - SOS (RIGHT REAR FINAL)
51814	68889	Running Repair	G.E.T
54102	71503	Running Repair	ACH - APM ASSESSMENT
37706	51846	Preventative Maintenance...	DET - SOS (HYD SYSTEM)
40129	54787	Running Repair	VENDOR REPAIRS (TOROMONT)
53615	70992	BIS - Pending Closure	KL - CHIP OUT MUD FOR REPAIR
53615	70915	Breakdown / Emergency	KL - HYD LEAK
53513	70783	Running Repair	KL - T/S H-LINK NOT TAKING GREASE
52854	70029	Preventative Maintenance...	KL - 500HR SERVICE
51916	69001	BIS - Pending Closure	KL - T/S OIL LEAK ON STICK
50186	67076	BIS - Pending Closure	KL - HYD LEAK ON HYD PUMP
51037	68016	Running Repair	KL - NO START
43587	59605	Running Repair	POP - HANDRAIL REPAIRS
49257	66091	Running Repair	MR - REPLACE BENT RH SIDE STEP
50750	67664	Preventative Maintenance...	250 HR PM Service
49257	66031	Running Repair	MR - OUTGOING INSPECTION

45756	61660	Running Repair	POP - REPLACE LEFT & RIGHT TRACKS
43587	59609	Running Repair	POP - REPAIR BOOM PINS & BUSHINGS
44904	60608	Running Repair	POP - R/H IDLER LEAKING
44904	60609	Running Repair	POP - ENGINE/PUMP DRIVE LEAK
43587	59595	Running Repair	POP - ENGINE AIR INTAKE REPAIRS
44904	60605	Running Repair	POP - OUTGOING INSPECTION
43587	60398	Running Repair	POP - WASH UNIT
43587	58975	Running Repair	POP - INCOMING INSPECTION
43587	59745	Running Repair	POP - REPLACE SEATBELT
43587	59547	Running Repair	POP - REPLACE AIR TO AIR SOLENOID A...
43587	58994	Running Repair	POP - REPLACE CARRIER ROLLERS
43587	59608	Running Repair	POP - T/S HYD PUMP LEAK
42776	58104	Running Repair	DET - REPLACE CARRIER ROLLER
42776	57972	Running Repair	DET - OUTGOING INSPECTION
43602	58996	Running Repair	TOROMONT SUPPLY AND INSTAL TRACK ...
42776	58165	Running Repair	DET - WELD HANDRAIL CRACKS
42424	57539	Breakdown / Emergency	DET - ARD HEAD PLUGGED
40870	55637	Running Repair	DET - REPLACE QUICK ATTACH BOLTS
42558	57717	Running Repair	DET - R&R SPROCKETS
40743	55490	Running Repair	DET - T/S EMISSIONS FAULTS
41847	56804	Running Repair	DET - BUCKET SWAP
41532	56433	Running Repair	DET - WELDING INSPECTION
42893	58123	Preventative Maintenance...	1000 HR PM Service
41587	56497	BIS - Pending Closure	DET - BUCKET SWAP

23687	33862	Preventative Maintenance...	UNDERCARRIAGE REPORTS
40875	55642	BIS - Pending Closure	DET - GPS NOT WORKING PROPERLY
40871	55638	BIS - Pending Closure	DET - REPAIR COMPARTMENT DOOR LAT...
40652	55393	Running Repair	DET - BROKEN HANDRAILS
40734	55481	Running Repair	DET - BUCKET SWAP
40648	55389	Running Repair	DET - T/S HYD LEAK
39814	54403	Running Repair	DET - LOOSE TRACK PADS
39017	53599	Running Repair	DET - WELDING *JOB COST*
39359	53903	Running Repair	DET - TIGHTEN WEDGE BOLTS
39875	54478	Running Repair	DET - REPAIR LEAKING QUICK ATTACHE...
39471	54019	Running Repair	DET - BUCKET SWAP
39526	54080	Running Repair	DET - RE SEAL LOWER GLASS
39017	53511	Running Repair	DET - WELDING REPAIRS (BUCKET)
39469	54014	Running Repair	DET - T/S HYD LEAK
39432	53976	Running Repair	DET - T/S REGEN ISSUES
39418	53962	Running Repair	DET - BUCKET SWAP
38210	52487	BIS - Pending Closure	DET - FAILED BOTTOM ROLLERS
37954	52172	Preventative Maintenance...	500 HR PM Service
39075	53575	Running Repair	DET - GPS SENSOR GUARD LOOSE
38822	53274	Running Repair	DET - BUCKET SWAP
38794	53227	Running Repair	DET - T/S SWING BREAK NOT ENGAGING
38352	52665	Running Repair	DET - REPLACE CRACKED WINDSHIELD
38754	53181	Running Repair	DET - REPAIR 2-WAY RADIO ISSUES
37416	51474	BIS - Pending Closure	DET - LOW ENGINE OIL PRESSURE

37978	52200	BIS - Pending Closure	DET - T/S OIL IN FUEL
38379	52693	Running Repair	DET - BUCKET SWAP
38263	52555	Running Repair	DET - BUCKET SWAP
38025	52278	BIS - Pending Closure	DET - REPLACE CUTTING EDGE
37945	52162	Running Repair	DET - BUCKET SWAP
37256	51289	Running Repair	DET - RIGHT FRONT ROLLER WORN
34914	48531	BIS - Pending Closure	NEW - REPLACE GLASS *JOB CHARGE*
34914	50882	BIS - Pending Closure	NEW - REPLACE WINDOW GLASS *JOB C...
34914	48609	Running Repair	NEW - RETURN FILTER LIDS LEAKING
36654	46184	Preventative Maintenance...	2000 HR PM Service
22913	32909	BIS - Pending Closure	NEW - PLAY IN BUCKET PIN
36508	50425	Running Repair	DET - BUCKET SWAP
35546	49239	Running Repair	DET - ASSEMBLY
36427	50331	Running Repair	DET - REMOVE BUCKET
34914	48611	Running Repair	NEW - TRACK LINKS CRACKED
35815	49573	Running Repair	VENDOR REPAIRS - TOROMONT
34914	48607	Running Repair	NEW - UNDERCARRIAGE REPAIRS
25567	36170	Running Repair	NEW - HANDRAILS
34914	48610	Running Repair	NEW - BODY REPAIRS
34167	47105	Running Repair	NEW - COOLANT SAMPLE (TOROMONT)
25567	49085	Running Repair	NEW - REMOVE HANDRAILS
34914	48608	Running Repair	NEW - HYD HOSE LEAKING
34914	48308	Running Repair	NEW - OUTGOING INSPECTION
25967	36674	Breakdown / Emergency	NEW - GPS NOT READING

<u>33044</u>	<u>45434</u>	Running Repair	NEW - REPLACE TRACK PADS
<u>29032</u>	<u>40260</u>	Running Repair	NEW - WELD BUCKET ADAPTER
<u>33533</u>	<u>44380</u>	Preventative Maintenance...	500 HR PM Service
<u>28792</u>	<u>39984</u>	Running Repair	NEW - COOLANT LEAKS
<u>28405</u>	<u>39547</u>	Running Repair	NEW - TRACK REPAIRS
<u>29818</u>	<u>41194</u>	Running Repair	NEW - IDLER FAILURE
<u>29327</u>	<u>40581</u>	Running Repair	NEW - T/S LONG CRANKING ON STARTUP
<u>29311</u>	<u>40562</u>	Running Repair	NEW - LOOSE GPS MOUNT
<u>29146</u>	<u>40381</u>	Running Repair	NEW - LOOSE WEDGE
<u>29031</u>	<u>40259</u>	Running Repair	NEW - PUMP DRIVE OIL LOW
<u>29033</u>	<u>40261</u>	Running Repair	NEW - BUCKET SWAP TO CUB
<u>29035</u>	<u>40263</u>	Running Repair	NEW - FLIP EDGES/REPLACE BOLTS
<u>27723</u>	<u>38753</u>	Running Repair	NEW - BUCKET SWAP
<u>27457</u>	<u>38399</u>	Running Repair	NEW - BUCKET SWAP
<u>27314</u>	<u>38232</u>	Running Repair	NEW - BUCKET SWAP
<u>27029</u>	<u>37877</u>	Running Repair	NEW - HYD LEAK
<u>27030</u>	<u>37878</u>	Running Repair	NEW - BUCKET SWAP
<u>26574</u>	<u>37327</u>	BIS - Pending Closure	NEW - STICK CYL LEAKING
<u>17370</u>	<u>24966</u>	Running Repair	DET - PREP BUCKET FOR WELDING
<u>25965</u>	<u>36672</u>	Running Repair	NEW - MISSING BOLT IN PIN
<u>25347</u>	<u>35933</u>	Running Repair	NEW - SWAP CUB TO DIG BUCKET
<u>25966</u>	<u>36673</u>	Running Repair	NEW - LOOSE TRACK PAD
<u>25031</u>	<u>35533</u>	Running Repair	NEW - HYD LEAK

25060	35576	Running Repair	NEW - BUCKET SWAP
25104	35630	Running Repair	NEW - HYDRAULIC LINE FAILURE
24926	35361	Running Repair	NEW - LOOSE TRACKS
22745	32698	Running Repair	NEW - HYD LEAK
22909	32903	Running Repair	NEW - QUICK ATTACH MISSING ORING
22502	32407	Running Repair	NEW - BUCKET SWAP
17708	25698	Running Repair	DET - INSTALL CAB CAGE
17708	26885	Running Repair	DET - INSPECT IDLER
17708	25428	Running Repair	DET - OUTGOING INSPECTION
21502	31105	Running Repair	NEW - DRIVE HOSE LEAKING
20615	29986	Running Repair	NEW - INCOMING INSPECTION
22118	31931	Running Repair	NEW - BUCKET SWAP
22121	31938	Running Repair	NEW - TRACK REPAIRS
21419	30991	Running Repair	NEW - BUCKET SWAP
20615	29987	Running Repair	NEW- INSTALL HANDRAIL
20615	29985	Running Repair	NEW - REPAIR LIGHTS
21127	30594	Running Repair	NEW - T/S 2 WAY RADIO
21831	31547	Running Repair	NEW - AIR SEAT NOT WORKING
21063	30503	Running Repair	NEW - BUCKET SWAP
17708	26001	Running Repair	DET - REMOVE HAND RAILS
17708	27050	Running Repair	DET - VERIFY FITTINGS ON STICK
17708	27047	Running Repair	DET - INSTALL WRIST BUCKET
17708	26891	Running Repair	DET - HYDRAULIC LEAK
17708	26807	Running Repair	DET - TIGHTEN TRACK PAD
16778	24100	Running Repair	DET - BACK UP CAMERA NOT WORKING

18230	26150	Running Repair	DET - BUCKET SWAP
18227	26147	Running Repair	DET - REMOVE GPS
17348	24926	Running Repair	DET - REGEN UNIT
17417	25020	Running Repair	DET - NO AIR IN SEAT
17333	24910	Running Repair	DET - DOOR NOT CLOSING
17339	24917	Running Repair	DET - CHANGE BUCKET TEETH
17217	24742	Running Repair	DET - REPAIR ELECTRICAL ON BOOM
17216	24741	Running Repair	DET - HYD LEAK
17223	24748	Running Repair	DET - REGEN
16600	23850	Running Repair	DET - REPAIR WALKWAY
15766	22559	Running Repair	DET - REPLACE INJECTOR
15766	22558	Running Repair	DET - SCR CODES
15088	22279	Running Repair	DET - SCREEN MALFUNCTIONING
15088	21616	Breakdown / Emergency	DET - EMISSIONS SYSTEM CODES
14450	21227	Running Repair	DET - BUCKET SWAP
14450	20651	Running Repair	DET - REMOVE CUTTING EDGE
13708	20081	Running Repair	DET - GPS BRACKET BROKE
14380	20010	Preventative Maintenance...	1000 HR PM Service
13708	19579	Running Repair	DET - ENGINE LIGHT ON
13708	19871	Running Repair	DET - FORCED REGEN
13523	19119	Running Repair	DET- GPS POWER LOSS
13001	18398	Running Repair	DET - TRACK LOOSE
13708	19505	Running Repair	DET - LEAK IN PUMP BAY
13523	19209	Running Repair	DET - ENGINE RUNNING RICH
12873	18168	Running Repair	DET - REGEN ISSUES

<u>12747</u>	<u>18160</u>	Running Repair	DET - DPF LEVEL LOCKED OUT REMOVE ...
<u>13001</u>	<u>18663</u>	Running Repair	DET - ELECTRICAL ISSUE ON CAB CONTR...
<u>12630</u>	<u>17835</u>	Running Repair	DET - SEAT NOT WORKING
<u>12177</u>	<u>17158</u>	Running Repair	DET - WINDOW REPLACEMENT
<u>12177</u>	<u>17508</u>	Running Repair	DET - LEAKING O-RING
<u>12177</u>	<u>17774</u>	Running Repair	DET - REPAIR CAB LIGHTS
<u>12177</u>	<u>17773</u>	Running Repair	DET - REPAIR HYDRAULIC LEAK
<u>12177</u>	<u>17520</u>	Running Repair	DET - REMOVE/REINSTAL BUCKET
<u>11679</u>	<u>16910</u>	Running Repair	DET - LOCK WEDGE
<u>11679</u>	<u>16912</u>	Running Repair	DET - REPLACE SEAT SWITCH WIRE
<u>11464</u>	<u>16025</u>	Running Repair	DET - CRACKED GLASS
<u>11679</u>	<u>16914</u>	Running Repair	DET - POOR 2 WAY CONNECTION
<u>11679</u>	<u>16308</u>	Running Repair	DET - MISSING BOLT ON TOP RAILING
<u>11557</u>	<u>16128</u>	Running Repair	DET - GUARD RAIL BEHIND BOOM MISSI...
<u>8380</u>	<u>10859</u>	Running Repair	DET - MAIN WINDOW CRACKED
<u>8118</u>	<u>10415</u>	BIS - Pending Closure	DET - RAILING BY HYD TANK NEED TO B...
<u>10165</u>	<u>14755</u>	Running Repair	DET - CAB AND BODY
<u>10165</u>	<u>14731</u>	Running Repair	DET - ATTACHMENTS
<u>10165</u>	<u>14732</u>	Running Repair	DET - G.E.T.
<u>10165</u>	<u>13929</u>	BIS - Pending Closure	DET - ENGINE
<u>10165</u>	<u>13927</u>	BIS - Pending Closure	DET - ELECTRICAL
<u>10165</u>	<u>13928</u>	BIS - Pending Closure	DET - HYDRAULIC
<u>8165</u>	<u>10513</u>	BIS - Pending Closure	DET - HYD LINES RUBBING ON UNIT
<u>8164</u>	<u>10512</u>	BIS - Pending Closure	DET - GPS STICK SENSOR NEEDS A GUARD

<u>8339</u>	<u>10797</u>	BIS - Pending Closure	DET - TRACK PADS STARTING TO CRACK
<u>10094</u>	<u>13816</u>	BIS - Pending Closure	DET - REQUIRES NEW STARTER
<u>8653</u>	<u>11326</u>	BIS - Pending Closure	DET - REQUIRES CUTTING EDGES
<u>8085</u>	<u>10371</u>	BIS - Pending Closure	DET - LATCH BROKEN ON FRONT DOOR ...
<u>8989</u>	<u>11947</u>	BIS - Pending Closure	DET - L/S FEMALE THREAD ON FITTING ...
<u>7993</u>	<u>10227</u>	BIS - Pending Closure	DET - HYD MALE COUPLER FOR WRIST B...
<u>7921</u>	<u>10062</u>	BIS - Pending Closure	DET - MIDDLE TOOTH KEEPER MISSING ...
<u>7921</u>	<u>10975</u>	BIS - Pending Closure	DET- TIPS, PINS, RETAINERS
<u>9553</u>	<u>12928</u>	Preventative Maintenance...	2000 HR PM Service
<u>7853</u>	<u>9943</u>	BIS - Pending Closure	DET - RAIL BEHIND SWING MOTOR LOOSE
<u>7896</u>	<u>10010</u>	BIS - Pending Closure	DET - BROKEN BOTTOM WINDOW
<u>3796</u>	<u>4513</u>	Preventative Maintenance...	500 HR PM Service