

EA30-7

<u>Work Order</u>	<u>Request</u>	<u>Request Type</u>	<u>Description</u>
60170	78696	BIS - Pending Closure	BAS - T/S WASHER FLUID PUMP
59697	78254	BIS - Pending Closure	BAS - UNDERCARRIAGE
59697	78123	BIS - Pending Closure	BAS - DRY RENT INCOMING INSPECTION
35530	49221	Preventative Maintenance...	G.E.T.
60514	79096	Running Repair	BAS - REMOVE PANELS TO BE STEAMED
59234	77555	Preventative Maintenance...	BAS - SAMPLE ENGINE OIL
59724	78152	BIS - Pending Closure	BAS - REPLACE FINAL DRIVES
60707	79318	Running Repair	BAS - PREP FOR AUCTION
52217	69330	BIS - Pending Closure	BAS - BURNING COOLANT AND FINALS N...
58852	77095	Running Repair	BAS - FUEL SENSOR REPLACE
59697	78919	BIS - Pending Closure	BAS - WIPER REPAIRS
59697	78331	BIS - Pending Closure	BAS - LIGHT REPAIRS
59697	78334	BIS - Pending Closure	BAS - HYD LEAKS
59173	77478	BIS - Pending Closure	BAS - CAMERA REPAIR
59620	78034	Preventative Maintenance...	250 HR PM Service
56882	74849	BIS - Pending Closure	BAS - ENGINE CODES
56442	74307	Running Repair	BAS - UNDERCARRIAGE REPAIRS
52441	69575	Running Repair	BAS - LIGHT REPAIRS
55266	72940	Preventative Maintenance...	BAS - FIRE SUPPRESSION (LEVITT)
58637	76842	BIS - Pending Closure	BAS - REPLACE DEF HEADER
59174	77479	BIS - Pending Closure	BAS - BUCKET SWAP
57128	75129	BIS - Pending Closure	BAS - COOLANT LEAK
51696	69105	Running Repair	BAS - HYD COUPLER

57654	75784	BIS - Pending Closure	BAS - HIGH HYD TEMPS
56641	74576	Preventative Maintenance...	BAS - T/S NO AC
58624	76825	Running Repair	BAS - CHARGE AIR SENSOR
58226	76401	Preventative Maintenance...	500 HR PM Service
55580	73315	BIS - Pending Closure	BAS - REPLACE BATTERIES
57579	75694	Running Repair	BAS - REPLACE DEF INJECTOR
57040	75035	Running Repair	BAS - GREASE BOOM PINS
54993	72583	Breakdown / Emergency	BAS - LEFT FINAL DRIVE FAILED
56740	74677	Preventative Maintenance...	BAS - 250 HR PM SERVICE
55362	73049	Running Repair	BAS - EGR HOSES / REPLACE
55360	73047	Preventative Maintenance...	BAS - SENSOR - COUNTER WEIGHT / RE...
54849	72401	BIS - Pending Closure	BAS - HORN REPAIR
53336	70581	BIS - Pending Closure	BAS - T/S DEF
54850	72402	BIS - Pending Closure	BAS - TIGHTEN TRACKS
52289	69414	Running Repair	BAS - INSTALL ADJUSTER ASSEMBLY
54222	71652	Running Repair	BAS - BUCKET SWAP
54399	71877	Breakdown / Emergency	BAS - TRACKS LOCKED UP
52687	69840	Running Repair	BAS - PUMP DRIVE OIL LOW
53850	71205	Breakdown / Emergency	BAS - FAILED LEFT FRONT IDLER
53850	71241	Running Repair	BAS - TRACK TENSIONER LEAK
53993	71390	Preventative Maintenance...	2000 HR PM Service
52446	69580	Running Repair	BAS - BUCKET SWAP
52545	69688	Running Repair	BAS - T/S CHECK ENGINE LIGHT
53257	70483	Preventative Maintenance...	BAS - 250HR PM

51530	68563	Running Repair	BAS - TRACK REPAIRS
53137	70343	Running Repair	BAS - AFTER TREATMENT AND DEF CODE
51696	68741	Running Repair	BAS - HYD LEAKS
51371	68373	Preventative Maintenance...	BAS - GREASE UNIT
51286	68278	Running Repair	BAS - BUCKET SWAP
51423	68439	Running Repair	BAS - LEFT SIDE CUTTING EDGE RIPPED ...
51452	68476	Running Repair	BAS - ENGINE CODES
50034	66896	Running Repair	BAS - COUNTERWEIGHT ALARM
49962	66811	Running Repair	BAS - T/S HYD OIL LOW
51268	68260	Preventative Maintenance...	1000 HR PM Service
51373	68375	Running Repair	BAS - NO POWER
51192	68182	Running Repair	BAS - REPLACE BEACON LIGHTS
51372	68374	Running Repair	BAS - REPAIR LIGHTS
50362	67250	Running Repair	BAS - HANDRAIL REPAIRS
50372	67263	BIS - Pending Closure	BAS - STICK LIGHTS NOT WORKING
49298	66082	BIS - Pending Closure	BAS - RE & RE BROKEN GUARD RAIL
42366	62655	Vendor Repairs	ACH - VENDOR REPAIRS (GIRDEL)
50959	67925	Running Repair	BAS - FAILED DEF COOLANT LINE
50652	67545	Running Repair	BAS - BUCKET SWAP
49297	66081	Running Repair	BAS - T/S SCR SYSTEM CODES
47600	64006	Running Repair	BAS - REPLACE QUICK FILL VENT
50152	67041	Running Repair	BAS - COLD START
49051	65795	BIS - Pending Closure	BAS - REPLACE FUEL CAP
49957	66806	Running Repair	BAS - REPLACE BEACON LIGHT
42366	57469	BIS - Pending Closure	BAS - T/S SWING DRIVE ISSUES

48480	65087	BIS - Pending Closure	BAS - NOISE COMPLAINT
48270	64834	BIS - Pending Closure	BAS - ENGINE CODES
47848	64321	Preventative Maintenance...	500 HR PM Service
21384	34826	BIS - Pending Closure	BAS - T/S LOW POWER
21384	30950	BIS - Pending Closure	BAS - T/S REGEN ISSUES
46948	63171	Running Repair	BAS - T/S NO START
46868	63070	Running Repair	BAS - T/S POWER EXHAUST SYSTEM
46570	62707	Running Repair	BAS - INSTALL WINTER FRONT
46389	62474	Running Repair	BAS - REPLACE PIN CAP ON STICK
45799	61723	Preventative Maintenance...	2000 HR PM Service
44836	60519	Running Repair	BAS - BATTERY REPLACEMENT
42823	58821	Running Repair	BAS - MOUNT NUMBER PLATES
42823	58822	Running Repair	BAS - INSTALL BELLY PANS
42823	59003	Running Repair	BAS - REPAIR LIGHT WIRING
42823	58033	Running Repair	BAS - DRY RENT INSPECTION
42166	57214	Running Repair	BAS - WASH
42778	57974	Running Repair	BAS - INSTALL DECALS
43235	58572	Running Repair	BAS - REPLACE ALT BELT
43298	58640	Preventative Maintenance...	BAS - FIRE SUPPRESSION
42829	58039	Running Repair	BAS - REPAIR BOOM LIGHT
41198	56017	Running Repair	BAS - WORN SPROCKETS
42314	57404	Running Repair	BAS - T/S POOR TRACK POWER
23282	33378	BIS - Pending Closure	BAS - T/S BLOCK HEATER CORD
23282	57938	Running Repair	BAS - RE ROUTE POWER CONVERTER

42505	57643	Running Repair	BAS - REPLACE FLOOR MAT
42505	57792	Running Repair	BAS - FLOOR MAT *JOB COST*
42250	57314	Running Repair	BAS - WELDING INSPECTION
42196	57245	Running Repair	BAS - REPLACE OPERATOR SEAT
42260	57332	Running Repair	BAS - T/S HORN BUTTON NOT WORKING
41197	56016	Running Repair	BAS - HYD PUMP LEAKING
41639	56554	Preventative Maintenance...	250 HR PM Service
40013	54643	Running Repair	BAS - T/S LEAK AT TURN TABLE
23608	33775	BIS - Pending Closure	BAS - REPLACE DEF PUMP
40568	55300	Preventative Maintenance...	500 HR PM Service
39716	54284	Preventative Maintenance...	BAS - SOS (ENGINE)
40599	55334	Running Repair	BAS - CATWALK REPAIRS
40014	54644	Running Repair	BAS - REPAIR LIGHTS
39097	53605	BIS - Pending Closure	BAS - TRACK ADJUSTER FAILED
39119	53631	Running Repair	BAS - BROKEN THROTTLE KNOB *JOB CO...
39119	53679	Running Repair	BAS - THROTTLE KNOB
38648	53021	Preventative Maintenance...	250 HR PM Service
37347	51395	Running Repair	BAS - REPAIR LIGHT WIRING
36981	50961	Running Repair	BAS - T/S A/C NOT WORKING
36930	50893	Preventative Maintenance...	1000 HR PM Service
30866	42455	Preventative Maintenance...	BAS - SOS ENGINE
36726	50666	BIS - Pending Closure	KL - REPLACE SEAT RECLINE CABLE
36725	50665	BIS - Pending Closure	BAS - TIGHTEN TRACKS
36521	50437	Running Repair	BAS - T/S SEAT

35702	49436	Running Repair	BAS - T/S LEAKING SWINGS
35475	49137	Running Repair	BAS - ELECTRICAL REPAIRS
30777	42343	BIS - Pending Closure	BAS - REPLACE ENGINE AIR FILTER
34677	47972	Running Repair	BAS - TRACK REPAIRS
35926	49698	Running Repair	BAS - REPLACE WIPER BLADE
34865	48233	Preventative Maintenance...	250 HR PM Service
35476	49138	Running Repair	BAS - REPLACE WIPER BLADE
35473	49135	Running Repair	BAS - REPLACE GREASE ZERK
35108	48613	Running Repair	BAS - T/S ACTIVE CODES
34295	47318	Running Repair	BAS - T/S SCR FAULTS
32515	44726	BIS - Pending Closure	BAS - A/C REPAIRS
32517	44729	BIS - Pending Closure	BAS - REPLACE R/S LADDER
22112	31925	BIS - Pending Closure	BAS - KNOB MISSING IN CAB
23929	35058	BIS - Pending Closure	BAS - REPLACE BUCKET CYL HOSE *JOB ...
30352	41832	Running Repair	BAS - WORN ROLLERS/CARRIERS
30352	46224	Running Repair	BAS - WORN ROLLERS/CARRIERS JOB CO...
32584	46227	Running Repair	BAS - INSTALL BUCKET
32584	46226	Running Repair	BAS - ADJUST TRACKS
32584	45706	Running Repair	BAS - RADIO
32584	46228	Running Repair	BAS - T/S STICK LIGHT
32584	46084	Running Repair	BAS - REPLACE GREASE ZERKS
32584	46225	Running Repair	BAS - T/S STICK LIMIT SWITCH
32584	45366	Running Repair	BAS - HYD LEAK STICK CYL JOB COST
32584	46083	Running Repair	BAS - ASSEMBLE FRONT END TO Q/A

32584	45838	Running Repair	BAS - HYD LEAK STICK CYL
32588	44825	Running Repair	BAS - REPLACE UNIT NUMBERS
33552	46177	Running Repair	BAS - TRACK TENSIONER VALVES
33611	46258	Running Repair	BAS - LEAKING SWIVEL JOINT
32584	46239	Running Repair	BAS - REPAIR/REBUILD GUARDS
31681	43558	Preventative Maintenance...	BAS - FIRE SUPPRESSION SYSTEM INSPE...
32584	45365	Running Repair	BAS - COOLANT LEAK
32584	44991	Running Repair	BAS - STEAM UNIT
32584	44820	Running Repair	BAS - TA2 INSPECTION
32888	45205	Running Repair	BAS - BROKEN CAT WALK MOUNTING BR...
30349	41829	Running Repair	BAS - BENT CATWALK
32163	44223	Preventative Maintenance...	500 HR PM Service
31842	43775	Breakdown / Emergency	BAS - ALTERNATOR REPLACEMENT
31366	43090	Running Repair	BAS - REPLACE BUCKET TEETH
30989	42603	Running Repair	BAS - REPLACE BUCKET TEETH
31126	42778	Running Repair	BAS - REPLACE LIGHT BULB ON TRACK
30350	41830	Running Repair	BAS - REPAIR HYD LEAK
26102	36815	Running Repair	BAS - REPLACE BEACON/REPAIR ELECTRI...
30163	41585	Running Repair	BAS - BUCKET SWAP
30127	41540	Preventative Maintenance...	BAS - 2000 HR PM
28979	40199	Running Repair	BAS - REPLACE BLOCK HEATER CORD
28772	39961	Running Repair	BAS - RE & RE BOTTOM KICK GLASS
27815	38867	BIS - Pending Closure	BAS - BUCKET SWAP
27234	38120	Breakdown / Emergency	BAS - NOX SENSOR FAILURE

<u>26660</u>	<u>37433</u>	BIS - Pending Closure	BAS - WIPER REPLACEMENT
<u>26227</u>	<u>36945</u>	Running Repair	BAS - ALTERNATOR / BATTERY LIGHT ON
<u>26986</u>	<u>37817</u>	Running Repair	BAS - HYD LEAK
<u>26202</u>	<u>26930</u>	Preventative Maintenance...	500 HR PM Service
<u>24274</u>	<u>34587</u>	Running Repair	BAS - FINNING SAMPLE - ENGINE
<u>26100</u>	<u>36813</u>	Running Repair	BAS - CHECK OVER
<u>26099</u>	<u>36812</u>	Running Repair	BAS - ADJUST TRACKS
<u>25703</u>	<u>36346</u>	Running Repair	BAS - CHECK OVER
<u>25102</u>	<u>35628</u>	Running Repair	BAS - T/S LOW ENGINE POWER
<u>22141</u>	<u>31976</u>	Running Repair	BAS - EGR HOSES LEAKING
<u>23929</u>	<u>34134</u>	Running Repair	BAS - REPLACE BUCKET CYL HOSE
<u>25103</u>	<u>35629</u>	Running Repair	BAS - REPLACE CUTTING EDGES
<u>23282</u>	<u>33779</u>	Running Repair	BAS - PICK UP PARTS
<u>23378</u>	<u>33440</u>	Preventative Maintenance...	1000 HR PM Service
<u>23833</u>	<u>34028</u>	Running Repair	BAS - FUEL LINE ISSUES
<u>22633</u>	<u>32556</u>	Running Repair	BAS - BOOM LIGHT NOT WORKING
<u>23282</u>	<u>33376</u>	Running Repair	BAS - REPAIR COOLANT LEAK
<u>23282</u>	<u>33377</u>	Running Repair	BAS - PM ASSESSMENT
<u>22771</u>	<u>32732</u>	Running Repair	BAS - REPLACE CAB FILTERS
<u>22253</u>	<u>32118</u>	Running Repair	BAS - REPAIR BROKEN CATWALK
<u>21973</u>	<u>31762</u>	Running Repair	BAS - COOLANT LEAK
<u>22157</u>	<u>31995</u>	Running Repair	BAS - ADJUST STICK CYL LIMIT SENSOR
<u>21779</u>	<u>31475</u>	Running Repair	BAS - REPAIR CAB SEALS / CHANGE CAB ...
<u>22114</u>	<u>31927</u>	Breakdown / Emergency	BAS - STICK CYL LEAKING ON ROD END

<u>22111</u>	<u>31924</u>	Running Repair	BAS - HORN WIRING REPAIRS
<u>21890</u>	<u>31633</u>	Preventative Maintenance...	500 HR PM Service
<u>19560</u>	<u>29835</u>	Breakdown / Emergency	BAS - COOLANT LEAK DEF INJECTOR LINE
<u>19538</u>	<u>28146</u>	Running Repair	BAS - DAMAGED CATWALK
<u>19560</u>	<u>29055</u>	Running Repair	BAS - ELECTRICAL PLUG
<u>20255</u>	<u>29481</u>	Running Repair	BAS - LED LIGHTS
<u>19914</u>	<u>28831</u>	Running Repair	BAS - SCR CODES
<u>19913</u>	<u>28830</u>	Running Repair	BAS - T/S ENGINE NOISE
<u>19560</u>	<u>28174</u>	Breakdown / Emergency	BAS - INJECTION PUMP COUPLER FAILURE
<u>20163</u>	<u>29238</u>	Running Repair	BAS - GREASE UNIT
<u>19833</u>	<u>28668</u>	Preventative Maintenance...	BAS - T/S MULTIPLE CODES
<u>19423</u>	<u>27987</u>	Breakdown / Emergency	BAS - COOLANT LEAK
<u>19667</u>	<u>28363</u>	Running Repair	BAS - BUCKET CYL REPAIRS
<u>19368</u>	<u>27907</u>	Running Repair	BAS - T/S ENGINE CODE
<u>18288</u>	<u>26226</u>	Running Repair	BAS - BOTTOM PANS
<u>18384</u>	<u>26432</u>	Breakdown / Emergency	BAS - FIRE SUPPRESSION INSTALL
<u>18007</u>	<u>25864</u>	Running Repair	BAS - INSTALL STICK LIGHTS
<u>18912</u>	<u>27252</u>	Running Repair	BAS - INSTALL CUB
<u>18912</u>	<u>27253</u>	Running Repair	BAS - INSTALL FUEL TANK PANEL
<u>18912</u>	<u>27251</u>	Running Repair	BAS - FAB NEW ENGINE PANEL
<u>18912</u>	<u>27254</u>	Running Repair	BAS - T/S TOOL BOX LIGHT
<u>18912</u>	<u>27250</u>	Running Repair	BAS - OUTGOING/SUNCOR INSPECTION
<u>17982</u>	<u>25824</u>	Running Repair	BAS - NEEDS CORKS
<u>18852</u>	<u>27159</u>	Running Repair	BAS - INSTALL SUNCOR RADIO
<u>18075</u>	<u>25932</u>	Running Repair	BAS - INSTALL UNIT #'S

18282	26220	Running Repair	BAS - STICK CYLINDER BARREL END HOSE
18404	26454	Preventative Maintenance...	BAS - 250 HR PM
15768	22561	Running Repair	POP - CLEAN H LINK BORES
14580	20836	Running Repair	BAS - REPAIR HANDRAIL & STEPS
14111	20153	Running Repair	BAS - FRONT END REPAIRS
18102	25972	Breakdown / Emergency	BAS - COOLANT LEAK
18108	25983	Running Repair	BAS - HVAC REPLACEMENT
18103	25973	Running Repair	BAS - STICK LIMIT CIRCUIT
7501	9398	Breakdown / Emergency	BAS - DIAG EXCESSIVE BLOW BY (ENGIN...
7501	19646	Major Component Replace...	POP - ENGINE REMOVAL FROM 02-6455 ...
17264	24819	Running Repair	BAS - REPLACE FAILED DEF PUMP/SENSO...
17759	25515	Running Repair	BAS - FUEL LEAK
17071	24531	Running Repair	BAS - REPLACE HOOD SHOCK
17080	24560	Running Repair	BAS - REPLACE BATTERIES
14050	20052	Running Repair	BAS - INSPECT AND MEASURE ATTACHM...
13867	19774	Running Repair	POP - WASH RIPPER STICK
9499	12793	BIS - Pending Closure	BAS - INSPECTION
6184	7398	BIS - Pending Closure	BAS- BUCKET PIN HAS MINOR PLAY AND ...
8150	10473	BIS - Pending Closure	BAS - STEAMING UNIT
6717	8175	BIS - Pending Closure	BAS - ACTIVE CODES
6928	8578	BIS - Pending Closure	BAS- T/S ENGINE CODES
3657	4364	BIS - Pending Closure	BATTERY LIGHT
2911	3457	Running Repair	ENGINE OIL COMING OUT OF BLOW BY ...
6327	7554	Running Repair	BAS- HAND RAILING WELDS CRACKED

5411	6483	BIS - Pending Closure	BAS - OIL LEAK FROM BLOW BY
5796	6910	BIS - Pending Closure	BAS - REPAIR BRACKET @ BOOM BASE
5905	7022	BIS - Pending Closure	BAS - EXTRACTED BROKEN BOLTS FROM ...
5917	7033	BIS - Pending Closure	BAS - REPLACED GREASE FITTINGS
5918	7034	BIS - Pending Closure	BAS - HYD LEAK
5919	7035	BIS - Pending Closure	BAS - RAILING HARDWARE
4228	5083	Running Repair	WELD CRACKED ON DIG BUCKET
5613	6747	Running Repair	BAS- BELLY PAN HANGING DOWN
4960	5960	Running Repair	BAS-PLAY IN BUCKET PIN, INSPECT
5425	6502	Running Repair	BAS- BUCKET NEEDS NEW TEETH
2659	3142	Running Repair	BAS - RATTLING NOISE FROM HYD. PUM...
5755	6875	BIS - Pending Closure	BAS - THROTTLE POSITION SENSOR COD...
5749	6868	BIS - Pending Closure	2000 HR PM Service
5706	6829	BIS - Pending Closure	BAS - INSTALL TEETH
5705	6828	BIS - Pending Closure	BAS - INSTALL BUCKET
5714	6837	BIS - Pending Closure	BAS - TIGHTEN TRACKS
5615	6749	BIS - Pending Closure	BAS- INSTALL MISSING ACCESS PANEL B...
5445	6520	BIS - Pending Closure	BAS- T/S ENGINE LIGHT
4841	5780	BIS - Pending Closure	BAS- OIL LEAK FROM BELLY
5409	6310	BIS - Pending Closure	250 HR PM Service
4290	5129	BIS - Pending Closure	REGEN ISSUES
3684	4393	BIS - Pending Closure	DEF CODES
4261	5108	BIS - Pending Closure	BUCKET SWAP
4208	5063	BIS - Pending Closure	REGEN ISSUES

4106	4944	BIS - Pending Closure	HEAT AND BEND STEP	:
4105	4943	BIS - Pending Closure	WELDING INSPECTION	:
4061	4807	BIS - Pending Closure	FUEL, OIL & COOLANT LEAK	:
4015	4751	BIS - Pending Closure	HEAT UNIT	:
4053	4793	Breakdown / Emergency	STICK CYLINDER	:
3808	4523	BIS - Pending Closure	STICK CYLINDER	:
3931	4654	Breakdown / Emergency	FUEL, OIL & COOLANT LEAK	:
4016	4752	BIS - Pending Closure	INSTALL SEAT COVERS	:
3933	4656	BIS - Pending Closure	HANDRAIL	:
3853	4577	BIS - Pending Closure	BELLY PAN GUARDS	:
3772	4489	Running Repair	REPLACE TRACK ADJUST GREASE FITTING...	:
1446	1706	Running Repair	BAS - FRONT WINDOW BADLY SCRATCHED	:
3756	4473	BIS - Pending Closure	REPLACED FRONT WIPER	:
3017	3627	Breakdown / Emergency	POSSIBLE SWING DRIVE, COOLANT AND ...	:
3225	3834	Preventative Maintenance...	FULL INSPECTION	:
3601	4310	BIS - Pending Closure	BEACON LIGHT	:
3600	4309	BIS - Pending Closure	REMOVE BUCKET	:
3244	3859	Running Repair	BROKEN HANDRAILS	:
2585	3069	BIS - Pending Closure	BAS - V BELT LOOSE	:
3342	3959	BIS - Pending Closure	500 HR PM Service	:
2592	3074	BIS - Pending Closure	BAS - BUCKET SWAP	:
2412	2876	BIS - Pending Closure	BAS - NEEDS TOP CAB LIGHT TIGHTENED	:
2503	2960	Running Repair	BAS - DERATE - COMPLETED MANUAL RE...	:
2287	2755	Running Repair	BAS - FUEL LEAK	:

2288	2756	Running Repair	BAS - DOOR SLIDING WINDOW WON'T O...	\$
2307	2772	Running Repair	BAS - RIPPER TOOTH NEEDS TO BE REPL...	\$
2000	2441	Running Repair	BAS - FINNING SAMPLE, R/S FINAL DRIV...	\$
2727	3215	Running Repair	BAS - TIGHTENED LOOSE BUCKET WEDGE	\$
2601	3083	Running Repair	BAS - BATTER LIGHT/ALTERNATOR ISSUES	\$
2331	2797	Running Repair	BAS - NEEDS BEACON WIRES REPLACED	\$
2179	2662	Running Repair	BAS - CHANGED OUT BALL STUD CAP AN...	\$
2178	2661	Running Repair	BAS - DEF CODES	\$
2136	2612	Running Repair	BAS - RELAY POWER CODE	\$
2137	2613	Running Repair	BAS - CHAIN FOR HANGER FOR HYD HOS...	\$
1446	1960	Running Repair	BAS - FUEL PUMP CODE	\$
1655	2026	Preventative Maintenance...	BAS - 1000 HR PM SERVICE	\$
1661	2031	Preventative Maintenance...	1000 HR PM Service	\$
1422	1649	Running Repair	BAS- R/S TRACK LOOSE	\$
1547	1382	Preventative Maintenance...	250 HR PM Service	\$