









Box 730  
 Grande Prairie, AB T8V 3R5  
 Phone: (780) 876-8949  
 Fax: (780) 830-0580

# 150 / 300 / 450 HOUR HEAVY DUTY VEHICLE MAINTENANCE

Date: March 18 Unit: 252 KMs: 242381 Hours: 14023

Cab Interior Inspection	Checked	Changed	N/A	Around Vehicle Inspection	Checked	Changed	N/A	Under Hood or Raised Cab Inspection	Checked	Changed	N/A
Turn key on – check for fault codes; record.				Check cab and body appearance – condition & damage				Check positive air shutoff – test for proper function			
Start engine – observe instrument operation				Check air fairings, extenders, & brackets				Check radiator, fan drive, & shroud			
Apply and release brakes 10 times				Check license plate holder & light				Pressure test cooling system			
Check low air warning buzzer & light				Check lights – head, tail/stop, turn, marker, backup reflectors, & work				Test DCA, extended life & freeze protection			
Check that dash parking brake valve pop out at 35 psi				Check doors – access and latches				Check belts – visual inspection for wear & tension			
Check clutch pedal free travel				Check steps & grab handles				Check hoses – condition and/or leaks			
Check clutch brake operation				Check hood latches				Check hose & wire routing & securing			
Check transmission hi-low spitter or 2 speed axle controls				Check fuel tank straps & fuel fill cap				Check exhaust – mounting, clamping, & evidence of leaks			
Check clutch and/or neutral safety switch				Check batteries – visual inspection of cables, clamps, & fluid level				Check air filter – condition & damage			
Check HVAC defrosters, air vents, fan speed & controls				Check vertical exhaust, muffler, clamps, & brackets				Check air cleaner restriction gauge			
Check HVAC duct temperature, record				Check mirrors – condition & mounts				Check air cleaner housing, air-to-air piping and clamping			
Check cabin air filter				Check mud flaps, splash guards, & dock bumpers				Check alternator – visual inspection			
Check windshield wipers & washers				Check trailer electrical, air hoses, & glad hands				Check wiper blade condition			
Check horns, electric & air				Check cab air ride system				Check starting system – visual inspection			
Check interior lights, turn indicators, & dash lights				Check fifth wheel – mounting & jaws				Check steering shaft, shaft U-joints, box mounting, pitman arm & drag link			
Check door glass & mirror controls				Check frame & crossmembers		/		Check power steering fluid level			
Check seats, seat belts, & floor mats				Check pintle hook & safety chain loops				Top off windshield washer fluid			
Check tractor hand valve				Check tow hook and bumper attachment – bolts and/or welds secure & no cracking		/		Drain water from fuel water separator			
Dock power divider shift operating				Check tires & wheels – enter existing PSI & tread depth		/		Change fuel filter (engine mounted, include prescreen element if equipped)			
Check fifth wheel slider air lock operation								Change fuel water separator element			
Check air suspension dump valve						Change water filter					
Check ABS antilock monitor light, if equipped											
Check parking brake											
Check for three approved warning triangles											





Box 730  
Grande Prairie, AB T8V 3R5  
Phone: (780) 876-8949  
Fax: (780) 830-0580

# 150 / 300 / 450 HOUR HEAVY DUTY VEHICLE MAINTENANCE

Date: MAY 27, 2025

Unit: 252

KMs: 248036

Hours: 14327

Cab Interior Inspection	Checked	Changed	N/A	Around Vehicle Inspection	Checked	Changed	N/A	Under Hood or Raised Cab Inspection	Checked	Changed	N/A			
Turn key on – check for fault codes; record.				Check cab and body appearance – condition & damage				Check positive air shutoff – test for proper function						
Start engine – observe instrument operation				Check air fairings, extenders, & brackets				Check radiator, fan drive, & shroud						
Apply and release brakes 10 times				Check license plate holder & light				Pressure test cooling system						
Check low air warning buzzer & light				Check lights – head, tail/stop, turn, marker, backup reflectors, & work				Test DCA, extended life & freeze protection						
Check that dash parking brake valve pop out at 35 psi				Check doors – access and latches				Check belts – visual inspection for wear & tension						
Check clutch pedal free travel			/	Check steps & grab handles				Check hoses – condition and/or leaks						
Check clutch brake operation			/	Check hood latches				Check hose & wire routing & securing						
Check transmission hi-low spitter or 2 speed axle controls	/			Check fuel tank straps & fuel fill cap				Check exhaust – mounting, clamping, & evidence of leaks						
Check clutch and/or neutral safety switch			/	Check batteries – visual inspection of cables, clamps, & fluid level				Check air filter – condition & damage						
Check HVAC defrosters, air vents, fan speed & controls				Check vertical exhaust, muffler, clamps, & brackets				Check air cleaner restriction gauge						
Check HVAC duct temperature, record				Check mirrors – condition & mounts				Check air cleaner housing, air-to-air piping and clamping						
Check cabin air filter				Check mud flaps, splash guards, & dock bumpers				Check alternator – visual inspection						
Check windshield wipers & washers				Check trailer electrical, air hoses, & glad hands				Check wiper blade condition						
Check horns, electric & air				Check cab air ride system				Check starting system – visual inspection						
Check interior lights, turn indicators, & dash lights				Check fifth wheel – mounting & jaws			/	Check steering shaft, shaft U-joints, box mounting, pitman arm & drag link						
Check door glass & mirror controls				Check frame & crossmembers	/			Check power steering fluid level						
Check seats, seat belts, & floor mats				Check pintle hook & safety chain loops	.		/	Top off windshield washer fluid			/			
Check tractor hand valve				Check tow hook and bumper attachment – bolts and/or welds secure & no cracking	/			Drain water from fuel water separator						
Dock power divider shift operating				Check tires & wheels – enter existing PSI & tread depth	/			Change fuel filter (engine mounted, include prescreen element if equipped)						
Check fifth wheel slider air lock operation			/								Change fuel water separator element			
Check air suspension dump valve											Change water filter			
Check ABS antilock monitor light, if equipped														
Check parking brake														
Check for three approved warning triangles														






Box 730  
 Grande Prairie, AB T8V 3R5  
 Phone: (780) 876-8949  
 Fax: (780) 830-0580

# 150 / 300 / 450 HOUR HEAVY DUTY VEHICLE MAINTENANCE

Date: July 23/25 Unit: 252 KMs: 254058 Hours: 14673

Cab Interior Inspection	Checked	Changed	N/A	Around Vehicle Inspection	Checked	Changed	N/A	Under Hood or Raised Cab Inspection	Checked	Changed	N/A
Turn key on – check for fault codes; record.	/			Check cab and body appearance – condition & damage	/			Check positive air shutoff – test for proper function	/		
Start engine – observe instrument operation	/			Check air fairings, extenders, & brackets	/			Check radiator, fan drive, & shroud	/		
Apply and release brakes 10 times	/			Check license plate holder & light	/			Pressure test cooling system	/		
Check low air warning buzzer & light	/			Check lights – head, tail/stop, turn, marker, backup reflectors, & work	/			Test DCA, extended life & freeze protection	/		
Check that dash parking brake valve pop out at 35 psi	/			Check doors – access and latches	/			Check belts – visual inspection for wear & tension	/		
Check clutch pedal free travel			/	Check steps & grab handles	/			Check hoses – condition and/or leaks	/		
Check clutch brake operation			/	Check hood latches	/			Check hose & wire routing & securing	/		
Check transmission hi-low spitter or 2 speed axle controls			/	Check fuel tank straps & fuel fill cap	/			Check exhaust – mounting, clamping, & evidence of leaks	/		
Check clutch and/or neutral safety switch	/		/	Check batteries – visual inspection of cables, clamps, & fluid level	/			Check air filter – condition & damage	/		
Check HVAC defrosters, air vents, fan speed & controls	/			Check vertical exhaust, muffler, clamps, & brackets	/			Check air cleaner restriction gauge	/		
Check HVAC duct temperature, record	/			Check mirrors – condition & mounts	/			Check air cleaner housing, air-to-air piping and clamping	/		
Check cabin air filter	/			Check mud flaps, splash guards, & dock bumpers	/			Check alternator – visual inspection	/		
Check windshield wipers & washers	/			Check trailer electrical, air hoses, & glad hands	/			Check wiper blade condition	/		
Check horns, electric & air	/			Check cab air ride system	/			Check starting system – visual inspection	/		
Check interior lights, turn indicators, & dash lights	/			Check fifth wheel – mounting & jaws	/		/	Check steering shaft, shaft U-joints, box mounting, pitman arm & drag link	/		
Check door glass & mirror controls	/			Check frame & crossmembers	/			Check power steering fluid level	/		
Check seats, seat belts, & floor mats	/			Check pintle hook & safety chain loops	/		/	Top off windshield washer fluid	/		
Check tractor hand valve	/			Check tow hook and bumper attachment – bolts and/or welds secure & no cracking	/			Drain water from fuel water separator	/		
Dock power divider shift operating	/			Check tires & wheels – enter existing PSI & tread depth	/			Change fuel filter (engine mounted, include prescreen element if equipped)	/		
Check fifth wheel slider air lock operation			/					Change fuel water separator element	/		
Check air suspension dump valve	/							Change water filter	/		
Check ABS antilock monitor light, if equipped	/										
Check parking brake	/										
Check for three approved warning triangles	/										





Box 730  
Grande Prairie, AB T8V 3R5  
Phone: (780) 876-8949  
Fax: (780) 830-0580

7292

# 150 / 300 / 450 HOUR HEAVY DUTY VEHICLE MAINTENANCE

Under Vehicle Inspection	Checked	Changed	N/A	Under Vehicle Inspection (Continued)	Checked	Changed	N/A	Other	Condition & Expiry	
Check for oil leaks-engine, steering, axle, transmission & differential	✓			Check brake rod travel	✓			Fire Extinguisher	✓	
Check engine & transmission mounts				Check brake lining and/or pad water					CVIP Decal & Paperwork	10/2025
Check transmission oil level				Check ABS wiring & routing					VKIP Decal & Paperwork	10/2025
Check driveline and U-joints				Check PTO, wetline pumps & hose routing					Load Hose Paperwork	10/2025
Check transmission and differential yoke for play				Check air ride height					Ground Reel Continuity	3.1
Check differential oil level				Raise front axle -inspect king pins & wheel bearings					Load Hose Continuity	
Check springs, hangers and shocks				Grease king pins following the "turn and load" procedure					Check Valve on End of Hose and Highline	
Check tie rod ends				Grease complete chassis (include lift gate if equipped)					Proper Whip Checks	
Check air tanks, air dryer - drain & observe for oil & water				<b>Engine Oil</b>		Checked	Changed	N/A	Barett Valve Checked	
Check horizontal exhaust, muffler, clamps & brackets				Change engine oil			✓		Highlines and Hydraulic Hoses.	
			Change oil filter		✓		Tire Chains & Hangers.			
			Install oil plug and torque	✓			Winter Fronts			

Additional Comments: 300 Service / inspection

Replace Door cabinet Seal for up wiring

KCC - Oil Change CHECK LIGHTS

help Keaton

Qty	Part Number	Description	Price
2		Grease	
1	LF14000NW	oil filter	
		Plates	See manual
		Door Seal	\$20

Completed By: Kelton Signature: \_\_\_\_\_ Hours Worked: 2

KCC - 1



Box 730  
 Grande Prairie, AB T8V 3R5  
 Phone: (780) 876-8949  
 Fax: (780) 830-0580

~~#113~~  
 7473

**150 / 300 / 450 HOUR HEAVY DUTY  
 VEHICLE MAINTENANCE**

Date: SEP 10 2025 Unit: 252 KMS: 258108 Hours: 14905

Cab Interior Inspection	Checked	Changed	N/A	Around Vehicle Inspection	Checked	Changed	N/A	Under Hood or Raised Cab Inspection	Checked	Changed	N/A
Turn key on – check for fault codes; record.	✓			Check cab and body appearance – condition & damage	✓			Check positive air shutoff – test for proper function	✓		
Start engine – observe instrument operation	✓			Check air fairings, extenders, & brackets	✓			Check radiator, fan drive, & shroud	✓		
Apply and release brakes 10 times	✓			Check license plate holder & light	✓			Pressure test cooling system	✓		
Check low air warning buzzer & light	✓			Check lights – head, tail/stop, turn, marker, backup reflectors, & work	✓			Test DCA, extended life & freeze protection	✓		
Check that dash parking brake valve pop out at 35 psi	✓			Check doors – access and latches	✓			Check belts – visual inspection for wear & tension	✓		
Check clutch pedal free travel	✓			Check steps & grab handles	✓			Check hoses – condition and/or leaks	✓		
Check clutch brake operation	✓			Check hood latches	✓			Check hose & wire routing & securing	✓		
Check transmission hi-low spitter or 2 speed axle controls	✓			Check fuel tank straps & fuel fill cap	✓			Check exhaust – mounting, clamping, & evidence of leaks	✓		
Check clutch and/or neutral safety switch	✓			Check batteries – visual inspection of cables, clamps, & fluid level	✓			Check air filter – condition & damage	✓		
Check HVAC defrosters, air vents, fan speed & controls	✓			Check vertical exhaust, muffler, clamps, & brackets	✓			Check air cleaner restriction gauge	✓		
Check HVAC duct temperature, record	✓			Check mirrors – condition & mounts	✓			Check air cleaner housing, air-to-air piping and clamping	✓		
Check cabin air filter	✓			Check mud flaps, splash guards, & dock bumpers	✓			Check alternator – visual inspection	✓		
Check windshield wipers & washers	✓			Check trailer electrical, air hoses, & glad hands	✓			Check wiper blade condition	✓		
Check horns, electric & air	✓			Check cab air ride system	✓			Check starting system – visual inspection	✓		
Check interior lights, turn indicators, & dash lights	✓			Check fifth wheel – mounting & jaws			✓	Check steering shaft, shaft U-joints, box mounting, pitman arm & drag link			
Check door glass & mirror controls	✓			Check frame & crossmembers	✓			Check power steering fluid level			
Check seats, seat belts, & floor mats	✓			Check pintle hook & safety chain loops			✓	Top off windshield washer fluid			
Check tractor hand valve	✓			Check tow hook and bumper attachment – bolts and/or welds secure & no cracking	✓			Drain water from fuel water separator			
Dock power divider shift operating	✓			Check tires & wheels – enter existing PSI & tread depth	✓			Change fuel filter (engine mounted, include prescreen element if equipped)			
Check fifth wheel slider air lock operation	✓							Change fuel water separator element			
Check air suspension dump valve	✓		Change water filter								
Check ABS antilock monitor light, if equipped	✓										
Check parking brake	✓										
Check for three approved warning triangles	✓										





Box 730  
 Grande Prairie, AB T8V 3R5  
 Phone: (780) 876-8949  
 Fax: (780) 830-0580

8179

# 150 / 300 / 450 HOUR HEAVY DUTY VEHICLE MAINTENANCE

Date: Nov 18 2025

Unit: #252

KMs: 267264

Hours: 15300

Cab Interior Inspection	Checked	Changed	N/A	Around Vehicle Inspection	Checked	Changed	N/A	Under Hood or Raised Cab Inspection	Checked	Changed	N/A
Turn key on – check for fault codes; record.				Check cab and body appearance – condition & damage				Check positive air shutoff – test for proper function			
Start engine – observe instrument operation				Check air fairings, extenders, & brackets				Check radiator, fan drive, & shroud			
Apply and release brakes 10 times				Check license plate holder & light				Pressure test cooling system			
Check low air warning buzzer & light				Check lights – head, tail/stop, turn, marker, backup reflectors, & work				Test DCA, extended life & freeze protection			
Check that dash parking brake valve pop out at 35 psi				Check doors – access and latches				Check belts – visual inspection for wear & tension			
Check clutch pedal free travel				Check steps & grab handles				Check hoses – condition and/or leaks			
Check clutch brake operation				Check hood latches				Check hose & wire routing & securing			
Check transmission hi-low splitter or 2 speed axle controls				Check fuel tank straps & fuel fill cap				Check exhaust – mounting, clamping, & evidence of leaks			
Check clutch and/or neutral safety switch				Check batteries – visual inspection of cables, clamps, & fluid level				Check air filter – condition & damage			
Check HVAC defrosters, air vents, fan speed & controls				Check vertical exhaust, muffler, clamps, & brackets				Check air cleaner restriction gauge			
Check HVAC duct temperature, record				Check mirrors – condition & mounts				Check air cleaner housing, air-to-air piping and clamping			
Check cabin air filter				Check mud flaps, splash guards, & dock bumpers				Check alternator – visual inspection			
Check windshield wipers & washers				Check trailer electrical, air hoses, & glad hands				Check wiper blade condition			
Check horns, electric & air				Check cab air ride system				Check starting system – visual inspection			
Check interior lights, turn indicators, & dash lights				Check fifth wheel – mounting & jaws				Check steering shaft, shaft U-joints, box mounting, pitman arm & drag link			
Check door glass & mirror controls				Check frame & crossmembers				Check power steering fluid level			
Check seats, seat belts, & floor mats				Check pintle hook & safety chain loops				Top off windshield washer fluid			
Check tractor hand valve				Check tow hook and bumper attachment – bolts and/or welds secure & no cracking				Drain water from fuel water separator			
Dock power divider shift operating				Check tires & wheels – enter existing PSI & tread depth				Change fuel filter (engine mounted, include prescreen element if equipped)			
Check fifth wheel slider air lock operation								Change fuel water separator element			
Check air suspension dump valve						Change water filter					
Check ABS antilock monitor light, if equipped											
Check parking brake											
Check for three approved warning triangles											



Box 730  
Grande Prairie, AB T8V 3R5  
Phone: (780) 876-8949  
Fax: (780) 830-0580

# 150 / 300 / 450 HOUR HEAVY DUTY VEHICLE MAINTENANCE

Date: Dec 16/2026

Unit: 252

KMs: 269886

Hours: 15507

Cab Interior Inspection	Checked	Changed	N/A	Around Vehicle Inspection	Checked	Changed	N/A	Under Hood or Raised Cab Inspection	Checked	Changed	N/A
Turn key on – check for fault codes; record.				Check cab and body appearance – condition & damage				Check positive air shutoff – test for proper function			
Start engine – observe instrument operation				Check air fairings, extenders, & brackets				Check radiator, fan drive, & shroud			
Apply and release brakes 10 times				Check license plate holder & light				Pressure test cooling system			
Check low air warning buzzer & light				Check lights – head, tail/stop, turn, marker, backup reflectors, & work				Test DCA, extended life & freeze protection			
Check that dash parking brake valve pop out at 35 psi				Check doors – access and latches				Check belts – visual inspection for wear & tension			
Check clutch pedal free travel				Check steps & grab handles				Check hoses – condition and/or leaks			
Check clutch brake operation				Check hood latches				Check hose & wire routing & securing			
Check transmission hi-low splitter or 2 speed axle controls				Check fuel tank straps & fuel fill cap				Check exhaust – mounting, clamping, & evidence of leaks			
Check clutch and/or neutral safety switch				Check batteries – visual inspection of cables, clamps, & fluid level				Check air filter – condition & damage			
Check HVAC defrosters, air vents, fan speed & controls				Check vertical exhaust, muffler, clamps, & brackets				Check air cleaner restriction gauge			
Check HVAC duct temperature, record				Check mirrors – condition & mounts				Check air cleaner housing, air-to-air piping and clamping			
Check cabin air filter				Check mud flaps, splash guards, & dock bumpers				Check alternator – visual inspection			
Check windshield wipers & washers				Check trailer electrical, air hoses, & glad hands				Check wiper blade condition			
Check horns, electric & air				Check cab air ride system				Check starting system – visual inspection			
Check interior lights, turn indicators, & dash lights				Check fifth wheel – mounting & jaws				Check steering shaft, shaft U-joints, box mounting, pitman arm & drag link			
Check door glass & mirror controls				Check frame & crossmembers				Check power steering fluid level			
Check seats, seat belts, & floor mats				Check pintle hook & safety chain loops				Top off windshield washer fluid			
Check tractor hand valve				Check tow hook and bumper attachment – bolts and/or welds secure & no cracking				Drain water from fuel water separator			
Dock power divider shift operating				Check tires & wheels – enter existing PSI & tread depth				Change fuel filter (engine mounted, include prescreen element if equipped)			
Check fifth wheel slider air lock operation								Change fuel water separator element			
Check air suspension dump valve						Change water filter					
Check ABS antilock monitor light, if equipped											
Check parking brake											
Check for three approved warning triangles											







Box 730  
Grande Prairie, AB T8V 3R5  
Phone: (780) 876-8949  
Fax: (780) 830-0580

**150 / 300 / 450 HOUR HEAVY DUTY  
VEHICLE MAINTENANCE**

Date: March 20 2026

Unit: 252

KMs: 274464

Hours: 16602

Cab Interior Inspection			Checked	Changed	N/A	Around Vehicle Inspection			Checked	Changed	N/A	Under Hood or Raised Cab Inspection			Checked	Changed	N/A
Turn key on – check for fault codes; record.			✓			Check cab and body appearance – condition & damage			✓			Check positive air shutoff – test for proper function			✓		
Start engine – observe instrument operation			✓			Check air fairings, extenders, & brackets			✓			Check radiator, fan drive, & shroud			✓		
Apply and release brakes 10 times			✓			Check license plate holder & light			✓			Pressure test cooling system			✓		
Check low air warning buzzer & light			✓			Check lights – head, tail/stop, turn, marker, backup reflectors, & work			✓			Test DCA, extended life & freeze protection			✓		
Check that dash parking brake valve pop out at 35 psi			✓			Check doors – access and latches			✓			Check belts – visual inspection for wear & tension			✓		
Check clutch pedal free travel					✓	Check steps & grab handles			✓			Check hoses – condition and/or leaks			✓		
Check clutch brake operation					✓	Check hood latches			✓			Check hose & wire routing & securing			✓		
Check transmission hi-low splitter or 2 speed axle controls			✓			Check fuel tank straps & fuel fill cap			✓			Check exhaust – mounting, clamping, & evidence of leaks			✓		
Check clutch and/or neutral safety switch			✓			Check batteries – visual inspection of cables, clamps, & fluid level			✓			Check air filter – condition & damage			✓		
Check HVAC defrosters, air vents, fan speed & controls			✓			Check vertical exhaust, muffler, clamps, & brackets			✓			Check air cleaner restriction gauge			✓		
Check HVAC duct temperature, record			✓			Check mirrors – condition & mounts			✓			Check air cleaner housing, air-to-air piping and clamping			✓		
Check cabin air filter			✓			Check mud flaps, splash guards, & dock bumpers			✓			Check alternator – visual inspection			✓		
Check windshield wipers & washers			✓			Check trailer electrical, air hoses, & glad hands			✓			Check wiper blade condition			✓		
Check horns, electric & air			✓			Check cab air ride system			✓			Check starting system – visual inspection			✓		
Check interior lights, turn indicators, & dash lights			✓			Check fifth wheel – mounting & jaws			✓			Check steering shaft, shaft U-joints, box mounting, pitman arm & drag link			✓		
Check door glass & mirror controls			✓			Check frame & crossmembers			✓			Check power steering fluid level			✓		
Check seats, seat belts, & floor mats			✓			Check pintle hook & safety chain loops					✓	Top off windshield washer fluid					✓
Check tractor hand valve			✓			Check tow hook and bumper attachment – bolts and/or welds secure & no cracking			✓			Drain water from fuel water separator					✓
Dock power divider shift operating			✓			Check tires & wheels – enter existing PSI & tread depth						Change fuel filter (engine mounted, include prescreen element if equipped)					✓
Check fifth wheel slider air lock operation					✓							Change fuel water separator element					✓
Check air suspension dump valve			✓		Change water filter												
Check ABS antilock monitor light, if equipped			✓														
Check parking brake			✓														
Check for three approved warning triangles			✓														