

Date	Work Description	Plant No	Work Type
15/02/22	Change Belt, Paint Front of Cab. Put Strut Covers	DT70	LMF - Labour Maintenance Fitter
15/03/22	DT70- Fuel Water Seperator Fault	DT70	LMF - Labour Maintenance Fitter
15/03/22	DT70- Fuel Water Seperator Fault	DT70	LMF - Labour Maintenance Fitter
16/03/22	DT70 - Purge Grease/ Adjust pump	DT70	LMF - Labour Maintenance Fitter
23/03/22	DT70 - 2000Hr Service	DT70	LMF - Labour Maintenance Fitter
23/03/22	DT70 -2000hr Service	DT70	LMF - Labour Maintenance Fitter
23/03/22	DT70 - 2000Hr Service	DT70	LMF - Labour Maintenance Fitter
23/03/22	DT70 - Transfer to KG1	DT70	LMF - Labour Maintenance Fitter
23/03/22	DT70- 2000Hr Service	DT70	LMF - Labour Maintenance Fitter
31/03/22	DT70 - Fit Quick Fill System	DT70	LMF - Labour Maintenance Fitter
05/04/22	DT70 replace grease lines	DT70	LMF - Labour Maintenance Fitter
05/04/22	DT70 repair gease system	DT70	LMF - Labour Maintenance Fitter
06/04/22	DT70 replace grease lines	DT70	LMF - Labour Maintenance Fitter
06/04/22	DT70	DT70	LMF - Labour Maintenance Fitter
14/04/22	DT70 - Diff oil low	DT70	LMF - Labour Maintenance Fitter
05/05/22	DT70 replace coolant and hoses	DT70	LMF - Labour Maintenance Fitter
05/05/22	DT70 replace coolant hose	DT70	LMF - Labour Maintenance Fitter
24/05/22	DT70 hose repairs	DT70	LMF - Labour Maintenance Fitter
24/05/22	DT70 Brakes	DT70	LMF - Labour Maintenance Fitter
01/06/22	DT70 defects	DT70	LMF - Labour Maintenance Fitter
01/06/22	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
11/08/22	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
12/08/22	DT70 Gas strut	DT70	LMF - Labour Maintenance Fitter
01/09/22	DT70 fuel leak	DT70	LMF - Labour Maintenance Fitter
07/09/22	DT70 investigate fuel leak	DT70	LWGH - Labour Workshop General Hand
30/09/22	DT70 service	DT70	LMF - Labour Maintenance Fitter
13/10/22	DT70 pos 2 change	DT70	LMF - Labour Maintenance Fitter
13/10/22	DT70 pos 2 change	DT70	LMF - Labour Maintenance Fitter
18/11/22	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
18/11/22	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
18/11/22	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
18/11/22	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
10/01/23	DT70 remove rock ejector, straighten pin	DT70	LWGH - Labour Workshop General Hand
10/02/23	DT70 service + defects	DT70	LWGH - Labour Workshop General Hand
10/02/23	DT70 250 hr service	DT70	LWGH - Labour Workshop General Hand
25/03/23	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
25/03/23	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
25/03/23	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
03/04/23	DT70 trans fault and gas struts	DT70	LMF - Labour Maintenance Fitter
03/04/23	DT70 gas front strut and transmisison fault	DT70	LMF - Labour Maintenance Fitter
04/04/23	DT70 repair mirror brackets	DT70	LMF - Labour Maintenance Fitter
05/04/23	DT70 repair lights	DT70	LMF - Labour Maintenance Fitter
11/04/23	DT70 Replace stairs	DT70	LMF - Labour Maintenance Fitter
18/04/23	DT70 Inner air filters	DT70	LMF - Labour Maintenance Fitter
08/06/23	DT70 C/O Radio	DT70	LMF - Labour Maintenance Fitter
20/06/23	DT70 fuel tank breather	DT70	LMF - Labour Maintenance Fitter
20/06/23	DT70 Inspect Fuel Tank Breather	DT70	LMF - Labour Maintenance Fitter
26/06/23	DT70 Fit LHR Rock Ejector	DT70	LMF - Labour Maintenance Fitter
26/06/23	DT70 Fit new Pos 3 Rock Ejector	DT70	LMF - Labour Maintenance Fitter
10/07/23	DT70 Jumpstart Truck	DT70	LMF - Labour Maintenance Fitter
14/07/23	DT70 1000hr service and repairs	DT70	LMF - Labour Maintenance Fitter
14/07/23	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
14/07/23	DT70 Service and Defects	DT70	LMF - Labour Maintenance Fitter
14/07/23	DT70 Tranny Temp fault	DT70	LMF - Labour Maintenance Fitter
18/07/23	DT70 Oil Leak	DT70	LMF - Labour Maintenance Fitter
19/07/23	DT70 Leaking tyre and filter	DT70	LMF - Labour Maintenance Fitter
20/07/23	DT70 Change Tyre	DT70	LMF - Labour Maintenance Fitter
20/07/23	DT70 Change Pos 3 tyre	DT70	LMF - Labour Maintenance Fitter
22/07/23	DT70 250 hr Service and Defects	DT70	LMF - Labour Maintenance Fitter
25/07/23	DT70 Inspect Load Counter	DT70	LMF - Labour Maintenance Fitter
28/07/23	DT70 Strip tyres	DT70	LMF - Labour Maintenance Fitter
21/08/23	DT70 re-gas POS 1 strut, repair grease lines	DT70	LMF - Labour Maintenance Fitter
17/10/23	DT70 Strut rebuild	DT70	LMF - Labour Maintenance Fitter
17/10/23	DT70 LHF Strut rebuild	DT70	LMF - Labour Maintenance Fitter
17/10/23	DT70 Rebuild strut	DT70	LMF - Labour Maintenance Fitter
18/10/23	DT70 Fit front l/h strut	DT70	LMF - Labour Maintenance Fitter
18/10/23	DT70 defect pos 1 strut	DT70	LMF - Labour Maintenance Fitter
18/10/23	DT70 c/o front strut	DT70	LMF - Labour Maintenance Fitter
19/10/23	DT70 Program screen	DT70	LMF - Labour Maintenance Fitter
17/11/23	DT70 Service	DT70	LMF - Labour Maintenance Fitter
17/11/23	DT70 Service and Defects	DT70	LMF - Labour Maintenance Fitter
17/11/23	DT70 Service and Defects	DT70	LMF - Labour Maintenance Fitter
23/11/23	DT70 Organise parts	DT70	LMF - Labour Maintenance Fitter
24/11/23	DT70 Start/tranny fault issues	DT70	LMF - Labour Maintenance Fitter
24/11/23	DT70 Start/tranny fault issues	DT70	LMF - Labour Maintenance Fitter

27/11/23	DT70 C/O batteries, faults	DT70	LMF - Labour Maintenance Fitter
29/11/23	DT70 Tranny and fuel fault	DT70	LMF - Labour Maintenance Fitter
05/12/23	DT70 Prep for tyre change	DT70	LMF - Labour Maintenance Fitter
06/12/23	DT70 fit pos 1 tyre	DT70	LMF - Labour Maintenance Fitter
06/12/23	DT70 Change Pos 1 tyre	DT70	LMF - Labour Maintenance Fitter
20/12/23	DT70 replace exhaust springs	DT70	LMF - Labour Maintenance Fitter
21/12/23	DT70 A/C fault	DT70	LMF - Labour Maintenance Fitter
08/02/24	DT70 500 hr service	DT70	LMF - Labour Maintenance Fitter
09/02/24	DT70 500 hr service, reseal rhs fuel injectors	DT70	LMF - Labour Maintenance Fitter
09/02/24	DT70 service and defects, injector o-rings	DT70	LMF - Labour Maintenance Fitter
09/02/24	DT70 500 hr service and reseal injectors	DT70	LMF - Labour Maintenance Fitter
11/03/24	DT70 c/o pos 6 tyre	DT70	LMF - Labour Maintenance Fitter
11/03/24	DT70 c/o pos 6 tyre	DT70	LMF - Labour Maintenance Fitter
29/03/24	DT70 Service	DT70	LMF - Labour Maintenance Fitter
29/03/24	DT70 250 hr service and defects	DT70	LMF - Labour Maintenance Fitter
17/04/24	DT70 c/o pos 3 tyre	DT70	LMF - Labour Maintenance Fitter
17/04/24	DT70 c/o pos 3 tyre	DT70	LMF - Labour Maintenance Fitter
27/04/24	DT70 replace front stairs	DT70	LMF - Labour Maintenance Fitter
29/04/24	DT70 change hyd hose	DT70	LMF - Labour Maintenance Fitter
24/05/24	DT70 1000 Hr service	DT70	LMF - Labour Maintenance Fitter
24/05/24	DT70 1000 hr service	DT70	LMF - Labour Maintenance Fitter
08/08/24	DT70 weld broken rock injector	DT70	LMF - Labour Maintenance Fitter
09/08/24	DT70 250 hr service	DT70	LMF - Labour Maintenance Fitter
09/08/24	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
17/09/24	DT70 c/o tyre	DT70	LMF - Labour Maintenance Fitter
17/09/24	DT70 c/o Pos 5	DT70	LMF - Labour Maintenance Fitter
27/09/24	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
02/12/24	DT70 replace hyd hoses	DT70	LMF - Labour Maintenance Fitter
02/12/24	DT70 replace hyd hoses	DT70	LMF - Labour Maintenance Fitter
13/12/24	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
13/12/24	DT70 service and defects	DT70	LMF - Labour Maintenance Fitter
07/01/25	DT70 fit A-Frame grease line	DT70	LMF - Labour Maintenance Fitter
09/01/25	DT70 Tranny hose	DT70	LMF - Labour Maintenance Fitter
09/01/25	DT 70 pump up tyres	DT70	LMF - Labour Maintenance Fitter
26/02/25	DT70 install clamps on turbo	DT70	LMF - Labour Maintenance Fitter
28/02/25	DT70 1000 hr service	DT70	LMF - Labour Maintenance Fitter
28/02/25	DT70 1000 hr service	DT70	LMF - Labour Maintenance Fitter
03/03/25	DT70 replace rock ejector	DT70	LMF - Labour Maintenance Fitter
03/03/25	DT70 change rock ejector	DT70	LMF - Labour Maintenance Fitter
05/03/25	DT70 c/o tyre	DT70	LMF - Labour Maintenance Fitter
05/03/25	DT70 c/o pos 5 tyre, investigate flat tyre	DT70	LMF - Labour Maintenance Fitter
07/03/25	DT70 air filter restriction	DT70	LMF - Labour Maintenance Fitter
16/04/25	DT70 Replace Hose	DT70	LMF - Labour Maintenance Fitter
12/05/25	DT70 Rock Ejector Replacement	DT70	LMF - Labour Maintenance Fitter
12/05/25	DT70 Set up rims to build tyres	DT70	LMF - Labour Maintenance Fitter
13/05/25	DT70 Rock Ejector	DT70	LMF - Labour Maintenance Fitter
15/05/25	DT70 Build Tyres	DT70	LMF - Labour Maintenance Fitter
19/05/25	DT70 Service & C/O Wheels	DT70	LMF - Labour Maintenance Fitter
19/05/25	DT70 250hr Service & Defects	DT70	LMF - Labour Maintenance Fitter
19/05/25	DT70 250hr Service & Defects	DT70	LMF - Labour Maintenance Fitter
19/05/25	DT70 Replace Tyres	DT70	LMF - Labour Maintenance Fitter
20/05/25	DT70 C/O rear tyres, hoist hose, weld repairs	DT70	LMF - Labour Maintenance Fitter
01/07/25	DT70 Repair Grease Line	DT70	LMF - Labour Maintenance Fitter
29/07/25	DT70 Defects	DT70	LMF - Labour Maintenance Fitter
29/07/25	DT70 500hr Service	DT70	LMF - Labour Maintenance Fitter
29/07/25	DT70 Service & Defects	DT70	LMF - Labour Maintenance Fitter
30/07/25	DT70 Defects	DT70	LMF - Labour Maintenance Fitter
30/07/25	DT70 Service & Defects	DT70	LMF - Labour Maintenance Fitter
04/08/25	DT70 Fit brake pump hose and mine radio	DT70	LMF - Labour Maintenance Fitter
07/10/25	DT70 250hr Service	DT70	LMF - Labour Maintenance Fitter
07/10/25	DT70 Prep for service	DT70	LMF - Labour Maintenance Fitter
07/10/25	DT70 250hr Service	DT70	LMF - Labour Maintenance Fitter
08/10/25	DT70 Shim rear tub pins & grease, set rear struts	DT70	LMF - Labour Maintenance Fitter
08/10/25	DT70 Coolant Fault	DT70	LMF - Labour Maintenance Fitter
08/10/25	DT70 Fit new dog bone, gas rear struts, shim tray	DT70	LMF - Labour Maintenance Fitter
09/10/25	DT70 Strip dog bone	DT70	LMF - Labour Maintenance Fitter