

Date	Work Description	Plant No	Work Type
15/02/22	Speed Limit	DT72	LMF - Labour Maintenance Fitter
16/03/22	DT72 - Adjust grease pump	DT72	LMF - Labour Maintenance Fitter
17/03/22	DT72 - Inspect & Make Bracket for grease pot	DT72	LMF - Labour Maintenance Fitter
17/03/22	DT72 - Low voltage fault	DT72	LMF - Labour Maintenance Fitter
17/03/22	DT72 - 250Hr Service	DT72	LMF - Labour Maintenance Fitter
22/03/22	DT72 - Adjust door, check charge rate, ins. Harness	DT72	LMF - Labour Maintenance Fitter
24/03/22	DT72- Repair Grease System	DT72	LMF - Labour Maintenance Fitter
28/03/22	DT72 - Fix Grease system, adjust timer & Purge lin	DT72	LMF - Labour Maintenance Fitter
31/03/22	DT73 - Wash & Grease system	DT72	LMF - Labour Maintenance Fitter
31/03/22	DT72 - Grease Fault, Point not receiving Grease	DT72	LMF - Labour Maintenance Fitter
01/04/22	DT72 - Test Wiring	DT72	LMF - Labour Maintenance Fitter
01/04/22	DT72 - Remove Excess Wiring and test	DT72	LMF - Labour Maintenance Fitter
05/04/22	DT72 electrical faults	DT72	LMF - Labour Maintenance Fitter
12/04/22	DT72 - Remove & replace Harness & Test	DT72	LMF - Labour Maintenance Fitter
13/04/22	DT72 change harness and repair wires	DT72	LMF - Labour Maintenance Fitter
13/04/22	DT72, DT65 transport	DT72	LMF - Labour Maintenance Fitter
28/04/22	DT72 Broken grease block	DT72	LMF - Labour Maintenance Fitter
03/05/22	DT72 grease faults	DT72	LMF - Labour Maintenance Fitter
04/05/22	DT72 grease system	DT72	LMF - Labour Maintenance Fitter
17/05/22	Dt72 injector fault	DT72	LMF - Labour Maintenance Fitter
17/05/22	DT72 order parts	DT72	LMF - Labour Maintenance Fitter
19/05/22	DT72 injector fault	DT72	LMF - Labour Maintenance Fitter
19/05/22	DT72 injector change	DT72	LMF - Labour Maintenance Fitter
15/06/22	DT72 service and defects	DT72	LMF - Labour Maintenance Fitter
27/06/22	DT72 grease fault	DT72	LWGH - Labour Workshop General Hand
10/08/22	DT72 service	DT72	LMF - Labour Maintenance Fitter
06/09/22	DT72 c/o blown hoist pump hose	DT72	LWGH - Labour Workshop General Hand
07/09/22	DT72 investigate eng oil leak	DT72	LWGH - Labour Workshop General Hand
30/09/22	DT72 service	DT72	LMF - Labour Maintenance Fitter
27/10/22	DT72 replace blown hose	DT72	LMF - Labour Maintenance Fitter
18/11/22	DT72 replace shroud	DT72	LMF - Labour Maintenance Fitter
18/11/22	DT72 replace shroud	DT72	LMF - Labour Maintenance Fitter
25/11/22	DT72 service	DT72	LMF - Labour Maintenance Fitter
25/11/22	DT72 service	DT72	LMF - Labour Maintenance Fitter
08/12/22	DT72 pull hose off	DT72	LMF - Labour Maintenance Fitter
10/02/23	DT72 service + defects	DT72	LWGH - Labour Workshop General Hand
10/02/23	DT72 1000 hr service + defects	DT72	LWGH - Labour Workshop General Hand
16/02/23	DT72 change oil filters	DT72	LMF - Labour Maintenance Fitter
03/04/23	DT72 temp fault	DT72	LMF - Labour Maintenance Fitter
05/04/23	DT72 ambient temp sensor	DT72	LMF - Labour Maintenance Fitter
18/04/23	DT72 C/O inner air filters	DT72	LMF - Labour Maintenance Fitter
27/04/23	DT72 brake fault	DT72	LMF - Labour Maintenance Fitter
12/05/23	DT72 change tyres pos 1 and 2	DT72	LMF - Labour Maintenance Fitter
17/05/23	DT72 replace tray pin	DT72	LMF - Labour Maintenance Fitter
26/05/23	DT72 service and defects	DT72	LMF - Labour Maintenance Fitter
13/06/23	DT72 Change Tyres	DT72	LMF - Labour Maintenance Fitter
13/06/23	DT72 C/O Pos 5 Tyre	DT72	LMF - Labour Maintenance Fitter
10/07/23	DT72 Fill Strut with Nitrogen	DT72	LMF - Labour Maintenance Fitter
22/07/23	DT72 Service and Defects	DT72	LMF - Labour Maintenance Fitter
31/07/23	DT72 Fuel leak	DT72	LMF - Labour Maintenance Fitter
01/08/23	DT72 Inspect start fault, serial no for rims/tyres	DT72	LMF - Labour Maintenance Fitter
17/10/23	DT72 Get Parts	DT72	LMF - Labour Maintenance Fitter
13/12/23	DT72 Inspect broken exhaust coupling	DT72	LMF - Labour Maintenance Fitter
15/12/23	DT72 service and defects	DT72	LMF - Labour Maintenance Fitter
15/12/23	DT72 1000HR service and defects	DT72	LMF - Labour Maintenance Fitter
15/12/23	DT72 1000HR service and defects	DT72	LMF - Labour Maintenance Fitter
07/02/24	DT72 repair a/c	DT72	LMF - Labour Maintenance Fitter
19/02/24	DT72 Service and Defects	DT72	LMF - Labour Maintenance Fitter
08/03/24	DT72 inspect for engine missing - nothing found	DT72	LMF - Labour Maintenance Fitter
08/03/24	DT72 Investigate engine miss	DT72	LMF - Labour Maintenance Fitter
11/03/24	DT72 check miss in engine	DT72	LMF - Labour Maintenance Fitter
12/04/24	DT72 250 hr service and defects	DT72	LMF - Labour Maintenance Fitter
12/04/24	DT72 250 hr service and defects	DT72	LMF - Labour Maintenance Fitter
12/04/24	DT72 500 hr service	DT72	LMF - Labour Maintenance Fitter
15/04/24	DT72 c/o rock ejector	DT72	LMF - Labour Maintenance Fitter
31/05/24	DT72 dismantle exhaust, remove broken bolts	DT72	LMF - Labour Maintenance Fitter
31/05/24	DT72 Strip 773 Wheel End	DT72	LMF - Labour Maintenance Fitter
04/06/24	DT72 c/o pos 5 and service	DT72	LMF - Labour Maintenance Fitter
04/06/24	DT72 c/o tyre	DT72	LMF - Labour Maintenance Fitter
04/06/24	DT72 pos 5 and pos 6 tyres	DT72	LMF - Labour Maintenance Fitter
05/06/24	DT72 service and defects, tyres	DT72	LMF - Labour Maintenance Fitter
05/06/24	DT72 pos 6 tyre	DT72	LMF - Labour Maintenance Fitter
06/08/24	DT72 fit new rock ejector to pos 3	DT72	LMF - Labour Maintenance Fitter
23/08/24	DT72 1000 hr service	DT72	LMF - Labour Maintenance Fitter

29/08/24	DT72 wiring fault wouldn't start	DT72	LMF - Labour Maintenance Fitter
08/11/24	DT72 service	DT72	LMF - Labour Maintenance Fitter
08/11/24	DT72 service	DT72	LMF - Labour Maintenance Fitter
15/11/24	DT72 leaking cooler hose	DT72	LMF - Labour Maintenance Fitter
15/11/24	DT72 hyd hoses	DT72	LMF - Labour Maintenance Fitter
28/11/24	DT72 seat switch	DT72	LMF - Labour Maintenance Fitter
28/11/24	DT72 fit seat switch	DT72	LMF - Labour Maintenance Fitter
31/12/24	DT72 500 hr service and defects	DT72	LMF - Labour Maintenance Fitter
31/12/24	DT72 500 hr service and defects	DT72	LMF - Labour Maintenance Fitter
15/01/25	DT72 trans/drive shaft fault	DT72	LMF - Labour Maintenance Fitter
15/01/25	DT72 inspect trans/drive shaft breakdown	DT72	LMF - Labour Maintenance Fitter
20/01/25	DT72 drive line break down	DT72	LMF - Labour Maintenance Fitter
20/01/25	DT72 remove guards and hoses, order parts	DT72	LMF - Labour Maintenance Fitter
21/01/25	DT72 recover and tow to workshop	DT72	LMF - Labour Maintenance Fitter
21/01/25	DT72 recover truck, set up for trans removal	DT72	LMF - Labour Maintenance Fitter
22/01/25	DT72 remove trans	DT72	LMF - Labour Maintenance Fitter
22/01/25	DT72 remove trans	DT72	LMF - Labour Maintenance Fitter
22/01/25	DT72 remove trans	DT72	LMF - Labour Maintenance Fitter
23/01/25	DT72 remove broken shaft, order parts	DT72	LMF - Labour Maintenance Fitter
28/01/25	DT72 trans	DT72	LMF - Labour Maintenance Fitter
28/01/25	DT72 disassemble trans and order parts	DT72	LMF - Labour Maintenance Fitter
17/02/25	DT72 trans c/o	DT72	LMF - Labour Maintenance Fitter
21/02/25	DT72 assemble transmission	DT72	LMF - Labour Maintenance Fitter
25/02/25	DT72 build transmission	DT72	LMF - Labour Maintenance Fitter
26/02/25	DT72 rebuild transmission	DT72	LMF - Labour Maintenance Fitter
27/02/25	DT72 install trans	DT72	LMF - Labour Maintenance Fitter
27/02/25	DT72 fit trans, drive shaft, plumb up	DT72	LMF - Labour Maintenance Fitter
06/03/25	DT72 install trans	DT72	LMF - Labour Maintenance Fitter
12/03/25	DT72 install trans, fault find	DT72	LMF - Labour Maintenance Fitter
12/03/25	DT72 finish installing and plumbing trans, fault	DT72	LMF - Labour Maintenance Fitter
17/03/25	DT72 fit speed sensor and test	DT72	LMF - Labour Maintenance Fitter
18/03/25	DT72 trans and elec faults	DT72	LMF - Labour Maintenance Fitter
18/03/25	DT72 diagnose trans fault and repair	DT72	LMF - Labour Maintenance Fitter
19/03/25	DT72 tension tyre, put new nuts on	DT72	LMF - Labour Maintenance Fitter
24/03/25	DT72 fit 4 new batteries	DT72	LMF - Labour Maintenance Fitter
27/03/25	DT72 air con	DT72	LMF - Labour Maintenance Fitter
08/05/25	DT72 remove broken bolts, install mirror	DT72	LMF - Labour Maintenance Fitter
15/05/25	DT72 Replace Hoiset Pin	DT72	LMF - Labour Maintenance Fitter
16/06/25	DT72 Investigate Starting Fault	DT72	LMF - Labour Maintenance Fitter
08/07/25	DT72 Set up for hydraulic pipe replacement	DT72	LMF - Labour Maintenance Fitter
14/07/25	DT72 Replace Hydraulic Pipe, Repair Coil Ejector	DT72	LMF - Labour Maintenance Fitter
16/07/25	DT72 Oil Leak	DT72	LMF - Labour Maintenance Fitter
16/07/25	DT72 Inspect trans oil leak, order parts	DT72	LMF - Labour Maintenance Fitter
21/07/25	DT72 fit new tranny hose, oil top up, test	DT72	LMF - Labour Maintenance Fitter
04/08/25	DT72 Fit mirror	DT72	LMF - Labour Maintenance Fitter
05/08/25	DT72 Fit mine radio	DT72	LMF - Labour Maintenance Fitter
11/08/25	DT72 250hr Service & Repair lights	DT72	LMF - Labour Maintenance Fitter
11/08/25	DT72 Service & Defects	DT72	LMF - Labour Maintenance Fitter
04/09/25	DT72 Failed RH hoist cylinder bearing	DT72	LMF - Labour Maintenance Fitter
08/09/25	DT72 Repair RH Hoist Cylinder	DT72	LMF - Labour Maintenance Fitter
09/09/25	DT72 Defect Repairs	DT72	LMF - Labour Maintenance Fitter
23/09/25	DT72 Replace rock ejector	DT72	LMF - Labour Maintenance Fitter
24/09/25	DT72 Tyre	DT72	LMF - Labour Maintenance Fitter
24/09/25	DT72 Replace Pos 6 Tyre	DT72	LMF - Labour Maintenance Fitter
25/09/25	DT72 C/O POS 6 Tyre	DT72	LMF - Labour Maintenance Fitter
25/09/25	DT72 Build Tyres	DT72	LMF - Labour Maintenance Fitter
14/10/25	DT72 Remove & fit new tyres & rims on rear axle	DT72	LMF - Labour Maintenance Fitter
14/10/25	DT72 C/O Rear tyres, repair rock ejector	DT72	LMF - Labour Maintenance Fitter
15/10/25	DT72 re-torque rear axle wheel nuts	DT72	LMF - Labour Maintenance Fitter
29/10/25	DT72 Assemble dog bone	DT72	LMF - Labour Maintenance Fitter
10/11/25	DT72 fit fuel check valves, diagnose elec fault	DT72	LMF - Labour Maintenance Fitter
12/11/25	DT72 Fault Diagnosis	DT72	LMF - Labour Maintenance Fitter
12/03/26	DT72 coms link error	DT72	LMF - Labour Maintenance Fitter