

Truck 20,000Km 'B' Service

MVTC NO:171133

(Trade License)

Date:	1/8/2025	Rego:		CL59.MH
Fleet #:	NPR300 Isuzu	Kilometres	/Hours:	361900Kms

Mechanic	Ok	X	Ok = Passed Inspection X = Repairs Needed or Not Applicable
	>		Remove & replace service sticker
	✓		Check seat condition and correct operation of seat & seat belts
	✓		Check operation of horns & low air buzzers
	✓		Check operation of gauges
	✓		Check windscreen for cracks or damage
	✓		Check operation of windscreen wipers & rubber condition
	✓		Check operation of windscreen washers & nozzles
	✓		Check operation of A/C from inside cab
	✓		Check condition of clutch & brake pedal rubber
	✓		Check operation of internal lights (stay out of sleeper)
		N/a	Check clutch adjustment
	✓		Check operation of all external lights including load lights
	✓		Adjust brakes & record brake lining/pad remaining
	✓		Check all brake drums/rotors for cracks
	✓		Check condition of all brake hoses
	✓		Check all axles for wheel seal leaks
	✓		Check rear carrier pinion seals for leaks
	✓		Check all shock absorbers for leaks and mount condition
		N/a	Check suspension airbags condition & mounting
	✓		Check rear suspension U-bolts & saddles for signs of movements
	✓		Check rear suspension for cracked springs
	✓		Check condition of torque & tracking rod mounting bolts & bushes
	✓		Check rear tyres for unusual wear
	✓		Check condition and tightness of universal joints, including yokes
	✓		Check all cross members for cracks
	✓		Check over transmission for oil leaks
	✓		Check condition of all engine mount bolts, rubbers & brackets
	✓		Check clutch linkage for wear
	✓		Drain all air tanks
	✓		Check steer axle springs for cracks
	✓		Check steer spring U-bolts & saddles for signs of movement
	✓		Check steering tie rod ends & drag link
			Check steer hub oil level
	✓		Check steer tyres for unusual wear
	✓		Check radiator mount bolts & brackets
	✓		Check intercooler & A/C condenser mount bolts
	✓		Check condition of fan & A/C belts (check belt & tensioner alignment)
	✓		Check A/C compressor mounting bolts & brackets
	✓		Check alternator mount bracket & bolt

✓		Check radiator core & tanks for leaks, Check all hoses & clamps
✓		Check fan shroud for damage or cracks
✓		Check over engine for oil/fuel or coolant leaks
✓		Check complete exhaust system for sign for leaks
✓		Check exhaust manifold gaskets
✓		Check steering shaft spine & universals for movement
	N/a	Check bonnet mount bolts, bushes & clips
✓		Check cab mount bushes
✓		Check cab mount shock absorbers for leaks & mount condition
✓		Check drive guard post for movement
	N/a	Check turntable mount bolts tension
✓		Jack up steer axle & check wheel bearings & kingpins for movement
		Retension drive & steer U-bolts
✓		Change engine oil & filters
✓		Change fuel filters
✓		Check coolant level
✓		Check powersteering oil level
✓		Check transmission oil level
✓		Check diff oil levels
✓		Grease all grease points
✓		Check and clean batteries

					. 4
(വ	m	m	161	1ts:

REMOVE AND REPLACE COMPLETE GEARBOX INCLUDING PTO
NEW ISUZU GENUINE AMT GEARBOX OIL USED

Mechanic:	Callum Ramstadius	Date:	1.8.25
Signature:	Chille		



Truck 20,000Km 'B' Service

MVTC NO:171133

(Trade License)

Date:	27/10/2024	Rego:		CL59.MH
Fleet #:	NPR300 Isuzu	Kilometres	/Hours:	350000Kms

Mechanic	Ok	X	Ok = Passed Inspection $X = Repairs Needed or Not Applicable$
	✓		Remove & replace service sticker
	\		Check seat condition and correct operation of seat & seat belts
	✓		Check operation of horns & low air buzzers
	✓		Check operation of gauges
	✓		Check windscreen for cracks or damage
	✓		Check operation of windscreen wipers & rubber condition
	✓		Check operation of windscreen washers & nozzles
	✓		Check operation of A/C from inside cab
	✓		Check condition of clutch & brake pedal rubber
	✓		Check operation of internal lights (stay out of sleeper)
		N/a	Check clutch adjustment
	✓		Check operation of all external lights including load lights
	✓		Adjust brakes & record brake lining/pad remaining
	✓		Check all brake drums/rotors for cracks
	✓		Check condition of all brake hoses
	✓		Check all axles for wheel seal leaks
	✓		Check rear carrier pinion seals for leaks
	✓		Check all shock absorbers for leaks and mount condition
		N/a	Check suspension airbags condition & mounting
	✓		Check rear suspension U-bolts & saddles for signs of movements
	✓		Check rear suspension for cracked springs
	✓		Check condition of torque & tracking rod mounting bolts & bushes
	✓		Check rear tyres for unusual wear
	✓		Check condition and tightness of universal joints, including yokes
	✓		Check all cross members for cracks
	✓		Check over transmission for oil leaks
	✓		Check condition of all engine mount bolts, rubbers & brackets
	✓		Check clutch linkage for wear
	✓		Drain all air tanks
	✓		Check steer axle springs for cracks
	✓		Check steer spring U-bolts & saddles for signs of movement
	✓		Check steering tie rod ends & drag link
			Check steer hub oil level
	✓		Check steer tyres for unusual wear
	✓		Check radiator mount bolts & brackets
	✓		Check intercooler & A/C condenser mount bolts
	✓		Check condition of fan & A/C belts (check belt & tensioner alignment)
	✓		Check A/C compressor mounting bolts & brackets
	✓		Check alternator mount bracket & bolt

_/		Charle redictor care & tenks for looks Charle all hoose & clamps
V		Check radiator core & tanks for leaks, Check all hoses & clamps
✓		Check fan shroud for damage or cracks
✓		Check over engine for oil/fuel or coolant leaks
✓		Check complete exhaust system for sign for leaks
✓		Check exhaust manifold gaskets
✓		Check steering shaft spine & universals for movement
	N/a	Check bonnet mount bolts, bushes & clips
✓		Check cab mount bushes
✓		Check cab mount shock absorbers for leaks & mount condition
✓		Check drive guard post for movement
	N/a	Check turntable mount bolts tension
✓		Jack up steer axle & check wheel bearings & kingpins for movement
		Retension drive & steer U-bolts
✓		Change engine oil & filters
✓		Change fuel filters
✓		Check coolant level
✓		Check powersteering oil level
✓		Check transmission oil level
✓		Check diff oil levels
✓		Grease all grease points
✓		Check and clean batteries

Comments:

Major service completed at 350000 inleuding new brakes and bearings				

Mechanic:	Callum Ramstadius	Date:	27/10/2024
Signature:	Marke		



Vehicle 'B' Service

Date:	13/5/2022	Rego:		CL.59.MH
Fleet #:	Isuzu NPR 300	Kilometres	Hours:	328909kms 7327Hrs

Mechanic	Ok	X	Ok = Passed Inspection $X = Repairs Needed or not required$
	✓		Remove & replace service sticker
	✓		Check seat condition and correct operation of seat & seat belts
	✓		Check operation of horn
	✓		Check operation of gauges
	✓		Check windscreen for cracks or damage
	✓		Check operation of windscreen wipers & rubber condition
	✓		Check operation of windscreen washers & nozzles
	✓		Check operation of A/C from inside cab
		NA	Check computer system for any active faults
	✓		Check brake pedal operation
		NA	Check clutch pedal operation
	✓		Check operation of all lights including extras (spotlights etc)
			eners of craves of an again measuring energy (of congain cos)
			←—
			Front
	√	+	Record brake lining/pad remaining
	-/		Check all brake drums/rotors for cracks
	▼		
	▼	+	Check condition of all brake hoses / pipes
	✓		Check all axles for wheel seal leaks
	∀		Check rear carrier pinion seals for leaks
	∀	NT A	Check all shock absorbers for leaks and mount condition
		NA	Check front / rear suspension coils for damage
	√		Check rear suspension U-bolts & saddles for signs of movements
	✓		Check rear suspension for cracked springs
	√		Check condition of torque & tracking rod mounting bolts & bushes
	√		Check condition of tailshaft uni joints and yokes
	✓		Check diff's for oil leaks
		NA	Check over transfer case for oil leaks
	✓		Check over transmission for oil leaks
	✓		Check condition of all engine mount bolts, rubbers & brackets
	✓		check steering tie rod ends and drag links
	✓		Check steer tyres for unusual wear
	✓		Check drive tyres for unusual wear
	✓		Inspect chassis / body for damge
	✓		Check cab mounts
	✓	†	Blow out radiators / coolers

	✓ ✓ ✓ ✓ ✓ ✓	Check intercooler & A/C condenser mount bolts Check condition of fan & A/C belts (check belt & tensioner alignment) Check A/C compressor mounting bolts & brackets Check alternator mount bracket & bolt Check radiator core & tanks for leaks, Check all hoses & clamps Check fan shroud for damage or cracks Check over engine for oil/fuel or coolant leaks Check complete exhaust system for sign for leaks Check exhaust manifold gaskets
	* * * * * * * * * * * * * * * * * * *	Check condition of fan & A/C belts (check belt & tensioner alignment) Check A/C compressor mounting bolts & brackets Check alternator mount bracket & bolt Check radiator core & tanks for leaks, Check all hoses & clamps Check fan shroud for damage or cracks Check over engine for oil/fuel or coolant leaks Check complete exhaust system for sign for leaks
	√ √ √ √	Check A/C compressor mounting bolts & brackets Check alternator mount bracket & bolt Check radiator core & tanks for leaks, Check all hoses & clamps Check fan shroud for damage or cracks Check over engine for oil/fuel or coolant leaks Check complete exhaust system for sign for leaks
	√ √ √ √	Check alternator mount bracket & bolt Check radiator core & tanks for leaks, Check all hoses & clamps Check fan shroud for damage or cracks Check over engine for oil/fuel or coolant leaks Check complete exhaust system for sign for leaks
	√ √ √	Check radiator core & tanks for leaks, Check all hoses & clamps Check fan shroud for damage or cracks Check over engine for oil/fuel or coolant leaks Check complete exhaust system for sign for leaks
	✓	Check fan shroud for damage or cracks Check over engine for oil/fuel or coolant leaks Check complete exhaust system for sign for leaks
	✓	Check over engine for oil/fuel or coolant leaks Check complete exhaust system for sign for leaks
	✓	Check complete exhaust system for sign for leaks
	*	
	✓	Check exhaust mannota gaskets
	<u> </u>	Check steering shaft spine & universals for movement
	✓	Jack up steer axle and check wheel bearings for movement
	· /	Jack up drive axle and check wheel bearings for movement
	•	Jack up unive axie and eneck wheel bearings for movement
	✓	Change or clean air filters / cab filters
	✓	Change engine oil & filters
	✓	Change fuel filters
	✓	Check coolant level
	✓	Check powersteering oil level
	√	Check transmission oil level
	· /	Check diff oil levels
	· /	Grease all grease points
	1	Check and clean batteries
		
echanic:	Ca <u>l</u> l	um Ramstadius Date: 13/5/2022