



# Equipment Service Report

Date: Sept 27-2019\_\_ Completed By: \_Michel\_\_\_\_\_ Unit #: H4\_\_\_\_\_

Hour Meter Reading:3930 Next Service: \_4330\_ Machine: \_Cat 329F (HERL00157)

| Item/Part Checked            | Checked | Changed | Item/Part Checked                    | Checked | Changed | Item/Part Checked       | Checked | Changed |
|------------------------------|---------|---------|--------------------------------------|---------|---------|-------------------------|---------|---------|
| <b>Engine</b>                |         |         | <b>Cabs</b>                          |         |         | <b>Electrical</b>       |         |         |
| Oil Levels                   |         | 40L     | Windows                              |         |         | Fuses                   |         |         |
| Oil Filters                  |         |         | A/C & Heater                         |         |         | Lights                  |         |         |
| Air Filters                  |         |         | Two Way Radio (Fossils Rental)       |         |         | Gauges                  |         |         |
| Fuel Filters                 |         |         | Doors & Latches                      |         |         | <b>Other</b>            |         |         |
| Oil Leaks                    |         |         | System Controls (covers, pedals)     |         |         | Exhaust System          |         |         |
| Water Separator              |         |         | <b>Attachments</b>                   |         |         | Spill kit               |         |         |
| Batteries                    |         |         | Pins and Bushings                    |         |         | Dozer Pin               |         |         |
| Alternator                   |         |         | Grease                               |         |         | Cat Bar                 |         |         |
| Coolant Leaks                |         |         | Cutting Edges/Corner Bits            |         |         | C-Frame                 |         |         |
| Antifreeze Levels/Strength   |         |         | Ripper Teeth/ Shanks/ Guards/Buckets |         |         | Grease Gun              |         |         |
| Hoses                        |         |         | Side Arm Pins Must Have Chains       |         |         | Track Shovel            |         |         |
| <b>Transmission</b>          |         |         | Install Blade & Check Tilts          |         |         | Fire Extinguisher       |         |         |
| Oil Level                    |         |         | <b>Coolant System</b>                |         |         | First Aid Kit           |         |         |
| Filters/Screens              |         |         | Radiator                             |         |         | <b>Attachments</b>      |         |         |
| Oil Leaks                    |         |         | Hoses                                |         |         | Final Drives            |         |         |
| Hoses                        |         |         | Fan Belts and Fan                    |         |         | Oil Level               |         |         |
| <b>Hydraulics</b>            |         |         | Test & Top Coolant Level             |         |         | Differential Front/Rear |         |         |
| Oil Level                    |         |         | <b>Under Carriage</b>                |         |         | Transfer Case           |         |         |
| Check Cylinders              |         |         | Check for Cracks                     |         |         | Check for Cuttings      |         |         |
| Filters                      |         |         | Check Oil in Track Frame             |         |         | Check for Leaks         |         |         |
| Check Hoses                  |         |         | Check Track Adjustment               |         |         | Sprocket Bolts          |         |         |
| Check Valves (Leaks, Damage) |         |         | Check Rollers                        |         |         | Winch & Winch Line      |         |         |
|                              |         |         | Check for Loose/Broken Bolts         |         |         |                         |         |         |
|                              |         |         | Check Grease Equalizer Bar           |         |         |                         |         |         |
|                              |         |         | Check Oil for Pivot Shaft            |         |         |                         |         |         |

Parts and Supplies: Changed Engine Oil 0-40 coop DMO-0-40



# Equipment Service Report

Date: May 28-2019\_\_ Completed By: \_Michel\_ Unit #: H4\_\_  
 Hour Meter Reading:3660 Next Service: \_4060\_ Machine: \_Cat 329F (HERL00157)

| Item/Part Checked            | Checked | Changed | Item/Part Checked                    | Checked | Changed | Item/Part Checked       | Checked | Changed |
|------------------------------|---------|---------|--------------------------------------|---------|---------|-------------------------|---------|---------|
| <b>Engine</b>                |         |         | <b>Cabs</b>                          |         |         | <b>Electrical</b>       |         |         |
| Oil Levels                   |         | 40L     | Windows                              |         |         | Fuses                   |         |         |
| Oil Filters                  |         |         | A/C & Heater                         |         |         | Lights                  |         |         |
| Air Filters                  |         |         | Two Way Radio (Fossils Rental)       |         |         | Gauges                  |         |         |
| Fuel Filters                 |         |         | Doors & Latches                      |         |         | <b>Other</b>            |         |         |
| Oil Leaks                    |         |         | System Controls (covers, pedals)     |         |         | Exhaust System          |         |         |
| Water Separator              |         |         | <b>Attachments</b>                   |         |         | Spill kit               |         |         |
| Batteries                    |         |         | Pins and Bushings                    |         |         | Dozer Pin               |         |         |
| Alternator                   |         |         | Grease                               |         |         | Cat Bar                 |         |         |
| Coolant Leaks                |         |         | Cutting Edges/Corner Bits            |         |         | C-Frame                 |         |         |
| Antifreeze Levels/Strength   |         |         | Ripper Teeth/ Shanks/ Guards/Buckets |         |         | Grease Gun              |         |         |
| Hoses                        |         |         | Side Arm Pins Must Have Chains       |         |         | Track Shovel            |         |         |
| <b>Transmission</b>          |         |         | Install Blade & Check Tilts          |         |         | Fire Extinguisher       |         |         |
| Oil Level                    |         |         | <b>Coolant System</b>                |         |         | First Aid Kit           |         |         |
| Filters/Screens              |         |         | Radiator                             |         |         | <b>Attachments</b>      |         |         |
| Oil Leaks                    |         |         | Hoses                                |         |         | Final Drives            |         |         |
| Hoses                        |         |         | Fan Belts and Fan                    |         |         | Oil Level               |         |         |
| <b>Hydraulics</b>            |         |         | Test & Top Coolant Level             |         |         | Differential Front/Rear |         |         |
| Oil Level                    |         |         | <b>Under Carriage</b>                |         |         | Transfer Case           |         |         |
| Check Cylinders              |         |         | Check for Cracks                     |         |         | Check for Cuttings      |         |         |
| Filters                      |         |         | Check Oil in Track Frame             |         |         | Check for Leaks         |         |         |
| Check Hoses                  |         |         | Check Track Adjustment               |         |         | Sprocket Bolts          |         |         |
| Check Valves (Leaks, Damage) |         |         | Check Rollers                        |         |         | Winch & Winch Line      |         |         |
|                              |         |         | Check for Loose/Broken Bolts         |         |         |                         |         |         |
|                              |         |         | Check Grease Equalizer Bar           |         |         |                         |         |         |
|                              |         |         | Check Oil for Pivot Shaft            |         |         |                         |         |         |

Parts and Supplies: Changed Engine Oil 0-40 coop DMO-0-40

Parts and Supplies: Changed Engine Oil 0-40 coop DMO-0-40



# Equipment Service Report

Date: Dec 20-2019\_ Completed By: \_Michel\_ Unit #: H4\_

Hour Meter Reading:4305 Next Service: \_4705\_ Machine: \_Cat 329F (HERL00157)

| Item/Part Checked            | Checked |         | Item/Part Checked                    | Checked |         | Item/Part Checked       | Checked |         |
|------------------------------|---------|---------|--------------------------------------|---------|---------|-------------------------|---------|---------|
|                              | Checked | Changed |                                      | Checked | Changed |                         | Checked | Changed |
| <b>Engine</b>                |         |         | <b>Cabs</b>                          |         |         | <b>Electrical</b>       |         |         |
| Oil Levels                   |         | 40L     | Windows                              |         |         | Fuses                   |         |         |
| Oil Filters                  |         |         | A/C & Heater                         |         |         | Lights                  |         |         |
| Air Filters                  |         |         | Two Way Radio (Fossils Rental)       |         |         | Gauges                  |         |         |
| Fuel Filters                 |         |         | Doors & Latches                      |         |         | <b>Other</b>            |         |         |
| Oil Leaks                    |         |         | System Controls (covers, pedals)     |         |         | Exhaust System          |         |         |
| Water Separator              |         |         | <b>Attachments</b>                   |         |         | Spill kit               |         |         |
| Batteries                    |         |         | Pins and Bushings                    |         |         | Dozer Pin               |         |         |
| Alternator                   |         |         | Grease                               |         |         | Cat Bar                 |         |         |
| Coolant Leaks                |         |         | Cutting Edges/Corner Bits            |         |         | C-Frame                 |         |         |
| Antifreeze Levels/Strength   |         |         | Ripper Teeth/ Shanks/ Guards/Buckets |         |         | Grease Gun              |         |         |
| Hoses                        |         |         | Side Arm Pins Must Have Chains       |         |         | Track Shovel            |         |         |
| <b>Transmission</b>          |         |         | Install Blade & Check Tilts          |         |         | Fire Extinguisher       |         |         |
| Oil Level                    |         |         | <b>Coolant System</b>                |         |         | First Aid Kit           |         |         |
| Filters/Screens              |         |         | Radiator                             |         |         | <b>Attachments</b>      |         |         |
| Oil Leaks                    |         |         | Hoses                                |         |         | Final Drives            |         |         |
| Hoses                        |         |         | Fan Belts and Fan                    |         |         | Oil Level               |         |         |
| <b>Hydraulics</b>            |         |         | Test & Top Coolant Level             |         |         | Differential Front/Rear |         |         |
| Oil Level                    |         |         | <b>Under Carriage</b>                |         |         | Transfer Case           |         |         |
| Check Cylinders              |         |         | Check for Cracks                     |         |         | Check for Cuttings      |         |         |
| Filters                      |         |         | Check Oil in Track Frame             |         |         | Check for Leaks         |         |         |
| Check Hoses                  |         |         | Check Track Adjustment               |         |         | Sprocket Bolts          |         |         |
| Check Valves (Leaks, Damage) |         |         | Check Rollers                        |         |         | Winch & Winch Line      |         |         |
|                              |         |         | Check for Loose/Broken Bolts         |         |         |                         |         |         |
|                              |         |         | Check Grease Equalizer Bar           |         |         |                         |         |         |
|                              |         |         | Check Oil for Pivot Shaft            |         |         |                         |         |         |

Parts and Supplies: Changed Engine Oil 0-40 coop DMO-0-40

Changed track tightener on the left side