



Equipment Service Report

Date: Dec 7-2021_ Completed By: _Michel_ Unit #: H4_

Hour Meter Reading:5560 Next Service: _5960_ Machine: _Cat 329F (HERL00157)

Item/Part Checked	Checked	Changed	Item/Part Checked	Checked	Changed	Item/Part Checked	Checked	Changed
Engine			Cabs			Electrical		
Oil Levels		40L	Windows			Fuses		
Oil Filters			A/C & Heater			Lights		
Air Filters			Two Way Radio (Fossils Rental)			Gauges		
Fuel Filters			Doors & Latches			Other		
Oil Leaks			System Controls (covers, pedals)			Exhaust System		
Water Separator			Attachments			Spill kit		
Batteries			Pins and Bushings			Dozer Pin		
Alternator			Grease			Cat Bar		
Coolant Leaks			Cutting Edges/Corner Bits			C-Frame		
Antifreeze Levels/Strength			Ripper Teeth/ Shanks/ Guards/Buckets			Grease Gun		
Hoses			Side Arm Pins Must Have Chains			Track Shovel		
Transmission			Install Blade & Check Tilts			Fire Extinguisher		
Oil Level			Coolant System			First Aid Kit		
Filters/Screens			Radiator			Attachments		
Oil Leaks			Hoses			Final Drives		
Hoses			Fan Belts and Fan			Oil Level		
Hydraulics			Test & Top Coolant Level			Differential Front/Rear		
Oil Level			Under Carriage			Transfer Case		
Check Cylinders			Check for Cracks			Check for Cuttings		
Filters			Check Oil in Track Frame			Check for Leaks		
Check Hoses			Check Track Adjustment			Sprocket Bolts		
Check Valves (Leaks, Damage)			Check Rollers			Winch & Winch Line		
			Check for Loose/Broken Bolts					
			Check Grease Equalizer Bar					
			Check Oil for Pivot Shaft					

Parts and Supplies: Changed Engine Oil 0-40 coop DMO-0-40



Equipment Service Report

Date: Jan 21-2021_ Completed By: _Michel_ Unit #: H4_

Hour Meter Reading:5150 Next Service: _5550_ Machine: _Cat 329F (HERL00157)

Item/Part Checked	Checked	Changed	Item/Part Checked	Checked	Changed	Item/Part Checked	Checked	Changed
Engine			Cabs			Electrical		
Oil Levels		40L	Windows			Fuses		
Oil Filters			A/C & Heater			Lights		
Air Filters			Two Way Radio (Fossils Rental)			Gauges		
Fuel Filters			Doors & Latches			Other		
Oil Leaks			System Controls (covers, pedals)			Exhaust System		
Water Separator			Attachments			Spill kit		
Batteries			Pins and Bushings			Dozer Pin		
Alternator			Grease			Cat Bar		
Coolant Leaks			Cutting Edges/Corner Bits			C-Frame		
Antifreeze Levels/Strength			Ripper Teeth/ Shanks/ Guards/Buckets			Grease Gun		
Hoses			Side Arm Pins Must Have Chains			Track Shovel		
Transmission			Install Blade & Check Tilts			Fire Extinguisher		
Oil Level			Coolant System			First Aid Kit		
Filters/Screens			Radiator			Attachments		
Oil Leaks			Hoses			Final Drives		
Hoses			Fan Belts and Fan			Oil Level		
Hydraulics			Test & Top Coolant Level			Differential Front/Rear		
Oil Level			Under Carriage			Transfer Case		
Check Cylinders			Check for Cracks			Check for Cuttings		
Filters			Check Oil in Track Frame			Check for Leaks		
Check Hoses			Check Track Adjustment			Sprocket Bolts		
Check Valves (Leaks, Damage)			Check Rollers			Winch & Winch Line		
			Check for Loose/Broken Bolts					
			Check Grease Equalizer Bar					
			Check Oil for Pivot Shaft					

Parts and Supplies: Changed Engine Oil 0-40 coop DMO-0-40