Equipment Protection Plans (EPP)

3 EASY STEPS TO PROTECT YOUR NEW CAT® EQUIPMENT

You count on your Cat® machines to get the job done, day in and day out. Choose a protection plan that's just as dependable and long-lasting. EPP offers the only coverage designed specifically for new Cat equipment – giving you the highest level of repair cost protection available. Comprehensive EPP options protect your investment and your beace of mind.

ELECT YOUR PROTECTION OPTION

Choose from our Powertrain, Powertrain + Hydraulics, Powertrain + Hydraulics + Technology, Pro and Premier plans to get the exact age and hours for the protection you need.

PREMIER

STRUCTURES Frame

Boom & stick

ROPS

CAB

Steering Column

Gauges/Indicators/Instruments

Circuit Board OTHER MAJOR COMPONENTS

Includes ALL Powertrain, Powertrain + Hydraulics, and Powertrain + Hydraulics + Technology and Pro components listed below.

Quick Coupler **Asphalt Paver Screed**

ELECTRONICS

Protection Devices & Alarms

PRO*

ELECTRIC SYSTEM

Engine and all other wiring harnesses

Alternator

Fuse/Circuit Breaker Panel

Main Power & Start Relay

OTHER MAJOR COMPONENTS

Cab Air Conditioner & Heater

Refrigerant Compressor &

Condenser

Switches

Dash Group

Wiper Group

Antennas

Relays

Radiator

Electric Starting Motor Engine Mount

Fuel Tank **Engine Oil Lines**

STEERING & SUSPENSION Control Valve

Includes ALL Powertrain, Powertrain + Hydraulics and Powertrain + Hydraulics + Technology components listed below.

POWERTRAIN + HYDRAULICS + TECHNOLOGY

CAT CONNECT™ TECHNOLOGY COMPONENTS - COMPACT™, GRADE™, PAYLOAD™, LINK™, TERRAIN™

Components covered under standard warranty that are factory or dealer installed prior to delivery

TERRAIN

Displays Monitors

Sensors**

Satellite Receivers Laser Receivers

Integrated Joystick Buttons/

Controls Machine Software

VIMS (Vital Information Management System) Product Link™ System

Global Positioning System

Electronic Control Suspension Control Cat Grade Control

Speed Sensors **Grade Control Sensors** Compactometer Payload Monitor System **Autodig Control**

STEERING & SUSPENSION

Suspension Cylinder

Computer Aided Earthmoving

Includes ALL Powertrain and Powertrain + Hydraulics components listed below.

POWERTRAIN + HYDRAULICS

STEERING & IMPLEMENT CONTROLS

Hydraulic Pumps Hydraulic Motors Hydraulic Cylinders Hydraulic Valves

Hydraulic Accumulators Hydraulic Lines Hydraulic Hoses

Implement & Steering Electronic Controls** Implement Electronic Control System Joystick Pilot Control Valve Hydraulic Tank Swivel

Hydraulic Oil Temp Sensor Hydraulic Oil Cooler Transmission Oil Lines Steering Gear & Valve

Includes ALL Powertrain components listed on next page.

POWERTRAIN

ENGINE

Fan & Fan Drive Hydraulic Fan Motor Jacket Water Pump, Drive Group Thermostat/Regulator Timing/Accessory Gears Timing Chain/Belt **Engine Oil Cooler** Engine Oil Pump Engine Oil Pan Group Engine Oil Filter Housing/Base Cylinder Block Cylinder Head Casting Crankshaft Main & Rod Bearings Connecting Rod Governor/Speed Limiter Pistons & Piston Rings Camshaft & Camshaft Bearing Inlet/Exhaust Valve Push Rod & Balancer

Rocker Arm & Rocker Shaft Assembly Valve Cover & Base Valve Spring Valve Guide Flywheel Aftercooler Group Turbocharger Manifolds, Inlet & Exhaust High Pressure Fuel Pump **Fuel Injection Lines Fuel Injection Pump** Fuel Transfer Pump Electronic Control Module (ECM)

TRANSMISSION, TORQUE **CONVERTER & TRANSFER CASE**

Transmission Case Transmission Gears Transmission Shaft Transmission Hydraulic Control Transmission Electronic Control Transmissions Oil Pump Transmissions Oil Filter Base Torque Converter Transfer Gear Group

DRIVE TRAIN

Differential Case Differential Steering Axle Housing Assembly Drive Axle Final Drive Case/Bore Final Drive Gears Universal Joint

STEERING & SUSPENSION

Steering Linkage

ELECTRONICS

Traction Control System

BRAKING

Brake Master Cylinder Control Valves Accumulator Parking Brake

OTHER MACHINE COMPONENTS

Swing Gear

CLEAN EMISSIONS MODULE COMPONENTS

Clean Gas Induction Cooler Diesel Particulate Filter (DPF) Diesel Exhaust Fluid Module Diesel Exhaust Fluid Injector Diesel Exhaust Fluid Pump Catalytic Converter

KNOW YOUR RESPONSIBILITIES

To qualify for coverage under an EPP, you need to:

- Operate your equipment according to the Cat Operation & Maintenance Manual (OMM) (e.g., no improper fuel use)
- Ensure recommended preventive maintenance is performed at intervals specified in the OMM
- Provide proof of preventive maintenance compliance (receipts, copies of work orders, invoices) on request
- Promptly provide your equipment for repair in the event of a covered failure

You can count on us to perform necessary inspections to confirm eligibility, install parts approved by Caterpillar on covered repairs and validate your enrollment in the program.

PURCHASE AND REGISTER YOUR EPP

Work with your local Cat dealer to complete the process and get the protection and peace of mind you deserve.

Please contact your Cat dealer for more details.

EXCLUSIONS*

If a component isn't listed, it may not be included in your plan. Other exclusions include:

- > Failures caused by normal wear-out or improper or abusive use of the machine
- Lubricating oil, antifreeze, filters, consumables and other maintenance items replaced during the covered component repair, unless such items are rendered unusable by a covered component failure
- > Freight charges for parts shipments
- Travel time and mileage involved in getting to a jobsite
- Hauling, retrieval, equipment rental or overtime labor
- Repair costs resulting from the failure of any noncovered components
- Downtime loss
- Any incidental or consequential damages or costs incurred as a result of a covered component failure
- Modifications unless approved by Caterpillar
- These are examples of covered and excluded components or items. The actual dealer contract will govern. See your Cat dealer for a complete list of covered components and more information

Pro EPP currently only available in the U.S. and Canada on governmental purchases of Cat Motor Graders (excludes the following models: 16, 18 and 24).

** Electronic controls and sensors which function to direct power for the purpose of moving the machine are included. This includes power shift controls, engine pressure controls, differential lock, finger-tip controls, wiring connectors that are part of the designated Powertrain components. Hydraulic valves & controls - includes specified valve parts for directing or controlling Hydraulic fluid for steering and implements, including automatic blade controls and bucket position controls

This marketing tool does not represent a contract or obligation of any kind between Cat Financial Insurance Services, its parent or affiliates, and the equipment owner. For details on any dealer agreement, including a complete description of the terms, conditions, and/or exclusions, contact your local Cat dealer. All graphics and lists in this marketing tool are provided solely for general information purposes and are not intended to be a solicitation or an offer to sell any product or service. *CAT DEALERS ONLY: For terms, conditions, and/or exclusions of Equipment Protection, see the appropriate Cat Financial Insurance Services Equipment Protection Plan Service Guide found at https://warranty.cat.com/en/global-guide/caterpillar-financialinsuranceservices.html. These guides are the only safe source for Equipment Protection programs

To the extent that the above publication(s), bulletin(s), and/or any designated contract(s) are ambiguous or inconsistent with the policy language, the policy language shall determine the coverage under this policy.

© 2024 Caterpillar. All Rights Reserved. CAT, CATERPILLAR, LET'S DO THE WORK, their respective logos, "Caterpillar Corporate Yellow", the "Power Edge" and Cat "Modern Hex" trade dress as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission

