D40-50
MAY

Unit # BTP 47 BOMAG SHEEPFOOT

Mileage_____ Hrs_____

Date	Description of Work	Parts Costs	Labour Costs
APR/13 WO#0040	Repair hydraulics (adjust high and low linkage), change oil in torque hubs, send out left rear wheel motor for repair (hydraulics), tap off hyd. tank, check fluid levels in torque hubs and vibrator drum. (LEO) HRS. 2981.6		
May4/21 WO#0454	Check air filters, levels and start to get ready for season.		