	CR 9.90 NA YGG119827		CR 9.90 NA YGG119827
Repair	**Issue**	**Repair**	**Part Number**
1	Rear shoe pivot plate	**1**	84457842
2	½ link feeder chain / left hand adjustment bushing out of place	**2**	
3	Feeder drive chain	**3**	
4	Top feeder house drive tensioner bushing	**4**	84057311 (X2)
5	Bottom feeder house drive tensioner bushing	**5**	84057311 (X2)
6	Vac fan tensioner bushing	**6**	382974 (X2)
7	Flip feeder sprockets	**7**	
8	2 feeder chain wear strips (all 3 sections)	**8**	84530707 (X2), 51443489 (X2), 51443490 (X2)
9	LH rotor roof	**9**	86974430
10	RH rotor roof, center panel	**10**	86974436, 86974427
11	RH return cross auger bearing	**11**	364908, 140119 (X5)
12	Shoe drive tensioner bushing	**12**	84056770, 84056679
13	RH ground drive shaft, coupler, bolt and hardware	**13**	87586665, 84439102 (X2), 100037, 84440165
14	Clean grain drive chain	**14**	
15	Beater drive tensioner pulley	**15**	86588003
16	Unload drive tensioner pulley	**16**	443898 (X2)
17	Beater bearings	**17**	84330075 (X2)
18	Bubble up idler bearing	**18**	443898
19	Unload auger drive chain tensioner pin cotter pin	**19**	
20	(1) unload sheer pin (2) concave sheer pin	**20**	
21	Shoe drive tensioner rod worn	**21**	87642115, 439857
22	Chopper knives	**22**	
23	LH chopper bearing	**23**	87338614
24	Fuel filter sensor leak	**24**	90425106
25	RH header drive tensioner bushing	**25**	84057311 (X2)
26	Clean grain elevator drive belt tensioner	**26**	84057311 (X2)
27	RH header drive tensioner rod bent	**27**	84589000
28	DSP tensioner bushing	**28**	84057311 (X2)
29	Unload gearbox oil	**29**	
30	Feeder drum return spring	**30**	87712216
31	Clean grain jackshaft slip clutch bushing	**31**	51626956
32	Clean grain jackshaft, bearings	**32**	87605590, 87605592
33	(2x) clean grain drive chain sprockets	**33**	87283101 (X2)
34	Rotor screen idler bushing	**34**	382974 (X2)
35	Bubble up hopper seal	**35**	51453022
36	Water pump	**36**	
37	Fan idler pulley	**37**	727874
38	Aspirator exhaust hose	**38**	47450815
39	Shoe slip clutch bushing	**39**	80210022
40	Main drive belt	**40**	87545651
41	Unload auger 90-degree gearbox plug	**41**	86598044
42	Tighten rear wheel bearings	**42**	
43	Top feeder floor	**43**	
44	DSP front floor	**44**	