DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB73CK	TRAILER NUMBER	251	DATE:	2/2/26
KILOMETRES/HUBO		DOLLY NUMBER			

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	NA	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	NA	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	NA	
Inspect load strap and winder for condition and security	NA	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect Suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIANCE STICKER YES / NO	✓	

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check U-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check centre bolts		
Check springs		
Check rocker bushes and rods		
Check hangers		
Check shockers		

TOWING CONNECTION		
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
inspect all lights and reflectors - refer to NHVIM 14.20	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES / OTHER WORK CARRIED OUT:

NAME	SIGNATURE	DATE
Dale	Dale	2/2/26

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB73CK	TRAILER NUMBER	251	DATE:	5/1/26
KILOMETRES/HUBO		DOLLY NUMBER	—		

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	NA	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	NA	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	NA	
Inspect load strap and winder for condition and security	NA	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect Suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIANCE STICKER (YES) NO	✓	

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check U-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check centre bolts		
Check springs		
Check rocker bushes and rods		
Check hangers		
Check shockers		

TOWING CONNECTION	A	C
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
inspect all lights and reflectors - refer to NHVIM 14.20	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES / OTHER WORK CARRIED OUT:

NAME	SIGNATURE	DATE
Dale Dom		5/1/26

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB73CK	TRAILER NUMBER	251	DATE:	6/3/26
KILOMETRES/HUBO		DOLLY NUMBER			

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	NA	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	NA	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	NA	
Inspect load strap and winder for condition and security	NA	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect Suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIANCE STICKER YES / NO	✓	

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check U-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check centre bolts		
Check springs		
Check rocker bushes and rods		
Check hangers		
Check shockers		

TOWING CONNECTION		
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
inspect all lights and reflectors - refer to NHVIM 14.20	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES / OTHER WORK CARRIED OUT:

NAME	SIGNATURE	DATE
Cam Dale		6/3/26

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB 73CK	TR251	TRAILER NUMBER	N/A [illegible]	DATE: 11/2/25
KILOMETERS/HUBO	79845		DOLLY NUMBER		

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	N/A	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	N/A	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	N/A	
Inspect load strap and winder for condition and security	N/A	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIENCE STICKER YES / NO		

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check u-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check center bolts		
Check springs		
Check rocker bushes and rods		
Check hangers		
Check shockers		

TOWING CONNECTION		
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
Inspect all lights and reflectors - refer to NHVIM	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES:

Repair L/H/M ~~[illegible]~~ inner Puncture.

NAME Jesse Callaghan	SIGNATURE [signature]	DATE 11/2/25

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB73CK	TRAILER NUMBER	251	DATE:	13/3/25
KILOMETRES/HUBO		DOLLY NUMBER	—		

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	NA	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	NA	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	NA	
Inspect load strap and winder for condition and security	NA	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect Suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIANCE STICKER (YES) / NO	✓	

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check U-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check centre bolts		✓
Check springs		✓
Check rocker bushes and rods		✓
Check hangers		✓
Check shockers		

TOWING CONNECTION		
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
inspect all lights and reflectors - refer to NHVIM 14.20	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES / OTHER WORK CARRIED OUT:

NAME	SIGNATURE	DATE
Dale Dom		13/3/25

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB 73CK		TRAILER NUMBER	251	DATE: 16/12/25
KILOMETERS/HUBO			DOLLY NUMBER		

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	—	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	—	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	—	
Inspect load strap and winder for condition and security	—	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIENCE STICKER YES / NO		

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check u-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check center bolts		
Check springs		
Check rocker bushes and rods		
Check hangers		
Check shockers		

TOWING CONNECTION		
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
Inspect all lights and reflectors - refer to NHVIM 14.20	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES:

NAME Jesse Callaghan	SIGNATURE	DATE 16/12/25

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB [redacted] 73 CK	TRAILER NUMBER	251	DATE:	17/8/26
KILOMETRES/HUBO	—	DOLLY NUMBER	—		

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	—	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	—	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	✓	
Inspect load strap and winder for condition and security	✓	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect Suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seat as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIANCE STICKER YES / NO	✓	

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check U-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check centre bolts		
Check springs	✓	
Check rocker bushes and rods	✓	
Check hangers	✓	
Check shockers	✓	

TOWING CONNECTION	A	C
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
Inspect all lights and reflectors - refer to NHVIM 14.20	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES / OTHER WORK CARRIED OUT:

Re-kitted turn table.
Replaced 2x LH guards.
Replaced flat tyre.

NAME	SIGNATURE	DATE
Jacob Murrell	[signature]	17/8/26

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB 73CK		TRAILER NUMBER	— 251	DATE: 22/4/25
KILOMETERS/HUBO	—		DOLLY NUMBER	—	

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	—	—
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	—	—
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	✓	
Inspect load strap and winder for condition and security	—	—

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/gram	✓	
Inspect brake hoses for chaffing	✓	
Inspect suzi coils	—	—
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	—	—
COMPLIENCE STICKER YES / NO	✓	

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check u-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check center bolts	X	X
Check springs		
Check rocker bushes and rods		
Check hangers		
Check shockers		

TOWING CONNECTION		
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
Inspect all lights and reflectors - refer to NHVIM	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES:

REPAIRED HYDRAULIC OIL LEAK ON FITTINGS UNDER TRAILER

NAME	Sam Fletcher	SIGNATURE		DATE	22/4/25

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB736K		TRAILER NUMBER	251	DATE: 24/11/25
KILOMETERS/HUBO			DOLLY NUMBER		

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams		
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation		
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security		
Inspect roof, walls and doors, including hardware		
Inspect curtain condition, operation, posts and rollers		
Inspect load strap and winder for condition and security		

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs		

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures		
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIENCE STICKER YES / NO		

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check u-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check center bolts	✓	
Check springs		
Check rocker bushes and rods		
Check hangers		
Check shockers		

TOWING CONNECTION		
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
Inspect all lights and reflectors - refer to NHVIM 14.20	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES:

Replaced Rear Axle Tyres.

NAME	Sam Fullerton	SIGNATURE		DATE

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB73CK		TRAILER NUMBER	251	DATE: 27/5/25
KILOMETERS/HUBO	110965		DOLLY NUMBER		

STRUCTURE	(A)	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	/	
Inspect cracks in twist lock beams	—	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	/	
Inspect twist locks condition/operation	—	
Inspect condition and security of landing legs/bracketry - check operation	/	
Inspect floor condition/security	/	
Inspect roof, walls and doors, including hardware	/	
Inspect curtain condition, operation, posts and rollers	—	
Inspect load strap and winder for condition and security	—	
BRAKE COMPONENTS/AIR SYSTEM	(A)	C
Inspect air fittings	/	
Test for air leaks - park brake, service brake applied	/	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	/	
Inspect brake drums - refer manufacturer's specification	/	
Inspect S cam - lubricate	/	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	/	
Inspect brake boosters and brake valves - including blanking/vent plugs	/	
Inspect air tank mounting points/grain	/	
Inspect brake hoses for chafing	/	
Inspect suzi coils	—	
Check operation of brakes	/	
Inspect brake backing plates - fit where missing	/	
Fault Report Repairs	/	
WHEELS, TYRES AND BEARINGS	(A)	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	/	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	/	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	/	
Check tyre pressures	/	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	
SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags		
COMPLIENCE STICKER YES / NO		

GENERAL	(A)
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	/
Check toolbox mount/security	/
AIR SUSPENSION	(A)
Check all shockers	/
Check all airbags for leaks/perished	/
Check spring saddles and alignment	/
Check ride height valve	/
Check eye bushes	/
Check u-bolt tension	/
MECHANICAL SUSPENSION	A
Check center bolts	
Check springs	
Check rocker bushes and rods	
Check hangers	
Check shockers	
TOWING CONNECTION	
Inspect turntable jaws - adjust if required	/
Inspect turntable top/turntable inserts	/
Inspect skid plate wear - refer NHVIM 14.6	/
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	/
Check mounting bolt tension	/
ELECTRICAL SYSTEM	(A)
Inspect trailer plug - check pin condition	/
Inspect all lights and reflectors - refer to NHVIM	/
Inspect wiring harness - refer to NHVIM 14.18	/
Inspect condition and security of GPS tracker	/

NOTES:

Rt unit stickers.

NAME	Jesse Callaghan	SIGNATURE		DATE	27/5/25

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO		YB73CK	TRAILER NUMBER	Stag A-251	DATE: 9/12/24
KILOMETERS/HUBO		594586km	DOLLY NUMBER		

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	—	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	—	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect roof, walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers	—	
Inspect load strap and winder for condition and security	—	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect stack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect suzi coils	✓	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and Inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIENCE STICKER YES / NO	✓	

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check u-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check center bolts		
Check springs		
Check rocker bushes and rods		
Check hangers		
Check shockers		

TOWING CONNECTION		
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
Inspect all lights and reflectors - refer to NHVIM	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES:

NAME	Jacob Murrell	SIGNATURE		DATE	9/12/24

DAWSONS HAULAGE TRAILER SERVICE SHEET

TRAILER REGO	YB73CK		TRAILER NUMBER	Stag A(251)	DATE: 23/9/24
KILOMETERS/HUBO	21459 km		DOLLY NUMBER		

STRUCTURE	A	C
Inspect chassis/cross members and body mounts for cracks and security - refer to NHVIM 14.19	✓	
Inspect cracks in twist lock beams	✓	
Inspect all guards, infills and mudflaps - refer NHVIM 14.15	✓	
Inspect twist locks condition/operation	—	
Inspect condition and security of landing legs/bracketry - check operation	✓	
Inspect floor condition/security	✓	
Inspect ~~roof,~~ walls and doors, including hardware	✓	
Inspect curtain condition, operation, posts and rollers Tarps	✓	
Inspect load strap and winder for condition and security	—	

BRAKE COMPONENTS/AIR SYSTEM	A	C
Inspect air fittings	✓	
Test for air leaks - park brake, service brake applied	✓	
Inspect brake lining thickness - refer to manufacturer's specification - refer NHVIM 14.1	✓	
Inspect brake drums - refer manufacturer's specification	✓	
Inspect S cam - lubricate	✓	
Inspect slack adjusters - lubricate - check and adjust brake adjustment as required - refer to NHVIM 14.1	✓	
Inspect brake boosters and brake valves - including blanking/vent plugs	✓	
Inspect air tank mounting points/grain	✓	
Inspect brake hoses for chaffing	✓	
Inspect suzi coils	—	
Check operation of brakes	✓	
Inspect brake backing plates - fit where missing	✓	
Fault Report Repairs	✓	

WHEELS, TYRES AND BEARINGS	A	C
Inspect wheel bearing adjustment - refer to manufacturer's specification	✓	
Inspect all wheel studs and nuts - refer to NHVIM 14.12	✓	
Inspect tyre wear - must report on irregular tyre wear - refer NHVIM 14.4	✓	
Check tyre pressures	✓	
Wash and inspect wheel bearings	N/A	
Repack bearing - must use Genuine BPW grease	N/A	
Inspect/replace hub seal as required	N/A	
Clean all grease from hubs and repack	N/A	

SAFETY SYSTEMS	A	C
Inspect all safety items including retractable stop blocks and lock pin warning flags	✓	
COMPLIENCE STICKER YES / NO	✓	

GENERAL	A	C
Inspect marker plates including con signs, chevrons, and overtake/long signs - refer NHVIM 14.16	✓	
Check toolbox mount/security	✓	

AIR SUSPENSION	A	C
Check all shockers	✓	
Check all airbags for leaks/perished	✓	
Check spring saddles and alignment	✓	
Check ride height valve	✓	
Check eye bushes	✓	
Check u-bolt tension	✓	

MECHANICAL SUSPENSION	A	C
Check center bolts	/	
Check springs	/	
Check rocker bushes and rods	/	
Check hangers	/	
Check shockers	/	

TOWING CONNECTION	A	C
Inspect turntable jaws - adjust if required	✓	
Inspect turntable top/turntable inserts	✓	
Inspect skid plate wear - refer NHVIM 14.6	✓	
Inspect king pin wear/tension and security - refer NHVIM 14.7 Grease	✓	
Check mounting bolt tension	✓	

ELECTRICAL SYSTEM	A	C
Inspect trailer plug - check pin condition	✓	
Inspect all lights and reflectors - refer to NHVIM	✓	
Inspect wiring harness - refer to NHVIM 14.18	✓	
Inspect condition and security of GPS tracker	✓	

NOTES:

NAME	Jacob Murrell	SIGNATURE		DATE	23/9/24