

**CHASSIS DETAIL FOR 151143****Print****Model** T880**Class** 8**Unit Type** Tractor**Stock Type** Customer**Invoice Date** 2/29/2024**Build Date** /**VIN** 1XKZA48X9SJ151143**Sleeper Type****Intended Service** LOCAL PICKUP & DELIVERY**Commodity Hauled** GRAVEL/CRUSHED ROCK**DEALER TRUCK PURCHASE ORDER (DTPO) INFORMATION****DTPO Order Date** 12/6/2023**DTPO Number** 10107277**MAJOR COMPONENTS**

<b>Type</b>	<b>Make</b>	<b>Model</b>	<b>Serial #</b>
DIESEL PARTICULATE FILTER (DPF)	CUMMINS	EXH: SING CAN 2024 RH UND W/DUAL SOC TP	6D046247252
ENGINE	CUMMINS	ENG: CUMMINS X15 500V, 2024 500@1900 1650@900, PRODUCTIVITY SERIES	80615541
FORWARD REAR AXLE	MERITOR	MERITOR RS23-161 23K*SINGLE	FOR09043218
STEERING AXLE	DANA SPICER	DANA SPICER D-1321LW @13.2K, 3.5" DROP	MY02529828
TRANSMISSION	FULLER	FULLER FRO16210C 10-SPEED CONCEPT	P1657449

**Chassis: 151143    Model: T880 SERIES CONVENTIONAL    Build**  
**Date: 02/23/24**

**0000-NAM-E53 ENGR I.D.**

ENGR I.D.

**0000-ZZZ-ZZZ VEHICLE ID NO:1XKZA48X9SJ151143**

VEHICLE ID NO:1XKZA48X9SJ151143

PAINT COLOR NUMBER(S)

A - L0006EY WHITE

B - 841580EY GREEN WIT

FRAME N0001EA BLACK

BUMPER UNPAINTED

Day Cab Pearl/Metallic Paint

Spectrum Design Day Cab

Roof and Fenders

NON-STANDARD PAINT COLOR

\*\*\*PAINT SKETCH VERIFIED\*\*\*

PAINT:BASE COAT/CLEAR COAT\*REQ

EXTERIOR & PAINT COLOR L SERIES CODES\*

**0000-001-A9J MODEL: T880 - DAYCAB**

MODEL: T880 - DAYCAB

**0000-001-G16 SALES CHANGE ORDER LEVEL 016**

SALES CHANGE ORDER LEVEL 016

**0000-001-H01 FRAME DESIGN PROG; GLOS-FRM-002 (G)**

FRAME DESIGN PROG; GLOS-FRM-002 (G)

\* RULE DRIVEN FRAME DRILLINGS/PARTS/

LOCATIONS

**0000-001-M05 PRO-E FRAME DATA MODEL VERSION 5**

PRO-E FRAME DATA MODEL VERSION 5

**0000-001-M99 PRO-E FRAME DATA MODEL - AFDT IMPACT**

PRO-E FRAME DATA MODEL - AFDT IMPACT

**0000-111-110 DEALER NO : P187**

DEALER NO : P187

DEALER NAME: PAPE TRUCKS, INC.

\*\*\*\*\* CHASSIS INFORMATION SHEET \*\*\*\*\*

CHASSIS NO: 151135 - 151143

CUSTOMER : MDB TRUCKING LLC

DEALER LOC: P187

\*\*\*\*\* GROSS WEIGHT RATINGS \*\*\*\*\*

GVWR : 0015898 KG

GAWR FRONT : 0005602 KG

GAWR REAR : 0010296 KG

\*\*\* CHASSIS DIMENSION INFORMATION \*\*\*

WHEELBASE: 0004064 MM CUTOFF: 0000787 M

FAX DIM : 0000905 MM FX/BOC: 0001879

CAB/AXLE : 0002184 MM CB/EOF: 0002971

FRAME CUT LENGTH: 0005755 MM

CTRBRG: X= 117 MM Y= 230 MM

\*\*\*\*\* SPEEDO INFORMATION \*\*\*\*\*

\*\*\*\*\* SPEEDO INFORMATION \*\*\*\*\*  
 \*\*\*\*\* SPEEDO INFORMATION \*\*\*\*\*  
 VEHICLE SPEED: 136 KPH IN DIRECT  
 \*\*\*\*\* MAIN DRIVELINE \*\*\*\*\*  
 E05D0895 D/L-MAIN REAR  
 \*\*\*\*\* CENTERBEARING DRIVELINE \*\*\*\*\*  
 E05D1105 D/L-CENTRBRG  
 CENTERBEARING: 2470 MM

**0001-A00-A04 FINAL CHASSIS BILL OF MATERIAL INDEX**

FINAL CHASSIS BILL OF MATERIAL INDEX  
 TABLE OF CONTENTS  
 FRAME LAYOUT AND GROSS WEIGHT INFO  
 COMPONENT \*\*\*\*\* B/M NO.

- FRONT AXLE 0001
- REAR AXLE AND SUSPENSION 0002
- AIR BRAKE PIPING 0011
- EMERGENCY BRAKE 0012
- TRANSMISSION AND CLUTCH 0015
- AUX. TRANS, PTO, TRANSFER CASE 0016
- EXHAUST SYSTEM 0017
- CENTER BEARING & DRIVELINE 0018
- FRAME LAYOUT INFORMATION 0020
- DRIVELINES 0021
- FRONT FRAME 0022
- REAR & INTERMEDIATE C/M 0024
- BUMPER 0025
- REAR TOW HITCH & HOOK 0027
- FRONT TOW HOOK 0028
- CAB COMPONENTS 0030
- FUEL TANKS 0032
- SHEET METAL 0035
- UNDER CAB FAIRINGS
- HOOD 0037
- RADIATOR 0038
- ENGINE 0039
- CONT .....2010-2199
- AIR CLEANER 0039
- ELECTRICAL SYSTEM 0046
- LAMPS 0047
- INSTRUMENTS 0048
- BASIC STEERING 0051
- POWER STEERING 0052
- MUD FLAPS, FENDER, TOOLS 0057
- CRUISE CONTROL, AIR SHIELDS
- CAB/SLPR EXTNDERS
- FIFTH WHEEL 0063
- CAB STRUCTURE 0067
- ENGINES 2010-2099
- ENGINE EQUIPMENT 2100-2199
- TRANSMISSIONS 2200-2249
- FRT AXLES & SUSPENSIONS 2250-2299

REAR AXLES & SUSPENSION 2300-2399  
 TIRES 2400-2499  
 WHEELS & RIMS 2500-2599  
 FRAME & EQUIPMENT 2600-2699  
 BRAKE AIR PIPING 2810-2879  
 MISC REFLECTORS & LTS 2900-2909  
 TRLR LT LINES  
 FRAME 3A00-3A99  
 FRONT AXLE/SUSPENSION 3B00-3B99  
 REAR AXLE/SUSPENSION 3C00-3C99  
 ENGINE AND ENGINE EQUIPMENT 3D00-3D99  
 TRANS/CLUTCH/DRIVELINES 3E00-3E99  
 COOLING SYSTEM 3F00-3F99  
 AIR SYSTEM 3G00-3G99  
 TIRES/WHEELS 3H00-3H99  
 STEERING 3J00-3J99  
 FUEL/HYDRAULIC TANKS 3K00-3K99  
 HOOD 3L00-3L99  
 EXHAUST 3M00-3M99  
 BUMPER/BATTERY BOX/TOOL BOX 3N00-3N99  
 ELECTRICAL 3P00-3P99  
 INSTRUMENTS/CONTROLS 3Q00-3Q99  
 CAB STRUCTURE/EXTERIOR TRIM 3R00-3R99  
 CAB INTERIOR/TRIM 3S00-3S99  
 SLPR STRUCTURE/EXTERIOR TRIM 3T00-3T99  
 SLPR INTERIOR/TRIM 3U00-3U99  
 CERT,LABELS, DOCUMENTS 3Y00-3Y99

**0001-A00-G01 VEHICLE CLASSIFICATION - COMPLETE**

VEHICLE CLASSIFICATION - COMPLETE

VEHICLE CLASSIFICATION - COMPLETE

**0001-A00-000 FRONT AXLE S/N: MY02529828**

FRONT AXLE S/N: MY02529828

**0002-A00-000 FWD REAR S/N: FOR09043218**

FWD REAR S/N: FOR09043218

**0011-425-Z50 AIR TANK MATERIAL: ALUMINUM**

AIR TANK MATERIAL: ALUMINUM

\* CUSTOMER REQUEST FOR ALUMINUM TANKS

NOTE - THIS BILL CONTAINS NO PARTS

- REFERENCE TO SHOP ONLY

AIR TANK MATERIAL: ALUMINUM

**0011-850-Z01 R414-647 RTG - AIR TANK MTG & HARDWARE**

R414-647 RTG - AIR TANK MTG & HARDWARE

R414-647 RTG - AIR TANK MTG & HARDWARE

**0015-A00-000 UNIT TRANS S/N: P1657449**

UNIT TRANS S/N: P1657449

**0015-802-A68 TRANS SHIFT PIPING**

TRANS SHIFT PIPING

SHIFT KNOB MTG NUT

X9-802

Jam Nut, Self Locking (1/2- 1  
13)

**TUBE HARNESS INSTL O-RINGS**

13571	O-Ring	4
52600	TUBING-HARNESS	1

**UNION FTGS-CONNECTION OF TRANS****SHIFT PIPING-COLOR CODED PIPING**

G38-1033-0303	FTG - 5/32 NPT X 5/32	2
---------------	-----------------------	---

**R115-5816 DIAG-TRANS SHIFT PIPING****0015-804-A90 EATON ADVANTAGE SELF-ADJ CLUTCH ASSY****EATON ADVANTAGE SELF-ADJ CLUTCH ASSY**

309701-34	Advantage Clutch Assembly (15-1/2")	1
-----------	--	---

27-01394-010	HEX BOLT-7/16 ZINC	8
--------------	--------------------	---

27-00790-007	Flat Washer (7/16")	8
--------------	---------------------	---

**0015-804-E08 TRANS. TO FLYWHEEL HSG ATTACHING PARTS****TRANS. TO FLYWHEEL HSG ATTACHING PARTS**

W34-1155	BOLT-STUD, XMSN	12
----------	-----------------	----

**INSTALLATION TORQUE:**

70 LB-FT +/- 5 LB-FT

**0017-A00-000 CILS S/N: 31619793**

CILS S/N: 31619793

**0024-800-L04 SHORT TRACTOR TAPER W/O CROSSMBR****SHORT TRACTOR TAPER W/O CROSSMBR**

- W/O FLANGES BENT DOWN &amp; WELDED

R112-87 CADAM L/O - CUTOFF

**0032-850-F06 RTG - FUEL TANKS BOC****RTG - FUEL TANKS BOC**

K028-2489-18	90° Standoff Bracket	2
--------------	----------------------	---

W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	2
------------------	---	---

K041-802-20CA	Hex Bolt (M6 x 1.00 x 20mm)	4
---------------	-----------------------------	---

27-00801-004	Flat Washer (1/4")	4
--------------	--------------------	---

K077-123-24	Cushioned Clamp (1-1/2")	4
-------------	--------------------------	---

HDM500B	Cable Tie Mount, High Torque	4
---------	------------------------------	---

FW500NYL	Washer - Nylon (1/2")	4
----------	-----------------------	---

ROUTE PER CMS0258 6.1

**0032-870-A01 STD NON-LOCKING FUEL TANK CAP****STD NON-LOCKING FUEL TANK CAP**

K22-1029	FUEL TANK CAP	2
----------	---------------	---

**0032-870-B01 FUEL TANK VENT & BREATHER HOSE****FUEL TANK VENT & BREATHER HOSE**

2115-01	Fuel Tank Vent (1/2")	2
---------	-----------------------	---

W16-1019-015	CLAMP - PINCH EAR	2
--------------	-------------------	---

26-03179-0000	Low Pressure Fuel Hose (#5)	2
---------------	-----------------------------	---

**SHOP NOTE: APPROX LENGTH OF**

26-03179-0000 VENT BREATHER HOSE

IS 12 INCHES. ACTUAL LENGTH

TO BE DETERMINED AT CHASSIS ASSY.

D2139-2257	Plug - Pipe (1/4")	2
------------	--------------------	---

**VENT BREATHER HOSE ANCHOR CLIP:**

P03-1002	Adhesive Base Mount	2
----------	---------------------	---

K231-363-172 Tie Strap 2

R115-4914 DIAG-BREATHER HOSE

**0032-870-H01 COVER- FUEL GA. SENDING UNIT OPENING**

COVER- FUEL GA. SENDING UNIT OPENING

PLUGS TO FILL DRAW & RETURN PORTS

K097-811 Fuel Gauge Opening Cover 1

K129-194-08 Square Pipe Plug (1/2-14 NPTF) 2

K134-216 Fuel Level Sending Unit Gasket 1

**0032-870-U04 (2) FUEL GAUGE SENDING UNITS - OPT.**

(2) FUEL GAUGE SENDING UNITS - OPT.

5549-13714-24 Fuel Level Sender 2

W01-10-03T10V019Z Truss Head Screw (#10-16 x 10 19mm)

R063-274 INSTRN-FUEL SENDER GASKET

\*\*\*\*\* SHOP NOTE \*\*\*\*\*

CONNECT ADD L FUEL SENDING UNIT

HARNES TO RH FUEL TANK SENDER.

ROUTE HARNES FORWARD TO FIREWALL

AND CONNECT TO FUEL GAUGE HARNES.

CONNECT BREAKOUT FOR FUEL GAUGE ON

CHASSIS HARNES TO LH FUEL SENDER.

**0032-871-A05 DUAL DRAW SENDING UNIT IN LH & RH**

DUAL DRAW SENDING UNIT IN LH & RH

FUEL TANKS

DUAL DRAW SENDING UNIT IN LH & RH

FUEL TANKS

FUEL TANKS

**0039-A00-000 ENGINE S/N: 80615541**

ENGINE S/N: 80615541

**0046-810-X01 BATTERY TERMINAL LUBE POINTS**

BATTERY TERMINAL LUBE POINTS

R414-350 BTRY TERM LUBE POINTS

NYOGEL 759G SYNTHETIC GREASE

- APPROX 1 OZ PER TRK

\* APPLY HEAVY COAT OF NYOGEL 759G

SYNTHETIC GREASE TO POWER FEED STUD

ON PD BOX BEFORE ASSEMBLY.

**0063-A00-A08 FIFTH WHEEL POSITION**

FIFTH WHEEL POSITION

REAR MOST SETTING OR FIXED SETTING

203.2MM( 8") AHEAD CL OF BOGIE

**0063-A00-000 5TH WHEEL S/N: 14240320497**

5TH WHEEL S/N: 14240320497

**0063-803-C2P HOLLAND FIFTH WHEEL**

HOLLAND FIFTH WHEEL

FWALZ700XL00 5TH WHL-HOLLAND AL TOP 1  
PL

**0063-820-A34 STEEL 5TH WHEEL ANGLES - K516-7**

*STEEL 5TH WHEEL ANGLES - K516-7*  
 K516-7 ANGLE-FIFTH WHEEL 1  
 OUTBRD  
 K516-7R ANGLE-FIFTH WHEEL 1  
 OUTBRD

**0063-820-T11 FASTENERS - HOLLAND FIXED 5TH WHLS**

*FASTENERS - HOLLAND FIXED 5TH WHLS*  
*SHOP NOTE: TC BOLTS REQUIRED ON FIFTH*  
*WHEEL ANGLES. LENGTH OF BOLT BASED*  
*ON STANDARD CMS0267.*

**0063-820-X02 THREADED BOLTS ON FIFTH WHEEL ANGLES**

*THREADED BOLTS ON FIFTH WHEEL ANGLES*  
*THREADED BOLTS ON FIFTH WHEEL ANGLES*

**2003-A03-H01 JACOB ENG BRAKE OWNER INFO PACKET**

*JACOB ENG BRAKE OWNER INFO PACKET*  
 11390 ENG. BRAKE OP MANUAL 1

**2003-A03-P07 EATON/FULLER TRANS OPERATOR MANUAL**

*EATON/FULLER TRANS OPERATOR MANUAL*  
 TRDR0515 OP INSTR, 10-SPEED 1

**2003-A03-S19 HOLLAND FIFTH WHEEL OWNER S MANUAL**

*HOLLAND FIFTH WHEEL OWNER S MANUAL*  
 XL-FW10049UM-EN-US OWNER S MANUAL HOLLAND 1  
 FW

**2003-A03-T06 ALCOA WHEEL SERVICE & OPERATOR MANUAL**

*ALCOA WHEEL SERVICE & OPERATOR MANUAL*  
 GAXLTORG1 WHEEL SERVICE & OP 1  
 MANUAL

**2003-A03-U03 MICHELIN TIRE WARRANTY & OPER MANUAL**

*MICHELIN TIRE WARRANTY & OPER MANUAL*  
 MWE40021 TIRE WARRANTY & OP 1  
 MANUA

**2003-A03-Y15 NEWAY SUSPENSION MAINTENANCE MANUAL**

*NEWAY SUSPENSION MAINTENANCE MANUAL*  
 XL-PS10452MM-EN-US MAINT MANUAL, NEWAY ADZ 1  
 XL-AK405-01 DECAL, TIRE CLRANCE- 1  
 NEWAY  
 XL-PS10456DC-EN-US DECAL-TORQUE REQ ADZ 1  
 XL-WC112-04 WARRANTY CERTIFICATE 1

**2003-A05-A01 CAB CONFIGURATON -**

*CAB CONFIGURATON -*  
*ROBOTIC PAINT PROGRAM IDENTIFIER*  
 Y95-01-9R560507AL05 CAB - ROBOTIC PAINT P 1  
*CAB CONFIGURATION & FEATURES*

**2003-A05-B02 HOOD CONFIGURATON -**

*HOOD CONFIGURATON -*  
*ROBOTIC PAINT PROGRAM IDENTIFIER*  
 Y95-02-40033000 HOOD - ROBOTIC PAINT 1  
 PRG.  
*HOOD CONFIGURATION & FEATURES*

**2003-A05-F02 MISC. COMPONENTS #2 CONFIGURATION -***MISC. COMPONENTS #2 CONFIGURATION -**ROBOTIC PAINT PROGRAM IDENTIFIER*

Y95-08-062108004 MISC #2-ROBOTIC PAINT 1

*MISC. COMPONENTS #2 - CONTENT/FEATURES***2003-A07-Q02 PREMIER CARE DECAL***PREMIER CARE DECAL*

S53-1012 DECAL - PREMIER CARE 1

*INSTALL PREMIER CARE DECAL ON INSIDE**UPPER LH CORNER OF WINDSHIELD GLASS.***2003-A07-S02 DECAL-CLING W/QR CODE FOR TRNING VIDEO***DECAL-CLING W/QR CODE FOR TRNING VIDEO**SHOP NOTE: INSTALL S53-1382-600 ON**INSIDE OF WINDSHIELD NEAR TOP LH**CORNER, OUT OF PRIMARY VIEW OF DRIVER.*

S53-1382-600 DECAL-CLING W/ QR CODE 1

**2010-A01-A40 ENGINE HP @ 500***ENGINE HP @ 500**ENGINE @ 500 HP***2010-A01-B02 GOVERNED RPM - 1900***GOVERNED RPM - 1900**GOVERNED RPM - 1900***2010-A01-D08 ENGINE INSTALLED AT \*4 DEGREE\****ENGINE INSTALLED AT \*4 DEGREE\***ENGINE INSTALLED AT \*4 DEGREE\****2010-A02-B07 10" REAR AIR SUSP FRAME HEIGHT***10" REAR AIR SUSP FRAME HEIGHT**10" REAR AIR SUSP FRAME HEIGHT***2010-A03-A46 3.73 REAR AXLE RATIO***3.73 REAR AXLE RATIO**3.73 REAR AXLE RATIO***2010-A04-A07 SINGLE REAR AXLE SLANTED @ 4 DEG***SINGLE REAR AXLE SLANTED @ 4 DEG**SINGLE REAR AXLE SLANTED @ 4 DEG***2012-800-A04 2024 CUMMINS ENGINE - CARB X15***2024 CUMMINS ENGINE - CARB X15**X15 500V, GOV@2000 512@1700*

E8R45E2H401V830H15 PNG-CUMMINS ENGINE 1

*E8 ENGINE - CUMMINS***2180-810-A02 THREE GROUP 31 BATTERIES***THREE GROUP 31 BATTERIES*

P27-1284-111 BATTERY EAST PENN 3

PC7T31N

*PACCAR 700 CCA BATTERIES - THR POSTS***2180-810-D03 BATTERY TERMINAL NUTS***BATTERY TERMINAL NUTS*

K169-111 Battery Terminal Nut (3/8- 6

16)

**2205-800-A01 FRO16210C 10-SPEED TRANSMISSION**

**FRO16210C 10-SPEED TRANSMISSION**

T-A3YC2K5N02F720000 PNG-EATON/FULLER TRANS 1

**FRO16210C 10-SPEED TRANSMISSION**

T-A TRANS - EATON

**2205-800-C05 PS386 SYNTHETIC TRANSMISSION OIL**

PS386 SYNTHETIC TRANSMISSION OIL

PS386 SYNTHETIC TRANSMISSION OIL

PS386 SYNTHETIC TRANS. OIL 16

**2205-800-S01 SHIFT KNOB ASSY FOR FR(O), FA(O)**

SHIFT KNOB ASSY FOR FR(O), FA(O)

S2574 Shift Knob &amp; Valve 1

SHIFT KNOB ASSY FOR FR(O), FA(O)

**226P-805-EAC LH - FRONT DISC BRAKE ASSY - BENDIX**

LH - FRONT DISC BRAKE ASSY - BENDIX

G4-01201813000000L Air Disc Brake Assembly, LH 1

**226P-805-FAC RH - FRONT DISC BRAKE ASSY - BENDIX**

RH - FRONT DISC BRAKE ASSY - BENDIX

G4-01201805000000R Air Disc Brake Assembly, RH 1

**2260-805-X04 STEER AXLE FASTENERS**

STEER AXLE FASTENERS

W34-1161-060 Hex Bolt (M20 x 2.50 x 60mm) 12

W34-1162-020 Flat Washer (3/4") 12

B97-6008 INSTL - DISC BRAKES

**2260-810-C18 HUB/ROTOR ASSEMBLY**

HUB/ROTOR ASSEMBLY

CM10081101 Preset Front Hub &amp; Rotor Assembly, Aluminum 2

B97-6008 - INSTL-DISC BRAKES

B97-6030 INSTL-PRESET PLUS HUBS

**2260-810-F01 ABS SENSOR**

ABS SENSOR

K145016BX SENSOR- WHEEL SPEED, STR 2

K152407 SLEEVE- SENSOR, ABS 2

**2260-810-K01 STD VENTED HUBCAPS - 4.5" BC**

STD VENTED HUBCAPS - 4.5" BC

CR1612 Hub Cap, 6 Hole, 4-1/2" Bolt Circle, Black, Zytel 2

27-00671-004 Bolt &amp; Washer Assembly (5/16-18 X 1") 12

**2270-800-J06 WHEEL NUTS**

WHEEL NUTS

H20-6000 WHEEL NUT-TWO PIECE M22 20

**231P-800-A01 RS23-161 ROCKWELL SINGLE R/A**

RS23-161 ROCKWELL SINGLE R/A

C05-603405080400037 REAR AXLE - MERITOR 1

12.7MM HSG STD TRACK BSS 64.88

FF 54.50 (NOM 72.24)

W/O SUSP BRKT &amp; DOWEL PINS

SPL250 FWD INPUT YOKE

SINGLE REAR AXLE, NO I/A YOKE  
 FWD RR SING SPEED W/ CROSSLOCK  
 W/O IAD  
 NOT NMD AT STE T  
 3.73 RATIO

C05-6 AXLE- SPECIFICATIONS

**2310-800-C52 FE75W90 SYNTHETIC GEAR OIL**

FE75W90 SYNTHETIC GEAR OIL

>>> KW FACTORY FILL <<<

FE75W90 LUBE-BASF 7106 FE 75W90 24

FE75W90 SYNTHETIC GEAR OIL

**2310-800-D01 REAR AXLE ATTACHING HARDWARE**

REAR AXLE ATTACHING HARDWARE

W34-1169 WASHER - HARD 16

27-00791-010 Lock Nut (5/8") 16

03-01568 Axle Shaft Gasket 2

C93-1288 ASSY AXLE-SHAFT

**2310-800-F01 DOWELS F/ TAPERED R/A SHAFT HOLES**

DOWELS F/ TAPERED R/A SHAFT HOLES

1246V1166 Dowel 16

**2310-800-G19 FWD RR DRIVE AXLE LUBE QTY = 19 QUARTS**

FWD RR DRIVE AXLE LUBE QTY = 19 QUARTS

FWD RR DRIVE AXLE LUBE QTY = 19 QUARTS

**2310-800-J01 CROSSLOCK JUMPER**

CROSSLOCK JUMPER

16-10095-0150 HARNESS-JUMPER, NEUT SW 1

**234P-805-AAD LH FWD-REAR BRAKE ASSY**

LH FWD-REAR BRAKE ASSY

FORWARD OR SINGLE REAR AXLE

G3-789060G0000000B Rear Brake Assembly, ES-X 1  
 (16.5" x 7")

**234P-805-BAD RH FWD-REAR BRAKE ASSY**

RH FWD-REAR BRAKE ASSY

FORWARD OR SINGLE REAR AXLE

G3-789060G0000000A Rear Brake Assembly, ES-X 1  
 (16.5" x 7")

**2340-800-B68 CONMET PRESET PLUS HUB ASSY**

CONMET PRESET PLUS HUB ASSY

HUB - ABS

CM10081301 Preset Plus Rear Hub 2  
 Assembly, Aluminum

CM10033073 Oil Fill Plug 2

FIRST DRIVE AXLE

C97-6063 INSTL-PRESET PLUS HUBS

**2340-800-G07 WHEEL NUTS**

WHEEL NUTS

FIRST DRIVE AXLE

H20-6000 WHEEL NUT-TWO PIECE M22 20

**2340-800-J46 BENDIX AUTO SLACK ADJUSTERS - 6"**

BENDIX AUTO SLACK ADJUSTERS - 6"

**1ST DRIVE AXLE**

K097645	Slack Adjuster, Automatic	2
90347	Clevis Pin (1/2" x 1.25)	2
90043	Cotter Pin (1/2")	2
K102375	Anchor Bracket, Slack Adjuster	2
W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25)	2

**2340-800-P27 CAST BRAKE DRUM - CONMET, 123 LBS***CAST BRAKE DRUM - CONMET, 123 LBS***FIRST DRIVE AXLE**

CM10037819	DRUM- BRAKE, 16.5 X 7 HD	2
------------	--------------------------	---

**2340-800-S97 BENDIX 3030 LONG STROKE CHAMBERS***BENDIX 3030 LONG STROKE CHAMBERS***LEFT CHAMBER**

K193947	CHAMBER- BRAKE, T3030 LS	1
---------	--------------------------	---

**RIGHT CHAMBER**

K193946	Brake Chamber, Spring	1
---------	-----------------------	---

**2340-800-T05 BRAKE ASSEMBLY ORIENTATION***BRAKE ASSEMBLY ORIENTATION**SERVICE OR SERV/SPRG BRAKE CHAMBER**LOCATION W/ S-CAM BRAKES**FIRST DRIVE AXLE**SHOP NOTE:**LOCATE BRAKE CHAMBERS IN POSITION:**- FWD SIDE OF SINGLE RR AXLE OR**FIRST AXLE IN TANDEM/TRIDEM**ROTATE BRAKE ASSEMBLIES 0 DEG***2340-800-W25 CAMSHAFT BRACE***CAMSHAFT BRACE*

C85-1021-001	BRACE- CAMSHAFT TUBE	2
C16-1001	CLAMP - CAM TUBE	2
W34-1162-010	Washer (10MM)	4

*C97-1101-001 INSTL - CAMSHAFT SUPPORT***2340-800-X01 ATTACHING HARDWARE - BRAKES***ATTACHING HARDWARE - BRAKES**FIRST DRIVE AXLE*

W34-1160-050	Lock Nut w/ Nylon Insert (M16 x 1.75)	16
--------------	---------------------------------------	----

W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	16
--------------	------------------------------	----

W34-1169	WASHER - HARD	16
----------	---------------	----

**2375-811-A22 NEWAY ADZ SUSP FRAME KIT***NEWAY ADZ SUSP FRAME KIT*

33020088	Frame Kit	1
----------	-----------	---

*33020088 NEWAY ADZ126 FRAME KIT***2375-811-B18 LOWER CONTROL ARM KITS***LOWER CONTROL ARM KITS*

33002252	Lower Control Arm Kit, Single	1
----------	-------------------------------	---

*C93-1196 AXLE INSTL - NEWAY ADZ***2375-811-C19 AXLE BRACKETS AND WELDMENT**

**AXLE BRACKETS AND WELDMENT**

33001269 KIT- AXLE BRKT, ADZ RS23 1

**C93-1191-040 AXLE WELDMENT****2375-811-F03 FWD SUSPENSION C/M****FWD SUSPENSION C/M**

A24-1612-02211 Crossmember Assembly 1

**A24-1612-00000 C/M ASSY - ADZ****2375-811-H01 REAR SUSPENSION CROSSMEMBER****REAR SUSPENSION CROSSMEMBER**

A24-1586 CROSSMEMBER- REAR FRAME 1

K140-2433 Rear Gusset, LH 2

K140-2433R Rear Gusset, RH 2

W34-1162-016 Washer (16MM) 24

W34-1162-016 Washer (16MM) 12

W34-1160-050 Lock Nut w/ Nylon Insert (M16 x 1.75) 12

W20-1028-016 Lock Nut (M16 x 2.00 x 16mm) 12

**2375-811-K01 HEIGHT CONTROL VALVE BRACKET****HEIGHT CONTROL VALVE BRACKET****SHOP NOTE:****INSTALL HCV BRKTS ON LH SIDE OF THE AXLE, MTD ON THE INBRD END OF LOWER SHOCK BOLT.**

90026410 HCV Bracket 1

**C93-1196 AXLE INSTL - NEWAY ADZ****2375-811-M01 V-ROD SPACERS - FWD/CENTER REAR AXLE****V-ROD SPACERS - FWD/CENTER REAR AXLE**

K221-5086-3 SPACER-SUSPENSION 4

**SHOP NOTE: INSTALL SPACERS BETWEEN CROSSMEMBER AND V-ROD****2375-811-Q01 AXLE STOPS****AXLE STOPS**

33006091 Axle Stop Kit 1

**2375-811-R01 NEWAY ADZ SUSP INSTALLATION DRAWINGS****NEWAY ADZ SUSP INSTALLATION DRAWINGS****SHOP NOTE:****ORIENT PIVOT BOLTS (FRAME BRACKET TO SUSP BEAM) W/ HEAD OUTBOARD FOR MAX TIRE/CHAIN CLEARANCE****C97-1092 INSTL - NEWAY ADZ SINGLE****C97-1100 INSTL - NEWAY ADZ BRAKES****C93-1196 INSTL - AXLE, NEWAY ADZ****G95-1120S01 INSTL - ADZ LEVELING****G97-1262S01 INSTL - ADZ VLV BRKT, SING****G95-1125S01 ROUTING - ADZ BRAKES, SING****2375-811-S06 \* AIR SPRINGS****\* AIR SPRINGS**

90557394 AIRSPRING- ADZ 23K 2

**2375-811-T02 FRAME LAYOUT DRAWINGS**

FRAME LAYOUT DRAWINGS

A96-1400 LAYOUT - NEWAY ADZ126 10"

**2375-811-U01 FRAME BRACKET TC BOLTS**

FRAME BRACKET TC BOLTS

W34-1182-060	BOLT-TENSION CTRL M20X2.50X60MM	24
W34-1162-020	Flat Washer (3/4")	48
W20-1028-020	Lock Nut (M20 x 2.50)	24

**2379-820-A01 REAR SUSP RTG SUPPORTS**

REAR SUSP RTG SUPPORTS

W11-1033-103	BRACKET, Z STANOFF ASSY	12
--------------	-------------------------	----

**2383-800-B36 LEVELING VALVE**

LEVELING VALVE

G90-1113-084441121	Air Suspension Leveling Valve 1 Assembly w/ Dump	
--------------------	---	--

G95-1120S01 ROUTING - ADZ LEVELING

G94-1879S01 DIAG - AIR SUSPENSION

**2383-800-L10 CHASSIS SUSP PIPING - LINE #147**

CHASSIS SUSP PIPING - LINE #147

LINE #147 AIR DRYER AUX PORT(S) TO

SUSPENSION LEVELING VALVE.

G50-6022-06PURCTL	Purple Nylon Tubing (3/8")	1
G38-1021-0406	90° Elbow Fitting (#4 Male NPT to #6 J2494)	1

**2400-804-B85 FRONT MICHELIN TIRES \*QTY 2\***

FRONT MICHELIN TIRES \*QTY 2\*

MN275/80R225GXZE2 - SALES CODE 4017156

MN275/80R225GXZE2	TIRE - MICHELIN	2
-------------------	-----------------	---

**2420-804-B87 REAR MICHELIN TIRES \*QTY 4\***

REAR MICHELIN TIRES \*QTY 4\*

MN275/80R225GXDN2 - S/C 4217127

MN275/80R225GXDN2	TIRE MICHELIN	4
-------------------	---------------	---

REV PER MILE - 511

**2500-800-F3B FRONT ALCOA WHEELS \*QTY 2\***

FRONT ALCOA WHEELS \*QTY 2\*

ULA187 ALCOA WHEEL

ULA187	WHEEL- 22.5X8.25	2
--------	------------------	---

**2520-800-F93 REAR ALCOA WHEELS \*QTY 2\***

REAR ALCOA WHEELS \*QTY 2\*

ULA187 ALCOA WHEEL

ULA187	WHEEL- 22.5X8.25	4
--------	------------------	---

**2520-800-T01 VALVE, STEM EXTENSION**

VALVE, STEM EXTENSION

HE389	VALVE EXTENSION	2
-------	-----------------	---

**2600-A00-A05 FRAME RAIL - PUNCHED AT METALSA**

FRAME RAIL - PUNCHED AT METALSA

**2640-B00-A01 LH UNDER BATTERY BOX**

LH UNDER BATTERY BOX

*LH UNDER BATTERY BOX***2641-800-A03 PERFORATED 36" ALUM DECKPLATE***PERFORATED 36" ALUM DECKPLATE*

A22-1001-3	Deck Plate Cover Assembly	1
K041-750ZN	Huck Pin (3/16")	12
K097-2124	Deck Plate Cover	3
K197-4456	Deck Plate Reinforcement	2
K220-519	Huck Collar (3/16")	12

*A93-1037-3 COVER DECK PLATE INSTL**PERFORATED 36" ALUM DECKPLATE***2641-800-B61 DECKPLATE HOLDDOWNS***DECKPLATE HOLDDOWNS*

A03-1028-001	HOLDDOWN-DECK PLATE	6
27-00801-004	Flat Washer (1/4")	6
K041-802-30CA	Hex Bolt (M6 x 1.00 x 30mm)	6

*SHOP NOTE: ADD TWO (2) EXTRA WASHERS**P/N: K363-340-2-250 IF C/M GUSSET**INTERFERES W/ BOLT***2641-800-C01 DECKPLATE ASSY DRWG***DECKPLATE ASSY DRWG**R414-133 HOSETENNA INSTL & LOCATION***2641-800-E03 PERFORATED 36" ALUM DECKPLATE***PERFORATED 36" ALUM DECKPLATE**R001-7598 LAYOUT - DECKPLATE***2672-401-A02 B-25 BETTS HOLDERS - STD***B-25 BETTS HOLDERS - STD*

A25	Bracket - Mudflap, Straight	2
K179-21	Safety Pin	2

**2672-401-B01 BETTS B-1732 BRKTS - STD***BETTS B-1732 BRKTS - STD*

B1732	Mounting Bracket, Mud Flap	2
-------	----------------------------	---

**2672-401-N76 STRAIGHT MUDFLAP SHIELDS***STRAIGHT MUDFLAP SHIELDS*

A46-1133-2430103	Mudflap White w/ logo	2
------------------	-----------------------	---

**2672-401-Y01 COMMON MUDFLAP INSTL***COMMON MUDFLAP INSTL**A97-1082 L/O - MUDFLAP**A97-1082 L/O - MUDFLAP***2672-405-A01 MUDFLAP HARDWARE***MUDFLAP HARDWARE*

R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	8
27-01008-008	Lock Nut (M8 x 1.15-6H) Cadmium Plate	8

**2820-433-C01 ABS - SPEED SENSOR SLEEVE***ABS - SPEED SENSOR SLEEVE*

B13-1001	Speed Sensor Sleeve	2
----------	---------------------	---

**2820-438-D02 ABS SENSOR HOLDER***ABS SENSOR HOLDER*

C11-1073 ABS Sensor Block 2  
 \*\*\* FOR DRIVING AXLE(S) \*\*\*

### **2820-438-E15 ABS SENSOR WELDMENT**

ABS SENSOR WELDMENT

R030-1736-12 AXLE WELDMENT-ABS SENSOR

\*\*\* FOR DRIVING AXLE(S) \*\*\*

### **2820-438-V14 ABS SENSORS & CLIPS FOR F/A AND R/A**

ABS SENSORS & CLIPS FOR F/A AND R/A

BENDIX 6 ABS; 4S/4M

FRONT STEER AXLE SENSORS/CLIPS

COME INSTALLED W/ DISC BRAKES

HM3 MOUNT-H,5/8 2

REAR AXLE SENSOR/CLIPS

K144020BX SENSOR- WHEEL SPEED, 90 2

K152407 SLEEVE- SENSOR, ABS 2

HM3 MOUNT-H,5/8 2

P95-6955 ROUTING-WHEEL SPEED SENSOR

P95-6955 ROUTING-WHEEL SPEED SENSOR

R414-1222 ABS HARNESS ROUTING

SHOP NOTE: INSTL ABS SENSOR HARN PER

R414-1222, SHEET 3, DETAIL "A". LEAVE

APROX 1" OF SLACK IN THE HARN BETWEEN

THE SENSOR & THE FIRST TIE WRAP. DO

NOT OVER TIGHTEN THE TIE WRAP AND

CRUSH THE CONVOLUTE TUBING.

### **2820-443-B20 REAR SERVICE/SPRING BRAKE CHAMBER FTGS**

REAR SERVICE/SPRING BRAKE CHAMBER FTGS

G15-1000-04 Brake Chamber Spring Fitting 2  
 Kit

### **2820-443-M11 BASIC VALVE BRKTS**

BASIC VALVE BRKTS

A11-1879 BRACKET- R12 1

K041-721-100CA Bolt - Lock (3/8-16 X1") 2

W34-1162-010 Washer (10MM) 2

G97-1262S01 INSTL-ADZ VLV BRKT

### **2820-444-D13 DIFF VALVE BRKT - SINGLE REAR AXLE**

DIFF VALVE BRKT - SINGLE REAR AXLE

A11-1864-002 BRACKET- AIR FITTING 1

### **2820-444-H1A LEVELING VALVE - LINK STD**

LEVELING VALVE - LINK STD

G74-1001-3381 Height Control Valve Linkage 1  
 Kit (381mm)

### **2820-448-L1C RAM-ATR6 VALVE ASSY**

RAM-ATR6 VALVE ASSY

G90-1228-511 Rear Axle Module Valve 1  
 Assembly

### **2820-448-W01 JUMPER HOSE - SPRING BRAKES**

JUMPER HOSE - SPRING BRAKES

#48-1 - QR-1C OR SR-7 VALVE LH

DELIVERY TO LH SPRING BRAKE CHAMBER:

26-03424-022 Air Brake Hose Assy, SAE 1  
Flared, Crimped, (#6 x 22")

#48-2 - QR-1C OR SR-7 VALVE RH

DELIVERY TO RH SPRING BRAKE CHAMBER:

26-03424-022 Air Brake Hose Assy, SAE 1  
Flared, Crimped, (#6 x 22")

### **2820-448-X01 JUMPER HOSE - SERVICE BRAKES**

JUMPER HOSE - SERVICE BRAKES

#66-1 - RAM VALVE LH DELIVERY TO

LH SERVICE BRAKE CHAMBER:

26-03425-028 Air Brake Hose Assy, SAE 1  
Flared, Crimped, (#8 x 28")

#66-2 - RAM VALVE RH DELIVERY TO

RH SERVICE BRAKE CHAMBER:

26-03425-028 Air Brake Hose Assy, SAE 1  
Flared, Crimped, (#8 x 28")

### **2820-800-F03 JUMPER HOSE**

JUMPER HOSE

#191 ANCHOR ELBOW TO REAR AXLE

AIR PORT

K342-211-24 Hose - Air Brake (3/8" X 1  
610mm)

### **2907-800-B27 TAILLIGHT BRKT & INSTL**

TAILLIGHT BRKT & INSTL

A11-2437 BRACKET - TAIL LIGHT 1

A11-1822 BRACKET-TAILLAMP 2

### **2909-800-E01 REFLECTIVE MATERIAL & ALUM BACKPLATE**

REFLECTIVE MATERIAL & ALUM BACKPLATE

STRAIGHT MUDFLAP

18-04258L Conspicuity Bracket, Mudflap, 1  
LH

18-04258R Conspicuity Bracket, Mudflap, 1  
RH

### **2909-800-GAC NGP DAYCAB - REFLECTOR BOC**

NGP DAYCAB - REFLECTOR BOC

R59-1011 TAPE-RETROREFLECTIVE 4

R97-1485-006 INSTL-DAYCAB CONSPICUITY

### **2910-810-A58 BENDIX AD-HF (EP) AIR DRYER BRKT**

BENDIX AD-HF (EP) AIR DRYER BRKT

MTD INSIDE LH OR RH RAIL BOC

AIR DRYER BRKT

G11-2098 BRACKET - AIR DRYER 1

SHOP NOTE: USE RAISED HOLE PATTERN

WITH WIREBRAID HOSES IN FRAME

(S/C/ 9140015)

G97-6010-0000 INSTL/DRLG AIR DRYER

### **2910-810-B28 BENDIX AD-HF EP HTD AIR DRYER-K160648**

BENDIX AD-HF EP HTD AIR DRYER-K160648

SHOP NOTE: FOR COMPRESSOR DISCHARGE TO

AIR DRYER INLET LINE USE NOT LESS THAN

6 FEET OF TEFLON & WIREBRAID HOSE FOR ANY COMPRESSOR. MAX LENGTH OF LINE SHOULD NOT EXCEED 20 FT IN ALL CASES. COMPRESSOR DISCHARGE LINE SHOULD BE ROUTED SO THAT NO WATER TRAPS ARE FORMED. MOUNT AIR DRYER VERTICALLY W/ PURGE VALVE EXHAUST TOWARDS GROUND AWAY FROM FRAME AND OTHER COMPONENTS. INSTALL AS CLOSE TO SERVICE RESERVOIRS POSSIBLE.

K160648	Air Dryer Assembly, AD-HF	1
K041-756-100CA	Hex Bolt (3/8-16 X 1")	4
W34-1162-010	Washer (10MM)	4

### **2910-810-H10 REMOTE MOUNTED SCHRADER VALVE**

REMOTE MOUNTED SCHRADER VALVE

G50-6022-04S1LCTL	Silver Nylon Tubing (1/4")	1
D2224-2406	FTG-Q/C-ISO 7241 B -BLKHD	1
G38-1021-0204	90° Elbow Fitting (#2 Male NPT to #4 J2494)	1

SHOP NOTE: REMOTE SCHRADER VALVE MTD ON OUTSIDE OF LH RAIL.

INSTALL WITH WABCO AIR DRYER G97-6371-100 INSTL - REMOTE AIR LEAK

### **2910-810-J01 AIR DRYER WARNING LABEL**

AIR DRYER WARNING LABEL

G53-6036	Label-Air Dryer Warning	1
----------	-------------------------	---

SHOP NOTE:

PLACE WARNING LABEL ON OUTSIDE OF FRAME RAIL IN A VISIBLE LOCATION NEAR THE AIR DRYER MTG LOCATION.

### **3A0P-810-AAC FIFTH WHEEL TRIM**

FIFTH WHEEL TRIM

A74-11NANA00000000	TRIM - FIFTH WHEEL	1
--------------------	--------------------	---

### **3A00-D00-AFH FRONT CROSSMEMBER ASSY**

FRONT CROSSMEMBER ASSY

A24-1784-002	Radiator Support	1
	Crossmember Assembly	
R34-6002-12055RHLM	Exterior Threaded Hex Screw (M12 x 1.75 x 55mm)	4

SHOP NOTE:

INSTALL 2 BOLTS EACH SIDE, INTO THE HOOD MOUNT BRKT 1 IN THE TOP & 1 IN THE BOTTOM HOLE.

P97-1170 INSTL-BRACKET, HOOD

P11-1519	Bracket - Hood Harness	1
W34-1160-170	Hex Bolt (M16 x 2.00 x 170mm)	2

### **3A00-D00-BAJ FRONT CAB SUPT/OVERBELL/ISOLATORS**

FRONT CAB SUPT/OVERBELL/ISOLATORS

A85-6136	SUPPORT - FRONT CAB NGP	1
----------	-------------------------	---

A85-6136R	SUPPORT - FRONT CAB NGP	1
R62-6013	ISOLATOR-CAB FRONT MOUNT	2
W34-1160-100	Hex Bolt (M16 x 2.00 x 100mm)	4
A24-6330	CROSSMEMBER-NGP OVERBELL	1
W34-1182-110	BOLT-TENSION CTRL M20X2.50X110MM	4
W20-1028-020	Lock Nut (M20 x 2.50)	4
W34-1162-020	Flat Washer (3/4")	8
A22-6019	PLATE-NGP OVERBELL	1
A62-6079	Mount: Chassis Module, P	1
<i>HARDWARE TO ATTACH CAB TO CHASSIS</i>		
W34-1160-180	Hex Bolt (M16 x 2.00 x 180mm)	2
W34-1162-016	Washer (16MM)	2
<i>A97-6261 INSTL - CHASSIS MODULE, PRI</i>		
<i>R97-1624 INSTL - FRT CAB MOUNT BOLTS</i>		
<i>A97-6260 INSTL - 2.1M OVERBELL</i>		
<i>A97-6260 INSTL - 2.1M OVERBELL</i>		
<i>A97-6260 INSTL - 2.1M OVERBELL</i>		

### **3A00-D00-CDA REAR CAB CROSSMEMBER**

#### *REAR CAB CROSSMEMBER*

A24-6336-002	CROSSMEMBER	1
W34-1160-060	Hex Bolt (M16 x 2.00 x 60mm)	16
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	16
W34-1162-016	Washer (16MM)	32
A47-6077	GUSSET-EXTRUDED	2
A47-6077R	GUSSET-EXTRUDED	2
<i>A93-6026 ASSEMBLY, CROSSMEMBER</i>		

### **3A00-D10-AAC FRONT TOW HOOK**

#### *FRONT TOW HOOK*

A20-6014	Tow Hitch, Front	2
A16-6000	Cotter Pin, Stainless Steel	2
A65-6008	PIN-HITCH	2
A65-6007	PIN-FRONT TOW	2

### **3A00-D10-CAF FRAME RAIL RTG HDWR & WELD STUDS**

#### *FRAME RAIL RTG HDWR & WELD STUDS*

RT255S0H1R	Tie Strap, Releasable	19
S2CM25	Mount - Saddle Tie	4
12-0302-001	Low profile Mount	4
K206-98-25	Weld Stud	40
WSR01MHSUVH4	Tie Strap, Wide	30
A62-6084	Cable Tie Mount	32
<i>Y95-6003 ROUTING-RAIL, LH FRAME NGP</i>		
<i>A96-1464-000 LAYOUT - WELD STUD, NGP</i>		

### **3A00-D10-DAC ROCKSCREEN**

#### *ROCKSCREEN*

F46-1112 SCREEN - ROCK 1

*SHOP NOTE: MOUNT ROCKSCREEN AFTER*

*RADIATOR SET*

K041-808-30BK BOLT-HEX METRIC-SST 2

K363-340-2-250BK Flat Washer (1/4") 2

**3A00-D14-BAD AIR/ELEC RCS XMBR MTD SUPPORT BRKT**

*AIR/ELEC RCS XMBR MTD SUPPORT BRKT*

A11-6295 BRACKET-XMBR ELEC 2

*ROUTING*

A11-6340 BRACKET-UNDER XMBR AIR 1

*SP*

*A97-6220 INSTL-BOC RTG BRKT*

**3A00-D14-FAC AIR & ELEC ROUTING SUPT (STD)**

*AIR & ELEC ROUTING SUPT (STD)*

A11-6266 BRACKET-FRAME AIR/ELEC 1

*A97-6221 INSTL-PRIMARY RTG BRKTS*

**3A00-D14-JAD AIR/ELEC XMBR MTD SUPPORT BRKT**

*AIR/ELEC XMBR MTD SUPPORT BRKT*

A11-2122 BRACKET - ROUTING, XMBR 2

*A97-1303 INSTL-RTG BRKT,1-PIECE XMBR*

**3A00-D14-SAM FRAME MTD - VECU1 ROUTING BRACKETS**

*FRAME MTD - VECU1 ROUTING BRACKETS*

A11-6483 Cab Mount Routing Bracket 1

A11-6430 BRACKET-OVER-RAIL,RTG 1

*A96-6320 - DRILLING OVER RAIL ROUTING*

*A95-6050 RTG - REAR A-SECTION*

*A97-6260 INSTL - 2.1M OVERBELL*

*A97-6261 INSTL - CHASSIS MODULE, PRI*

**3A00-D14-TAE VECU1 MULTIPLEXED SOLENOID BANK BRKT**

*VECU1 MULTIPLEXED SOLENOID BANK BRKT*

A11-2235 BRACKET-MSB FRAME 1

*G97-1430-000 INSTL - MUX BANK BRACKET*

**3A00-D16-BAC A&E SUPPORT W/ BATT CABLES W/O DEF**

*A&E SUPPORT W/ BATT CABLES W/O DEF*

A11-2197-100 BRACKET-ROUTING FRAME 1

**3A00-D16-CAC AFTERTREATMENT HARNESS SUPPORT**

*AFTERTREATMENT HARNESS SUPPORT*

K299-420 Clip - Miscellaneous, Plated 1

**3A00-D30-AAE THREADED BOLTS THROUGHOUT FRAME - STD**

*THREADED BOLTS THROUGHOUT FRAME - STD*

*THREADED BOLTS THROUGHOUT FRAME*

**3A00-D30-BAC 10-5/8" X 5/16" STL RAIL - A70-1120M**

*10-5/8" X 5/16" STL RAIL - A70-1120M*

A70-1120M side rail - frame 1

A70-1120RM side rail - frame 1

*A70-1120M SIDERAIL - 10-5/8" STEEL*

*A70-1120M \* SIDERAIL*

**3A00-D32-ABN CTR BEARING BRACKET FOR 1ST CTR BRG**

*CTR BEARING BRACKET FOR 1ST CTR BRG*

12-02565-90230 PLATE-MIDSHIPCAST ALUM 1

12-02565-90230 CTR BRG BRKT

**3A00-D32-JAC ORIENTATION FOR 1ST CTR BRG BRKT**

ORIENTATION FOR 1ST CTR BRG BRKT

NO PARTS INCLUDED IN THIS B/M

USE WITH PART NUMBER 12-02565-00000

SHOP NOTE: MOUNT CTR BRG BRKT

FORWARD MOUNTED ON CROSSMEMBER

**3A00-802-EAH MISC FRAME SPACER - A80-1042-008**

MISC FRAME SPACER - A80-1042-008

A80-1042-008	Spacer (1-1/2")	2
--------------	-----------------	---

**3A30-802-AAD 1ST CENTERBEARING XMBR**

1ST CENTERBEARING XMBR

A24-6036-002	Cast Aluminum Crossmember 1 Assembly	
--------------	---	--

G52-6002	Nylon Insert, LH	2
----------	------------------	---

G52-6002R	Nylon Insert, RH	2
-----------	------------------	---

**3B00-D00-AAL FRONT SPRINGS**

FRONT SPRINGS

B81-6013-003	Front Spring Assembly, 13.2K2	
--------------	-------------------------------	--

**3B00-D00-BAE FRONT SPRING HARDWARE MOUNTING**

FRONT SPRING HARDWARE MOUNTING

B22-6000	Cap, Spring Pin	4
----------	-----------------	---

B65-1000	Locator Pin	2
----------	-------------	---

W20-1028-012	Lock Nut (M12 x 1.75)	8
--------------	-----------------------	---

W34-1162-012	Flat Washer	16
--------------	-------------	----

W34-1159-070	Hex Bolt (M12)	8
--------------	----------------	---

B20-1007	SHACKLE - LINK	4
----------	----------------	---

W20-1028-012	Lock Nut (M12 x 1.75)	8
--------------	-----------------------	---

W34-1162-012	Flat Washer	16
--------------	-------------	----

W34-1159-080	Hex Bolt (M12 x 1.75 x	8
--------------	------------------------	---

	80mm)	
--	-------	--

B65-1008	Spring Pin, Threaded (199mm)	2
----------	---------------------------------	---

B65-6008	PIN - THREADED SPRING	4
----------	-----------------------	---

K129-261-0290	Fitting - Grease (90 Deg)	6
---------------	---------------------------	---

B93-6005

SHOP NOTE: TORQUE TO 102 +/- 14 NM

(70 +/-10 LB-FT)

POINTED END OF LOCATOR PIN IS

INSERTED INTO DRIVE BRACKET UNTIL

FLAT END IS FLUSH OR 1.3MM BELOW

SURFACE OF DRIVE BRACKET.

SHOP NOTE: INSTALL SHACKLE LINK PINCH

BOLTS WITH HEAD TOWARDS REAR OF

TRUCK.

SHOP NOTE: INSTALL LONGER SPRING PIN

IN FRONT SPRING EYE. ORIENT ALL

ZERK FITTINGS INBOARD AND POINTED

DOWN.

**3B00-D00-CAC FRONT SHOCKS AND BRACKETS**

**FRONT SHOCKS AND BRACKETS**

A11-2134-001	BRKT-SHOCK ABSORBER	2
B71-6019	Shock - Front Suspension	2

**UPPER SHOCK MTD HARDWARE**

W34-1160-130	Hex Bolt (M16 x 2.00 x 130mm)	2
W34-1162-016	Washer (16MM)	4
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2

**LOWER SHOCK MTD HARDWARE**

W34-1160-150	Hex Bolt (M16 x 2.00 x 150mm)	2
W34-1162-016	Washer (16MM)	4
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2

**SHOP NOTE:**

**INSTALL LOWER SHOCK BOLT WITH HEAD OUTBOARD TO MAXIMIZE CLEARANCE TO STEER ARM B93-1037 ASSY - AXLE INSTL**

**3B00-D00-DFR FRONT AXLE U-BOLTS & SPACER BLOCKS****FRONT AXLE U-BOLTS & SPACER BLOCKS**

B80-6011-080	SPACER-BLOCK, FRONT AXLE	1
K241-570-270	U-Bolt (3/4-16 X 122.2mm X 270mm)	2
B80-6011-070	SPACER-BLOCK, FRONT AXLE	1
K241-570-257	U-Bolt (257mm)	2
B63-1004	SADDLE-FRONT SUSPENSION	2
B65-1010	Pin - Spacer, Front Axle	2
W34-1162-020	Flat Washer (3/4")	8
K169-147-126CA	Hex Nut, U-Bolt (3/4-16)	8

**SHOP NOTE: INSTALL SHOCK BOLT WITH HEAD FACING REAR (NUT FACING FORWARD) TO AVOID CONTACT WITH FUEL LINES FORWARD OF FRAME MOUNTED FUEL FILTER. B93-1037 ASSY - AXLE INSTL**

**3B00-D00-EAE ALUMINUM SHACKLE BRACKETS****ALUMINUM SHACKLE BRACKETS**

B11-1034-5	Shackle Bracket Assembly	2
------------	--------------------------	---

**3B00-D00-FAC SHACKLE BRKT & FRT XMBR MTG HARDWARE****SHACKLE BRKT & FRT XMBR MTG HARDWARE**

W34-1160-090	BOLT-FINISHED HEX, M16	7
W34-1160-120	BOLT-FINISHED HEX, M16	2
W34-1160-060	Hex Bolt (M16 x 2.00 x 60mm)	4
W34-1162-016	Washer (16MM)	26
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	13
W34-1160-060	Hex Bolt (M16 x 2.00 x 60mm)	4

W34-1160-080	Hex Bolt (M16 x 2.00 x 080mm)	2
W34-1162-016	Washer (16MM)	12
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	6

A97-6160 INSTALL-SHACKLE BRACKETS

A97-6094 INSTALL-FRONT XMBR ASSY

### **3B00-D00-GAC BRKT - WINDUP BUMPER ASSY**

BRKT - WINDUP BUMPER ASSY

B11-1164-002	Windup Bumper Bracket Assembly	2
--------------	--------------------------------	---

B97-1110 INSTLN - WINDUP BUMPER

### **3B00-D00-HAC FRONT AXLE CASTER SHIMS**

FRONT AXLE CASTER SHIMS

P25783-036	Shim - Caster (1 Deg)	2
------------	-----------------------	---

SHOP NOTE:

INSTALL THICK END OF SHIM TOWARD

FRONT OF TRUCK

### **3B1P-X03-AAC DANA D-1321LW 13.2K FRONT AXLE**

DANA D-1321LW 13.2K FRONT AXLE

D-1321LW, 71" KPI, 3.5" DROP

D-1321LW, 71" KPI, 3.5" DROP

B05-6041-0H6000000	Front Steer Axle Assembly	1
--------------------	---------------------------	---

W/ AIR DISC BRAKES

W/ AIR DISC BRAKES

W/ AIR DISC BRAKES

W/ AIR DISC BRAKES

B05-6041 DANA FRONT AXLE

### **3B10-X00-L01 PS386 SYNTHETIC LUBE F/FRONT STEER AXL**

PS386 SYNTHETIC LUBE F/FRONT STEER AXL

>>>>>>> KW FACTORY FILL <<<<<<<<<<<

PS386	SYNTHETIC TRANS. OIL	1
-------	----------------------	---

PS386 SYNTHETIC LUBE

PS386 SYNTHETIC LUBE

### **3B10-X00-R01 RIM, WHEEL COMPATIBILITY SELECTION**

RIM, WHEEL COMPATIBILITY SELECTION

TIE ROD ARMS @ 17.3 DEGREE

\*\*\*\*\*

USE WITH ANY OF THE FOLLOWING ALCOA

WHEEL CONFIGURATIONS:

FWMAL01: 19.5X 6.75" .83 THK 5.55" OS

FWMAL02: 19.5X 7.50" .82 THK 6.10" OS

FWMAL04: 22.5X12.25" 1.16 THK 5.84" OS

W/O CENTRIFUSE OR MERITOR X-30 DRUMS

FWMAL05: 22.5X12.25" 1.13"THK 5.81" OS

W/O CENTRIFUSE OR MERITOR X-30 DRUMS

FWMAL06: 22.5X12.25" 1.13 THK 3.88" OS

FWMAL11: 22.5X8.25" .84"THK 6.66" OS

FWMAL12: 22.5X8.25" .85"THK 6.60" OS

FWMALA1: 22.5X8.25" .89"THK 6.60" OS

FWMAL13: 22.5X8.25" .81"THK 6.60" OS  
 FWMALA3: 22.5X8.25" .75"THK 6.60" OS  
 FWMAL14: 22.5X8.25" .97"THK 6.66" OS  
 FWMAL15: 22.5X8.25" .87"THK 6.66" OS  
 FWMAL16: 22.5X8.25" .79"THK 6.60" OS  
 FWMAL17: 22.5X9" .90"THK 6.94" OS  
 FWMALB7: 22.5X9" .98"THK 6.94" OS  
 FWMALB8: 22.5X9" .95"THK 6.94" OS  
 FWMAL18: 22.5X9" .94"THK 4.06" OS  
 FWMAL24: 22.5X 9.00" .92"THK 4.04" OS  
 FWMAL21: 24.5X 8.25" .97 THK 6.60" OS  
 FWMAL2A: 24.5X 8.25" .99 THK 6.60" OS  
 FWMAL22: 24.5X 8.25" .87 THK 6.60" OS  
 FWMAL23: 24.5X 8.25" .83 THK, 6.60 OS  
 FWMAC15: 22.5X 9" .98 THK 4.10" OS

\*\*\*\*\*

USE WITH ANY OF THE FOLLOWING ACCURIDE  
 ALUMINUM WHEEL CONFIGURATIONS: S

FWMACA2: 22.5X 8.25" .88"THK 6.59" OS  
 FWMAC02: 22.5X 8.25" .89"THK 6.59" OS  
 FWMACA6: 22.5X 9" .98"THK 7.00" OS  
 FWMACA3: 24.5X 8.25" .88"THK 6.59" OS

USE WITH ANY OF THE FOLLOWING ACCURIDE  
 STEEL WHEEL CONFIGURATIONS:

FWMAC03: 19.5X 6.75" .44"THK 5.60" OS  
 FWMAC04: 19.5X 6.75" .38"THK 5.50" OS  
 FWMAC11: 22.5X 8.25" .44"THK 6.62" OS  
 FWMAC13: 22.5X 8.25" .47"THK 6.62" OS  
 FWMAC14: 22.5X 8.25" .44"THK 6.60" OS  
 FWMAC15: 22.5X 9" .50"THK 5.75" OS  
 FWMAC16: 22.5X 9" .63"THK 7.00" OS  
 FWMAC18: 24.5X 8.25" .44"THK 6.62" OS  
 FWMAC19: 24.5X 8.25" .47"THK 6.62" OS

USE WITH ANY OF THE FOLLOWING ACCURIDE  
 STEEL RIM CONFIGURATIONS:

FWMAC21: 22.5X12.25" 3.00" OS  
 FWMAC23: 22.5X 8.25" 4.75" OS

USE WITH ANY OF THE FOLLOWING SUNRISE  
 STEEL WHEEL CONFIGURATIONS:

FWMSR13: 22.5X 8.25" .47"THK 6.60" OS  
 FWMSR14: 22.5X 8.25" .43"THK 6.60" OS  
 FWMSR16: 22.5X 8.25" .63"THK 7.00" OS

**3D00-D00-CAC CLEARANCE REQUIREMENT**

**CLEARANCE REQUIREMENT**

SHOP NOTE: REMOVAL OF LIFT EYE ON REAR  
 OF ENGINE. STATION AE TO REMOVE REAR  
 ENGINE LIFT EYE TO MEET REQUIREMENTS

**3D00-D01-AAC FRONT ENGINE SUPPORTS***FRONT ENGINE SUPPORTS*

A24-1079-3	Front Engine Support	1
	Crossmember	
W34-1160-060	Hex Bolt (M16 x 2.00 x 60mm)	4
W34-1162-016	Washer (16MM)	8
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	4
05-16401	Front Mount, Rubber	2
A22-1016-001	Snubbing Plate	1
A22-1016-002	Snubbing Plate	1
W34-1161-120	Hex Bolt (M20 x 2.50 x 120mm)	2
W34-1162-020	Flat Washer (3/4")	4
W20-1028-020	Lock Nut (M20 x 2.50)	2

**3D00-D01-BAG FRONT ENGINE BRKTS***FRONT ENGINE BRKTS*

A11-2205	BRACKET-FRT ENG SPRT	1
A11-2205R	BRACKET-FRT ENG SPRT	1

*A97-1068-000 INSTL-FRONT ENG SUPPTS***3D00-D01-CAC FRONT ENGINE SPACERS***FRONT ENGINE SPACERS**SHOP NOTE: NO SHIMS REQUIRED***3D00-D01-DAM REAR ENG SUPTS - TRELLEBORG***REAR ENG SUPTS - TRELLEBORG*

U30027	MOUNT - ENGINE REAR	2
--------	---------------------	---

**3D00-D01-EAD REAR ENGINE LEGS - TRELLEBORG***REAR ENGINE LEGS - TRELLEBORG*

D62-1152	LEG - ENGINE REAR	1
D62-1152R	LEG - ENGINE REAR	1
K041-626-225	Hex Bolt, Lock (3/4-10 X 2-1/4")	8
W34-1162-020	Flat Washer (3/4")	8

*A97-1172-000 INSTL- REAR ENG SUPPRT***3D00-D01-FAD REAR ENGINE SUPT SPACERS - TRELLEBORG***REAR ENGINE SUPT SPACERS - TRELLEBORG**SHOP NOTES: NO SPACER (SHIMS) REQUIRED***3D00-D01-GAG REAR ENGINE MOUNTING BOLTS***REAR ENGINE MOUNTING BOLTS*

W34-1158	BOLT - FLANGE HEAD M16X2	8
----------	--------------------------	---

**3D00-D02-AAN AIR FILTER***AIR FILTER*

D37-1050-21000	Air Cleaner Assembly	1
D11-1508	BRACKET-DRIVER SIDE	1
D11-1503	Bracket, Air Cleaner	1
R34-6002-08045RHLK	Exterior Threaded Hex Screw (M8 x 1.25 x 45mm)	15
G11-1940	Standoff Bracket Assembly	1
D11-1473	Standoff Bracket, Engine	1

**3D00-D02-BBD AIR INTAKE PIPING & CLAMPS***AIR INTAKE PIPING & CLAMPS*

D66-6258-150040135C	PIPE-AIR INTAKE ALUMINUM-	1
D04-1025	ELBOW - 45 DEGREE REDUCER	1
D04-1024	ELBOW - 90 DEGREE REDUCER	1
CT800L	Hose Clamp, Constant Torque	1
	(8")	
CT650L	Clamp, Constant Torque (6-	1
	1/2")	
CT600L	Hose Clamp, Constant Torque	1
	(6")	
CT450L	Clamp, Constant Torque (4-	1
	1/2")	

*D97-1277-000 INSTL- AIR INTAKE***3D00-D03-CAZ COOLANT RETURN MANIFOLD***COOLANT RETURN MANIFOLD*

V58-1110-46100	Coolant Return Manifold	1
----------------	-------------------------	---

**3D00-D03-DCT CRM TUBE BRKT INSTL***CRM TUBE BRKT INSTL*

F58-1028-212	Coolant Return Manifold Assembly	1
933-350-10H	Clamp, Constant Torque	1
F11-1964	BRACKET - HOSE SUPPORT	1
K363-338-1-250	Flat Washer (1/4")	2
K041-802-50CA	Hex Bolt (M6 x 1.00 x 50mm)	1
K169-163-6CA	Hex Nut, Steel (M3)	1
LN422PA	CLAMP - STAUFF SINGLE	1
W16-1019-010	CLAMP - PINCH EAR	1

*F97-2203-000 INSTL-CRM-STACK***3D00-D20-ABD CAB HEATER SUPPLY & RETURN LINE***CAB HEATER SUPPLY & RETURN LINE*

F50-2056-300	Heater Hose Bypass Assembly	1
K342-525-425	HOSE - HEATER, SILICONE	1
16700033	Oetiker Clamp - 27.1MM	2
RT255R0H1R	Cable Tie	2
151-06500	Saddle Mount, Dual Swivel	1

*F95-1248-200 COOLANT INSTL DRW***3D00-D22-ADX MAIN TRANSMISSION COOLER HOSES***MAIN TRANSMISSION COOLER HOSES**TRANSMISSION COOLER SUPPLY & RETURN*

V50-1426	HOSE - SILICONE	1
V50-6008-20475	Heater Hose w/ Convolutated Tubing, Blue (3/4" x 475mm)	1
933-270-10H	Constant Tension Clamp (27mm)	2
933-270-10H	Constant Tension Clamp (27mm)	2

F95-1248-020 COOLANT INSTL DRW

### **3D00-D22-PAF TRANSMISSION MTD COOLANT RTG BRKTS**

TRANSMISSION MTD COOLANT RTG BRKTS

F11-1993 Coolant Lines Bracket 1  
Assembly

### **3D00-S01-HBN INITIAL FILL ENGINE OIL AND STICKER**

INITIAL FILL ENGINE OIL AND STICKER

DELO 400 MULTI GRADE FA4 OIL

R414-103 STICKER LOCATION

10W30ZF4FA4BULK DELO 400 ZFA 10W-30 FA-4 1

CVDEDEL0400 LABEL-DELO 400 FACTORY FI 1

### **3D10-801-GAF PACCAR FUEL FILTER RESTRICTION SENSOR**

PACCAR FUEL FILTER RESTRICTION SENSOR

Q21-1033 Sensor - Fuel Filter 1  
Restriction

SHOP NOTE: REMOVE PLUG AND INSTALL

SENSOR. REFERENCE K37-1027.

### **3D10-832-CAG PORT C FTGS - CAB HEATER**

PORT C FTGS - CAB HEATER

V38-1090 FTG-45DEG 3/4 HOSE BEAD 1

SHOP NOTE:

INSTALL FTGS IN ENG PORT C.

FTGS IN THIS PORT ARE FOR

CAB/SLEEPER HEATER.

V97-1190-0C01 INSTL-ENG FITTINGS, X15

### **3D10-832-GAC PORT G FTGS - 1ST DRIVETRAIN COOLER**

PORT G FTGS - 1ST DRIVETRAIN COOLER

D2119-9013 FITTING-M27 ISO 1/2 FNPT 1

D2006-3211 Elbow Fitting, 45 Deg (1/4" 1

Hose Bead x 1/2" Male NPTF)

V97-1175-0G01 INSTL-ENG FTGS ISX15

SHOP NOTE: INSTALL FTGS IN ENG PORT G.

FTGS IN THIS PORT FOR 1ST DT COOLER.

### **3D10-832-JAG PORT J FTGS - DEF SUPPLY**

PORT J FTGS - DEF SUPPLY

V38-1347 FTG- 90 DEG 1/2 HB TO M1 1

### **3D10-852-RAC COOLANT ACCESSORIES SYSTEM DIAGRAM**

COOLANT ACCESSORIES SYSTEM DIAGRAM

F94-1011 DIAG-COOLANT SYS ACCY

### **3E0P-810-AAC DANA DRIVELINE PNG - DRIVELINE #1**

DANA DRIVELINE PNG - DRIVELINE #1

E05D250HC0000F1105 PNG - DANA DRIVESHAFT 1

### **3E0P-810-BAC DANA DRIVELINE PNG - DRIVELINE #2**

DANA DRIVELINE PNG - DRIVELINE #2

E05D250HS0000F0895 PNG - DANA DRIVESHAFT 1

### **3E00-D00-AAC CLUTCH CONTROL - CAB**

CLUTCH CONTROL - CAB

E21-6006 Clutch Pedal Assembly 1

R34-6002-08035RH0K Exterior Threaded Hex Screw 6  
(M12 x 1.75 x 35mm)

S63-1001 Pedal Pad, KW Logo 1

*E97-6103 INSTALLATION CLUTCH PEDAL*

**3E00-D00-BAF CLUTCH CONTROL - TRANS**

*CLUTCH CONTROL - TRANS*

E17-1002 Hydraulic Clutch System 1  
Assembly

K041-806-25CA Hex Bolt (M8 x 1.25 x 25mm)4

27-00428-005 Flat Washer (5/16") 4

\*\*\*\*\*

*T40 TORX FASTENERS F/ MASTER CYLINDER  
TO CLUTCH PEDAL*

R34-6002-08035RT0M FASTENER-THREADED,EXT 2

\*\*\*\*\*

*E97-6102 SERVO INSTALLATION DRAWING*

*E97-6104 MASTER CYLINDER INSTALLATION*

*SHOP NOTE: SEE TRANS AIR BM FOR RTG*

**3E00-D00-CAC CLUTCH BRAKE**

*CLUTCH BRAKE*

127760 Clutch Brake 1

**3E00-D00-DAF PILOT BEARING**

*PILOT BEARING*

05-18810 BEARING XMSN PILOT 1

**3E00-D00-EAE THROTTLE PEDAL**

*THROTTLE PEDAL*

D21-6034-300 PEDAL-THROTTLE, ASSY 1

*PEDAL HARDWARE*

W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25)3

*D97-6262 INSTL - THROTTLE*

**3E00-D02-AAE TMSN SUPPORT - FRAME MTD BRKT**

*TMSN SUPPORT - FRAME MTD BRKT*

E80-1027 SPACER-TMSN SPRT 2

A85-1688 SUPPORT - TRANSMISSION 1

A85-1932 SUPPORT - TRANSMISSION 1

W34-1160-060 Hex Bolt (M16 x 2.00 x  
60mm) 4

W34-1162-016 Washer (16MM) 8

W20-1028-016 Lock Nut (M16 x 2.00 x  
16mm) 4

*INSTALL A85-1932 BKT ON RH RAIL*

*USING FOREMOST HOLE*

*E97-1119-000 -INST- TMSN SUPPORT SPR*

*E97-1119-000 -INST- TMSN SUPPORT SPR*

**3E00-D02-BAD TMSN SUPPORT - MAIN SPRINGS**

*TMSN SUPPORT - MAIN SPRINGS*

E81-1003-001 SPRING-TMSN SUPPORT 1

**3E00-D05-AAD SHIFT LEVER - PAINTED**

*SHIFT LEVER - PAINTED*

E55-6029 LEVER-TRANSMISSION SHIFT 1

**3E00-D07-AAE GREASE BANK FOR RELEASE BEARING**

*GREASE BANK FOR RELEASE BEARING*

**FRAME MTD**

FRAME MTD GREASE BANK BULKHEAD &amp; FTGS

INSTALL BRKT W/ BOLT HEADS INSIDE

FRAME RAIL

SEE JUMPSTART BOM FOR BRKT

27-00498-006	Star Washer, Internal Tooth (3/8")	1
--------------	---------------------------------------	---

W34-6031	Nut (1/8 x 27)	1
----------	----------------	---

DECAL

A53-1129	DECAL-REMOTE LUBE	1
----------	-------------------	---

RELEASE BEARING LUBE HOSE

V50-6027-01575	Lube Hose Assembly (#4 x 1575mm)	1
----------------	-------------------------------------	---

26-02114	Connector-90 Deg (1/8" FP X #4 Flare)	1
----------	--	---

K129-201-0208	Fitting - Long Pipe Nipple (1/8-27 NPTF X 2")	1
---------------	--	---

A96-1547 DRLG - BATT JUMPER TERMINALS

E95-1041 ROUTING - REMOTE LUBE

**3E00-810-AAG DANA DRIVELINE HARDWARE - D/L #1**

DANA DRIVELINE HARDWARE - D/L #1

250-70-39	BEARING-CAP,SPL250	2
-----------	--------------------	---

5007417	BOLT-SPECIAL, M12 x 25-10	4
---------	---------------------------	---

TORQUE BEARING CAPS TO 105-125 LBS FT

(142 - 169 N.M.)

**3E00-810-CAP DANA DRIVELINE HARDWARE - D/L #2**

DANA DRIVELINE HARDWARE - D/L #2

250-70-39	BEARING-CAP,SPL250	4
-----------	--------------------	---

5007417	BOLT-SPECIAL, M12 x 25-10	8
---------	---------------------------	---

TORQUE BEARING CAPS TO 105-125 LBS FT

(142 - 169 N.M.)

**3F0P-D00-AAG MAHLE COOLING MODULE**

MAHLE COOLING MODULE

F31-1266-1732231	Cooling Module Assembly	1
------------------	-------------------------	---

**3F00-D00-AAF RADIATOR PIPING & HOSES**

RADIATOR PIPING &amp; HOSES

F04-6006	Hose Elbow, 90°, Silicone (2- 1/2" OD)	1
----------	---	---

K363-338-6-312	Flat Washer (5/16")	4
----------------	---------------------	---

K041-803-25CA	Hex Bolt (M8 x 1.25 x 25mm)	2
---------------	-----------------------------	---

F11-1685	Water Pipe Bracket	1
----------	--------------------	---

426-2375	U-Bolt Clamp (5/16-18)	1
----------	------------------------	---

F50-6308	Radiator Hose, Upper, Blue (2-1/2"), Silicone	1
----------	--	---

F66-2480	PIPE- UPPER WATER	1
----------	-------------------	---

F66-2730	Lower Water Pipe Assembly	1
----------	---------------------------	---

F50-1548	Silicone Hose (2-1/2")	1
----------	------------------------	---

F50-6179-2400125	Radiator Hose, Silicone (2- 1/2" ID x 125mm)	1
------------------	---	---

F97-1786-007

F97-1786-007

**3F00-D00-BAF CHARGE AIR COOLER PIPING***CHARGE AIR COOLER PIPING*

D50-6039	Hump Hose	2
F16-6009-031B413RB0	CLAMP-HOSE, T-BOLT	8
D66-2146	PIPE - CHARGE AIR, COLD	1
D66-2147	PIPE - CHARGE AIR, HOT	1

*SHOP NOTE:**D50-1076 (BLUE) TO BE INSTALLED ON**DRIVER/COLD SIDE OF CAC ONLY**D50-1076 HOSE-HUMP, COLD SIDE CAC 2**F97-1797-002 INSTALLATION - PIPING***3F00-D00-CAC RADIATOR LOWER MOUNTING***RADIATOR LOWER MOUNTING*

W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2
F13-1016	BUSHING-RADIATOR RUBBER	2
F13-1016	BUSHING-RADIATOR RUBBER	2
27-00776	Shim (5/8")	2
27-00776	Shim (5/8")	2

*F97-1405 INSTALL - RAD ISOLATORS***3F00-D00-DAL DRAWDOWN & VENT HOSES***DRAWDOWN & VENT HOSES*

F50-1050-0750	Engine Fill Coolant Hose	1
F50-2051-0550	HOSE-SILICONE 5/8	1
D2119-9014	FITTING - STRAIGHTM27 X	1
26-01693	90° Connector (3/4 MP to #16 Clamp)	1
Y84-6000-017	Tie Strap, Dual Loop	1
K028-2492-4	Standoff Bracket	1
D16-6003-5412124	Cushioned Clamp (1-1/2")	1
933-240-10G	Band Clamp Constant Tension	1
DSWS4	Dual Swivel Saddle Spacer	1
22-01618-001	Cable Tie, Heavy Duty	2
RT255R0H1R	Cable Tie	1
V38-1302	FTNG-5/8 Bead to M12x1.5	1

*F95-1206 INSTALLATION - FILL VENT***3F00-D00-EAC RADIATOR TIE ROD INSTALLATION***RADIATOR TIE ROD INSTALLATION*

F65-1080-637094	ROD-TIE, RADIATOR	1
W34-1160-080	Hex Bolt (M16 x 2.00 x 080mm)	1
W34-1160-070	Hex Bolt (M16 x 2.00 x 070mm)	1
W34-1162-016	Washer (16MM)	4
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	2
F65-1080-637094	ROD-TIE, RADIATOR	1
W34-1160-070	Hex Bolt (M16 x 2.00 x 070mm)	2
W34-1162-016	Washer (16MM)	4
W20-1028-016		

Lock Nut (M16 x 2.00 x 2  
16mm)

*F97-1640-001 INSTALLATION-RAD TIE ROD*

### **3F00-D00-GAC COOLANT FILL LABEL**

*COOLANT FILL LABEL*

F53-1055-001 LABEL-RADIATOR FILL 1

*F97-1982 INSTL - COOLANT FILL LABEL*

### **3F00-D00-LAC WATER PIPE CLAMPS**

*WATER PIPE CLAMPS*

*UPPER WATER PIPE CLAMPS*

CT300LSS HOSE CLAMP ASSY 4  
CONSTANT

*LOWER WATER PIPE CLAMPS*

CT300LSS HOSE CLAMP ASSY 4  
CONSTANT

*TIGHTEN CT300LSS TO 90 IN-LB (10.2 NM)*

*TIGHTEN CT300LSS TO 90 IN-LB (10.2 NM)*

### **3F00-D01-AAH FAN CLUTCH**

*FAN CLUTCH*

F17-6017M22 Fan Drive Clutch Assembly 1

W34-1159-045 Hex Bolt (M12 x 1.75 x 45mm) 4

K363-371CA Flat Washer (M12) 4

G50-6022-04BLK120 Black Nylon Tubing (1/4" x 120") 1

K129-231-0204 90° Male Fitting, J844 (1/8-27 NPTF x 7/16-24 NF) 1

*REF 275MM FAN CENTER*

*F97-1833-004 INSTALLATION-FAN DRIVE*

### **3F00-D01-BBW FAN BELT**

*FAN BELT*

D84-1000-6122160 BELT - ENGINE 1

D84-1000-6061665 BELT - ENGINE 1

*F97-1722-010 INSTALLATION-FAN BELT*

### **3F00-D01-CAE FAN BLADE**

*FAN BLADE*

F51-6008M04 FAN-ENGINE COOLING 1

27-00437 Lock Nut (5/16-18) 6

27-00790-005 Flat Washer (5/16") 6

*F97-1731-0000 INSTL - FAN BLADE*

### **3F00-D01-DAV FAN RING SHROUD & BRACKETS**

*FAN RING SHROUD & BRACKETS*

F91-1026 Fan Ring Assembly 1

F85-1360 SUPPORT- FAN RING ISX UPP 1

F85-1361 SUPPORT-FAN RING 1

F85-1362 SUPPORT-FAN RING 1

27-00790-005 Flat Washer (5/16") 2

27-00944-030 Hex Bolt (M8 x 1.25 x 30mm) 2

27-01008-008 Lock Nut (M8 x 1.15-6H) 4

Cadmium Plate

W34-1163-020	BOLT-FINISHED HEX M10	7
W34-1162-010	Washer (10MM)	7

F97-1728-009 INSTALLATION-FAN RING

### **3F00-D01-EAC FAN DRIVE SOLENOID PIPING**

FAN DRIVE SOLENOID PIPING

G90-6047	Solenoid Valve, Normally Closed	1
----------	---------------------------------	---

R34-6002-08045RHLLK	Exterior Threaded Hex Screw (M8 x 1.25 x 45mm)	1
---------------------	--	---

P97-1201-003 INST-ELECTRIC HORN

G94-2088-100 DIAG-FAN CONTROL

### **3F00-D01-FAC BELT ROUTING LABEL - ISX**

BELT ROUTING LABEL - ISX

F53-1025-001	LABEL-BELT ROUTING	1
--------------	--------------------	---

F97-1659-0000 INSTL-BELT ROUTING LABEL

### **3F00-D20-AAW AIR CONDITIONER COMPRESSOR**

AIR CONDITIONER COMPRESSOR

F69-1040-1110	Variable A/C Compressor	1
---------------	-------------------------	---

R34-6002-08115RHYM	Fastener - Threaded, EXT	4
--------------------	--------------------------	---

D97-1299 INSTL - ISX15 COMPRESSOR

### **3F00-800-AAU EXTENDED LIFE COOLANT**

EXTENDED LIFE COOLANT

F72-1002-001	COOLANT-LLC, BULK	1
--------------	-------------------	---

DILUTE CONCENTRATED COOLANT 50/50 WITH WATER BEFORE USE

ELC ANTIFREEZE USED AS REQUIRED

F53-1066	LABEL-SHELL,EXTENDED LI	1
----------	-------------------------	---

SHOP NOTE: PARA ESTA UNIDAD COLOCAR

ETIQUETA F53-1066 EN IDIOMA INGLES.

SHOP NOTE: LOCATE PER F97-6186.

LOCATION PREFERENCE

1) FIREWALL MOUNTED SURGE TANK

2) TOP TANK OF MODINE RADIATOR

3) RH SIDE OF COOLING MODULE

F97-1659-0000 INST, BELT ROUTING LABEL

F97-6186 INST, COOLANT LABEL

### **3G0B-800-AAC MINIMUM AIR VOLUME REQUIREMENTS**

MINIMUM AIR VOLUME REQUIREMENTS

### **3G0P-D00-AAC INTERIOR AIR MANIFOLD LABEL**

INTERIOR AIR MANIFOLD LABEL

G53-6014-3BCTTTTTH	LABEL-MANIFOLD, INTERIOR, 1 PNG	1
--------------------	---------------------------------	---

### **3G0P-D00-BAC EXTERIOR AIR MANIFOLD LABEL**

EXTERIOR AIR MANIFOLD LABEL

G53-6015-7BCTTTTTC	LABEL-MANIFOLD,EXT,PNG	1
--------------------	------------------------	---

### **3G0P-D00-CAC BULKHEAD FITTINGS LABEL**

BULKHEAD FITTINGS LABEL

G53-6016-1TTTTTTTA	LABEL-BULKHDFITTINGS,PNG	1
--------------------	--------------------------	---

### **3G0P-D00-EAD MUX SOLENOID BANK 1 LABEL**

**MUX SOLENOID BANK 1 LABEL**

G5334H1G1B4F100000 LABEL-MUX SOLENOID BANK 1  
1

**3G0P-D02-AAD BRAKE VALVE ASSY****BRAKE VALVE ASSY**

G90-1174-101111210 Dual Brake Valve Assembly 1

**3G0P-D02-BAG DASH AIR HARNESS****DASH AIR HARNESS**

G92-1159-130000140 HARNESS-TUBING, DASH 1

G95-1228 RTG - DASH AIR PIPING

G94-2047S00 DIAG - CAB AIR PIPING

G94-2048S01/S02 DIAG-CAB PPG HAND VLV

**3G0P-D02-EAC AIR ACCESSORY HARNESS****AIR ACCESSORY HARNESS**

G92-6074-100000000 HARNESS-ACCESSORY, DASH 1

**3G0P-D08-AAD TRAILER CONNECTION BRACKET****TRAILER CONNECTION BRACKET**

G11-6245-4380500G0 Pogo Stick & Trailer  
Connection Bracket Assembly 1

08-03406 Quick Release Valve 1

22-00923 Retaining Clip 2

27-00801-004 Flat Washer (1/4") 9

8520 Gladhand Holder 1

G11-1319 Bracket, Dummy Gladhand 1

G38-1022-0806 45° Elbow Fitting (#8 Male  
NPT to #6 J2494) 1

G38-1022-0808 45° Fitting (#8 Male NPT to  
#8 J2494) 1

K041-808-30 Hex Bolt (M6 x 1.00 x 30mm)2

K041-808-35 Hex Bolt (M6 x 1.00 x 35mm)1

K041-808-50 Hex Bolt (M6 x 1.00 x 50mm)1

K129-160-08 Anchor Coupling Fitting (1/2-  
14 NPTF x 1-1/8-14 UNF) 2

K129-194-08 Square Pipe Plug (1/2-14  
NPTF) 2

K169-154-6 Self Locking Hex Nut (M6 x  
1.00) 4

K371-119CP Hosetenna, Polished Chrome 1

W20-6011-10TDYOZ Flanged Lock Nut (M10 x  
1.50) 2

W34-1162-010 Washer (10MM) 2

W34-1163-070 Hex Bolt (M10 x 1.50 x  
70mm) 2

**3G0P-870-EAL FIRST AIR TANK MODULE (4416 CU IN) MTD****FIRST AIR TANK MODULE (4416 CU IN) MTD****BENEATH BTRY/TOOL BOX LH UNDER CAB****SECONDARY TK (1ST FRT SERV) INBOARD &****PRIMARY TK (1ST REAR SERVICE) OUTBOARD**

G86-11586112521311 TANK-ATM ASSY FS/RS UND 1  
N

*FITTINGS LOCATED TO REAR SIDE OF BOX*

*G96-1013 L/O - VOC ATM PRIORITIES*

### **3G00-D00-AAM COMPRESSOR FITTING KIT**

*COMPRESSOR FITTING KIT*

V38-1356 FTG-90 DEG #4 SAE FLARE T 1

*G97-1294 INSTL - AIR CPRSR DISCH LINE*

### **3G00-D00-BAT PIPING - AIR COMPR DISCHARGE HARDLINES**

*PIPING - AIR COMPR DISCHARGE HARDLINES*

G11-1611 BRACKET - CPRSR DISCH LIN 1

G11-1570 BRACKET - CPRSR 1

DISCHARGE

K041-802-20CA Hex Bolt (M6 x 1.00 x 20mm) 2

K041-806-20CA Hex Bolt (M8 x 1.25 x 20mm) 1

K169-163-6CA Hex Nut, Steel (M3) 1

K363-338-2-250 Flat Washer (1/4") 3

G88-1067 Air Compressor Discharge 1

Tube Assembly

D16-6003-5415116 CLAMP - CUSHIONED 2

D2115-4267 FTG-JIC UNION 1

W11-1019 Bracket - Standoff Assy 1

Y84-6000-013 Tie Strap 4

*G97-1294-000 INSTL - AIR COMPR DISCH*

*G97-1389-000 INSTL - RTG STANDOFFS*

### **3G00-D00-CAE PIPING - AIR COMPR DISCHARGE SOFTLINES**

*PIPING - AIR COMPR DISCHARGE SOFTLINES*

V50-1119-16011-000 Extreme Temp Hose 1

Assembly (#16)

*G97-1294 INSTL - AIR CPRSR DISCH LINE*

*G97-1317 INSTL - AIR CPRSR*

### **3G00-D00-EAC GOVERNOR LINE**

*GOVERNOR LINE*

*SHOP NOTE: FLARE TO PTC ADAPTER*

*INCLUDED IN HOSE ASSY*

G50-1064-04-016 Air Brake Hose Assembly, 1

Wirebraid (#4 x 16")

G50-6022-04DKPCTL TUBING- NYLON AIR BRAKE 1

Y84-6000-005 Tie Strap 1

*G95-1115-001 RTG - GOVERNOR HOSE*

*G94-1932S01 - DIAG-AIR DRYER PIPING*

### **3G00-D02-AAC AIR LINE IDENTIFICATION CHART**

*AIR LINE IDENTIFICATION CHART*

*BM CONTAINS NO PARTS*

*G94-2002 CHART-LINE IDENTIFICATION*

### **3G00-D04-AAD FIREWALL MANIFOLD**

*FIREWALL MANIFOLD*

G58-1082 MANIFOLD-CAB 1

G38-6011 FITTING-#8 PTC EXHAUST 1

D2030-9106 Retaining Ring, Steel, #6 2

2-014 O-Ring (1/2 X 5/8) 2

D2030-9103 FITTING - STRAIGHT 3/8 PT 1

*G97-6282 INSTL - EXHAUST VLV - FTG***3G00-D04-BAE MANIFOLD PLUGS & FITTINGS 1/4"***MANIFOLD PLUGS & FITTINGS 1/4"*

G38-1045-0004	Plug Fitting, Composite (1/4")	10
K183-134	Rubber Plug	7

**3G00-D04-GAC MANIFOLD PLUGS & FITTINGS PORTS A & K***MANIFOLD PLUGS & FITTINGS PORTS A & K*

G38-1045-0004	Plug Fitting, Composite (1/4")	4
---------------	-----------------------------------	---

**3G00-D04-HAD PLUGS & FTGS - HAND VALVES***PLUGS & FTGS - HAND VALVES**SHOP NOTE: PLUGS FOR INTERIOR MANIFOLD**PORTS L & M*

G38-1045-0006	Plug Fitting, Composite (3/8")	1
---------------	-----------------------------------	---

*SHOP NOTE: PLUGS FOR BULKHEAD**PORTS J & K*

G67-1000	Rubber Plug	2
----------	-------------	---

**3G00-D06-BAC DASH PARK BRAKE VALVE***DASH PARK BRAKE VALVE**W/ TRLR CONNECTIONS*

G90-6036	Parking Brake Control Valve, MV-3	1
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	4

**3G00-D06-CAG MANIFOLD AIR HARNESS***MANIFOLD AIR HARNESS*

G92-6077-111	HARNESS-MANIFOLD	1
--------------	------------------	---

**3G00-D06-DAK TP-5 VALVE***TP-5 VALVE*

G90-6096-062	TP-5 Valve Assembly	1
R34-6002-08070RH0M	FASTENER-THREADED,EXT	2
G50-6068	HOSE-TP5, PRIMARY	1

**3G00-D06-EAC AIR SEAT PIPING***AIR SEAT PIPING*

G50-6022-04BLKCTL	Black Nylon Tubing (1/4")	2
G38-1085-0404	Straight Union Fitting (#4 J2494 to #4 J2494)	1
G38-1036-0404	90° Elbow Stem Fitting (#4 to #4 J2494)	1
G90-6083	Pressure Protection Valve	1

*G97-1358 INSTL-AIR SEAT PIPING 2.1M***3G00-D06-HAC DASH PRESSURE SWITCHES & SENSORS***DASH PRESSURE SWITCHES & SENSORS*

6CP3-9	SENSOR-AIRPRESS 0-150 PSI	2
6CP3-10	SENSOR-AIRPRESS 0-80 PSI	1

**3G00-D06-LAJ UNDER CAB SOLENOID AIR SUPPLY***UNDER CAB SOLENOID AIR SUPPLY*

**LINE #1114 - MUX SOLENOID BANK SUPPLY**

ITEM 53

G50-6022-04GRNCTL Green Nylon Tubing (1/4") 1

SHOP NOTE: AIR DRYER TO MUX SOLENOID BANK

G94-1931, DIAGRAM-ELECTRIC OVER AIR

**3G00-D06-RAC EOA SOLENOID PLUGS (1)**

EOA SOLENOID PLUGS (1)

G38-1045-0004 Plug Fitting, Composite 1  
(1/4")

SHOP NOTE: INSTALL PLUG IN MSB PORT #3639.

**3G00-D06-TAE CAB PIPING DIAGRAMS**

CAB PIPING DIAGRAMS

G94-2047S02 DIAG-CAB PIPING 2.1M

G94-2047S02 DIAG-CAB PIPING 2.1M

G94-2047S02 DIAG-CAB PIPING 2.1M

G94-2047S02 DIAG-CAB PIPING 2.1M

G94-2047S02 DIAG-CAB PIPING 2.1M

**3G00-D07-CAD DASH MTD COMPACT VALVE**

DASH MTD COMPACT VALVE

G90-1260-011 COMPACT TRLR BRKE VLVE 1

**3G00-D07-EAF MUX - SOLENOID BANK (MSB) 1**

MUX - SOLENOID BANK (MSB) 1

G90-1266-141 Solenoid Valve, Bank 1 1

P16-1006-100 Fir Tree Clip 2

G97-1410-000 ISTL - MUX SOLENOID BANK

**3G00-D08-FAC CLAMPED HOSETENNA AT STANDARD LOCATION**

CLAMPED HOSETENNA AT STANDARD LOCATION

CLAMPED HOSETENNA AT STANDARD LOCATION

\* LOCATE CENTER MOUNT &amp; CLAMP-ON TYPE

HOSETENNA MIN OF 8" FROM BOC/BOS OR

INBOARD ROUTED EXHAUST

\* LOCATE OUTBOARD MTD HOSETENNA MIN OF

8" FROM BOC/BOS OR EXHAUST POST

SHOP NOTE: ADD EDGE PROTECTION AS REQD

BETWEEN TRLR CABLE AND BRKT.

**3G00-D08-GBK TRAILER AIR LINES - 12 FT SPIRAL WRAPD**

TRAILER AIR LINES - 12 FT SPIRAL WRAPD

D9001-7203-1010012 HARNESS - TRAILER ASSY 1

**3G00-D08-MAD BOC TRAILER CONNECTION PIPING**

BOC TRAILER CONNECTION PIPING

COLOR CODED NYLON PIPING

RED- TP-5 TRLR EMERGENCY DEL PORT

TO TRACTOR KIT EMERGENCY SUPPLY PORT

SHOP NOTE:

LINE ID #39 (NGP #1702)

G50-6022-06REDCTL Red Nylon Tubing (3/8") 1

BLUE- TP-5 TRLR SERVICE DEL PORT

TO TRACTOR KIT SERVICE SUPPLY PORT

**SHOP NOTE:****LINE ID #40 (NGP #1703)**

G50-6022-08BLUCTL Blue Nylon Tubing (1/2") 1

G11-6245 - INSTL - HOSETENNA

**3G00-D14-AAT FRONT BRAKE MODULE**

FRONT BRAKE MODULE

G90-6164-005 Front Axle Module Valve 1  
Assembly

K363-371CA Flat Washer (M12) 2

W20-1028-012 Lock Nut (M12 x 1.75) 2

G95-1207 ROUTING-FRONT BRAKE

G94-1948S02 DIAGRAM-FRONT BRAKE

**3G00-D14-BAQ FRONT BRAKE CHAMBER PIPING**

FRONT BRAKE CHAMBER PIPING

LINE #60 (#2001 NGP) LH PRESSURE

MODULATOR TO LH FRAM BULKHEAD

26-03425-051 Air Brake Hose Assembly, 1  
Crimped (#8 x 51")

K344-813-7 Convoluted Tubing 4

LINE #62 (#2001 NGP) LH FRAME BULKHEAD

TO LH BRAKE CHAMBER

26-03425-021 Air Brake Hose Assy, SAE 1  
Flared, Crimped, (#8 x 21")

LINE #61 (#2002 NGP) RH PRESSURE

MODULATOR TO RH FRAME BULKHEAD

26-03425-051 Air Brake Hose Assembly, 1  
Crimped (#8 x 51")

K344-813-7 Convoluted Tubing 4

LINE #62 (#2002 NGP) RH FRAME BULKHEAD

TO RH BRAKE CHAMBER

26-03425-021 Air Brake Hose Assy, SAE 1  
Flared, Crimped, (#8 x 21")26-02911 90° Bulkhead Fitting (#8 2  
Flare x #8 Flare)

27-00428-012 Flat Washer (3/4") 2

27-00498-012 Star Washer, Internal Tooth 2  
(3/4")

27-00710-012 Hex Jam Nut (5/8-18 x 3/4") 2

K129-188-0608 45° Male Elbow Fitting (3/8- 2  
18 NPTF x 3/4-16 NF)

G95-1207 ROUTING-FRONT BRAKE

G94-1948S01 DIAGRAM-FRONT BRAKE

A97-6085 DRILLING-COMMON CHASSIS

G97-1405 INSTL-FRT BRAKE CHAMBER FITTG

**3G00-D14-CAL FRONT BRAKE MODULE PIPING**

FRONT BRAKE MODULE PIPING

LINE #11 (#1206 NGP) FRONT SERVICE

TANK TO FRONT RELAY SUPPLY PORT

G50-6022-10GRNCTL Green Nylon Tubing (5/8") 1

LINE #14 (#1401 NGP) FOOT VALVE TO

FRONT RELAY PILOT PORT

G50-6022-06GRN115 HOSE - NYLON 3/8" GREEN 1  
 LINE #36 (#2007 NGP) FRONT RELAY TO  
 TRAILER MODULATOR VALVE  
 A62-6084 Cable Tie Mount 2  
 G50-6022-06BLU115 HOSE - NYLON 3/8" BLUE 1  
 R34-6002-06025RF0Z Exterior Threaded Hex Screw 2  
 (M6 x 1.00 x 25mm)

G95-1207 ROUTING-FRONT BRAKE  
 G94-1948S02 DIAGRAM-FRONT BRAKE  
 G94-1948S02 DIAGRAM-FRONT BRAKE  
 G95-1160 ROUTING-FRONT WALL

### **3G00-810-HAD AD-HF AIR DRYER FITTING KIT**

AD-HF AIR DRYER FITTING KIT

G37-1032-20123311 Air Dryer Fitting Kit, AD-HF 1  
 G38-1023-0404 Straight Fitting, Brass (#4 1  
 Male NPT to #4 J2494)

### **3G00-810-JDM AD-HF AIR DRYER SUPPLY FITTING KIT**

AD-HF AIR DRYER SUPPLY FITTING KIT

G37-1031-006 Air Dryer Fitting Kit, AD-HF 1

### **3G00-810-KDC AIR TANK PIPING**

AIR TANK PIPING

LINE #10, ITEM 73; AIR DRYER SECONDARY  
 SUPPLY PORT TO SECONDARY AIR TANK.

G50-6022-08GRNCTL Green Nylon Tubing (1/2") 1

LINE #20, ITEM 76; AIR DRYER PRIMARY  
 SUPPLY PORT TO PRIMARY AIR TANK.

G50-6022-080RNCTL Orange Nylon Tubing (1/2") 1

LINE #13, ITEM 83; SECONDARY AIR TANK  
 TO LOWER DUAL BRAKE SUPPLY.

G50-6022-10GRNCTL Green Nylon Tubing (5/8") 1

LINE #23, ITEM 96; PRIMARY AIR TANK  
 TO UPPER DUAL BRAKE SUPPLY.

G50-6022-120RNCTL Orange Nylon Tubing (3/4") 1

LINE #11, ITEM 83; SECONDARY AIR TANK  
 TO FRONT AXLE RELAY VALVE SUPPLY.

G50-6022-10GRNCTL Green Nylon Tubing (5/8") 1

LINE #21, ITEM 86; PRIMARY AIR TANK  
 TO REAR AXLE RELAY VALVE SUPPLY.

G50-6022-100RNCTL Orange Nylon Tubing (5/8") 1

G94-1880S01 TRACTOR/TRUCK AIR TANK PPG

### **3G02-802-KAG CROSSLOCK WARNING PLATE**

CROSSLOCK WARNING PLATE

WARNING PLATE INSTLD ON LH INSIDE  
 SUNVISOR

TP9579ALBL Plate - Crosslock Warning 1

R414-103 PLATE - ID DECAL LOCATION

### **3G02-802-MAC WHL DIFF LOCK/X-LOCK ACTUATION PIPING**

WHL DIFF LOCK/X-LOCK ACTUATION PIPING

ONE CNTRL FOR SINGLE REAR AXLE - NYLON  
 LN #93 (#3306) FROM RCJB \*OR\* EOA BANK

**TO REAR AXLE BULKHEAD****ITEM 5A**

G50-6022-04TANCTL TUBING- NYLON AIR BRAKE 1

*ITEM 1 BULKHEAD IS PART OF SEPARATE BM**LN #191 (#3309) JUMPER FROM BULKHEAD**TO X-LOCK PORT OF REAR AXLE IS PART OF**SEPARATE BM***ITEM 3**K129-388-04 90° Street Elbow Fitting (1/4-1  
18 NPTF)**ITEM 2**K129-163 Hose Fitting (1/4-18 x 3/4- 1  
20)*G94-2052S01 WHL DIFF/X-LOCK ACTUATION***3G02-830-AAC NEWAY ADZ - REAR BRAKE PIPING-NYLON***NEWAY ADZ - REAR BRAKE PIPING-NYLON**LINE #21 - REAR SERVICE TANK TO REAR**AXLE MODULE (RAM) VALVE SUPPLY PORT.***ITEM 86**G50-6022-100RNCTL Orange Nylon Tubing (5/8") 1  
*LINE #24-1 FROM REAR CAB JCT BLOCK TO**RAM PORT C***ITEM 66**G50-6022-060RNCTL Orange Nylon Tubing (3/8") 1  
*LINE #41 - PARKING CONTROL VALVE TO**QR-1C VALVE PARK BRK CONTROL PORT.***ITEM 65**G50-6022-06YELCTL Yellow Nylon Tubing (3/8") 1  
*LINE #68 - RAM VALVE RELAY DELIVERY**PORT TO QR-1C VALVE BALANCE PORT.***ITEM 66**G50-6022-060RNCTL Orange Nylon Tubing (3/8") 1  
*SHOP NOTE: TIES USED TO SECURE HOSES**TO MEET CMS 0258.*

QT16-074-002C0N STRAP-TIE, TYTON RUBBER L 4

*SHOP NOTE: W/ ATC & ABS, SEE FLAG**NOTE #7 ON G94-1561S07 FOR ATR-6/RAM**VALVE PIPING (REFERENCE).**SHOP NOTE: W/ ABS & W/O ATC SEE FLAG**NOTE #8 ON G94-1561S07 FOR RAMVALVE**PIPING (REFERENCE).**SHOP NOTE: W/O ATC & W/O ABS, SEE FLAG**NOTE #9 ON G94-1561S07 FOR R-12 VALVE**PIPING (REFERENCE).**G94-1561S07 DIAG-REAR BRAKE SINGLE**G95-1125S01 RTG-BRKS NEWAY ADZ SNINGLE***3G02-840-ABX QR-1C VALVE - SPRING BRAKE VALVE ASSY***QR-1C VALVE - SPRING BRAKE VALVE ASSY*08-03361-025 Quick Release Valve 1  
Assembly**3G02-848-KAD REAR R/A XLOCK OR 2 SPEED ANCHOR**

**REAR R/A XLOCK OR 2 SPEED ANCHOR****BLOCK - RH AXLE PORT**

G38-1023-0404	Straight Fitting, Brass (#4 Male NPT to #4 J2494)	1
V04-6010	Fitting Elbow Anchor (1/4" NPTF)	1

**3G02-860-KAW AIR SPRING PRESSURE GAUGE PIPING****AIR SPRING PRESSURE GAUGE PIPING****SINGLE GAUGE****LINE #730 (#3404) FIREWALL JUNCTION****BLOCK TO LH FORWARD MOST AIR BAG****ITEM 50**

G50-6022-04BLKCTL	Black Nylon Tubing (1/4")	1
G38-1023-0404	Straight Fitting, Brass (#4 Male NPT to #4 J2494)	1
K129-292-04	Fitting, Run Tee (1/4-18 NPTF), Brass	1

**G94-1810S01 DIAG - AIRSUSP GAUGE PPG****3G02-860-PAK ESP SUSPENSION SENSOR TEE FTG & SENSOR****ESP SUSPENSION SENSOR TEE FTG & SENSOR****TEE FITTING FOR SUSP PRESSURE GAUGE****LINE AND SENSOR AT FIREWALL**

G38-6018-040406	FITTING-UNION TEE, J2494	1
G50-6022-04BLKCTL	Black Nylon Tubing (1/4")	1
6CP3-17	PRESSURE-TRANSDUCER	1

**SHOP NOTE:**

INSTALL TEE FITTING ON THE END OF LINE #730 (#3404) OR #731 (#3405) AT THE FIREWALL.

CONTINUE LINE #730 OR #731 TO THE CAB MANIFOLD FROM ONE SIDE OF THE TEE AND INSTALL PRESSURE SENSOR IN THE OTHER SIDE.

USE LINE #730 WHEN DUAL LEVELING VALVE AND SINGLE GAUGE PRESSURE ARE IN THE CHASSIS.

USE LINE #731 WHEN SNGL LEVELING VALVE AND SINGLE GAUGE PRESSURE ARE IN THE CHASSIS.

**3G02-860-QAC AIR SUSPENSION - CHASSIS PIPING****AIR SUSPENSION - CHASSIS PIPING****NYLON TUBING W/ SINGLE LEVELING VALVE****LINE 110 - FROM SUSPENSION DUMP****CONTROL TO LEVELING VALVE**

G50-6022-04PURCTL	Purple Nylon Tubing (1/4")	1
<b>LINE 150 - LEVELING VALVE TO AIR BAGS</b>		
G50-6022-06BLKCTL	Black Nylon Tubing (3/8")	2
G38-1021-0406	90° Elbow Fitting (#4 Male NPT to #6 J2494)	2

G94-1236-1 DIAG - AIR SUSP

**3G04-816-AAF TRANSMISSION AIR SUPPLY LINE**

TRANSMISSION AIR SUPPLY LINE

LINE #81 ORN - PRIM. AIR TANK TO Y FTG

G50-6022-040RNCTL Orange Nylon Tubing (1/4") 1  
K129-388-06 90° Street Elbow Fitting (3/8-2  
18 NPTF)

G38-1044-060404 Y-Branch Fitting, Composite 1  
(#^MNPT to #4 J2494)

Y FTG TO SERVO

G50-6022-040RNCTL Orange Nylon Tubing (1/4") 1  
G11-6289 Routing Bracket Assembly 1

SHOP NOTE:

INSTL G11-6289 UNDER TMSN CASE & TIE

HYDRAULIC LINE TO IT.

E95-6041-100 HYD & AIR CLUTCH RTG

SHOPE NOTE: TIE STRAP LINES TO

COOLER HOSES.

**3G04-830-HAC CUSTOMER INSTALLED PTO (C/I PTO)**

CUSTOMER INSTALLED PTO (C/I PTO)

CUSTOMER INSTALLED PTO (C/I PTO)

**3G04-830-JAD 1ST PTO SINGLE ACTING**

1ST PTO SINGLE ACTING

LINE #89 (#3203) FROM PTO SWITCH 1

ELECT OVER AIR (EOA) TO 5 FT ADD L

LINE TIED & BUNDLED IN THE RAIL CLOSE

TO PTO

ITEM 50

G50-6022-04BLKCTL Black Nylon Tubing (1/4") 1

G94-2016S00 DIAG-NGP SINGLE ACT PTO

**3J0P-D00-AAJ STEERING COLUMN - ADJUSTABLE**

STEERING COLUMN - ADJUSTABLE

J19-6032-351112721 Adjustable Steering Column 1  
Assembly

**3J00-D00-AAC STEERING COLUMN MOUNTING**

STEERING COLUMN MOUNTING

COLUMN TO X-CAR BEAM

S34-6003-0830RHLOB Hex Lock Screw (M8 x 1.25 x 4  
30mm), Black

BEARING TO FRONT WALL

S34-6003-0830RHLOB Hex Lock Screw (M8 x 1.25 x 4  
30mm), Black

INSERT BLACK EXHAUST HOSE

ONE INCH BEYOND INSERTION MARK

WHEN INSERTING INTO BULKHEAD

J97-6038 INSTL - STEERING COLUMN

**3J00-D00-BAM STEERING WHEEL**

STEERING WHEEL

J91-6011-1150000 Steering Wheel Assembly 1

SHOP NOTE: PUSH BN13193 CLIP ONTO TOP

*OF INPUT SHAFT AFTER FINAL TORQUE  
OF NUT*

S63-6092	Horn Pad Assembly	1
W20-6023	NUT-FLANGE,STEERING WHEEL	1
BN13193	CLIP-EXTERNAL	1

**3J00-D04-AAM STEERING GEAR**

*STEERING GEAR*

J87-6028	Steering Gear Assembly	1
W34-1181-130	BOLT-TC-M16 X 130	2
W34-1181-150	BOLT-TC-M16 X 150	1
W34-1181-190	BOLT-TC-M16 X 190	2
W20-1028-016	Lock Nut (M16 x 2.00 x 16mm)	5
W34-1162-016	Washer (16MM)	10

**3J00-D04-BAC DRAGLINK & PITMAN**

*DRAGLINK & PITMAN*

J23-6038	ARM - PITMAN, 10.5 IN	1
K041-911	Hex Bolt (3/4-16 x 5-1/4")	1
K169-147-126CA	Hex Nut, U-Bolt (3/4-16)	1
W34-1162-020	Flat Washer (3/4")	2
J20-6011	LINK - DRAG LH	1
W65-1009-038	Cotter Pin (5/32" x 1-1/2")	2

**3J00-D04-CAC STEERING SHAFT**

*STEERING SHAFT*

418080	Intermediate Steering Shaft Assembly	1
27-00651	Hex Bolt (7/16-20 X 2")	1
NT8359	Lock Nut (7/16"-20)	1
27-00651	Hex Bolt (7/16-20 X 2")	1

**3J00-D06-AAC POWER STEERING PUMP**

*POWER STEERING PUMP*

PEV1816-18R101	PUMP-PWR STRG	1
4988280	GASKET-POWER STEERING	1
W34-1163-040	Hex Bolt (M10 x 40mm)	2
W34-1162-010	Washer (10MM)	2

*D97-1237-000*

**3J00-D06-BAS POWER STEERING RESERVIOR**

*POWER STEERING RESERVIOR*

J86-1070	Power Steering Reservoir Assembly	1
J11-1221	BRACKET - PS RESERVOIR	1
R34-6002-08030RH0M	FASTENER-THREADED,EXT	2

*J97-1115-000 INSTALL PS RESERVIOR*

**3J00-D06-CCB POWER STRG PRESSURE & SUCTION LINES**

*POWER STRG PRESSURE & SUCTION LINES*

26-02880	Fitting - 45 Deg (1-1/16" X #12 Clamp)	1
J50-6003-12010	HOSE-PUSH ON	1
26-02085		

Connector - 90 Deg (3/4" St 1 X #8 Flare)		
16700033	Oetiker Clamp - 27.1MM	2
J50-1007-08-036PT	37 Degree Flare Hose Assembly (#8 x 36")	1
K028-2492-4	Standoff Bracket	1
K041-830-25CA	Hex Bolt, Lock (M10 x 1.50 x 1 25mm)	1
W34-1162-010	Washer (10MM)	1
K077-123-16	Cushioned Clamp (1")	1
Y84-6000-017	Tie Strap, Dual Loop	1
K028-2489-16	90° Standoff Bracket	1
W20-6011-06TDY0Z	Exterior Threaded Hex Screw 1 (M6 x 1.00 x 25mm)	1
K041-802-20CA	Hex Bolt (M6 x 1.00 x 20mm)	1
K363-338-3-312	Flat Washer (5/16")	2
A62-6084	Cable Tie Mount	1

*J95-1304-020 ROUTING-PWR STRG*

### **3J00-D06-DBC POWER STEERING RETURN LINES**

*POWER STEERING RETURN LINES*

### **3K0P-D00-AAE PACCAR PRIMARY FUEL FILTER - PNG**

*PACCAR PRIMARY FUEL FILTER - PNG*

K37-1027-102001	Primary Fuel Filter Assembly	1
-----------------	------------------------------	---

### **3K00-D00-EAG PRIMARY PACCAR FUEL FILTER INSTL.**

*PRIMARY PACCAR FUEL FILTER INSTL.*

W20-1028-010	Lock Nut (M10 x 1.50)	1
W34-1163-050	Hex Bolt (M10 x 1.50 x 50mm)	1
W34-1162-010	Washer (10MM)	1

*K97-1150-000 INSTL - PACCAR FILTER*

### **3K00-D05-CAF UNDER HOOD FUEL LINE - ISX15**

*UNDER HOOD FUEL LINE - ISX15*

K74-1012-6122	Fuel Lines Kit	1
---------------	----------------	---

*K97-1139-20304 INSTL-SBFA PACCAR FLTR*

### **3K00-D05-FAC UNDERHOOD FUEL LINE CLIP**

*UNDERHOOD FUEL LINE CLIP*

157-00034	CLIP-STUD TIE	1
-----------	---------------	---

*K97-1139 INSTL-FUEL LINES SBFA PAC*

### **3K00-D05-KAD FUEL DRAW LINES**

*FUEL DRAW LINES*

V50-1399-0560	Formed Nylon Hose Assembly	1
---------------	----------------------------	---

*K97-1146 INSTL - NYLON FUEL LINES*

### **3K00-D05-LAH FUEL RETURN LINES W/O SNGL LHUC FT**

*FUEL RETURN LINES W/O SNGL LHUC FT*

V50-1493-0810	HOSE-ASSY FORMED NYLON	1
---------------	------------------------	---

*K97-1146 INSTL - NYLON FUEL LINES*

### **3K00-D05-NAK FUEL SPLITTER TEE HARDWARE**

*FUEL SPLITTER TEE HARDWARE*

W34-1162-012	Flat Washer	4
W20-1028-012	Lock Nut (M12 x 1.75)	2

W34-1159-050 Hex Bolt (M12 x 1.75 x 2  
50mm)

### **3K00-D05-PAG ROUTING HARDWARE - NOT UNDERHOOD**

*ROUTING HARDWARE - NOT UNDERHOOD*

*SHOP NOTE: INSTL K11-1299 ON M11-2889*

*BEFORE INSTLN OF M11-2889 ON FR RAIL.*

K11-1299 BRACKET-NYLON FUEL LINE 1  
W34-1160-050 Lock Nut w/ Nylon Insert 2  
(M16 x 1.75)  
W20-1028-016 Lock Nut (M16 x 2.00 x 2  
16mm)  
W34-1162-016 Washer (16MM) 4  
K11-1293 BRACKET-NYLON FUEL LINE 2  
K041-802-35CA Hex Bolt (M6 x 1.00 x 35mm)2  
K363-338-2-250 Flat Washer (1/4") 2  
W20-6011-06TDY0Z Exterior Threaded Hex Screw 2  
(M6 x 1.00 x 25mm)

*K97-1146 INSTL - NYLON FUEL LINES*

### **3K00-D05-QAD ROUTING HARDWARE - UNDERHOOD**

*ROUTING HARDWARE - UNDERHOOD*

K11-1282 Standoff Bracket Assembly 2  
W34-1162-010 Washer (10MM) 2  
W34-1163-035 Hex Bolt (M10 x 1.5 x 35mm)2  
W20-6011-10TDY0Z Flanged Lock Nut (M10 x 2  
1.50)  
W11-1030 Standoff Bracket Assembly 1  
5846039400 FTG-3/4-16 45° VOSS 2

*SHOP NOTES:*

*- USE COPPER GASKET W/ VOSS FITTING*

*- TORQUE VOSS ADAPTER TO 24FT-LB*

D2151-2697 Adapter, #8, Copper, SAE 2  
Flare Gasket

*K97-1139-10102 INSTL-SBFA FILTER NYLON*

### **3K00-D05-UAC REAR CAB CROSSMEMBER**

*REAR CAB CROSSMEMBER*

K11-1308 BRACKET-NYLON FUEL LINE 1  
A93-6026 ASSEMBLY - FIVE PIECE XMBR

### **3K00-D05-ZAC WIF/FUEL HEATER HARNESS**

*WIF/FUEL HEATER HARNESS*

*FUEL FILTER BOLT AND SECURE HARNESS  
TO IT WITH TIE*

HDM400B Cable Tie Mount, High Torque 1  
T255R0H1R Tie Down Strap, Heavy Duty 1

### **3K00-D10-EAX POL ALUM FUEL TANK LH BOC**

*POL ALUM FUEL TANK LH BOC*

*24.5" X 60*

K444-0356N0356K061 TANK FUEL DRAW 24.5 AL 1  
K444-0356N0356K061 ALUM TANK LH BOC

*24.5"X 60*

### **3K00-D10-GAX POL ALUM FUEL TANK RH BOC**

*POL ALUM FUEL TANK RH BOC**24.5" X 60*

K444-0356N0356K061 TANK FUEL DRAW 24.5 AL 1

*K444-0356N0356U061 ALUM TANK RH BOC**24.5"X 60***3K00-D39-AAC LH BOC TANK-24.5"***LH BOC TANK-24.5"**FRAME SUPPORTS*

K85-6003 BRACKET-FUEL TANK,24.5" 2

K161-1227-6 Tank Bracket Lining (26") 2

*K93-6000 ASSY-FUEL TANK SUPPORT***3K00-D39-BAC RH BOC TANK-24.5"***RH BOC TANK-24.5"**FRAME SUPPORTS*

K85-6003 BRACKET-FUEL TANK,24.5" 2

K161-1227-6 Tank Bracket Lining (26") 2

*K93-6000 ASSY-FUEL TANK SUPPORT***3K00-D39-CAH TANK STRAPS-POLISHED***TANK STRAPS-POLISHED**STRAPS*

K84-1068P STRAP - FUEL TANK 7 2

*STEP MOUNTING/HARDWARE*

K350-930 Plate - Step Fastener 4

W34-1163-040 Hex Bolt (M10 x 40mm) 8

W20-6011-10TDY0Z Flanged Lock Nut (M10 x 1.50) 8

W34-1162-010 Washer (10MM) 8

K041-857-40P0L Hex Bolt (M12 X 1.75 X 40mm) 4

K041-857-50P0L Hex Bolt (M12 X 1.75 X 50mm) 4

K363-340-2-500P0L Flat Washer (1/2"), Polished 4

27-01008-012 Nut - Flanged (M12-1.75) 8

*K93-6000 ASM-FUEL TANK SUPPORT***3K00-D39-DAD TANK STRAPS-POLISHED***TANK STRAPS-POLISHED**STRAPS*

K84-1053P STRAP - FUEL TANK 7" 2

K041-857-40P0L Hex Bolt (M12 X 1.75 X 40mm) 4

K041-857-50P0L Hex Bolt (M12 X 1.75 X 50mm) 4

K363-340-2-500P0L Flat Washer (1/2"), Polished 4

27-01008-012 Nut - Flanged (M12-1.75) 8

*K93-6000 ASM-FUEL TANK SUPPORT***3K00-D45-FAC FUEL TANK FITTINGS - LH BOC***FUEL TANK FITTINGS - LH BOC**FUEL TANK DRAW PORT FITTING*

K129-188-0808 45° Male Elbow Fitting (1/2-14 NPTF x 3/4-16 NF) 1

**FUEL TANK RETURN PORT FITTING**

K129-188-0606	45° Male Elbow Fitting (3/8-18 NPTF x 5/8-18 NF)	1
---------------	--	---

**3K00-D45-GAC FUEL TANK FITTINGS - RH BOC****FUEL TANK FITTINGS - RH BOC****FUEL TANK DRAW PORT FITTING**

K129-188-0808	45° Male Elbow Fitting (1/2-14 NPTF x 3/4-16 NF)	1
---------------	--	---

**FUEL TANK RETURN PORT FITTING**

K129-188-0606	45° Male Elbow Fitting (3/8-18 NPTF x 5/8-18 NF)	1
---------------	--	---

**3K1P-802-FAC FUEL TEE ASSEMBLY****FUEL TEE ASSEMBLY**

K74-1016-0145455045	KIT - FUEL TEE ASSEMBLY	1
0272563	Flange Nut, M6	2
K11-1291	Bracket, Fuel Tee	1
K38-1057	Fitting, Supply Fuel Tee	1
K38-1060	Fitting, Return Fuel Tee	1
V50-14860063111045	Fuel Hose Assembly, Steel Braid (#6 x 45")	1
V50-14860063111050	Hose Assembly, Steel Braid (#6 x 50mm)	1
V50-14860082111045	Fuel Hose Assembly, Wirebraid (#8 x 45")	2

**K97-1145-001 INSTL-NYLON FUEL TEE****3K10-800-CAK LH BOC FUEL TANK STEPS****LH BOC FUEL TANK STEPS**

K229-1169-8	STEP - FUEL TANK	2
-------------	------------------	---

**3L0P-D10-BAF VOCATIONAL HOOD - T880 (NOT SH)****VOCATIONAL HOOD - T880 (NOT SH)**

L29-6208-1111000	Hood Assembly	1
------------------	---------------	---

**3L00-D12-AAJ TILT ASSIST BRACKETS****TILT ASSIST BRACKETS**

L11-1354-004	BRKT- TILT ASSIST	1
L11-1354-001	BRKT- TILT ASSIST	1

**L97-6155 INST - VOC STRUT MOUNT****3L00-D12-CAD CROWN & GRILL W/ INTERNAL BUG SCREEN****CROWN & GRILL W/ INTERNAL BUG SCREEN****W/O EXT BUG SCREEN AND W/O WINTERFRONT**

R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	15
K363-338-5-312	Flat Washer (5/16")	4
L29-6240-110	Grille Crown Assembly	1
K363-175CA	Flat Washer (3/8")	2

**SHOP NOTE:****ADD K363-175CA WASHERS ON TOP 2****INBOARD BOLTS OF GRILLE****L97-6146 - INSTL - HOOD TRIM KW VOC.****3L00-D12-EAJ HOOD MOUNTING AND TRIM****HOOD MOUNTING AND TRIM**

*HOOD AIR - INTAKE SCREENS*

L46-1095	Intake Screen Assembly	1
L46-1095R	Intake Screen Assembly	1
L53-1014-100	EMBLEM-VITREOUS ENAMEL	2
W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	4

*HOOD PULL HANDLE & MTG HARDWARE*

L56-6023	HANDLE-PULL, KW AERO	1
W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25)	2

*HOOD TILT ASSIST & HARDWARE*

L71-6024	ASSIST-STRUT T880	1
L71-1017	Hood Strut Assist, Locking, Mechanically Dampened	1
L65-6008-011	PIN-CLEVIS	2
L20-6019	RETAINER-CLEVIS PIN	2

*HOOD PIVOT PINS*

L65-6008-014	PIN-CLEVIS	2
L20-6019	RETAINER-CLEVIS PIN	2

*HOOD LATCHES AND HARDWARE**HOOD LATCHES AND HARDWARE*

L56-6049	KEEPER-LATCH, HOOD	2
R34-6002-06035RF0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 35mm)	4
L56-1049	LATCH- HOOD, KW VOC	2
R34-6002-08045RHKL	Exterior Threaded Hex Screw (M8 x 1.25 x 45mm)	2

*UPPER HOOD SUPPORTS**UPPER HOOD SUPPORTS*

L85-6078	Bracket-Support, Hood	1
L85-6078R	Bracket-Support, Hood	1
R34-6002-08045RHKL	Exterior Threaded Hex Screw (M8 x 1.25 x 45mm)	8
L11-6234	BRACKET-LATCH, KW AERO SH	1
L11-6234R	BRACKET-LATCH, KW AERO SH	1
L85-6130	Hood Adjustment Support Assembly	2
L85-6081	Support-Hood,Bumper	2
L85-6082	Support-Hood,Bumper	2
R34-6002-08045RHKL	Exterior Threaded Hex Screw (M8 x 1.25 x 45mm)	20
L85-6131	SUPPORT-HOOD, LATERAL GUI	1
L85-6131R	SUPPORT-HOOD, LATERAL GUI	1
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	2
<i>HOOD SET PARTS</i>		
R34-6002-12055RHLM	Exterior Threaded Hex Screw (M12 x 1.75 x 55mm)	8

**LATERAL GUIDES**

L85-6114	SUPPORT-HOOD, LATERAL GUI	2
R34-6002-06035RF0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 35mm)	6

**P95-6651 RTG - FIREWALL GROUND WIRE  
GROUND WIRE**

P92-2530-23-0200	WIRE-GROUND, BRAIDED	1
------------------	----------------------	---

L97-6146 - INSTALL-HOOD TRIM KW VOC  
L97-6156 - INSTALL-VOC HOOD SET  
P95-6651 ROUTING-FIREWALL JUMPER

**3L00-D12-QAE UNDER HOOD MTD PRE-CLEANER****UNDER HOOD MTD PRE-CLEANER**

D37-1031	FILTER - PRECLEANER	2
R34-6002-06035RF0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 35mm)	14

**D97-1354 INSTL NGP PRE-CLEANER****3L00-D12-RAC LH FENDER SKIRT****LH FENDER SKIRT****FENDER ASSEMBLY**

N35-1118	FENDER - SPLIT, T880	1
W34-1162-010	Washer (10MM)	2
W34-1163-035	Hex Bolt (M10 x 1.5 x 35mm)	2
W20-6011-10TDY0Z	Flanged Lock Nut (M10 x 1.50)	2

**FENDER SUPPORT**

N85-1494	SUPPORT QUARTER FENDER	1
W34-1163-220	BOLT-FINISHED HEX M10	3
W34-1162-010	Washer (10MM)	3
W20-6011-10TDY0Z	Flanged Lock Nut (M10 x 1.50)	3

**N97-1200-100 INSTL-SPLIT FENDER****N97-1178-600 INSTL-SPLIT FNDR SUPPORT****3L00-D12-SAC RH FENDER SKIRT****RH FENDER SKIRT****FENDER ASSEMBLY**

N35-1120	Fender-Split T880	1
W34-1162-010	Washer (10MM)	2
W34-1163-035	Hex Bolt (M10 x 1.5 x 35mm)	2
W20-6011-10TDY0Z	Flanged Lock Nut (M10 x 1.50)	2

**FENDER SUPPORT**

N85-1494R	SUPPORT QUARTER FENDER	1
W34-1163-220	BOLT-FINISHED HEX M10	3
W34-1162-010	Washer (10MM)	3
W20-6011-10TDY0Z	Flanged Lock Nut (M10 x 1.50)	3

**N97-1200-100 INSTL-SPLIT FENDER****N97-1178-700 INSTL-SPLIT FNDR SUPPORT****3L00-D12-UAC SPLASH SHIELDS****SPLASH SHIELDS**

L22-1134	COVER-HDLP ASSY T880	1
L22-1134R	COVER-HDLP ASSY T880	1
L56-1046	Knob-Twist EM	6
L46-6105	GUARD-SPLASH, HOOD T880	2
R46-1234	LINER- FENDER KW T880MH	1
R46-1234R	LINER- FENDER KW T880MH	1
R34-6002-06035RF0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 35mm)	6
K363-340-5-250	Washer (1/4")	6
27-01212-003	Blind Rivet (3/16")	12

L97-6146 - INSTL - HOOD TRIM KW VOC.

L97-6146 - INSTL - HOOD TRIM KW VOC.

### **3L00-D12-VAC FENDER CLOSE-OUT**

FENDER CLOSE-OUT

L33-6029-100	SKIRT-FR FENDER, KW VOC	1
L33-6029-100R	SKIRT-FR FENDER, KW VOC	1
R34-6002-06035RF0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 35mm)	10

### **3M0P-D00-EAC RH EXHAUST STACK ASSEMBLY**

RH EXHAUST STACK ASSEMBLY

M66-9803-11103151	Exhaust Standpipe Assembly, RH	1
M11-9318	Exhaust Shield Bracket	1
W34-6115	Blind Rivet, Polished	2

### **3M0P-D00-FAC LH EXHAUST STACK ASSEMBLY**

LH EXHAUST STACK ASSEMBLY

M66-9803-21204251	Exhaust Standpipe Assembly, LH	1
-------------------	-----------------------------------	---

### **3M0P-D02-AAG DEF BUNDLE ASSEMBLY**

DEF BUNDLE ASSEMBLY

M50-6073-0851B0400	DEF Hose Bundle Assembly	1
--------------------	--------------------------	---

### **3M00-D00-CFL DPF/SCR RHUC HIGH ROUTE CUMMINS ENG**

DPF/SCR RHUC HIGH ROUTE CUMMINS ENG

M10-6200-041221200	DPF/SCR Box Assembly	1
--------------------	----------------------	---

HARDWARE

R34-6002-12100RF0M	Exterior Threaded Hex Screw (M12 x 1.75 x 100mm)	4
--------------------	---	---

M97-6423 INSTL - DPF/SCR RHUC

M93-6030-000 ASSEMBLY - EXH CANISTER

BOX COVER INSTALLED AT DYNACRAFT

M97-6574 INSTL - MASKING-DPF/SCR BOX

### **3M00-D04-AVH TURBO OUTLET PIPING**

TURBO OUTLET PIPING

M66-9443-302	PIPE-FLEX, 4 NON-TORN	1
90-0012	V-Band Clamp (4")	2
Q312526	Circular Gasket (4")	2

M97-6818 INSTL - FRONT PARTIAL EXH

### **3M00-D04-BLB DPF INLET PIPING**

DPF INLET PIPING

M66-9466-001	PIPE-EXHAUST, DPF IN	1
--------------	----------------------	---

A029E744	Spherical Gasket (5")	1
LP34216	V-Clamp (5")	1

*M97-6818 INSTL - FRONT PARTIAL EXH*

### **3M00-D06-BKX REAR PIPING DUAL SOC/SOS EXHAUST**

*REAR PIPING DUAL SOC/SOS EXHAUST*

*PIPES AND FLEX*

M66-9759-002	PIPE-EXHAUST	1
M66-9760-002	PIPE-EXHAUST	1
M66-9359-002	PIPE EXHT DSOC	1
K077-293-550	Hose Clamp (5-1/2")	1
14-01661	Heat Shield (5")	1

*SHOP NOTE: INSTALL HEAT SHIELD TO SHIELD FRAME RAIL ROUTINGS.*

*CLAMPS AND HARDWARE*

A50BFE	Accuseal Exhaust Clamp	2
M16-1047	Clamp, Exhaust Pipe (4")	1
K363-371CA	Flat Washer (M12)	2
W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm)	2
K077-234	Clamp, Exhaust Pipe (5"), Steel	1
W34-1163-040	Hex Bolt (M10 x 40mm)	2
W34-1162-010	Washer (10MM)	2

*TAILPIPE ASSY CLAMP-PS*

A50BFE	Accuseal Exhaust Clamp	1
<i>TAILPIPE ASSY CLAMP-DS</i>		
A50BFE	Accuseal Exhaust Clamp	1
LP55563	CLAMP-5 INCH BAND	1
S34-6003-1050RH00Z	Hex Screw (M10 x 1.50 x 50mm)	1

### **3M00-D08-APS SUPPORT - FRONT PARTIAL PIPING**

*SUPPORT - FRONT PARTIAL PIPING*

M11-8872	BRACKET-EXHAUST	1
R34-6002-10042RH0M	Exterior Threaded Hex Screw (M10 x 1.50 x 42mm)	1

*M97-6818 INSTL - FRONT PARTIAL EXH*

*M96-6256-000 DRILLING-EXHAUST, RHUC*

### **3M00-D08-B33 REAR PARTIAL PIPING SUPPORT-DUAL SOC**

*REAR PARTIAL PIPING SUPPORT-DUAL SOC*

*FRAME MOUNTED BRACKETS*

M11-6703	BRACKET-EXHAUST,DSOC	1
M85-6300	SUPPORT-EXHAUST,DSCO	2
M11-2889	BRACKET-EXHAUST,INSD DUAL	1
M11-9226-004	BRACKET - EXHAUST, SOC	1
S34-6003-1050RH00Z	Hex Screw (M10 x 1.50 x 50mm)	2

*M97-6825-000 INSTL-REAR PART PP, RHUC*

*M96-6260-000 DRILLING-EXHAUST, RHUC*

### **3M00-D08-FAD CAB MTD BRACKETS - DUAL EXH**

*CAB MTD BRACKETS - DUAL EXH*

R11-6785	BRACKET-EXH, UPPER CAB	1
	MTD	
R11-6785R	BRACKET-EXH, UPPER CAB	1
	MT	
R11-6786	BRACKET-EXH, LWR CAB	1
R11-6786R	BRACKET-EXH, LWR CAB	1
R42-6257	GASKET-EXHAUST BRKT	4
R34-6002-08045RHLK	Exterior Threaded Hex Screw	16
	(M8 x 1.25 x 45mm)	
R34-6002-10055RH0M	Exterior Threaded Hex Screw	6
	(M10 x 1.50 x 55mm)	
K363-338-3-500	Flat Washer (1/2")	6
<i>M97-6822-000 INSTL-EXH, STACK ASSY SOC</i>		
<i>M97-6843-000 INSTL-EXHAUST BRKT, CAB M</i>		

### **3M00-D10-AAE FRAME BRACKETS DPF/SCR - RHUC**

#### *FRAME BRACKETS DPF/SCR - RHUC*

#### *FRONT FRAME BRACKET*

M11-8381M00	Bracket-Exhaust	1
-------------	-----------------	---

#### *REAR FRAME BRACKET*

M11-8383M00	Bracket-Exhaust	1
-------------	-----------------	---

#### *M96-6051-000 DRILLING - DPF/SCR RHUC*

### **3M00-D16-ACS DEF TANK & MOUNTING**

#### *DEF TANK & MOUNTING*

M86-6300-227106	DEF Tank Assembly, Small	1
-----------------	--------------------------	---

M11-8744-003	BRACKET-FRAME	1
--------------	---------------	---

M11-8743-003	BRACKET - FRAME	1
--------------	-----------------	---

R34-6002-12030RHLM	FASTENER-THREADED	2
--------------------	-------------------	---

W20-1028-012	Lock Nut (M12 x 1.75)	2
--------------	-----------------------	---

W34-1162-012	Flat Washer	2
--------------	-------------	---

#### *M97-6803 INSTL-DEF TANK*

#### *M97-6803 INSTL-DEF TANK*

### **3M00-D16-CBH DEF ROUTING SYSTEMS**

#### *DEF ROUTING SYSTEMS*

#### *DEF & COOLANT HOSE ROUTING HARDWARE*

M11-8625-001	BRACKET-BOC XMBR	1
--------------	------------------	---

M11-8625-002	BRACKET-BOC XMBR	1
--------------	------------------	---

M11-8627	BRACKET-DEF, UNDR XMBR	1
----------	------------------------	---

M11-6675	BRACKET-DEF COOLANT, BOC	1
----------	--------------------------	---

#### *M97-6742 INSTL-DEF/COOLANT RTG 2.1M RH*

#### *M97-6743 INSTL - DEF COOLANT ROUTING*

#### *M97-6741 INSTL - DEF COOLANT ROUTING*

#### *P97-6759 INSTL - DEF HARNESS*

### **3M00-D16-GAC DEF COOLANT FILTER**

#### *DEF COOLANT FILTER*

M37-6278-002	DEF Coolant Filter Assembly	1
--------------	-----------------------------	---

933-200-10H	Constant Tension Clamp	2
	(20mm)	

#### *M97-6805-000 INSTL-DEF COOLANT FILTER*

#### *M96-6228-000 DRILL-DEF COOLANT FILTER*

### **3M14-802-FFN CUMMINS DPF/SCR AFTERTREATMENT DEVICE**

*CUMMINS DPF/SCR AFTERTREATMENT DEVICE*

A072E781 DPF/SCR Canister Assembly 1

*M93-6030-000 CUMMINS DPF/SCR***3M15-800-EBA DEF SYSTEM - DEF FLUID REQUIREMENT***DEF SYSTEM - DEF FLUID REQUIREMENT*M99-6000 FLUID-DIESEL EXHAUST 5  
(DEF)*SHOP NOTE: DEF VOLUME LISTED IS  
MINIMUM QUANTITY REQUIRED SO THAT  
THERE ARE NO WARNING LIGHTS OR  
FAULT CODES.***3N0P-D02-BAE TAPERED CHANNEL FRONT BUMPER***TAPERED CHANNEL FRONT BUMPER**POLISHED, NON-POLISHED, CHROME*

N71-1063-7111 BUMPER-TAPERED CHANNEL 1

K275-5864 BRACKET-LIC. PLATE FRON 1

*R064-1590 BUMPER ACCESSORY L/O***3N0P-D10-BAC LH UNDER BATTERY BOX ASSY - N10-1027***LH UNDER BATTERY BOX ASSY - N10-1027*

N10-1027-1J2929 Battery Box Assembly 1

**3N00-D02-AAX BUMPER BOLTS & WASHERS***BUMPER BOLTS & WASHERS*

K041-857-40 Hex Bolt (M12 X 1.75 X 40mm) 6

27-01008-012 Nut - Flanged (M12-1.75) 6

27-00801-008 Flat Washer (1/4") 6

**3N00-D04-DAC BUMPER STEP MTD IN CTR OF BUMPER***BUMPER STEP MTD IN CTR OF BUMPER*

K229-963 Bumper Step (4") 1

W34-1159-040 Hex Bolt (M12 x 1.75 x 40mm) 2

W20-1028-012 Lock Nut (M12 x 1.75) 2

K363-338-2-500 Flat Washer (1/2") 4

**3N00-D10-MAJ BTRY BOX MTG BRKTS - LH UNDER***BTRY BOX MTG BRKTS - LH UNDER**FRONT MOUNTING BRACKET*

N11-6258 BRACKET-BATTERY BOX 1

*REAR MOUNTING BRACKET*

N11-6242 BRACKET-BATTERY BOX 1

*MOUNTING BRACKET AND HARDWARE*

W34-1162-010 Washer (10MM) 6

W34-1162-016 Washer (16MM) 8

W34-1163-040 Hex Bolt (M10 x 40mm) 8

W20-1028-010 Lock Nut (M10 x 1.50) 6

*N93-6011-003 BOX-BATT/TOOL LHUC**N96-6003-006 ASSY-BATT/TOOL BOX MNT**P95-2182 - BATTERY BOX ROUTING:**DRAWING FOR TRANSMISSION TO BATTERY**BOX ROUTING ONLY. SEE APPLICABLE P95**FOR ENGINE SPECIFIC ROUTING.*

**3N00-D11-AAR BATTERY TRAY & HOLDDOWN INSTL***BATTERY TRAY & HOLDDOWN INSTL**3 GRP 31 BTRYS*

N20-6012-002	Battery Retainer	1
W34-1163-275	BOLT-FINISHED HEX M10	3
K363-3	Washer, Cupped (3/4")	3
4023	Button	3
W84-1000	Tie Down Strap	2
W34-1162-010	Washer (10MM)	3
N63-1005	Pad, Battery Box (316mm X 338mm)	1
N63-1006	Pad, Battery Box (316mm x 170mm), Black, Rubber	1

**3N00-D17-AAC POLISHED BATTERY OR TOOL BOX COVER***POLISHED BATTERY OR TOOL BOX COVER*

N22-1025-2	Battery Box Cover Assembly	1
------------	----------------------------	---

*HARDWARE FOR ATM BOX COVER*

W34-1074-040	Wing Screw (M10 x 1.50 x 40mm)	2
W34-1074-040	Wing Screw (M10 x 1.50 x 40mm)	2
K363-474	Padded Washer	4

**3N00-D17-FAC STEP FOR ATM BOX LH UNDER CAB***STEP FOR ATM BOX LH UNDER CAB**LOWER STEP*

N82-1001-1P	Battery/Tool Box Step, Polished	1
-------------	---------------------------------	---

*HARDWARE FOR LOWER STEP*

W34-1163-030	Hex Bolt (M10 x 1.50 x 30mm)	4
W20-6011-10TDY0Z	Flanged Lock Nut (M10 x 1.50)	4
W34-1162-010	Washer (10MM)	4

*N97-1097 INSTL-BATTERY BOX***3P10-X00-APC PACCAR ALTERNATOR - 160AMP***PACCAR ALTERNATOR - 160AMP*

D27-1016-0160P	ALTERNATOR - PACCAR 160A	1
----------------	--------------------------	---

*D97-1286-003 INSTL - MX-13 ENGINE ACC*

### \*\* BCE IMPACT! RERUN BCE! \*\*

*D97-1458 INSTL - ENG ACC***3P10-X00-BXA ALTERNATOR HARDWARE***ALTERNATOR HARDWARE**NOTE: ALTERNATOR PULLEY IS SUPPLIED**BY CUMMINS*

W34-1163-100	Hex Bolt (M10 x 1.50 x 100mm)	3
W34-1163-150	BOLT-FINISHED HEX M10	1
W34-1162-010	Washer (10MM)	4

*D97-1244 ISX15 INSTL**D97-1245 ISX11.9 INSTL*

D97-1299 INSTL - ALTERNATOR (NGP)

### **3P10-X00-SXF STARTER - PACCAR PREMIUM 12-VOLT**

STARTER - PACCAR PREMIUM 12-VOLT

D61-1008 STARTER - PACCAR DP60 1

### \*\* BCE IMPACT! RERUN BCE! \*\*

### **3P10-X00-TXA STARTER MOUNTING HARDWARE**

STARTER MOUNTING HARDWARE

K041-728-1P BOLT-CRANKING 3

MOTOR,12PT

P42-6000 PREVENTATIVE CORRORION 1

NOTE: AFTER COMPLETING ELECTRICAL

CONNECTIONS APPLY CORROSION

PREVENTATIVE TO TERNINALS OF

STARTER SOLENOID AS REQUIRED

D97-1244 INSTL

### **3P10-830-JAC BATTERY JUMPER**

BATTERY JUMPER

SHOP NOTE: P97-1220 FOR CANTILEVER OR

PAR BOC BTRY BOX

SHOP NOTE: P97-1211 FOR ACROSS RAILS

BTRY BOX

N92-6006-1AASS0020 CABLE-BATTERY (POS) ASSY 2

N92-6007-1AASS0020 CABLE-BATTERY, (NEG) ASSY 2

P97-1220 INSTALLATION - 3 BATTERY

P97-1211 INSTALLATION - BATTERY

### **3P10-830-PAC BATTERY TERMINAL EXPANDER**

BATTERY TERMINAL EXPANDER

P27-1194 Battery Terminal Expander 2

### **3P10-850-HAL RTG - BATTERY CABLE**

RTG - BATTERY CABLE

W11-1032-110 BRACKET - STANDOFF, ASSY 1

W11-1032-111 BRACKET - STANDOFF, ASSY 1

K041-802-30CA Hex Bolt (M6 x 1.00 x 30mm)2

K169-163-6CA Hex Nut, Steel (M3) 2

K028-2489-5 90° Standoff Bracket 2

27-01298 Washer - Flat (15/32") 1

W84-1000 Tie Down Strap 2

K363-267-2 Washer (9/32" ID x 1-1/4" 2

OD)

22-01618-002 Cable Tie, Heavy Duty 4

K363-338-2-312 Flat Washer (5/16") 2

DCT11 Cable Tie, Dual 3

K169-163-8CA Locking Hex Nut (M8 x 1.25) 2

P95-1961 RTG-STRT/BATT CABLE ISX

### **3P12-D00-AAF HEADLAMPS - SAE DUAL HALOGEN HEADLAMPS**

HEADLAMPS - SAE DUAL HALOGEN HEADLAMPS

P54-6165-100 Headlight Assembly, LH 1

P54-6165-100R Headlight Assembly, RH 1

P54-6116 LAMP-SIDE MARKER REFLEX 2

27-00905

Hex Nut, w/ Washer (M4 x 4  
0.70)  
W01-10-02P53N035N SCREW-PSD, PAN HD 4  
L97-6146 INSTL - HOOD TRIM KW VOC

### **3P12-D00-BAD MARKER LIGHTS: FIVE, LED RECTANGULAR**

MARKER LIGHTS: FIVE, LED RECTANGULAR  
P54-1120-100 LAMP - ROOF MARKER, KW 5  
W20-6017-05035B130 Self Retaining Nut (M5 x 10  
0.80)

R97-1500-000 INSTL-ROOF MOUNTED MARKER

### **3P12-D00-FAC TURN SIGNAL LIGHTS ON TOP OF FENDERS**

TURN SIGNAL LIGHTS ON TOP OF FENDERS  
P54-1276 LAMP-SIDE TURN INDICATOR 2  
W20-6011-05TDY0Z Flanged Lock Nut (M5 x 0.80) 4  
L97-1321 INSTL-SIDE TURN INDICATOR  
L97-1322S02 INSTL-SIDE TURN INDICATOR

### **3P12-D00-MAC SW/WRG: C/I CAB PANEL LTS**

SW/WRG: C/I CAB PANEL LTS  
P92-5646 JUMPER-NGP PANEL LIGHTS 1  
P92-5281-162400 HARNESS - EXTENSION 1

#### **SHOP NOTE:**

CONNECT J01 OF P92-5281 TO P158 OF  
CHASSIS HARNESS. ROUTE BREAKOUT W/  
CONNECTOR P02 ALONG CHASSIS HARNESS  
TO JUST UNDERNEATH THE FIREWALL.  
CONNECT J191 ON P92-5646 TO P02 ON  
P92-5281. RUN THE WIRE ALONG THE LH  
FRAME RAIL AND SECURE IT.

SHOP NOTE: SECURE CONNECTORS P192 &  
P193 AT CHASSIS NODE & BUNDLE EXCESS  
HARNESS LEAVING 6 INCH PIGTAIL FOR  
TESTING AND CUSTOMER ACCESS.

### **3P12-D00-WAS LED TAIL LAMPS - FLANGE MOUNTED**

LED TAIL LAMPS - FLANGE MOUNTED  
W/ (2) LED BACKUP LAMPS  
P92-5522-1720 HARNESS TAIL LAMP 1  
01-5390-74 TAILLAMP-LED, FLANGE MTD 2  
01-6074-70 PACCAR LED LICENSE LAMP 1  
01-6280-70 B/U LAMP-LED, FLANGE MTD 2  
MOUNTING HARDWARE  
W01-10-02P55N016N Pan Head Screw (M5 x 0.80 x 12  
16mm)  
W01-10-02P57N025W Pan Head Screw (M5 x 0.80 x 2  
25mm)  
W20-6011-06TDY0Z Exterior Threaded Hex Screw 2  
(M6 x 1.00 x 25mm)  
K363-340-2-190 Flat Washer, (#10) 28  
K363-340-2-250 Flat Washer (1/4") 2  
K169-154-5 Self Locking Hex Nut (M5 x 10  
0.80)  
W11-1033-101 BRACKET-Z STANDOFF ASSY 1

W11-1033-103 BRACKET, Z STANOFF ASSY 1  
 K041-808-20 Hex Bolt (M6 x 1.00 x 20mm)2

**SHOP NOTE:**

USE 2) W01-10-02P57N025W FASTENER -  
 SCREW, 2) K363-340-2-250 WASHER AND  
 2) W20-6011-06TDY0Z NUT-FLANGED  
 METRIC TO ATTACH LICENSE PLATE LAMP  
 TO BRACKET. SECURE THE LICENSE LAMP  
 PIGTAIL WITH THE TAIL-LAMP HARNESS

SHOP NOTE: USE W11-1033-101, -103  
 Z-BRKT STANDOFFS TO ATTACH HARNESS  
 TO TAIL LAMP BRACKET. ROTATE  
 W11-1033-101, -103 OUTWARD

**3P12-D01-BAE DUAL LOW FLUSH MOUNTED FLOODLIGHTS**

DUAL LOW FLUSH MOUNTED FLOODLIGHTS  
 ON BOC

P54-1230-001 Light-flood, clear lens l 2  
 R18-1004 BEZEL - FLOOD LAMP 2  
 MGLP-U6E FASTENER-MAGNA LOK 3/16 6

R97-1651-700 INSTL-FLOOD LIGHTS

**3P12-D01-SAC SW & WIRING HIGH C/I FLOODLAMPS**

SW & WIRING HIGH C/I FLOODLAMPS

P92-5089-28181 HARN-PASSTHRU GROMMET 2  
 NGP

K246-742-4000 WIRE-EXTENSION 2

SHOP NOTE: PLACE EXTRA JUMPER HARNESS

K246-742-4000 IN SHIP LOOSE BOX.

SHOP NOTE: TWO HARNESSES PASS THROUGH  
 THE FAR RIGHT AND LEFT OF BOC TOP  
 USE THE BOC HOLES FOR PEDESTAL MOUNTED  
 FLOODLAMPS.

R97-1486-000 - INSTL-DAYCAB LOADLIGHTS

**3P12-D01-TAD DAYCAB FLOODLIGHT JUMPER HARNESS**

DAYCAB FLOODLIGHT JUMPER HARNESS

SHOP NOTE: CONNECT 1 EA P92-5536-002

TO IP HARNESS CONNECTORS LABELED

LH & RH FLOOD LAMP. ROUTE FLOOD LAMP 1

CONNECTORS TO HIGHEST FLOOD LAMP

LOCATIONS ON CAB BACKWALL. ROUTE FLOOD

LAMP 2 CONNECTORS TO LOWEST FLOOD LAMP

LOCATIONS ON CAB BACKWALL.

P92-5536-002 HARNESS-FLDT, JUMPER 2

**3P21-D00-AAK STANDARD SWITCHES**

STANDARD SWITCHES

P27-1241-073-01 SWITCH-HEAD/PARK LPS 1

P27-1241-011-01 SWITCH-DOME/FOOTWELL 1

P27-1241-012-01 SWITCH-DIMMER 1

P27-1241-013-01 SWITCH-ELST ON/OFF 1

P27-1275-016-01 SWITCH-HAZARD 1

P27-1241-002-01 SWITCH-CLEARANCE LAMPS 1

P27-1048

Ignition Switch, for Double 1  
 Bit Key  
 Q21-1136-002-003 CTRL-Master Switch Module 1  
 P97-6738 INSTL - MASTER SWITCH MODULE  
**3P21-D00-DAD SWITCH - DPF START/STOP**  
 SWITCH - DPF START/STOP  
 P27-1241-009-01 SWITCH-DPF START/STOP 1  
**3P21-D03-BAD SWITCH - 1 SPARE AIR ACCESSORY SWITCH**  
 SWITCH - 1 SPARE AIR ACCESSORY SWITCH  
 P27-1241-051-01 SWITCH-AIR ACCESORY 1 1  
**3P21-D03-DAD SWITCH - AIR SUSPENSION DUMP**  
 SWITCH - AIR SUSPENSION DUMP  
 P27-1241-053-01 SWITCH-AIR SUSP DUMP 1  
**3P21-D04-CAD SWITCH - WHL DIF LCK SGL RA**  
 SWITCH - WHL DIF LCK SGL RA  
 P27-1241-047-01 SWITCH-WHL DIF LCK SGL 1  
 RA  
**3P21-D04-TAH BLANK SWITCH - COVERS**  
 BLANK SWITCH - COVERS  
 S67-1034 PLUG-DASH SWITCH 6  
**3P21-D04-UAC SWITCH - SHIELD SINGLE**  
 SWITCH - SHIELD SINGLE  
 S46-1007 SHIELD-SWITCH SINGLE 1  
**3P21-D04-VAC SWITCH - SHIELD DUAL**  
 SWITCH - SHIELD DUAL  
 S46-1006 SHIELD-SWITCH DUAL 1  
**3P21-D09-CAD SWITCH - ATC (AUTOMATIC TRACTION)**  
 SWITCH - ATC (AUTOMATIC TRACTION)  
 P27-1241-030-01 SWITCH-ATC 1  
**3P21-D09-QAD SWITCH - ENG FAN OVERRIDE**  
 SWITCH - ENG FAN OVERRIDE  
 P27-1241-015-01 SWITCH-ENG FAN OVERRIDE 1  
**3P21-D16-CAE SWITCH - PTO ELECTRIC OVER AIR (EOA)**  
 SWITCH - PTO ELECTRIC OVER AIR (EOA)  
 P27-1242-007-01 SWITCH-PTO1 1  
**3P21-D20-DAD PUSH BUTTON SW - FLOOD 1ST/2ND**  
 PUSH BUTTON SW - FLOOD 1ST/2ND  
 P27-1244-002-01 SWITCH-FLOOD 1ST/2ND 1  
**3P21-D30-BAC DASH OPTIONAL ACCESSARY POWER OUTLET**  
 DASH OPTIONAL ACCESSARY POWER OUTLET  
 79540-5002 PORT - KW USB CHARGER 1  
 S97-6148 INSTL - B-PANEL COMPONENTS  
 #### DASH IMPACT! RERUN DASH  
**3P21-D35-EAF ADD L 4/7-WAY PLUG WIRED TO DASH SW**  
 ADD L 4/7-WAY PLUG WIRED TO DASH SW  
 P27-1241-023-01 SWITCH-TRLR SPARE 1 1  
 P27-1241-110-01 SWITCH-TRLR SPARE 2 1  
**3P3P-D00-BAY CAB ROOF HARNESS**  
 CAB ROOF HARNESS

S92-1447-1M000111 HARN-CAB LOW ROOF KW 1  
2.1M

- W/O QUALCOMM MCP

S96-1179 SCHEM - ROOF HARN LOW

**3P3P-D00-DAS INSTRUMENT PANEL HARNESS**

INSTRUMENT PANEL HARNESS

Q922170610A0000202 HARNESS-INSTRUMENT 1  
PANEL

P96-1185 SCHEMATIC-INSTRUMENT PANEL

S95-1091 RTG - IP 2.1M VMUX

**3P3P-D05-AAX MAIN CHASSIS HARNESS**

MAIN CHASSIS HARNESS

A92-125070BM150020 HARN-CHASSIS SH- 1  
MED,VMUX

A96-1834 SCHEMATIC-CHASSIS VOC, VM

**3P3P-D05-BAC TRANSMISSION HARNESS**

TRANSMISSION HARNESS

P92-4507-01100 HARN - TMSN 1  
MANUAL/AUTO/U

**3P3P-D05-CAQ BENDIX ABS CHASSIS HARNESS**

BENDIX ABS CHASSIS HARNESS

A92-6131-4313C3001 HARN - BENDIX ABS 1  
CHASSIS

A96-1662 - SCHEM - BENDIX ABS CHASSIS

A95-1016 - RTG - ABS CHASSIS, MLU

**3P3P-D05-FAF REAR CHASSIS HARNESS**

REAR CHASSIS HARNESS

A92-6017-11B100000 HARNESS- REAR CHASSIS 1

A96-6335 - SCHE REAR CHASSIS

**3P3P-D05-GAD EOA SOLENOID BANK HARNESS**

EOA SOLENOID BANK HARNESS

A92-1069-304040000 HARN- MUX SOLENOID BANK 1

A96-1595 SCHEMATIC-MUX SOLENOID BANK

A95-1003 ROUTING-MUX SOLENOID BANK

**3P3P-D10-ABY CUMMINS ENGINE HARNESS**

CUMMINS ENGINE HARNESS

D92-6364-111301 HARNESS-ENG X15 2024 1

D96-6250 SCHEM-ENG CUMMINS X15 2024

**3P3P-D10-FAF AFTERTREATMENT HARNESS**

AFTERTREATMENT HARNESS

M92-6134-121011 HARNESS-AFT, 2024 1

M96-6307 SCHEMATIC-AFTERTREATMENT 2024

**3P31-D00-AAC DOOR HARNESS**

DOOR HARNESS

S92-1050-300 HARNESS-LH DOOR 2.1M 1

S92-1051-200 HARNESS- RH DOOR 2.1M 1

S96-1043 - SCHE LH DOOR 2.1M

S96-1044 - SCHE RH DOOR 2.1M

**3P31-D00-CAC DASH MTD HAND VALVE ADAPTER HARN**

DASH MTD HAND VALVE ADAPTER HARN

SHOP NOTE: ON HARN S92-1229 CONNECT  
J001 TO THE PRESSURE SW 16-09156 FOR  
TRLR BRAKE. CONNECT J002 TO EDITABLE  
TELLTALE BREAKOUT ON IP HARNESS.  
CONNECT T001 TO FIREWALL GROUND.

S92-1229	HARN-PRESSURE SW ADAPTER	1
----------	-----------------------------	---

### **3P31-D01-AAN MUX SWITCH LIN JUMPER**

MUX SWITCH LIN JUMPER

S92-1127-0125	HARNESS - LIN JUMPER	11
---------------	----------------------	----

S95-1015 ROUTING - LIN JUMPER

### **3P31-D02-JAR REMOTE DIAGNOSTICS**

REMOTE DIAGNOSTICS

PP607340	TIG Assembly	1
PP207280	TIG Adapter Harness witho	1

SHOP NOTE: INSTL ADAPTER (PP207280)  
BETWEEN TIG AND HARNESS

SHOP NOTE: ANTENNA INSTALLATION ON  
INTERIOR ROOF SURFACE REMOVE  
INSULATION PRE-CUT SECTION PEEL  
ANTENNA ADHESIVE STRIP PRESS TO ROOF  
SURFACE.

R97-1597-300 2.1(52") RMT DIAGNOSTICS  
R97-1597-400 2.1(76") RMT DIAGNOSTICS  
Q94-6009 CHART-SOFTWARE RMT DIAGNOSTIC  
P94-2154 DIAG - 2.1M VECU1 RDX

### **3P31-D05-AAG HOOD HARNESS**

HOOD HARNESS

L92-1040-10000	Harness- 2.1M T880 Hood	1
----------------	-------------------------	---

P95-2277 ROUTING-2.1M T880 HOOD  
L96-1034 SCHEMATIC-2.1M T880 HOOD  
P95-2277 ROUTING-2.1M T880 HOOD

### **3P31-D05-CBL PTO WIRING**

PTO WIRING

E92-6050-150000800	HARNESS- PTO JUMPER	1
K246-742-1000	WIRE-EXTENSION	1

E96-6021 SCHEM - PTO JUMPER  
P94-2302 DIAGRAM - PTO

### **3P31-D05-DAQ BACK-UP ALARM HARNESS**

BACK-UP ALARM HARNESS

A92-1004-01000	HARNESS- WIRE-JUMPER	1
----------------	----------------------	---

A96-1531 SCHE - WIRE JUMPER

### **3P31-D05-EDG AIR DRYER HARNESS**

AIR DRYER HARNESS

A92-1214-0011400	HARN-AIR DRYER	1
------------------	----------------	---

A96-1773 SCHEM- AIR DRYER

### **3P31-D05-FAJ FUEL TANK SENDING UNIT HARNESS**

FUEL TANK SENDING UNIT HARNESS

BM CONTAINS NO PARTS  
EXTENSION NOT REQUIRED

**3P31-D05-GAM F/T SENDING UNIT HARNESS***F/T SENDING UNIT HARNESS**BM CONTAINS NO PARTS**EXTENSION HARNESS NOT REQUIRED***3P31-D05-MCY REAR AXLE OIL TEMP GAGE HRNS INCL VIRT***REAR AXLE OIL TEMP GAGE HRNS INCL VIRT*

P92-5636-0001 HARN-REAR AXLE SENSOR 1

**3P31-D05-PES AXLE DIFF LOCK HARNESS***AXLE DIFF LOCK HARNESS*

P92-5636-1000 HARN-REAR AXLE SENSOR 1

**3P31-D08-AAC TRAILER 4-WAY***TRAILER 4-WAY*P92-8868-10900 HARNESS-TRLR,ADD L  
RECEPT 1*#### PD BOX IMPACT! VERIFY ID & FORMAT***3P31-D08-KAC TRAILER CABLES - J560, SEMI OR FULL***TRAILER CABLES - J560, SEMI OR FULL*

P92-4835-003003 HARN-TRLR J560 NGP 1

**3P31-D10-AAC CHARGE & START WIRING***CHARGE & START WIRING*

D92-1318-11111 HARNESS-CHARGE SYS 2.1M 1

**3P31-D10-BAV IMMERSION ENGINE HEATER HARNESS***IMMERSION ENGINE HEATER HARNESS*K068-5616-22-9 Wiring Harness, Engine  
Heater, (4500mm) 1*P95-2018 RTG-ISX 2013 ENG HEAT**SHOP NOTE: INSTALL HARNESS TO FWD MOST  
OF THE RECEPTACLES***3P31-D10-DDG CAB FEED HARNESS***CAB FEED HARNESS*D92-6330-2350 HARNESS - CAB POWER  
FEED 1*P95-2462 ROUTING - CAB POWER FEED***3P31-D10-JAC FRAME GROUND STUD***FRAME GROUND STUD*

K041-810-50F BOLT-HEXMETRIC-SST 1

K363-340-2-375 Flat Washer (3/8") 2

27-02040-010 Hex Nut (M10 x 1.50) 1

K169-154-10 Self Locking Hex Nut (M10 x  
1.50) 1

K363-340-2-375 Flat Washer (3/8") 2

*SHOP NOTE: FRAME GROUND STUD MUST BE  
INSTALLED INSIDE LH FRAME RAIL.**A96-1479 DRILLING-COMMON CHASSIS,NGP**A96-1479 DRILLING-COMMON CHASSIS,NGP***3P31-D10-LAC FRAME GROUND WIRE ROUTING STANDOFF***FRAME GROUND WIRE ROUTING STANDOFF*

K11-1146-010 Standoff Bracket Assembly 1

W34-1163-050 Hex Bolt (M10 x 1.50 x  
50mm) 1

W34-1162-010	Washer (10MM)	1
W20-1028-010	Lock Nut (M10 x 1.50)	1
Y84-6000-003	Tie Strap	1

P97-1124 FRAME GRND WIRE RTG NGP

P97-1078 INSTL - FRAMEGROUND STUD

### **3P31-D10-YAC HEATER CORD RECPT MTD LH UNDER**

HEATER CORD RECPT MTD LH UNDER

SHOP NOTES: BM CONTAINS NO PARTS

SHOP NOTE: HEATER CORD RECEPTACLE TO  
BE MTD LH UNDER CAB.

### **3P31-D11-CAC WATER IN FUEL (WIF) JUMPER EXTENSION**

WATER IN FUEL (WIF) JUMPER EXTENSION

SHOP NOTE: CONNECT JUMPER FROM ENGINE

HARNESS TO WIF SENSOR ON FUEL FILTER.

P92-5562-1000	JUMPER - WIF EXTENSION	1
---------------	------------------------	---

### **3P31-D16-GAE RP1226 KIT AND LABEL**

RP1226 KIT AND LABEL

IN THE SHIP LOOSE BOX WITH LITERATURE.

### **3P31-D16-HBV BRKT & FUSE PACK FOR BTRY BOX**

BRKT & FUSE PACK FOR BTRY BOX

P27-1257-13ZZZ0	Fuse Holder	1
-----------------	-------------	---

W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25)	2
------------------	------------------------------	---

W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	4
------------------	---	---

W20-6011-05TDY0Z	Flanged Lock Nut (M5 x 0.80)	2
------------------	------------------------------	---

R34-6002-06025RF0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	7
--------------------	---	---

K363-338-2-250	Flat Washer (1/4")	8
----------------	--------------------	---

P11-1655	BRACKET - FUSE HOLDER	1
----------	-----------------------	---

P93-1083-102 ASSY - FUSE VMUX BTRY BOX

### **3P31-D80-BAE ENGINE DIAGRAMS**

ENGINE DIAGRAMS

P94-2103 DIAG-2013 ISX12/15

### **3P31-D80-TAC BATTERY CABLE DIAGRAMS**

BATTERY CABLE DIAGRAMS

P94-6457-00000 DIAG BATTERY CABLE

P94-6457-00000 DIAG BATTERY CABLE

P94-6457-00000 DIAG BATTERY CABLE

P94-6457-00000 DIAG BATTERY CABLE

P94-6457-00000 DIAG BATTERY CABLE

### **3P31-D90-AAC TRANS HARNESS ROUTINGS**

TRANS HARNESS ROUTINGS

K028-2489-5	90° Standoff Bracket	2
-------------	----------------------	---

A62-6084	Cable Tie Mount	2
----------	-----------------	---

RT255R0H1R	Cable Tie	2
------------	-----------	---

P95-1804 RTG-MANUAL TRANS HARNESS

### **3P31-D90-BFE \* BENDIX ABS ELECTRIC MODULE**

\* BENDIX ABS ELECTRIC MODULE

Q27-1040-301	EC-80 ESP CAB ECU	1
--------------	-------------------	---

S34-6003-0525TP00B

PSD Screw, Black (M5 x 0.80 4  
x 25mm)

### **3P31-D90-CAC YAW RATE SENSOR**

YAW RATE SENSOR

K190676BX	SENSOR- YAW ACCELERATION	1
K363-338-2-438	Flat Washer (7/16")	1
W34-1163-020	BOLT-FINISHED HEX M10	1

P97-6591 INSTL-YAW SENSOR

### **3P31-D90-DAC CHASSIS HARNESS ROUTING**

CHASSIS HARNESS ROUTING

P16-1001-029	Edge Clip, Two-Piece	1
156-00070	Cable Tie Mount	1
P16-1006-100	Fir Tree Clip	1

A95-1015 RTG - CHASSIS 2.1M VECU

### **3P31-D90-EAF ABS SENSOR LEAD PASS-THRU - GROMMET**

ABS SENSOR LEAD PASS-THRU - GROMMET

A42-1007	GROMMET - FRONT ABS , WO2	
----------	---------------------------	--

G97-6105 INSTL-FRONT ABS GROMMET

### **3P31-D90-FAC FIREWALL ROUTING**

FIREWALL ROUTING

W11-1036	Standoff Bracket Assembly	1
22-01618-002	Cable Tie, Heavy Duty	2
W11-6070	BRACKET-STANDOFF, 90 DE	1

P95-2083 - ROUTING - FIREWALL

R97-1710 INSTAL - TREADLE RELIEF B

A95-6064 RTG - FIREWALL HARNESS

### **3P31-D90-HAM RELAY BOX MTG BRKT OUTBOARD**

RELAY BOX MTG BRKT OUTBOARD

P62-6051	MOUNT-CONN, ENG-TO-AFT	1
156-00070	Cable Tie Mount	1

P97-6869 INTSL - CONN, ENG-TO-AFT

P97-6769 INSTL - FIREWALL GROUND STRAP

### **3P31-D91-ABX ENGINE HARNESS ROUTING**

ENGINE HARNESS ROUTING

ROUTE OVER XMSN EATON FR

D11-6285	Standoff Bracket	1
K231-363-172	Tie Strap	2
K11-1282	Standoff Bracket Assembly	1
P11-1460	BRACKET - ENGINE HARNESS	1
K041-803-20CA	Hex Bolt (M8 x 1.25 x 20mm)	1
K363-338-2-312	Flat Washer (5/16")	2
Y84-6000-017	Tie Strap, Dual Loop	3
A62-6084	Cable Tie Mount	11
T255R0H1R	Tie Down Strap, Heavy Duty	14
Y84-6000-016	Tie Strap, Button Head	1
HDM3120H1R	Cable Tie Mount	1
05-16871	Hose Support, Steel	1
W34-1159-040	Hex Bolt (M12 x 1.75 x 40mm)	1

K041-802-25CA	Hex Bolt (M6 x 1.00 x 25mm)	10
K169-163-6CA	Hex Nut, Steel (M3)	13
K169-163-8CA	Locking Hex Nut (M8 x 1.25)	7
K028-2489-2	90° Standoff Bracket	3
W34-1162-010	Washer (10MM)	2
K363-338-2-250	Flat Washer (1/4")	24
K363-338-2-312	Flat Washer (5/16")	9
K231-363HTMP	Cable Tie	3
G11-1483	Routing Bracket Assembly	3
K028-2489-26	90° Standoff Bracket	2
K041-803-20CA	Hex Bolt (M8 x 1.25 x 20mm)	1
K041-803-35CA	Hex Bolt (M8 x 1.25 x 35mm)	1
K041-809-30	Hex Bolt (M8 x 1.25 x 30mm)	1
W34-1163-025	Hex Bolt (M10 x 1.50 x 25mm)	2
K363-338-1-500	Flat Washer (1/2")	1
HDM3120H1R	Cable Tie Mount	2
K028-2489-24	90° Standoff Bracket	1
P11-1192	BRACKET- HARN RTG, ISX10	1
P16-1001-029	Edge Clip, Two-Piece	1

*SHOP NOTE: SECURE SHIELD TO BRKT USING  
ADDITIONAL ZIP TIES*

*P95-2244 ROUTING - WASHER HARNESS*

*D95-6263 ROUTING-ENG X15, 2024*

*D95-6273 ROUTING-X15 ENGINE HARNESS*

### **3P31-D91-BAJ AFTERTREATMENT HARNESS ROUTING**

*AFTERTREATMENT HARNESS ROUTING*

RT255R0H1R	Cable Tie	11
DSWS4	Dual Swivel Saddle Spacer	4
BT100L	Tie Strap - Button Head	1
75000349	Windlace - Molding, Bulk	1
P16-1006-100	Fir Tree Clip	1

*M95-1064-110 RTG - MLU AFTMNT, 2021*

*M95-6146 RTG-AFTM EPA, 2024*

*M95-6147 RTG-AFTM CARB, 2024*

### **3P31-D92-BAD 4TH BAY BLOCK OFF PLATE**

*4TH BAY BLOCK OFF PLATE*

*SHOP NOTE: INSERT P22-1059 IN OPEN*

*PASS THRU PLATE P62-1014 WHERE 4TH BAY*

*CONNECTOR IS LOCATED AT FIREWALL.*

P22-1059	Plate - Block Off FW Assy	1
----------	---------------------------	---

### **3P31-S80-AAE BASIC SERVICE DIAGRAMS**

*BASIC SERVICE DIAGRAMS*

*P94-2409 DIAG-ACC OPT HD VMUX*

*P94-2409 DIAG-ACC OPT HD VMUX*

*P94-2409 DIAG-ACC OPT HD VMUX*

*P94-2409 DIAG-ACC OPT HD VMUX*

*P94-2413 DIAG-CHARGE & START*

*P94-2413 DIAG-CHARGE & START*

*P94-2413 DIAG-CHARGE & START*

*P94-2413 DIAG-CHARGE & START*

P94-2407 DIAG-HVAC  
P94-2407 DIAG-HVAC  
P94-2407 DIAG-HVAC  
P94-2407 DIAG-HVAC  
P94-2420 DIAG-INSTRUMENT  
P94-2420 DIAG-INSTRUMENT  
P94-2420 DIAG-INSTRUMENT  
P94-2420 DIAG-INSTRUMENT  
P94-2422 DIAG-J1939  
P94-2422 DIAG-J1939  
P94-2422 DIAG-J1939  
P94-2422 DIAG-J1939  
P94-2424 DIAG-LIGHTING EXT  
P94-2424 DIAG-LIGHTING EXT  
P94-2424 DIAG-LIGHTING EXT  
P94-2424 DIAG-LIGHTING EXT  
P94-2425 DIAG-LIGHTING INT  
P94-2425 DIAG-LIGHTING INT  
P94-2425 DIAG-LIGHTING INT  
P94-2425 DIAG-LIGHTING INT  
P94-2430 DIAG-SAFETY SYSTEMS  
P94-2430 DIAG-SAFETY SYSTEMS  
P94-2430 DIAG-SAFETY SYSTEMS  
P94-2430 DIAG-SAFETY SYSTEMS  
P94-2432 DIAG-TPMS  
P94-2432 DIAG-TPMS  
P94-2432 DIAG-TPMS  
P94-2432 DIAG-TPMS  
P94-2436 DIAG-WIPER/WASH/HORN  
P94-2436 DIAG-WIPER/WASH/HORN  
P94-2436 DIAG-WIPER/WASH/HORN  
P94-2436 DIAG-WIPER/WASH/HORN  
P94-2317 DIAG-DOORS  
P94-2317 DIAG-DOORS  
P94-2317 DIAG-DOORS  
P94-2317 DIAG-DOORS  
P94-2308 DIAG-TRANSMISSION VECU  
P94-2308 DIAG-TRANSMISSION VECU  
P94-2308 DIAG-TRANSMISSION VECU  
P94-2308 DIAG-TRANSMISSION VECU  
P94-2330 DIAG-MUX SWITCHES  
P94-2330 DIAG-MUX SWITCHES  
P94-2330 DIAG-MUX SWITCHES  
P94-2330 DIAG-MUX SWITCHES  
P94-2474 DIAG-REMOTE DIAGNOST  
P94-2474 DIAG-REMOTE DIAGNOST  
P94-2474 DIAG-REMOTE DIAGNOST  
P94-2474 DIAG-REMOTE DIAGNOST  
P94-2415 DIAG-EOA  
P94-2415 DIAG-EOA  
P94-2415 DIAG-EOA

P94-2415 DIAG-EOA

### **3P31-S80-GAE TRAILER DIAGRAM**

TRAILER DIAGRAM

P94-2433 DIAG-TRAILER CABLES

### **3P31-S80-HAE TELEMATICS DIAGRAM**

TELEMATICS DIAGRAM

P94-2429 DIAG-TELEMATICS VMUX

P94-2429 DIAG-TELEMATICS VMUX

P94-2429 DIAG-TELEMATICS VMUX

### **3P31-S80-KAC HVAC DIAGRAM**

HVAC DIAGRAM

P94-2322 DIAGRAM - HVAC

### **3P31-S80-LAD CHASSIS OPTION DIAGRAM**

CHASSIS OPTION DIAGRAM

P94-2316 DIAG-CHASSIS OPTIONS

### **3P31-S80-MAD ABS DIAGRAM**

ABS DIAGRAM

P94-2408 DIAG-ABS HD VMUX

P94-2408 DIAG-ABS HD VMUX

P94-2408 DIAG-ABS HD VMUX

P94-2408 DIAG-ABS HD VMUX

P94-2408 DIAG-ABS HD VMUX

### **3P31-S80-NAD AUDIO DIAGRAM**

AUDIO DIAGRAM

P94-2312 DIAG-AUDIO

P94-2312 DIAG-AUDIO

P94-2312 DIAG-AUDIO

P94-2312 DIAG-AUDIO

P94-2312 DIAG-AUDIO

### **3P33-S00-BAC COMMUNICATION - CB/VHF RADIO FUSES**

COMMUNICATION - CB/VHF RADIO FUSES

P27-1023-10 Mini Fuse (10 AMP) 1

SHOP NOTE: PLUG P27-1023-10 IN THE  
FOLLOWING POS ON DASH SIDE CAB PDC:  
POS-R7-"R7 CB/VHF"

### **3P33-S00-KCB EXT LIGHTS - FLOOD/BEACON LAMP FUSES**

EXT LIGHTS - FLOOD/BEACON LAMP FUSES

P27-1253 Relay, Micro 2

SHOP NOTE: PLUG P27-1253 IN THE  
FOLLOWING POS ON DASH SIDE CAB PDC:  
POS-D3-"CK D3 FLOOD LP1 RELAY"  
POS-B1-"CK B1 FLOOD LP2 RELAY"

P27-1023-15 Mini Fuse, Blue (15 AMP) 2

SHOP NOTE: PLUG P27-1023-15 IN THE  
FOLLOWING POS ON DASH SIDE CAB PDC:  
POS-A3-"A3 FLOOD LP1 15A"  
POS-A1-"A1 FLOOD LP2 15A"

### **3P33-S02-BAD RADIO WAKE UP FUSE**

RADIO WAKE UP FUSE

P27-1023-10 Mini Fuse (10 AMP) 1

SHOP NOTE: PLUG P27-1023-10 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-R18-"R18 RADIO WAKEUP"

#####PD BOX IMPACT! VERIFY ID & FORMAT

### **3P33-S04-AAK STANDARD POLYSWITCHES**

STANDARD POLYSWITCHES

BD280-1130-10/16 Polyswitch (10 AMP) 2

SHOP NOTE: PLUG BD280-1130-10/16 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-E6-"E6 CAB DOME LAMP"

POS-K14-"K14 SUSP/CHASSIS"

P27-1023-15 Mini Fuse, Blue (15 AMP) 3

SHOP NOTE: PLUG P23-1023-15 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-P7-"P7 AIR DRYER"

POS-N19-"N19 LH MIRROR"

POS-N11-"N11 RH MIRROR"

P27-1023-10 Mini Fuse (10 AMP) 6

SHOP NOTE: PLUG P23-1023-10 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-K7-"K7 HORN"

POS-K8-"K8 CAB MARKER LAMP"

POS-K15-"K15 MISC LOW CURR"

POS-K16-"K16 PARK LP-CAB"

POS-P13-"P13 KEY PWR SW"

POS-P14-"P14 DIGI DISPLAY PWR 2"

### **3P33-S04-BAM COMMUNICATION - SATELLITE SYSTEM FUSES**

COMMUNICATION - SATELLITE SYSTEM FUSES

P27-1023-10 Mini Fuse (10 AMP) 2

SHOP NOTE: PLUG P27-1023-10 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:

POS-E9-"E9 TELEMATICS (BAT)"

POS-R8-"R8 QCOM/LDWS/RMT DIAG"

### **3P33-S04-CAM ENGINE FUSES AND RELAYS**

ENGINE FUSES AND RELAYS

P27-1253 Relay, Micro 3

SHOP NOTE: PLUG P27-1253 IN THE FOLLOWING POS ON ENGINE SIDE CAB PDC:

POS-C6-"EK C6 DEF PUMP"

POS-C4-"EK C4 LINE HEAT 3"

POS-C8-"EK C8 LINE HEAT 2"

P27-1023-05 Mini Fuse (5 AMP) 2

SHOP NOTE: PLUG P27-1023-05 IN THE FOLLOWING POS ON ENGINE SIDE CAB PDC:

POS-E2-"E2 ENG ECU WAKE (ENG SD)"

POS-A5-"A5 LINE HEAT 3 (SUCTION)"

P27-1023-15 Mini Fuse, Blue (15 AMP) 5

SHOP NOTE: PLUG P27-1023-15 IN THE FOLLOWING POS ON ENGINE SIDE CAB PDC:

POS-A10-"A10 AUX TRAN/LIFT PUMP"

POS-G9-"G9 CUM AFT"

POS-A2-"A2 LINE HEAT 1 (PRESSURE)"  
 POS-A7-"A7 DEF PUMP/DPF/SCR"  
 POS-A9-"A9 LINE HEAT 2 (BACKFLOW)"  
 P27-1023-20 Mini Fuse, Yellow (20 AMP) 1  
 SHOP NOTE: PLUG P27-1023-20 IN THE  
 FOLLOWING POS ON ENGINE SIDE CAB PDC:  
 POS-L10-"L10 TRICAN/DEF CTL/DOSER"  
 P27-1023-30 Mini Fuse (30 AMP) 1  
 SHOP NOTE: PLUG P27-1023-30 IN THE  
 FOLLOWING POS ON ENGINE SIDE CAB PDC:  
 POS-N11-"N11 CUM ECM PWR"  
 P27-1023-10 Mini Fuse (10 AMP) 1  
 SHOP NOTE: PLUG P27-1023-10 IN THE  
 FOLLOWING POS ON DASH SIDE CAB PDC:  
 POS-A6-"A6 BODY IGNITION PWR"  
 ### PD BOX IMPACT! VERIFY ID & FORMAT

### **3P33-S04-FAE TRAILER FUSES AND RELAYS**

TRAILER FUSES AND RELAYS  
 P27-1150 Relay, Micro 280 2  
 SHOP NOTE: PLUG P27-1150 IN THE  
 FOLLOWING POS ON ENGINE SIDE CAB PDC:  
 POS-F7-"EK F7 TRAILER STOP RELAY"  
 POS-F5-"EK F5 MARKER LP TRLR RELAY"  
 P27-1023-30 Mini Fuse (30 AMP) 1  
 SHOP NOTE: PLUG P27-1023-30 IN THE  
 FOLLOWING POS ON DASH SIDE CAB PDC:  
 POS-K20-"K20 TRLR HOTLINE 30A"  
 P27-1023-15 Mini Fuse, Blue (15 AMP) 1  
 SHOP NOTE: PLUG P27-1023-15 IN THE  
 FOLLOWING POS DASH SIDE CAB PDC:  
 POS-N20-"N20 PARK LP-TRLR 15A"  
 P27-1023-30 Mini Fuse (30 AMP) 2  
 SHOP NOTE: PLUG P27-1023-30 IN THE  
 FOLLOWING POS ON ENGINE SIDE CAB PDC:  
 POS-J8-"J8 TRLR STOP 30A"  
 POS-J5-"J5 TRLR MARKER LP 30A"  
 P27-1023-25 Mini Fuse, Clear (25 AMP) 1  
 SHOP NOTE: PLUG P27-1023-25 IN THE  
 FOLLOWING POS ON ENGINE SIDE CAB PDC:  
 POS-L1-"L1 TRLR ABS 25A"  
 P27-1150 Relay, Micro 280 1  
 SHOP NOTE: PLUG P27-1150 IN THE  
 FOLLOWING POS ON DASH SIDE CAB PDC:  
 POS-R11-"CK R11 TRAILER ABS RELAY"

### **3P33-S04-GAG TRANSMISSION FUSES AND RELAYS**

TRANSMISSION FUSES AND RELAYS  
 P27-1023-10 Mini Fuse (10 AMP) 1  
 SHOP NOTE: PLUG P27-1023-10 IN THE  
 FOLLOWING POS ON ENGINE SIDE CAB PDC:  
 POS-J7-"J7 BACKUP LAMP 10A IGN"

### **3P33-S04-HAC SAFETY - ABS FUSE**

**SAFETY - ABS FUSE**

P27-1023-30 Mini Fuse (30 AMP) 1

*SHOP NOTE: PLUG P27-1023-30 IN THE FOLLOWING POS ON ENGINE SIDE CAB PDC:  
POS-A8-"A8 CAB ABS 30A BATT"*

*### PD BOX IMPACT! VERIFY ID & FORMAT*

**3P33-S04-LAC OPTIONAL CHASSIS MODULE FUSES****OPTIONAL CHASSIS MODULE FUSES**

P27-1023-15 Mini Fuse, Blue (15 AMP) 1

*SHOP NOTE: PLUG P27-1023-15 AMP IN THE FOLLOWING POS ON DASH SIDE CAB PDC:  
POS-E10-"E10 OCM F2 15A BATT"*

P27-1023-20 Mini Fuse, Yellow (20 AMP) 2

*SHOP NOTE: PLUG P27-1023-20 AMP IN THE FOLLOWING POS ON DASH SIDE CAB PDC:  
POS-C10-"C10 OCM TRLR OPT, SNOWPL"  
POS-K19-"K19 OCM F3 20A BATT"*

P27-1023-20 Mini Fuse, Yellow (20 AMP) 2

*SHOP NOTE: PLUG P27-1023-20 AMP IN THE FOLLOWING POS ON ENGINE SIDE CAB PDC:  
POS-G4-"G4 OCM F4 20A BATT"  
POS-J6-"J6 OCM F5 20A BATT"*

P27-1023-25 Mini Fuse, Clear (25 AMP) 1

*SHOP NOTE: PLUG P27-1023-25 AMP IN THE FOLLOWING POS ON ENGINE SIDE CAB PDC:  
POS-E3-"E3 OCM F6 25A BATT"*

*POS-E3-"E3 OCM F6 25A BATT"*

*POS-E3-"E3 OCM F6 25A BATT"*

**3P33-S10-AAR CAB POWER DISTRIBUTION CENTER - VMUX****CAB POWER DISTRIBUTION CENTER - VMUX**

P27-1297-0101 Cab Power Distribution 1

Center Fuse Assembly

S53-1383-111 LABEL - CAB PDC ENG SIDE 1

S53-1383-211 LABEL - CAB PDC ENG SIDE 1

W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25) 6

*P27-1023-05 FUSE-MINI 5A*

*SHOP NOTE: PLUG P27-1023-05 IN THE FOLLOWING POS ON DASH SIDE CAB PDC:  
POS-B9-"B9 MSM/SMARTWHEEL"  
POS-J9-"J9 DIAG PWR"*

*POS-J9-"J9 DIAG PWR"*

*POS-J10-"J10 VECU LVD V SENSE"*

*POS-K17-"K17 VECU/DIGI DISPLAY IGN"*

*POS-K18-"K18 RH STALK 5A IGN"*

*POS-P18-"P18 HVAC HEAD ACC"*

*POS-R9-"R9 VECU ACC PWR"*

*P27-1023-10 FUSE-MINI 10A*

*SHOP NOTE: PLUG P27-1023-10 IN THE FOLLOWING POS ON DASH SIDE CAB PDC*

*POS-A7-"A7 RP1226 IGN"*

*POS-A8-"A8 RP1226 BATT"*

*POS-B4-"B4 VECU BATT PWR 2"*

*POS-M7-"M7 SPLICE FEED, IGN"*

*POS-B3-"B3 GAUGE CLUSTER"*

P97-1023-15 FUSE-MINI 15A

SHOP NOTE: PLUG P27-1023-15 IN THE FOLLOWING POS ON DASH SIDE CAB PDC  
POS-C9-"C9 CB/RADIO POWER"

POS-E4-"E4 POWERPORT 1 LVD"

POS-E5-"E5 POWERPORT 2 LVD"

P27-1023-05 FUSE-MINI 5A

SHOP NOTE: PLUG P27-1023-05 IN THE FOLLOWING POS ON ENGINE SIDE CAB PDC  
POS-B12-"B12 HVAC HEAD PWR / D AJAR"

P27-1023-10 FUSE-MINI 10A

SHOP NOTE: PLUG P27-1023-10 IN THE FOLLOWING POS ON ENG SIDE CAB PDC  
POS-A4-"A4 SCM/OCM/MSB IGN"

POS-D12-"D12 A/C CLUTCH"

POS-G3-"G3 MUX SOL BNK 1"

POS-G10-"G10 VECU BATT PWR 1"

POS-J1-"J1 CAB ABS POWER-10A IGN"

P27-1023-15 FUSE-MINI 15A

SHOP NOTE: PLUG P27-1023-15 IN THE FOLLOWING POS ON ENG SIDE CAB PDC  
POS-L8-"L8 AFT MX/CUM (CNG/LNG)"

P27-1023-20 FUSE-MINI 20A

SHOP NOTE: PLUG P27-1023-20 IN THE FOLLOWING POS ON ENG SIDE CAB PDC  
POS-A6-"A6 HDLP LH HI/BRAKE"

POS-J3-"J3 LH HDLP LO/DRL/PRK"

POS-J4-"J4 SCM F7"

P27-1023-25 FUSE-MINI 25A

SHOP NOTE: PLUG P27-1023-25 IN THE FOLLOWING POS ON ENG SIDE CAB PDC  
POS-A11-"A11 WIPER MOTOR"

POS-J2-"J2 RH HDLP LO/DRL/PRK"

POS-L2-"L2 HDLP RH HI/FOG/DRL"

POS-J10-"J10 WIPER"

POS-N2-"N2 SCM F5"

POS-N3-"N3 SCM F6"

0495030 FUSE-JCASE 30A

SHOP NOTE: PLUG 0495030 IN THE FOLLOWING POS ON ENG SIDE CAB PDC  
POS-G1-"G1 HVAC BLDC MOTOR"

0495030 FUSE-JCASE 30A

SHOP NOTE: PLUG 0495030 IN THE FOLLOWING POS ON DASH SIDE CAB PDC  
POS-F5-"F5 RH DOOR MODULE"

POS-H5-"H5 LH DOOR MODULE"

P96-1140 SCHEM-PCB CAB PDC 2.1M

### **3P33-S10-CAD FIREWALL GROUND**

FIREWALL GROUND

P20-1485

CONNECTOR - GRND BUS 1  
BAR

W20-6011-06TDY0Z	Exterior Threaded Hex Screw 2 (M6 x 1.00 x 25mm)
W20-6011-06TDY0Z	Exterior Threaded Hex Screw 3 (M6 x 1.00 x 25mm)
W20-6011-06TDY0Z	Exterior Threaded Hex Screw 3 (M6 x 1.00 x 25mm)

*SHOP NOTE: FIREWALL GROUND STUD TORQUE  
VALUE 50 IN-LBS MAX*

### **3P33-S10-DAJ FIREWALL PASS-THRU**

#### *FIREWALL PASS-THRU*

P62-1014	Mount-Firewall Pass Thru	1
P16-1002	CLIP-F/W PASS THRU	4
P11-1220	BRACKET-F/W HARNESS	1
S34-6003-0619RXL0B	Torx Screw (M6 x 1.00 x 19mm), Black	6

### **3P34-D00-ANW BATTERY CABLES - LHUC**

#### *BATTERY CABLES - LHUC*

N92-6006-2AAAS0060	CABLE-BATTERY,(POS) ASSY	1
N92-6006-2AAAS0040	CABLE-BATTERY,(POS) ASSY	1
N92-6006-2ABAL0280	CABLE-BATTERY,(POS) ASSY	2
N92-6007-2AABS0230	CABLE-BATTERY, (NEG) ASSY	2

### **3P34-D00-WAC UNDER HOOD JUMP START TERMINALS**

#### *UNDER HOOD JUMP START TERMINALS*

N92-6006-2B8VU0110	CABLE-BATTERY,(POS) ASSY	1
N92-6007-2A8BU0100	CABLE-BATTERY, (NEG) ASSY	1

#### *A95-1009 - RTNG-JUMP START TERM U/HOOD*

### **3P34-D04-AAJ JUMP START BRACKETS**

#### *JUMP START BRACKETS*

#### *W/ GREASE BANK*

P11-1462	BRACKET - JUMP START	1
----------	----------------------	---

*\*\*\*\* SHOP NOTE \*\*\*\**

*TOP POSITION ON BRKT IS FOR NEG*

*JUMPSTART TERMINAL*

*BOTTOM POSITION IS FOR POS JUMPSTART  
TERMINAL*

*MOUNT BOTH TERMINALS FACING FORWARD*

*A96-1547 DRLG - BATT JUMPER TERMINAL*

*A96-1547 DRLG - BATT JUMPER TERMINAL*

### **3P34-D04-BAK BATTERY CABLE HARDWARE**

#### *BATTERY CABLE HARDWARE*

K363-371CA	Flat Washer (M12)	2
P27-1086-100	Battery Disconnect Switch, Single Pole	2
N80-1025	Spacer, Disconnect Switch	2
NL10	WASHER-NORDLOCK, M10	4
27-00498-006	Star Washer, Internal Tooth (3/8")	4

*SHOP NOTE: USE P95-1773 FOR ASSY  
OF WASHERS ON DISC SW.  
BE SURE BOTH HALVES OF NORDLOCK*

WASHERS ARE PRESENT WHEN INSTALLED.  
 P95-1773 INSTR - BATTERY DISC  
 SHOP NOTE: CONNECT THE TERMINAL LABL D  
 "BATTERY DISCONNECT SW" ON  
 P92-2818-XXXXX TO THE "STARTER" SIDE  
 OF BATTERY DISCONNECT SWITCH.

### **3P34-D04-EHU BATTERY BOX/ ALTERNATOR HARNESS**

BATTERY BOX/ ALTERNATOR HARNESS

N92-6006-8ABS10040	Battery Cable, Positive	1
P92-2818-500000	Power Feed Harness	1

### **3P41-D00-AAF CB RADIO**

CB RADIO

W3506GM	Speaker, Dual Cone (3-1/2")	1
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	2
PP107176	CB-29LXOEM, KIT	1

### **3P42-D00-ACD KENWORTH RADIO W/ AM/FM/WB/USB/**

KENWORTH RADIO W/ AM/FM/WB/USB/  
 BLUETOOTH/SATELLITE

PP107180-7303211200	RADIO-APTIV, DEA700	1
PP207236	ADAPTER-FAKRA TO MOTOROLA	1

### DASH IMPACT! RERUN DASH

### **3P42-D00-BAM SPEAKER INSTALLATION**

SPEAKER INSTALLATION

PP307006	SPKR-4X6 COAX, FOAM	2
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	8

### **3P43-D00-AED ANTENNA**

ANTENNA

W20-6011-05TDY0Z	Flanged Lock Nut (M5 x 0.80)	2
PP407031	Antenna (AM/FM/WB/SXM/GPS & Cell)	1
PP504839	CB Cable w/ Grommet	2
PP505003	ANTENNA-CB, WRAPPED, KW	2

R97-1514-000 INSTL-SIDEWALL GROMMETS

R97-1630 INSTL - ANTENNA COMBINATION

### **3P53-D00-FBQ BACK-UP ALARM / EXT AUDIBLE ALARM**

BACK-UP ALARM / EXT AUDIBLE ALARM

P49-1004	ALARM-VARIABLE, BACKUP AS	1
K041-803-30CA	Hex Bolt (M8 x 1.25 x 30mm)	4
K169-163-8CA	Locking Hex Nut (M8 x 1.25)	4
K363-338-2-312	Flat Washer (5/16")	8
Y84-6000-015	Strap-Tie	1

P97-1036-001 INSTL - BACKUP ALARM

### **3Q00-D00-AAY 15" DRIVER INFO DIGITAL DISPLAY**

15" DRIVER INFO DIGITAL DISPLAY

Q43-1202-100-100	DISPLAY-DRIV INFO 15 KW	1
S34-6003-0525TP00B		

PSD Screw, Black (M5 x 0.80 4  
x 25mm)

### **3Q00-D01-AAD FUEL FILTER RESTRICTION GAUGE**

*FUEL FILTER RESTRICTION GAUGE*

Q43-1171-309-100	LIN-KW FUEL FILT REST	1
Q20-1002	Gauge Mount Nut	1

### **3Q00-D01-BAE ENGINE OIL TEMPERATURE GAUGE - ENGLISH**

*ENGINE OIL TEMPERATURE GAUGE - ENGLISH*

Q43-1171-106-100	LIN-KW ENG OIL TEMP	1
Q20-1002	Gauge Mount Nut	1

### **3Q00-D01-DAE TURBO BOOST GAUGE - ENGLISH**

*TURBO BOOST GAUGE - ENGLISH*

Q43-1171-111-100	LIN-KW TURBO BOOST	1
Q20-1002	Gauge Mount Nut	1

### **3Q00-D01-HAJ REAR AXLE OIL TEMP GAUGE - ENGLISH**

*REAR AXLE OIL TEMP GAUGE - ENGLISH*

Q43-1171-119-100	LIN-KW FRT DRV AXLE TMP	1
Q20-1002	Gauge Mount Nut	1

### **3Q00-D01-LAE AIR FILTER RESTRICTION GAUGE**

*AIR FILTER RESTRICTION GAUGE*

Q43-1171-306-100	LIN-KW AIR FILT REST	1
Q20-1002	Gauge Mount Nut	1

### **3Q00-D04-DAC REAR AXLE OIL TEMP SENSOR**

*REAR AXLE OIL TEMP SENSOR*

K028-2489-35	BRACKET-90 DEG STANDOFF	1
Q21-1002	Temperature Sensor	1

### **3Q00-D07-AAC AIR SUSPENSION PRESS GAUGE**

*AIR SUSPENSION PRESS GAUGE*

Q20-1002	Gauge Mount Nut	1
Q43-1136-103	GAUGE-AIR SUSP PRESS NG	1

### **3Q00-D10-ZAG HARNESS - OPTIONAL GAUGES**

*HARNESS - OPTIONAL GAUGES*

P92-2192-0175	CVSG Wiring Harness (175mm)	5
---------------	--------------------------------	---

### **3Q00-D14-BAE PTO ENGAGED TELLTALE - BLANK**

*PTO ENGAGED TELLTALE - BLANK*

Q30-1008-502000000	PRMTR-OT BLANK, TELLTALE - PTO NOT IN CHASSIS.	1
--------------------	---	---

### **3Q00-D14-CAC RANGE INHIBIT TELLTALE - BLANK**

*RANGE INHIBIT TELLTALE - BLANK*

Q30-1008-503000000	PRMTR-BLANK TELLTALE - POSITION 3 BLANK	1
--------------------	--	---

### **3Q00-D14-EAE WINCH TELLTALE - BLANK**

*WINCH TELLTALE - BLANK*

Q30-1008-505000000	PRMTR - OT BLANK TELLTALE - WINCH NOT IN CHASSIS.	1
--------------------	--	---

### **3Q00-D14-FAE OVERSPEED SHUTDOWN TELLTALE - BLANK**

*OVERSPEED SHUTDOWN TELLTALE - BLANK*

Q30-1008-506000000	PRMTR - OT BLANK	1
--------------------	------------------	---

*TELLTALE - EOAS NOT IN CHASSIS.*

**3Q00-D18-DAC TRAILER BRAKE VALVE TELLTALE**

*TRAILER BRAKE VALVE TELLTALE*

*BM CONTAINS NO PARTS*

*SHOP NOTE: CONNECT IP HARNESS BREAKOUT*

*"EDITABLE TELLTALE 1" TO BREAK OUT*

*FOR "J002 TRLR BRK EDITABLE TELLTALE"*

**3Q00-D20-AAN CAB HVAC CONTROLS W/ DEG F TEMP GRAPH**

*CAB HVAC CONTROLS W/ DEG F TEMP GRAPH*

F21-1047-10012 HVAC CONTROL HEAD 1

**3Q00-S10-A30 PARAMETER FOR VEHICLE MODEL**

*PARAMETER FOR VEHICLE MODEL*

Q30-1003-0010NGPT8 MODEL PRMTR - ABS 6 1

**3Q00-S10-B06 PARAMETER FOR COMMODITY HAULED**

*PARAMETER FOR COMMODITY HAULED*

**3Q00-S10-C01 PARAMETER FOR VEHICLE TYPE**

*PARAMETER FOR VEHICLE TYPE*

**3Q00-S10-D99 PARAMETER FOR BODY TYPE**

*PARAMETER FOR BODY TYPE*

**3Q00-S10-E06 PARAMETER FOR TRAILER TYPE**

*PARAMETER FOR TRAILER TYPE*

**3Q00-S10-F01 PARAMETER FOR ABS CONFIGURATION**

*PARAMETER FOR ABS CONFIGURATION*

**3Q00-S10-G01 PARAMETER FOR REAR DRIVE AXLE CONFIG**

*PARAMETER FOR REAR DRIVE AXLE CONFIG*

**3Q00-S10-H01 PARAMETERS FOR DISTANCE TO PUSHER 1**

*PARAMETERS FOR DISTANCE TO PUSHER 1*

*\* ANY DIMENSION IN HUNDREDS 0XX*

*\* ANY DIMENSION IN TENS X0X*

**3Q00-S10-J01 PARAMETERS FOR DISTANCE TO PUSHER 2**

*PARAMETERS FOR DISTANCE TO PUSHER 2*

*\* ANY DIMENSION IN HUNDREDS 0XX*

*\* ANY DIMENSION IN TENS X0X*

**3Q00-S10-K01 PARAMETERS FOR DISTANCE TO PUSHER 3**

*PARAMETERS FOR DISTANCE TO PUSHER 3*

*\* ANY DIMENSION IN HUNDREDS 0XX*

*\* ANY DIMENSION IN TENS X0X*

**3Q00-S10-L01 PARAMETERS FOR DISTANCE TO PUSHER 4**

*PARAMETERS FOR DISTANCE TO PUSHER 4*

*\* ANY DIMENSION IN HUNDREDS 0XX*

*\* ANY DIMENSION IN TENS X0X*

**3Q00-S10-M01 PARAMETERS FOR DISTANCE TO TAG 1**

*PARAMETERS FOR DISTANCE TO TAG 1*

*\* ANY DIMENSION IN HUNDREDS 0XX*

*\* ANY DIMENSION IN TENS X0X*

**3Q00-S10-N01 PARAMETER FOR DISTANCE TO TAG 2**

*PARAMETER FOR DISTANCE TO TAG 2*

**3Q00-S10-P01 PARAMETER FOR PUSHER 1 TYPE**

*PARAMETER FOR PUSHER 1 TYPE*

**3Q00-S10-Q01 PARAMETER FOR PUSHER 2 TYPE***PARAMETER FOR PUSHER 2 TYPE***3Q00-S10-R01 PARAMETER FOR PUSHER 3 TYPE***PARAMETER FOR PUSHER 3 TYPE***3Q00-S10-S01 PARAMETER FOR PUSHER 4 TYPE***PARAMETER FOR PUSHER 4 TYPE***3Q00-S10-T01 PARAMETER FOR TAG 1 TYPE***PARAMETER FOR TAG 1 TYPE***3Q00-S10-U01 PARAMETER FOR TAG 2 TYPE***PARAMETER FOR TAG 2 TYPE***3Q00-S10-W02 PARAMETER FOR FRONT AXLE TRACK WIDTH***PARAMETER FOR FRONT AXLE TRACK WIDTH***3Q00-S10-X09 PARAMETER FOR GROSS COMBO WEIGHT***PARAMETER FOR GROSS COMBO WEIGHT***3Q00-S10-Y05 PARAMETER FOR GAWR STEER AXLE (LBS)***PARAMETER FOR GAWR STEER AXLE (LBS)***3Q00-S10-Z09 PARAMETER FOR GAWR INDIVIDUAL REAR***PARAMETER FOR GAWR INDIVIDUAL REAR  
AXLE (LBS)***3Q00-S11-B10 PARAMETER FOR STEERING GEAR TYPE***PARAMETER FOR STEERING GEAR TYPE*

Q30-1003-026000010 STRNG TYPE PRMTR - ABS 6 1

**3Q00-S11-C1F PARAMETER FOR REAR SUSPENSION TYPE***PARAMETER FOR REAR SUSPENSION TYPE*

Q30-1003-027000082 SUSP PRMTR - ABS 6 1

**3Q00-S11-D06 PARAMETER FOR STEER AXLE BRAKE SIZE***PARAMETER FOR STEER AXLE BRAKE SIZE***3Q00-S11-E11 PARAMETER FOR STEER AXLE SUSP TYPE***PARAMETER FOR STEER AXLE SUSP TYPE***3Q00-S11-F01 PARAMETER FOR REAR AXLE BRAKE SIZE***PARAMETER FOR REAR AXLE BRAKE SIZE***3Q00-S11-G99 PARAMETER FOR REAR AXLE SPACING***PARAMETER FOR REAR AXLE SPACING***3Q00-S11-H02 PARAMETER FOR YAW RATE SENSOR ORIENT.***PARAMETER FOR YAW RATE SENSOR ORIENT.***3Q00-S11-J01 PARAMETER FOR STEERING ANGLE SENSOR***PARAMETER FOR STEERING ANGLE SENSOR  
ORIENTATION***3Q00-S11-K04 PARAMETER: HIGH RESOLUTION WHEEL SPEED***PARAMETER: HIGH RESOLUTION WHEEL SPEED  
WHEEL SPEED ENABLED*

Q30-1003-034000003 PARAMETER- ABS, HRWS 1

**3Q00-S11-L02 PARAMETER FOR ATC PRESENT***PARAMETER FOR ATC PRESENT***3Q00-S11-M01 PARAMETER-ENG RETARDER RELAY PRESENT***PARAMETER-ENG RETARDER RELAY PRESENT***3Q00-S11-N02 PARAMETER FOR REAR AXLE RATIO***PARAMETER FOR REAR AXLE RATIO*

**3Q00-S11-P05 PARAMETER FOR FRONT AXLE TYPE***PARAMETER FOR FRONT AXLE TYPE***3Q00-S11-Q03 PARAMETER FOR ABS ECU TYPE***PARAMETER FOR ABS ECU TYPE***3Q00-S11-R01 PARAMETER FOR CLUTCH TYPE***PARAMETER FOR CLUTCH TYPE***3Q00-S11-S99 PARAMETER FOR BODY BUILDER***PARAMETER FOR BODY BUILDER***3Q00-S11-T99 PARAMETER FOR BODY INFORMATION***PARAMETER FOR BODY INFORMATION***3Q00-S11-U99 PARAMETER FOR ACB CONFIGURATION***PARAMETER FOR ACB CONFIGURATION***3Q00-S11-VAC SUSP BASED TRACTION SYSTEM PARAMETER***SUSP BASED TRACTION SYSTEM PARAMETER*

Q30-1003-044000000 SUSP BASE TRAC SYS-ABS 6 1

**3Q00-S11-WAD ATC MUD/SNOW SWITCH CONFIG PARAMETER***ATC MUD/SNOW SWITCH CONFIG PARAMETER*

Q30-1003-045000001 ATC MUD/SNOW SW-ABS 6 1

**3Q00-S11-X99 ACC FOLLOWING DISTANCE ALERTS***ACC FOLLOWING DISTANCE ALERTS*

Q30-1003-046000000 PARAMETER-ABS 6 1

**3Q00-S11-YAD VECU***VECU*

Q30-1003-047000002 PARAMETER- ABS, VECU 1

**3Q00-S11-ZAC RETARDER***RETARDER*

Q30-1003-048000000 PARAMETER- ABS, RETARDER 1

**3Q00-S12-AAE SDP SPEAKER LEFT VOLUME***SDP SPEAKER LEFT VOLUME*

Q30-1003-049999999 PARAMETER-ABS-6 1

**3Q00-S12-BAE SDP SPEAKER RIGHT VOLUME***SDP SPEAKER RIGHT VOLUME*

Q30-1003-050999999 PARAMETER-ABS-6 1

**3Q00-S12-CBC ENGINE MODEL***ENGINE MODEL*

Q30-1003-051000030 PARAMETER-ABS 6 1

**3Q00-S12-EAC PARAMETERS FOR AIR DRYER TYPE***PARAMETERS FOR AIR DRYER TYPE*

Q30-1003-053000000 PARAMETER - ABS 6 1

**3Q00-S12-FAC PARAMETER FOR COMPRESSOR TYPE***PARAMETER FOR COMPRESSOR TYPE*

Q30-1003-054000000 PARAMETER - ABS 6 1

**3Q00-S12-GAC PARAMETER FOR STEER AXLE TYPE***PARAMETER FOR STEER AXLE TYPE*

Q30-1003-055000000 PARAMETER - ABS 6 1

**3Q00-S12-HAE PARAMETER FOR STEER BRAKE CHAMBER SIZE***PARAMETER FOR STEER BRAKE CHAMBER SIZE*

Q30-1003-056000003 PARAMETER-ABS 6 1

**3Q00-S12-JAJ PARAMETER FOR REAR BRAKE CHAMBER SIZE**

PARAMETER FOR REAR BRAKE CHAMBER SIZE

Q30-1003-057000007      PARAMETER-ABS 6      1

**3Q00-S12-KAC PARAMETER FOR RADAR ALIGNMENT**

PARAMETER FOR RADAR ALIGNMENT

Q30-1003-058000000      Parameter-ABS 6      1

**3Q00-S12-LAC PARAMETER FOR RADAR OFFSET FROM CENTER**

PARAMETER FOR RADAR OFFSET FROM CENTER

Q30-1003-059000000      Parameter-ABS 6      1

**3Q00-S12-MAC PARAMETER FOR RAIL MODE**

PARAMETER FOR RAIL MODE

Q30-1003-060000000      Parameter-ABS 6      1

**3Q10-S40-BAP CUMMINS ENGINE BASE CALIBRATION**

CUMMINS ENGINE BASE CALIBRATION

D30-6011-0004      SOFTWARE-CUMM, 2021      1  
X15,**3Q10-S40-CAD DEF SOFTWARE**

DEF SOFTWARE

M30-6003-001      Software - DEF, SSI      1

M30-6007-003      SOFTWARE-DEF, KUS HD      1

**3Q10-S50-AAK BASE APPLICATION SOFTWARE PARAMETER**

BASE APPLICATION SOFTWARE PARAMETER

AASF12202435045R02      VMUX BASE APP SW MY23      1

**3Q10-S50-BAK ENGINE CALIBRATION PARAMETER**

ENGINE CALIBRATION PARAMETER

AASF12212429737P45      VMUX BASE CALIB MY23      1

**3Q10-S50-CAY ENGINE PARAMETER**

ENGINE PARAMETER

AASF13122435371R02      VMUX ARCH ENG ISX R20.10      1

**3Q10-S50-DCG TRUCK MODEL PARAMETER**

TRUCK MODEL PARAMETER

AASF13202397236N43      VMUX TRUCK KW T880 MY23      1

**3Q10-S50-EAH SPARE SOFTWARE PARAMETER**

SPARE SOFTWARE PARAMETER

AASF13162158954L05      VMUX SPARE SFTWARE      1  
R19.8+**3Q10-S50-FBW VMUX TRANS - MANUAL**

VMUX TRANS - MANUAL

AASF13002390935N36      VMUX TRANS MANUAL      1  
R19.9+**3Q10-S50-GBK ABS CONFIGURATION PARAMETER**

ABS CONFIGURATION PARAMETER

AASF13192422775P35      VMUX BENDIX W/O ACC      1  
W/ESP**3Q10-S50-HAR PCC CONFIGURATION PARAMETER**

PCC CONFIGURATION PARAMETER

AASF13182346713N09      VMUX - W/O PCC R19.8+      1

**3Q10-S50-JAY AUTO START CONFIGURATION PARAMETER**

AUTO START CONFIGURATION PARAMETER

AASF13222314404M09 VMUX W/O AUTO START 1

**3Q10-S50-KAJ SPARE SOFTWARE PARAMETER**

SPARE SOFTWARE PARAMETER

AASF13152158819L05 VMUX SPARE SFTWARE 1  
R19.8+

**3Q10-S50-LAV SWITCHES PARAMETER**

SWITCHES PARAMETER

AASF13132295791L38 VMUX SM SWITCHES R19.8+ 1

**3Q10-S50-MBE ENGINE BRAKE SWITCH CONFIG PARAMETER**

ENGINE BRAKE SWITCH CONFIG PARAMETER

AASF13142298234L38 VMUX ENG BRK - CE W/RHS 1

**3Q10-S50-NAT SPP VERSION PARAMETER**

SPP VERSION PARAMETER

AASF11192418751P35 VMUX CUMMINS SPP R20.8 1

**3Q10-S50-PBN LIFT AXLE PARAMETER**

LIFT AXLE PARAMETER

AASF13402164793L07 VMUX W/O LFT AXLES 1  
R19.8+

**3Q10-S50-QBA DRIVEN AXLE PARAMETER**

DRIVEN AXLE PARAMETER

AASF13422258008L07 VMUX SNGL DRV AXLE 1  
R19.8+

**3Q10-S50-RAX VMUX AUTO START & BRAKE CONFIGURATION**

VMUX AUTO START & BRAKE CONFIGURATION

AASF13432341042M52 W/O AUTO START & W/O ACE 1

**3Q10-S50-SAH SPARE INSTALLATION PARAMETER**

SPARE INSTALLATION PARAMETER

AASF13462151654L07 VMUX SPARE-INSTALL 1  
R19.8+

**3Q10-S50-TAH SPARE SOFTWARE PARAMETER**

SPARE SOFTWARE PARAMETER

AASF13212158820L05 VMUX SPARE SFTWARE 1  
R17.4+

**3Q10-S50-UAH SPARE SOFTWARE PARAMETER**

SPARE SOFTWARE PARAMETER

AASF13172158821L05 VMUX SPARE SFTWARE 1  
R19.8+

**3Q10-S50-VAH SPARE SOFTWARE PARAMETER**

SPARE SOFTWARE PARAMETER

AASF13302158822L05 VMUX SPARE SFTWARE 1  
R17.4+

**3Q10-S50-WCN CMS AND MSB CONFIGURATION PARAMETER**

CMS AND MSB CONFIGURATION PARAMETER

AASF13412135773L07 VMUX W/CM P&S, MSB 1

**3Q10-S50-XAN CAN CONFIGURATION**

CAN CONFIGURATION

AASF13662429738P45 VMUX CAN CONFIG MY23 1

**3Q10-S50-YAJ FLASH LOADER**

FLASH LOADER

AASF13652304958M30	VMUX FLASH LOADER R19.8+	1
<b><u>3Q10-S51-AAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF10262346324N06	VMUX SPARE SW R19.8+	1
<b><u>3Q10-S51-BAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF10512271594L05	VMUX SPARE SFTWARE R19.8+	1
<b><u>3Q10-S51-CAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF10522271595L05	VMUX SPARE SFTWARE R19.8+	1
<b><u>3Q10-S51-DAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF10532271596L05	VMUX SPARE SFTWARE R19.8+	1
<b><u>3Q10-S51-EAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF10552271597L05	VMUX SPARE SFTWARE R19.8+	1
<b><u>3Q10-S51-FAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF10562271598L05	VMUX SPARE SFTWARE R19.8+	1
<b><u>3Q10-S51-GAH SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF15982429739P45	1598 - DEM FILE MY23	1
<b><u>3Q10-S51-HAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF17762258021L07	VMUX SPARE-INSTALL R17.4+	1
<b><u>3Q10-S51-JAR SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF17772258023L07	VMUX 2.1M HD R19.8+	1
<b><u>3Q10-S51-KAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF12452257979L05	VMUX SPARE SFTWARE R19.8+	1
<b><u>3Q10-S51-LAG SPARE SOFTWARE PARAMETER</u></b>		
<i>SPARE SOFTWARE PARAMETER</i>		
AASF12442257978L05	VMUX SPARE SFTWARE R19.8+	1
<b><u>3Q10-S52-AAD BASE APPLICATION SOFTWARE</u></b>		
<i>BASE APPLICATION SOFTWARE</i>		
ACSA12222204147L12	CMP - VMUX - BASE APP SW	1
<b><u>3Q10-S52-BAF BASE CONFIGURATION</u></b>		
<i>BASE CONFIGURATION</i>		
ACSA13232324532N30	CMP - VMUX - BASE CONFIG	1

**3Q10-S52-CAQ SPARE SOFTWARE***SPARE SOFTWARE*

ACSA13242324528N30	CMP - VMUX -W/O CITY HORN	1
--------------------	------------------------------	---

**3Q10-S54-AAH CHASSIS MODULE SECONDARY***CHASSIS MODULE SECONDARY*

ADSA12232204148L12	CMS - VMUX - Base App SW	1
--------------------	--------------------------	---

**3Q10-S54-BAP CHASSIS MODULE SECONDARY***CHASSIS MODULE SECONDARY*

ADSA13252387050N30	CMS - VMUX - SPARE SOFTWA	1
--------------------	------------------------------	---

**3Q10-S54-CAJ CHASSIS MODULE SECONDARY***CHASSIS MODULE SECONDARY*

ADSA13262387051N30	CMS - VMUX - BASE CONFIG	1
--------------------	--------------------------	---

**3Q10-S56-AAD MSM APPLICATION SOFTWARE***MSM APPLICATION SOFTWARE*

AGSA12242266560L16	MSM APP SW - VMUX	1
--------------------	-------------------	---

**3Q10-S56-BAD MSM PARAMETER FILE***MSM PARAMETER FILE*

AGSA13272135781L12	MSM PAR FILE - VMUX	1
--------------------	---------------------	---

**3Q10-S56-CAD MSM PARAMETER FILE***MSM PARAMETER FILE*

AGSA13472135782L12	MSM INSTALL VAR - VMUX	1
--------------------	------------------------	---

**3Q10-S58-AAK INSTALLATION VARIANT - RH STALK***INSTALLATION VARIANT - RH STALK*

AHSA13942153933L12	RHS W/ ENG BRK W/O PAT- VM	1
--------------------	-------------------------------	---

**3Q10-S58-BAD RHS APPLICATION SOFTWARE***RHS APPLICATION SOFTWARE*

AHSA13972277283M15	RHS BASE SOFTWARE DNRP	1
--------------------	------------------------	---

**3Q10-S58-CAD RHS FLASH/BOOT LOADER -VMUX***RHS FLASH/BOOT LOADER -VMUX*

AHSA13932204801L12	RHS FLASH LOADER - VMUX	1
--------------------	-------------------------	---

**3Q10-S58-HAF (1291) INSTALLATION VARIANTS SWS***(1291) INSTALLATION VARIANTS SWS*

APSB12912257983M40	W/O TOGGLE SWITCH W/O VRS	1
--------------------	------------------------------	---

**3Q10-S58-NAL INSTALLATION VARIANTS***INSTALLATION VARIANTS*

AMSA10092251476L12	W/O RKE W/ HEAT W/ POWER	1
--------------------	-----------------------------	---

**3Q10-S58-UAC (1225) HVAC BASE SOFTWARE COMPONENT***(1225) HVAC BASE SOFTWARE COMPONENT*

ALSA12252297005L49	HVAC BASE SOFTWARE	1
--------------------	--------------------	---

**3Q10-S58-VAC (1060) CAB/UNIT INSTALLATION VARIANT***(1060) CAB/UNIT INSTALLATION VARIANT*

ALSA10602254100L13	DAY CAB - FAHRENHEIT	1
--------------------	----------------------	---

**3Q10-S60-AAK VEHICLE CONTROLLER SW***VEHICLE CONTROLLER SW*

AQSG10272431574P52 DD 15 VEH CONTROLLER SW 1  
**3Q10-S60-BAK APPLICATION CONTROLLER SW**  
 APPLICATION CONTROLLER SW

AQSG10282431576P52 DD 15 APP CONTROLLER SW 1  
**3Q10-S60-CAK EVENT & SOUND DATABASE**  
 EVENT & SOUND DATABASE

AQSG10292431578P52 DD 15 EVENT & SOUND SW 1  
**3Q10-S60-DAP CONTROL SWITCH IV**  
 CONTROL SWITCH IV

AQSG10012264322N40 DD 15 STEERING SWITCH 1  
**3Q10-S60-EAP DISPLAY CONFIG IV**  
 DISPLAY CONFIG IV

AQSG10022264323N40 DD 15 SNGL DISPLAY CONFG 1  
**3Q10-S60-FAK SPARE IV**  
 SPARE IV

AQSG10032273282N40 DD 15 SPARE IV (1003) 1  
**3Q10-S60-GAK SPARE IV**  
 SPARE IV

AQSG10042273283N40 DD 15 SPARE IV (1004) 1  
**3Q10-S60-HAK SPARE IV**  
 SPARE IV

AQSG10052273284N40 DD 15 SPARE IV (1005) 1  
**3Q10-S60-JAK SPARE IV**  
 SPARE IV

AQSG10062273285N40 DD 15 SPARE IV (1006) 1  
**3Q10-S60-KDF DIV & ENG CONFIG**  
 DIV & ENG CONFIG

AQSG10502330351N40 DD 15 X15 X1 PRODUCTIVIT 1  
**3Q10-S60-LAK PARAMETER IMG FILE**  
 PARAMETER IMG FILE

AQSG10572431580P52 DD 15 PARAMETER IMG FILE 1  
**3Q10-S60-MAK SPP VER / REV**  
 SPP VER / REV

AQSG12322417636P39 DD 15 SPP VER / REV 1  
**3Q10-S60-NBL TRANS SW CONFIG**  
 TRANS SW CONFIG

AQSG12872330357N40 DD 15 MANUAL TRANS 1  
**3Q10-S60-PAK FLASH LOADER**  
 FLASH LOADER

AQSG15742298998N40 DD 15 FLASHLOADER 1  
**3Q10-S60-QAK HARDWARE SECURITY MODULE**  
 HARDWARE SECURITY MODULE

AQSG15772273286N40 DD 15 HW SECURITY 1  
 MODULE

**3Q10-S60-RAK APP BOOT LOADER**  
 APP BOOT LOADER

AQSG15782389685N40 DD 15 APPL BOOT LOADER 1  
**3Q10-S60-SAK VEH BOOT LOADER**  
 VEH BOOT LOADER

AQSG15792298997N40 DD 15 VHCL BOOT LOADER 1

### **3Q20-S21-CAD SOFTWARE - RH STALK**

SOFTWARE - RH STALK

= REFERENCE ONLY =

Q30-6013-0B00 SOFTWARE-RH STALK,CNTRL 1

### **3Q20-S21-HAC SOFTWARE - BENDIX ABS - ESP MODULE**

SOFTWARE - BENDIX ABS - ESP MODULE

P30-1061-0003 SOFTWARE- BENDIX ABS ESP1

### **3Q21-D00-CAD CHASSIS MODULE MOUNTING**

CHASSIS MODULE MOUNTING

A97-6260 INSTL-2.1M OVERBELL

A97-6261 INSTL-CHASSIS MODULE, PRIMARY

A97-6261 INSTL-CHASSIS MODULE, PRIMARY

A97-6304 INSTL- CHASSIS MODULE, SECOND

A97-6304 INSTL- CHASSIS MODULE, SECOND

A97-6304 INSTL- CHASSIS MODULE, SECOND

P95-6887 RTG-VECU MODULE, SECONDARY

P95-6982 RTG-ENGINE TO AFT, 2.1M

PRIMARY CHASSIS MODULE MTG BRACKET

P62-6014 Mount-Chassis Module, P 1

ENGINE-TO-AFT HARN BULKHEAD BRACKET

PRIMARY CHASSIS MODULE MTG HARDWARE

R34-6002-08045RHLK Exterior Threaded Hex Screw 5  
(M8 x 1.25 x 45mm)

W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25)7

SECONDARY CHASSIS MOD MTG BRACKET

A62-6087 Mount-Chassis Module, Se 1

SECONDARY CHASSIS MOD MTG BRACKET

P62-6020 MOUNT-CHASSIS 1  
MODULE,SECO

SECONDARY CHASSIS MOD MTG HARDWARE

R34-6002-08045RHLK Exterior Threaded Hex Screw 4  
(M8 x 1.25 x 45mm)

R34-6002-08030RHLZ FASTENER-THREADED,EXT 3

W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25)7

W11-1033-103 BRACKET, Z STANOFF ASSY 1

P16-1006-100 Fir Tree Clip 2

### **3Q21-S00-EAG VECU2**

VECU2

S97-6293 INSTL-VECU MODULE

Q21-1139-019-019 CONTROL -VECU 1

S34-6003-0555TP00B PSD Screw (M5 x 0.80 x 3  
55mm), Black

### **3Q21-S00-FAC PRIMARY CHASSIS MODULE**

PRIMARY CHASSIS MODULE

Q21-1142-001-001 Primary Chassis Module 1

### **3Q21-S00-GAC SECONDARY CHASSIS MODULE**

SECONDARY CHASSIS MODULE

Q21-1143-001-001 Secondary Chassis Module 1

### **3ROP-D00-AAC COWL AND HEADER ASSEMBLIES**

**COWL AND HEADER ASSEMBLIES**

R29-6048-100	COWL-HEADER RECONFIG,PNG	1
--------------	-----------------------------	---

**SINGLE WINDSHIELD****- DRILL PATTERN A1****3R0P-D00-BAD LH AND RH WALL ASSEMBLY****LH AND RH WALL ASSEMBLY**

R25-1233-180090000	APERTURE-SIDEWALL RECONFI	1
--------------------	------------------------------	---

**3R0P-D00-DAC CAB FLOOR ASSEMBLY, DAY-CAB OR ANY****CAB FLOOR ASSEMBLY, DAY-CAB OR ANY****SLEEPER-CAB**

R40-6082-100000004	FLOOR-RECONFIGURATION, PNG	1
--------------------	-------------------------------	---

**3R0P-D00-EAC ALL DAY-CAB S BACK WALL ASSEMBLIES****ALL DAY-CAB S BACK WALL ASSEMBLIES****(W/O WINDOW, W/ 1 REAR WINDOW OR****W/ (3) REAR WINDOWS)**

R64-1433-312002001	BACKWALL- RECONFIGURATION, PNG	1
--------------------	-----------------------------------	---

**3R0P-D00-FAC CAB ROOF ASSEMBLY, DAY-CAB.****CAB ROOF ASSEMBLY, DAY-CAB.**

R22-1454-017000001	ROOF ASSY CONFIGURATION	1
--------------------	-------------------------	---

**3R0P-D04-AAD CAB KEY AND LOCK KIT****CAB KEY AND LOCK KIT****DOORS - IF KEYED SEPARATELY**

R56-6067-03K2P0000	Cab Door Lock, Handle & Ignition Key Kit	1
--------------------	---	---

**3R00-D00-AAC CAB STRUCTURE - FRONT WALL, COWL AND****CAB STRUCTURE - FRONT WALL, COWL AND****HEADER ASSEMBLIES**

R64-6123	Engine Cover Panel Assembly	1
R29-6040	Cowl Structure Assembly	1
R24-6099	Cab Header Assembly	1

**3R00-D00-BBQ CAB STRUCTURE- LH WALL ASSEMBLY,****CAB STRUCTURE- LH WALL ASSEMBLY,****W/O SLEEPER**

R25-1312-011	APERTURE-SIDE WALL DAY CA	1
--------------	------------------------------	---

**3R00-D00-CBQ CAB STRUCTURE- RH WALL ASSEMBLY,****CAB STRUCTURE- RH WALL ASSEMBLY,****W/O SLEEPER**

R25-1312-011R	APERTURE-SIDE WALL DAY CA	1
---------------	------------------------------	---

**3R00-D00-DAC CAB STRUCTURE- STD CAB FLOOR ASSEMBLY****CAB STRUCTURE- STD CAB FLOOR ASSEMBLY****USE W/ DAY CAB**

M38-1030-02	LOW-FORCE TREE	3
M36-0630-07	Christmas Tree Fastener	11
G67-1000	Rubber Plug	2

R40-6127 Day Cab Floor Assembly 1

\*\*\*\*\* *SHOP NOTE* \*\*\*\*\*

*INSTALL PINETREES AND RUBBER PLUGS ON  
TOP FLOOR BEFORE CARPET INSTALLATION.*

\*\*\*\*\*

R97-1637 INSTL - CAB FLOOR PLUGS

### **3R00-D00-EAE CAB STRUCTURE - REAR WALL ASSEMBLY,**

*CAB STRUCTURE - REAR WALL ASSEMBLY,*

*DAY CAB*

R64-1728-003 Cab Backwall Panel Assembly 1

R67-1000 PLUG-CAB LIFT HOLE 2

R97-1482 INSTL - DAYCAB LIFT PLUG

R97-1482 INSTL - DAYCAB LIFT PLUG

### **3R00-D00-FAC CAB ROOF ASSY - DAY CAB**

*CAB ROOF ASSY - DAY CAB*

R22-1369 Cab Roof Assembly 1

R34-6002-08035RH0K Exterior Threaded Hex Screw 10  
(M12 x 1.75 x 35mm)

### **3R00-D02-AAC COMMON COMPONENTS**

*COMMON COMPONENTS*

W34-6037-5NXG070S3 RIVET-SELF PIERCING,5MM 20

W34-6037-5NWG050S3 RIVET-SELF PIERCING,5MM 14

W34-6037-5NVA100S5 RIVET-SELF PIERCING 5MM 26

W34-6037-5NUA090S5 Rivet 19

W34-6037-5NTA080S5 Self Piercing Rivet (5mm x  
80mm) 40

W34-6037-5NSA070S5 Self Piercing Rivet (5mm x  
70mm) 27

W34-6037-5NRA060S5 Self Piercing Rivet (5mm x  
60mm) 24

R42-1247-100 SEALER-SECONDARY

R42-6246 Structural Adhesive

HKLT-R8-06 Truss Head Rivet (1/4") 26

F25-1006 Vent 2

R42-1180 Grommet - 2-Way Plug 2

R97-1525 INSTL-PRV

R97-1514-000 INSTL-SIDEWALL GROMMETS

R29-1051-0000 CAB, DAY ASSY

R97-6239 INSTL - SECONDARY SEALER, BIW

R97-6238 INSTL - STRCUTRL ADHSIVE, BIW

### **3R00-D02-BAE LH/RH HINGE COVERS AND A PILLAR MID.**

*LH/RH HINGE COVERS AND A PILLAR MID.*

*COVERS*

R22-1414 CLOSEOUT-A PILLAR,MID 1

R22-1414R CLOSEOUT-A PILLAR,MID 1

R34-6002-08035RH0K Exterior Threaded Hex Screw 4  
(M12 x 1.75 x 35mm)

R22-6158-001 COVER ASSY-HINGE PLR KW, 1

R22-6160-001 COVER ASSY-HINGE PLR KW, 1

R34-6002-06025SHLN Exterior Threaded Hex Screw 6  
(M6 x 1.00 x 25mm)

R34-6002-06025SHLB Exterior Threaded Hex Screw 4  
(M6 x 1.00 x 25mm)

*R97-6212 INSTALLATION HINGE COVER*

**3R00-D02-CBP LH ROCKER PANEL W/ SST PERMIT PANEL**

*LH ROCKER PANEL W/ SST PERMIT PANEL*

R22-1399-002 COVER-CAB ROCKER LH 1  
R34-6002-06025SHLN Exterior Threaded Hex Screw 7  
(M6 x 1.00 x 25mm)  
29-05726 U-Nut (M6 x 1.00) 2  
R65-1065 Rod - Rocker Attach Front 1  
R65-1066 Rod - Rocker Attach Rear 1  
16-04592 Receptacle Housing 1  
W34-1052-156-57 RIVET-BREAK MANDREL 2  
R22-1492-101 PLATE-PERMIT PANEL 1

*R97-1583-199999 INSTL- ROCKER MTD OPTS*

*R97-1515-000 INSTL - ROCKERS, KW*

*R97-1515-000 INSTL - ROCKERS, KW*

**3R00-D02-DAC RH ROCKER PANEL**

*RH ROCKER PANEL*

R22-1441 COVER-ROCKER, RH 1  
R34-6002-06025SHLN Exterior Threaded Hex Screw 3  
(M6 x 1.00 x 25mm)

*R97-1515-000 INSTL-ROCKERS*

**3R00-D02-EAC BULKHEAD ASSEMBLY**

*BULKHEAD ASSEMBLY*

R64-6162 Bulkhead Panel Assembly 1  
R34-6002-08035RH0K Exterior Threaded Hex Screw 15  
(M12 x 1.75 x 35mm)

*R97-6213 INSTL-BULKHEAD ASSY*

**3R00-D02-FAL LH & RH REINFORCEMENTS**

*LH & RH REINFORCEMENTS*

R77-1663 LH Upper Sleeper 1  
Reinforcement Assembly  
R77-1663R RH Upper Sleeper 1  
Reinforcement Assembly  
W16-1020-0B0101NB0P CLIP - PINETREE 2  
R77-6231 REINF-B PILLAR 1  
R77-6231R REINF-B PILLAR 1  
R77-6246 REINF-B PILLAR 2  
R34-6002-08035RH0K Exterior Threaded Hex Screw 8  
(M12 x 1.75 x 35mm)

**3R00-D02-KAD SST EXTERIOR SUNVISOR - OPTIONAL**

*SST EXTERIOR SUNVISOR - OPTIONAL*

*SUN VISOR ASSEMBLY*

R73-1031 Exterior Sunvisor Assembly 1  
R34-6002-06025SHLN Exterior Threaded Hex Screw 10  
(M6 x 1.00 x 25mm)

*SUN VISOR BRACKETS*

R11-6374 Bracket-Visor,Center 1  
R11-6375 BRACKET-VISOR, INBOARD 1

R11-6375R	BRACKET-VISOR, INBOARD	1
R11-6378	Bracket-visor, outboard	1
R11-6378R	Bracket-Visor, Outboard	1
<i>HARDWARE</i>		
W20-6017-06040B130	Pacsert Self Retaining Nut (M6 x 1.00), Gold	4
W20-6017-06090B150	NUT-SELF RETAINING, PACS	4
W20-6017-06115B160	NUT-SELF RETAINING, PACS	8
W34-6057-060421500	STUD-SELF RETAINING, METR	6
R34-6002-06025RHLZ	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	16
W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	6

*R97-1575 INSTL-EXTERIOR VISOR***3R00-D02-LBP B PILLAR ROCKER PANELS***B PILLAR ROCKER PANELS*

R22-1404	Cover - B-Pillar EXH	1
R22-1350R	Cover - B-Pillar STD	1
R34-6002-06025RHLZ	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	6

*R97-1515-000 INSTL - ROCKERS***3R00-D02-MAD CAB SUSPENSION***CAB SUSPENSION*

25522247	Rear Cab Suspension Assembly	1
----------	---------------------------------	---

*HARDWARE - SUSP TO XMBR*

W34-1159-050	Hex Bolt (M12 x 1.75 x 50mm)	6
W34-1162-012	Flat Washer	12
W20-1028-012	Lock Nut (M12 x 1.75)	6
K028-2491-5	90° Standoff Bracket (140mm)	2

*HARDWARE - TRACK ROD TO CAB*

W34-1095-110	BOLT-FLANGE HEAD, M16X2	1
--------------	-------------------------	---

*LINE #147 (NGP #1216) AIR DRYER TO CAB**SUSP*

G50-6022-04PURCTL	Purple Nylon Tubing (1/4")	1
27-00304-004	Lock Washer (1/4")	1

*BALL STUD - CAB HEIGHT CONTROL*

15000228	BALL-PIVOT THREADED	1
----------	---------------------	---

*HARDWARE - SHOCK TO CAB*

R34-6002-12110RHLM	Exterior Threaded Hex Screw (M12 x 1.75 x 110mm)	1
--------------------	---	---

W34-1162-012	Flat Washer	1
--------------	-------------	---

*WARNING LABEL*

22-01525	Warning Label, Cab Suspension	2
----------	----------------------------------	---

*R97-6240 INSTL-CAB AIR SUSPENSION**R97-6221 INSTL-CAB SPSN BALL STUD***3R00-D04-AAC LH DOOR STRUCTURE ASSY**

**LH DOOR STRUCTURE ASSY**

R25-1287-001	LH Cab Door Assembly	1
R48-1053	Cab Door Hinge Assembly	1
R48-1052	Cab Door Hinge Assembly	1
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	4
K363-175CA	Flat Washer (3/8")	4
W20-1027	NUT - NGP DOOR HINGE	6
R34-6002-06025RF0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	2

*R97-1518 INSTL - DOOR HANG T680**R97-1518 INSTL - DOOR HANG T680***3R00-D04-BAC RH DOOR STRUCTURE ASSY*****RH DOOR STRUCTURE ASSY***

R25-1287-001R	RH Cab Door Assembly	1
R48-1059	RH Cab Door Hinge Assembly	1
R48-1058	RH Cab Door Hinge Assembly	1
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	4
K363-175CA	Flat Washer (3/8")	4
W20-1027	NUT - NGP DOOR HINGE	6
R34-6002-06025RF0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	2

*R97-1518 INSTL - DOOR HANG T680**R97-1518 INSTL - DOOR HANG T680***3R00-D04-CAC LH DOOR COMPONENTS*****LH DOOR COMPONENTS***

R42-1107	SEAL - GLASS RUN CHANNEL	1
R42-1134	SEAL-CONTINUOUS NGP KW	1
R44-1110	GLASS- SIDEDOOR,KENWORTH	1
R83-1026	STOP - CHECKLINK KW, LH	1
K363-491-6	Washer - Flat, Nylon (M6)	1
W20-6011-05TDY0Z	Flanged Lock Nut (M5 x 0.80)	1
W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	2
R21-1021	CONTROL-WINDOW REGULATOR,	1
S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black	3
R56-1206	LATCH-CABLE ATTACH ASSEMB	1
R65-1046	ROD-LOCK	1
R65-1070	Rod - Latch Bell Crank	1
S55-1008	LEVER - BELL CRANK, OUTER	1
S34-6003-0619RXL0B	Torx Screw (M6 x 1.00 x 19mm), Black	5
R46-1208	SHIELD - WATER, REAR, NGP	1
R65-1054	ROD-O/S HANDLE, KW	1
S55-1007	LEVER - BELL CRANK INNER	1
S56-1080		

LH Lock Rod & Knob Assembly	1	
R42-1195	SEAL - INNERBELT, KW	1
R42-1169	SEAL-OUTERBELT, KW	1
R46-1169	SHIELD - WATER, DOOR	1
S56-1070	HANDLE-INSIDE REL, KW	1
R42-1208	SEAL - DOOR MTD PRIMARY	1
K363-339-2-250	Flat Washer (1/4"), Black	1
G67-1000	Rubber Plug	1
R42-1165	SEAL-BODY MTD SECONDARY	1
R42-1115	SEAL-AUXILLARY UPPER	1
16896766	Striker-Latch	1
W34-1120-08F59L30Z	M8X1.0X30MM COUNTERSINK	2
R46-1207	SHIELD - WATER, REAR, NGP	1
<i>R97-1511 INSTL - DOOR TRIM, KW</i>		
<i>R97-1511 INSTL - DOOR TRIM, KW</i>		
<i>R97-1554 INSTL - BODY MTD DOOR SEALS</i>		
<i>R97-1554 INSTL - BODY MTD DOOR SEALS</i>		

### **3R00-D04-DAC RH DOOR COMPONENTS**

#### *RH DOOR COMPONENTS*

R42-1107R	SEAL - GLASS RUN CHANNEL	1
R42-1134	SEAL-CONTINUOUS NGP KW	1
R44-1110R	GLASS- SIDEDOOR,KENWORTH	1
R83-1025	CHECKLINK 2.1M KW RH	1
K363-491-6	Washer - Flat, Nylon (M6)	1
W20-6011-05TDY0Z	Flanged Lock Nut (M5 x 0.80)	1
W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	2
R21-1021R	CONTROL-REGULATOR WINDOW,	1
S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black	3
R56-1206R	LATCH-CABLE ATTACH ASSEMB	1
R65-1046R	ROD-LOCK	1
R65-1070	Rod - Latch Bell Crank	1
S55-1008	LEVER - BELL CRANK, OUTER	1
S34-6003-0619RXL0B	Torx Screw (M6 x 1.00 x 19mm), Black	5
R46-1208	SHIELD - WATER, REAR, NGP	1
R65-1054	ROD-O/S HANDLE, KW	1
S55-1007	LEVER - BELL CRANK INNER	1
S56-1080R	RH Lock Rod & Knob Assembly	1
R42-1195R	SEAL - INNERBELT, KW	1
R42-1169R	SEAL-OUTERBELT, KW	1
R46-1169R	SHIELD - WATER, DOOR	1
S56-1070R	HANDLE-INSIDE, REL, KW	1
R42-1208	SEAL - DOOR MTD PRIMARY	1

K363-339-2-250	Flat Washer (1/4"), Black	1
G67-1000	Rubber Plug	1
R42-1165	SEAL-BODY MTD SECONDARY	1
R42-1115R	SEAL-AUXILLARY UPPER	1
16896766	Striker-Latch	1
W34-1120-08F59L30Z	M8X1.0X30MM COUNTERSINK	2
R46-1207	SHIELD - WATER, REAR, NGP	1

*R97-1511 INSTL - DOOR TRIM, KW*

*R97-1511 INSTL - DOOR TRIM, KW*

*R97-1554 INSTL - BODY MTD DOOR SEALS*

*R97-1554 INSTL - BODY MTD DOOR SEALS*

### **3R00-D04-EAE DOOR TRIP LEDGES, LH AND RH**

*DOOR TRIP LEDGES, LH AND RH*

R60-6017	Window Fairing Assembly	1
R60-6018	Window Fairing Assembly	1

*R97-1511 INSTL - DOOR TRIM*

### **3R00-D06-AAC WINDSHIELD & WIPER SYSTEM**

*WINDSHIELD & WIPER SYSTEM*

R44-6097	Windshield Glass	1
R42-6089	Adhesive-Windshield	1
R42-6108	ADHESIVE-WINDSHIELD ACTIV	1
R23-6025	Windshield Wiper Module Assembly	1
R23-6027	Windshield Wiper Arm & Blade Assembly	2
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	2
W20-6011-10TDY0Z	Flanged Lock Nut (M10 x 1.50)	2
R11-6175	Bracket-Wiper Attachment	1
HKLT-R8-06	Truss Head Rivet (1/4")	3
R06-6016	Cowl Tray Assembly	1
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	10
K344-1029-11	Insulation-Convolute Tube	3.50000
W34-1009	Flat Washer (M8 x 1.25)	1

*NOTE: ADD WASHER UNDER TRAY AT AIR*

*CLEANER BRACKET*

05-16865	Battery Cable Bracket	1
----------	-----------------------	---

*R97-6209 INSTALLATION COWL AND WIPER*

*R97-6208 INSTALLATION WINDSHIELD*

*R97-6226 - INSTL COWL DRAIN TUBE*

*D95-1035 - RTG WASHER FLUID HOSE*

### **3R00-D06-BAD 19" X 36" REAR CENTER WINDOW & SEAL -**

*19" X 36" REAR CENTER WINDOW & SEAL -*

*STD GLASS, DARK TINT - DAY CAB*

R44-1111	GLASS-REAR CENTER WINDOW	1
R42-1080-2657	SEAL-REAR WINDOW	1

R97-1481-000 INSTL-DAYCAB REAR WINDOW

**3R00-D06-CAD OPT OUTBOARD REAR WINDOWS - DARK TINT-**

OPT OUTBOARD REAR WINDOWS - DARK TINT-

DAY CAB

R44-1113 GLASS-REAR SIDE WINDOW 2

R42-1080-1461 SEAL-REAR WINDOW 2

R97-1481-000 INSTL-DAYCAB REAR WINDOW

**3R00-D15-BAC UNDER CAB SINGLE AIR HORN**

UNDER CAB SINGLE AIR HORN

G49-6007 Horn Assembly 1

G50-6022-04BLK050 Black Nylon Tubing (1/4" x 50") 1

P16-1001-021 CLIP- TWO PIECE EDGE CLIP 2

R22-6249 PLATE-BACKING, UC AIR HOR1

W20-6011-06TDY0Z Exterior Threaded Hex Screw 2  
(M6 x 1.00 x 25mm)

P16-1001-031 Edge Clip, Two-Piece 1

G38-1097-0404 Snap Head Fastener w/  
Washer (M4 x 0.70 x 30mm) 1

G90-6118-001 Air Horn Valve & Bracket  
Assembly 1

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80  
x 25mm) 1

S84-1028 STRAP-HORN PULL 1

G97-6351 INSTL-AIR HORN AND ROUTING

G97-6195 INSTL-HORN VALVE, ROUTING

**3R00-D15-CAC ELECTRIC HORN**

ELECTRIC HORN

R34-6002-08045RHLK Exterior Threaded Hex Screw 2  
(M8 x 1.25 x 45mm)

P49-1001-300 HORN - ELECTRIC FIAMM 1

**3R00-D25-CAC CENTER MTD GRAB HANDLE BOC**

CENTER MTD GRAB HANDLE BOC

R56-1146-212 Grab Handle 1

R34-6002-06025SHLN Exterior Threaded Hex Screw 4  
(M6 x 1.00 x 25mm)

W20-6017-06065B140 Self Retaining Nut (M6 x  
1.00) 4

R97-1477-1C1 INSTL-GRABHANDLES BOC

**3R00-D25-DAD GRAB HANDLE LH BACK OF CAB**

GRAB HANDLE LH BACK OF CAB

R56-1147-200 HANDLE-GRAB,BOC WIDE PB 1

R34-6002-06025SHLN Exterior Threaded Hex Screw 6  
(M6 x 1.00 x 25mm)

W20-6017-06090B150 NUT-SELF RETAINING, PACS 4

W20-6017-06040B130 Pacsert Self Retaining Nut 2  
(M6 x 1.00), Gold

R97-1477-1L2 INSTL-GRABHANDLES BOC

**3R00-D30-AAC STD LOOK-DOWN MIRROR**

STD LOOK-DOWN MIRROR

R59-1081-101	MIRROR-LOOKDOWN, DOOR 1 MTD	1
R34-6002-08045RHLK	Exterior Threaded Hex Screw 2 (M8 x 1.25 x 45mm)	2

*R97-6205 INSTL - LOOKDOWN MIRROR*

### **3R00-D30-BAE DUAL REAR VIEW AERO. MIRRORS**

*DUAL REAR VIEW AERO. MIRRORS*

*W/ CB PRE-WIRED*

R59-6092-221100	Cab Mounted Mirror Assembly, LH	1
R59-6093-221000	Cab Mounted Mirror Assembly, RH	1
R22-6298-300	HOUSING-MIRROR, LH	1
R22-6299-300	HOUSING-MIRROR, RH	1
R34-6002-08045RHLK	Exterior Threaded Hex Screw 8 (M8 x 1.25 x 45mm)	8

*R97-6204 INSTALLATION - MIRROR*

### **3S0P-D00-AAK CAB/SLEEPR FLOOR COVERING**

*CAB/SLEEPR FLOOR COVERING*

S14-1218-10S100000	FLOORCOVER-CAB	1
--------------------	----------------	---

*S14-1218 FLOORCOVER - CAB*

### **3S0P-D30-AAU GT701 DRIVER SEAT**

*GT701 DRIVER SEAT*

S78-1172-7900C2T75	SEAT-KW GRMG GT701	1
--------------------	--------------------	---

### **3S0P-D31-ABA GT100 RIDER SEAT**

*GT100 RIDER SEAT*

S78-1205-2035J2T75	SEAT - KW GRAMAG STATIC	1
--------------------	-------------------------	---

### **3S00-D00-AAJ CAB HEADLINER**

*CAB HEADLINER*

S89-1504-11X661	Cab Headliner Assembly, Light Gray	1
M38-1030-02	LOW-FORCE TREE	12
S72-1140-202	INSULATION- EXT DAYCAB	1
P54-1194-100	Dome Lamp	1
P54-1203-100	Lamp - Overdoor	2

*SHOP NOTE: CONNECT HARNESS RESISTOR*

*JUMPER S92-1477 J01 TO ROOF HARNESS*

*LH OVER DOOR CONNECTOR AND P01 TO LH  
OVER DOOR LAMP.*

S92-1477	HARNESS-RESISTOR JUMPER	1
----------	-------------------------	---

*S97-1329 INSTL - KW HEADLNR NGP DAYCAB*

*S96-1186 SCHEMATIC - RESISTOR JUMPER*

### **3S00-D00-EAW CAB BACK WALL SOFT TRIM**

*CAB BACK WALL SOFT TRIM*

S89-6000-61M2901	LINING-BACKWALL, DAYCAB	1
------------------	-------------------------	---

### **3S00-D00-FAC FRONT WALL INSULATION**

*FRONT WALL INSULATION*

S72-6133-100	Insulation-NVH, Front Wal	1
SJ3748	Dual Lock Fastener	1

*S97-6209 INSTL - FRONT WALL INSTL*

**3S00-D02-AAL CAB DOOR PADS - LH AND RH***CAB DOOR PADS - LH AND RH*

S60-1522-230901	LH Door Pad Trim Assembly, Midnight Black	1
S60-1523-230901	RH Door Pad Trim Assembly, Midnight Black	1
S45-1032-901	GRILLE-DOOR TRIM SPKR, LH	1
S45-1032-901R	GRILLE-DOOR TRIM SPKR, LH	1
S60-1617-0C2000	TRIM-HANDLE ACCENT	1
S60-1617-0C2000R	TRIM-HANDLE ACCENT	1
S67-1027-901	PLUG - LOWER DOOR PAD	6
P54-1195-100	Lamp - Door Pad	2
S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black	14

*S98-1007 SPECIFICATION TRIM - FILM***3S00-D02-BAF CONTROL MODULE***CONTROL MODULE*

Q27-1043-1211	CONTROL - DOOR, DRIVER	1
Q27-1044-1101	CONTROL - PASSENGER SIDE	1

**3S00-D04-AAE SUNVISORS***SUNVISORS*

S73-1045-101661	LH Interior Sunvisor, Light Gray	1
S73-1045-000661R	RH Interior Sunvisor, Light Gray	1
S73-1043-661	Sun Visor-Center	1
S22-1260-661	Visor Mount Cover	2
S16-1023-661	Visor Clip	2
W01-10-01P55N025B	Pan Head Screw (M5 x 0.80 x 8 25mm), Black	
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	2

**3S00-D04-BAD OVER DOOR TRIM***OVER DOOR TRIM*

S60-1468-661	LH Over Door Trim Cover, Light Gray	1
S60-1540-20661	TRIM - COVER, OVER DOOR, RH	1

**3S00-D04-CAE THRESHOLD***THRESHOLD*

S60-1715-901	Cab Door Threshold Trim, RH	1
S60-1714-901	Cab Door Threshold Trim, LH	1
S60-1716-200	Threshold Trim Extrusion, LH	1
S60-1716-200R	Threshold Trim Extrusion, RH	1
S34-6003-0630TP00B	PSD Screw (M6 x 1.00 x 30mm), Black	8
W01-10-02P57N020N	SCREW-PSD	4

*S97-1494 INSTL - DOOR THRESHOLD TRIM*

**3S00-D04-DAD CAB BACK WALL HARD TRIM***CAB BACK WALL HARD TRIM*

S60-1581-0661	TRIM-BACKWALL, UPR	1
S03-1012-661	HOOK-COAT HOOK	2
W01-10-01P55N010B	Pan Head Screw (M5 x 0.80 x 2 10mm), Black	
S03-1014-661	HOOK-HARD HAT	1
S03-1013-661	HOOK-HARD HAT RETAINER	1
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	1
15-15988	U-Nut (M5 X 0.80)	1

*S97-1319-000 INSTL - BACKWALL TRIM***3S00-D04-HBU A PILLAR TRIM***A PILLAR TRIM*

S60-1621-000661	TRIM- APILLAR W/O TWT,LH	1
S60-1622-0000661	TRIM- APILLAR W/O TWT, RH	1
S60-1492-901	TRIM - CAP, GRAB HANDLE,	1
S60-1491-901	TRIM - CAP, GRABHANDLE, L	1

*S97-1313-000 INSTL - A PILLAR TRIM***3S00-D04-LAF B PILLAR TRIM, UPPER***B PILLAR TRIM, UPPER*

S60-1485-00661	LH Upper B-Pillar Trim Assembly	1
S60-1485-00661R	RH Upper B-Pillar Trim Assembly	1

*S97-1317-000 INSTL-LOWER B-PILLAR TRIM***3S00-D04-MAT B PILLAR TRIM, LOWER***B PILLAR TRIM, LOWER*

S60-1482-0011901	LH Lower B-Pillar Trim Assembly, Midnight Black	1
S60-1658-0011901	RH Lower B-Pillar Trim Assembly, Midnight Black	1

*S97-1316-000 INSTL - UPPER B-PILLAR TR***3S00-D06-AAD DAY CAB FRONT STORAGE***DAY CAB FRONT STORAGE*

S60-1370-00661	Front Header Trim Assembly, Light Gray	1
S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	11
S11-1476	KW-Bracket Day Cab	1
S11-1476R	KW-Bracket Day Cab	1
K169-239-5-33	Self Retaining Hex Nut (M5 x 7 0.80)	

*S97-1322 INSTL - NGP DAYCAB HEADER***3S00-D06-BBH OVER DOOR STORAGE***OVER DOOR STORAGE*

S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 x 25mm)	2
S60-1337-0661	KW-OVR DR WING	1
S60-1337-0661R	KW-OVR DR WING	1

15-15988 U-Nut (M5 X 0.80) 2

*S97-1322 INSTL - NGP DAYCAB HEADER*

**3S00-D06-DAE REAR WALL RECORDS HOLDER**

*REAR WALL RECORDS HOLDER*

S29-1071-00901 COMPT- RECORDS, PLASTIC 1

S64-1435-00901 Plate - Backing IM 1

W20-6017-05035S030 Self Retaining Nut (M5 x 0.80) 2

W01-10-01P55N035B Pan Head Screw (M5 x 0.80 x 4 35mm), Black

S34-6003-0630TP00B PSD Screw (M6 x 1.00 x 30mm), Black 2

29-05726 U-Nut (M6 x 1.00) 2

*S97-1373-100 INSTL - RECORDS HOLDER*

**3S00-D06-MCD HEADER BEZEL**

*HEADER BEZEL*

S60-1560-13601 Header Electrical Tray Assembly, Black 1

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 x 25mm) 3

S60-1664-101661 Header Bezel Trim Assembly, Light Gray 1

*S97-1322 INSTL - NGP DAYCAB HEADER*

**3S00-D08-AAC INTERIOR CAB GRAB HANDLES - STD**

*INTERIOR CAB GRAB HANDLES - STD*

S56-1042-601 LH A-Pillar Grab Handle, Black 1

S56-1044-601 RH Grab Handle 1

S56-1049-601 HANDLE-GRAB B-PILLAR BLK 2

S34-6003-0835RHL0B FASTENER-INTERIOR THREADE 14

S42-1026 GROMMET-HANDLE, KW 2

S42-1028 GROMMET-HANDLE, B-PILLAR4

*S97-1311-000 INSTL-GRAB HANDLE, INTER.*

**3S00-D08-BAE TRANS ACCESS COVER PLATE MANUAL TRANS**

*TRANS ACCESS COVER PLATE MANUAL TRANS*

S22-6041M01-252 COVER-SHIFTER,PLATE 1

05-17811-272 PLATE-SHIFTER ALUM 1

05-17812-230 INSULATOR-FOAM SHIFTER PLATE 1

S34-6003-0640TP00B FASTENER-INTERIOR THREADE 12

S09-6000 Shifter Boot 1

05-17808-001 Shifter Boot, for Hollow Shifter 1

05-17809 Shifter Boot Retainer, Aluminum 1

27-01426-005 Pan Head Thread Rolling Screw (#10-24 x 5/8") 6

*SK27172 PLATE COVER FLOOR*

*E97-6105 INSTL - SHIFTER BOOTS*

**3S00-D20-AAM HVAC CAB MODULE, FINE PARTICULATE FLTR***HVAC CAB MODULE, FINE PARTICULATE FLTR*

F31-1358-118	Air Intake Module Assembly	1
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	8
Q21-1088	SENSOR - SUN LOAD	1
F31-1375	Cab HVAC Module Assembly	1
F04-1007	ELBOW-DRAIN TUBE	1
D2030-9106	Retaining Ring, Steel, #6	1
<i>F97-1922-100 INSTL - HVAC, CAB</i>		
<i>F97-1922-200 INSTL - HVAC, CAB</i>		

**3S00-D20-BAC HVAC CAB DUCTING***HVAC CAB DUCTING*

F66-2363	Floor Duct LH	1
<i>F97-1922-100 INSTL - HVAC, CAB</i>		
<i>F97-1922-200 INSTL - HVAC, CAB</i>		

**3S00-D20-DAD HVAC RECEIVER / DRYER***HVAC RECEIVER / DRYER*

F37-1022-200	DRYER - RECEIVER W/DYE	1
R34-6002-08035RH0K	Exterior Threaded Hex Screw (M12 x 1.75 x 35mm)	3
<i>F97-1922-200 INSTL - HVAC, CAB</i>		

**3S00-D20-EBC HVAC CAB DISCHARGE LINE***HVAC CAB DISCHARGE LINE*

F50-2481-120	A/C Discharge Line	1
W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25)	2
<i>F97-2306-100 INSTL - HVAC LINES</i>		

**3S00-D20-FDP CAB HVAC SUCTION LINE***CAB HVAC SUCTION LINE**F97-2211 INSTL - A/C, SUCTION***3S00-D20-GAC CAB HVAC LIQUID LINE***CAB HVAC LIQUID LINE**CAB TRIM LIQUID LINES & HARDWARE*

F50-2043-200	TXV Liquid Line Assembly	1
W20-6011-08TDY0Z	Flanged Lock Nut (M8 x 1.25)	1
<i>ASSEMBLY 1 LIQUID LINE HARDWARE</i>		
F50-2038-003	Liquid Line Assembly	1
D16-6003-7612106	Cushioned Clamp (3/8")	3
D16-6003-5412110	Cushioned Clamp (1-1/2")	1
K169-163-8CA	Locking Hex Nut (M8 x 1.25)	3
K041-802-20CA	Hex Bolt (M6 x 1.00 x 20mm)	1
K028-2489-18	90° Standoff Bracket	1
W20-6011-06TDY0Z	Exterior Threaded Hex Screw (M6 x 1.00 x 25mm)	1
K363-338-2-250	Flat Washer (1/4")	1
K363-338-2-312	Flat Washer (5/16")	6
K041-803-40CA	Hex Bolt (M8 x 1.25 x 40mm)	3
<i>ASSEMBLY 1 LIQUID LINE HARDWARE</i>		
D16-6003-7612106	Cushioned Clamp (3/8")	1
K206-34-15		

Hex Screw, Self-Tapping (M6 1  
x 1.00 x 15mm)  
W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25) 1  
*ASSEMBLY 2 LIQUID LINE HARDWARE*  
W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25) 1  
*F97-1922-200 INSTL - HVAC, CAB*  
*F97-2147-003 INSTL - HVAC LIQUID LINE*

### **3S00-D30-AAC DRIVER SEAT MOUNTING HARDWARE**

#### *DRIVER SEAT MOUNTING HARDWARE*

R34-6002-12055VFLK Exterior Threaded Hex Screw 4  
(M12 x 1.75 x 55mm)  
S80-1021 Spacer - Seat 4  
*S97-1332 - INSTL - SEAT, NGP*

### **3S00-D30-BBB DRIVER SEAT RESTRAINTS**

#### *DRIVER SEAT RESTRAINTS*

S84-1087-00601 Belt-Kit, Seat Mounted 1  
*S97-1333 INSTL - SEAT BELT*

### **3S00-D31-AAF PASSENGER SEAT MOUNTING HARDWARE**

#### *PASSENGER SEAT MOUNTING HARDWARE*

R34-6002-12055VFLK Exterior Threaded Hex Screw 4  
(M12 x 1.75 x 55mm)  
S80-1021 Spacer - Seat 4  
*S97-1332 - INSTL - SEAT, NGP*

### **3S00-D31-BBM PASSENGER SEAT RESTRAINTS**

#### *PASSENGER SEAT RESTRAINTS*

S84-1089-00601 Belt - Kit, Seat Static 1  
*S97-1333 INSTL - SEAT BELT*

### **3S00-D50-AAE COMMON DASH STRUCTURE**

#### *COMMON DASH STRUCTURE*

S07-6017-600 Beam - Cross Car 1  
S85-6028 SUPPORT- COWL STRAP 1  
*HARDWARE - X CAR BEAM TO DASH STRUT*  
S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 2  
x 25mm)

#### *HARDWARE - BODY SIDE TO BEAM*

R34-6002-08105RH0M Exterior Threaded Hex Screw 6  
(M8 x 1.25 x 105mm)

#### *HARDWARE - FRONT WALL, DRIVER CENTER*

R34-6002-08070RH0M FASTENER-THREADED,EXT 1  
*HARDWARE - CTR STK BRKT TO ENG RECESS*

S34-6003-0830RHLOB Hex Lock Screw (M8 x 1.25 x 1  
30mm), Black

#### *S97-6138 INSTL-DASH ASSEMBLY*

#### *S97-6136 INSTL-DASH STRUCTURE*

### **3S00-D50-BAY ECU HOTEL BRACKET**

#### *ECU HOTEL BRACKET*

S11-6311-102 ECU Hotel Bracket Assembly, 1  
Bendix

#### *HARDWARE - HOTEL TO X-CAR BEAM*

W20-6011-08TDY0Z Flanged Lock Nut (M8 x 1.25) 2

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 1  
x 25mm)

*HARDWARE - HOTEL TO RECESS*

S34-6003-0830RHL0B Hex Lock Screw (M8 x 1.25 x 2  
30mm), Black

A62-6084 Cable Tie Mount 1

**3S00-D52-ABZ DASH TRIM**

*DASH TRIM*

S62-6142-2C2901901 Dash Assembly, Midnight 1  
Black

S10-6031-0901 Glovebox Assembly, Midnight 1  
Black

S64-1286-1601 Louver Defrost Panel 1  
Assembly, Gray

*DASH ASSY HARDWARE*

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 12  
x 25mm)

*GLOVE BOX HARDWARE*

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 6  
x 25mm)

*DASH TO STRUCTURE HARDWARE*

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 5  
x 25mm)

*S97-6145 INSTL-DASH ASSY*

*S97-6146 INSTL-GLOVEBOX*

*S98-1007 SPECIFICATION TRIM - FILM*

**3S00-D52-BAN KICK PANELS**

*KICK PANELS*

S06-6040-0761901 Dash Cupholder Assembly, 1  
Midnight Black

S60-6274-0K901 LH Kick Panel Trim Assembly, 1  
Midnight Black

S60-1422-901 TRIM-A PILLAR LOWER RH 1

S60-1302-901 TRIM-KICK PANEL, RH 1

S60-6261-901 TRIM-KICK PANEL,LH 1

S60-1304-0901 LH Upper Kick Panel Trim, 1  
Midnight Black

S22-6100-901 COVER-ACCESS, PDM 1

S60-6233-901 TRIM-GRABHANDLE 2

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 9  
x 25mm)

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 2  
x 25mm)

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 1  
x 25mm)

S34-6003-0525TP00B PSD Screw, Black (M5 x 0.80 2  
x 25mm)

*SHOP NOTE: REMOVE LOCATION TAB FROM  
LEFT SIDE OF S06-1069.*

*SHOP NOTE: ON S06-1069 BEND CLIP  
CLOSEST TO REMOVED TAB AN ADDITIONAL*

20DEG TO BETTER GRIP S06-1070.

S97-6150 INSTL - KICK PANEL

**3S00-D54-ABA DASH A PANEL**

DASH A PANEL

S18-1050-1C2761	A-Panel Bezel Assembly, Riverstone	1
-----------------	---------------------------------------	---

S97-1454 INSTALL-DASH PANELS

S98-1007 SPECIFICATION TRIM - FILM

**3S00-D54-BBP DASH B PANEL**

DASH B PANEL

S18-1055-01C2761	B-Panel Bezel Assembly, Riverstone	1
------------------	---------------------------------------	---

S77-1039-2901	B-Panel Reinforcement Assembly, Midnight Black	1
---------------	---	---

S64-1312	PANEL-5 SWITCHES	1
----------	------------------	---

S64-1314	PANEL-11 SWITCHES	1
----------	-------------------	---

S64-1315	PANEL-7 SWITCHES	1
----------	------------------	---

SWITCH PANEL HARDWARE

S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 8 x 25mm)	8
--------------------	--	---

REINF PANEL HARDWARE

S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 10 x 25mm)	10
--------------------	---	----

B-SUBPANEL HARDWARE

S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 6 x 25mm)	6
--------------------	--	---

S97-1454 INSTLN PANEL AND TRIM

S97-6148 INSTLN B-PANEL COMPONENT

**3S00-D54-CAC DASH C PANEL**

DASH C PANEL

S64-1313-601	C-Panel Reinforcement Assembly, Black	1
--------------	--	---

S34-6003-0525TP00B	PSD Screw, Black (M5 x 0.80 3 x 25mm)	3
--------------------	--	---

S97-6147 INSTALLATION PANEL AND TRIM

S97-6151 INSTL C-PANEL COMPONENT

**3S00-D54-DAW DASH D PANEL**

DASH D PANEL

S18-1037-12761	D-Panel Bezel Assembly, Riverstone	1
----------------	---------------------------------------	---

S97-6147 INSTL - PANEL & TRIM

S97-6152 INSTL - D PANEL

**3S00-D54-EAK LH B-SUBPANEL W/ SIX GAUGES**

LH B-SUBPANEL W/ SIX GAUGES

S64-1284-06901	PANEL-B,GAUGE	1
----------------	---------------	---

**3S00-D54-FAK RH B-SUBPANEL W/ STORAGE BIN**

RH B-SUBPANEL W/ STORAGE BIN

S29-1043-601	BIN-STORAGE	1
--------------	-------------	---

**3S00-D56-DAC STORAGE TRAY - RIGHT THREE SWITCH BANK**

STORAGE TRAY - RIGHT THREE SWITCH BANK

S06-1073-601 TRAY-STORAGE,3 POSN 1

#### DASH IMPACT! RERUN DASH

**3Y00-D00-ABA DOOR LABEL- U.S RGSTRY- COMPLETE VEH**

DOOR LABEL- U.S RGSTRY- COMPLETE VEH

S53-1391 LABEL-CERT, BLANK STOCK 1

22-01644 LABEL-CLEAR,SHEET 1

SHOP NOTE: THE FOLLOWING LABELS WILL  
BE PRINTED ON BLANK STOCK:

- S53-6167 LABEL-EPA NOISE EMISSIONS
- 22-01467 LABEL-FMVSS CERTIFICATION
- S53-1269 LABEL-CHASSIS SCALE WEIGHT
- 22-01478 LABEL-COMP AND COLORS

S97-1402 INSTL-DOOR LABELS 2.1M

**3Y00-D00-BAC KW PATENT LABELS - ENGLISH**

KW PATENT LABELS - ENGLISH

S53-1248-001 LABEL-PATENT 1

S97-1310-000 INST - LABEL CAB

**3Y00-D00-GAC DOOR MTD - C.A.R.B EMISSION LABELS**

DOOR MTD - C.A.R.B EMISSION LABELS

5259894 DECAL-CLEAN IDLE, CARB 1

R97-1734-100 INSTL - EMISSIONS LABEL

**3Y00-D00-KAC VIN BADGE PLATE**

VIN BADGE PLATE

R22-1530 PLATE-SERIAL NUMBER 1

R97-1473 INSTL-SERIAL NO.PLATE

**3Y00-D00-RAC BACKUP ALARM LABELS**

BACKUP ALARM LABELS

16-03337 Label - Backup Alarm 1

S97-1309-000 INSTL-NGP SUN VISOR

**3Y00-D00-XAC A/C REFRIGERANT DECAL**

A/C REFRIGERANT DECAL

ENGLISH USE W/ DAY CAB OR 40" SLEEPER

A/C REFRIGERANT CHARGE 3 LBS, 4 OZ

F53-1046-100 DECAL-AC CHARGE 1

SHOP NOTE:

A/C CHARGE LABEL TO BE INSTALLED ON  
THE FRAME RAIL PER F97-1922-000

SHEET 3

F97-1922-000 - INSTL HVAC, CAB

**3Y00-D00-YAC FIRE EXTINGUISHER LABELS/PLATES**

FIRE EXTINGUISHER LABELS/PLATES

K281-4320 PLATE - FIRE EXTINGUISHER 1

**3Y00-D02-AAD RECEPTACLE DECALS - SIDE OF CAB**

RECEPTACLE DECALS - SIDE OF CAB

PLACE LABEL ON THE CENTER OF  
RECEPTACLE COVER (SIDE OF THE CAB)

R53-1037-002 DECAL-RECPT COVER 1

U97-1104 INSTL-CAB/SLPR DECALS LOC

**3Y00-D02-DAD DOOR BADGE**

DOOR BADGE

R53-1043 BADGE - T880 2

R97-1703 INSTL - 2.1M DOOR EMBLEM

R97-1703 INSTL - 2.1M DOOR EMBLEM

### **3Y00-D02-EAF ESP CAB LABELS - ENGLISH**

ESP CAB LABELS - ENGLISH

S53-6208-100 LABEL-DASH, ESP - ENGLISH 1

G53-6029-100 Stability Control Label, English 1

S97-1251-001 INSTL - LABELS, ESP

### **3Y00-D02-HAC GHG LABEL**

GHG LABEL

S53-6198 LABEL- GREEN HOUSE GAS 1

S97-1310-000 INST - LABEL CAB

### **3Y00-D02-NAC SERVICE MANAGEMENT QR CODE LABEL**

SERVICE MANAGEMENT QR CODE LABEL

S53-1330 LABEL - SERV MGMT QR CODE 1

S97-1310-000 INSTL - DOOR LABELS

### **3Y00-D02-QAC DIESEL EXHAUST LABEL**

DIESEL EXHAUST LABEL

S53-6190-100 LABEL-DIESEL EXHAUST 1

S97-1309 INSTL-SUNVISOR LABEL

### **3Y00-D02-VAC EPA EMISSION LABELS**

EPA EMISSION LABELS

6477369 LABEL-EPA CLEAN IDLE CM 1

SHOP NOTE: SEE INSTL PRINT SHEET 1 FOR

EPA LABEL ONLY. SEE SHEET 2 FOR EPA

AND CARB LABEL REQUIREMENT.

DOOR MTD EPA LABEL

R97-1734-100 INSTL-EPA EMISSION LBL

### **3Y00-D10-BAC SAFETY & WARNING LABELS**

SAFETY & WARNING LABELS

A53-1001-10 LABEL-CHASSIS COMBINATION 2

A53-1001-1 LABEL-CHASSIS,WHL LUGNUTS 4

SHOP NOTE: REF DWG R414-103 SHEET 8

### **3Y00-D10-CAC TIRE WARNING LABELS**

TIRE WARNING LABELS

A53-1043-1 DECAL-TIRE WARNING ENGL 2

SHOP NOTE: PLACE LABELS NEXT TO

A53-1001-1 NEAR THE FRONT AXLE OF

LH AND RH FRAME RAIL.

### **3Y00-D10-DAC FUEL TANK WARNING LABEL**

FUEL TANK WARNING LABEL

K53-6008-001 Fuel Tank Warning Label, English 2

SHOP NOTE: PLACE ADJACENT TO FUEL FILL

### **3Y00-D10-EAQ WARNING LABEL - BATTERY DISCONNECT**

WARNING LABEL - BATTERY DISCONNECT

P53-1284-001 LABEL - DISCONNECT SWITCH 1

*S97-1417-210 INSTL - BATT DISCO LABEL*

**3Y00-D10-GAC BBOX STEP/JUMP START/CHARGE LABELS**

*BBOX STEP/JUMP START/CHARGE LABELS*

A53-1054-100 Warning Label, Battery (English) 1

*P97-1085 INSTL - BATT WARNING LABELS*

**3Y00-D10-HAC TRAILER ABS LABEL**

*TRAILER ABS LABEL*

A53-1001-12 LABEL-CHASSIS, CENTER PIN 1

**3Y00-D10-KAF ESP FRAME LABELS - ENGLISH**

*ESP FRAME LABELS - ENGLISH*

A53-6025-100 LABEL-CHASSIS, STABILITY 2

J53-6003-100 Steering Column Label, English 2

*S97-1251-001 INSTL - ESP, LABELS*

**3Y00-D10-LAC SYNTHETIC OIL LABELS - REAR AXLE**

*SYNTHETIC OIL LABELS - REAR AXLE*

E53-6000 DECAL - SYNTHETIC LUBE 1

**3Y00-D10-NAC SYNTHETIC OIL LABELS - TRANSMISSIONS**

*SYNTHETIC OIL LABELS - TRANSMISSIONS*

**3Y00-D15-AEL OPERATORS MANUAL - ENGLISH**

*OPERATORS MANUAL - ENGLISH*

*OPERATOR S MANUAL KIT*

Y53-1200-1K1 OP MAN-T680, T880, ES 1

*OPERATOR S MANUAL SUPPLEMENT*

Y53-6091-1F1 MANL-OP, AFTMNT\_EN 1

*LITERATURE & DECAL*

Y53-1281 LITERATURE- TAT 1

Y53-1282 DECAL- TAT 1

*KENWORTH KEYCHAIN*

K4056C KEYCHAIN-STD, KW 1

**3Y00-D15-BDT ENGINE OPERATOR & MAINT MANUAL**

*ENGINE OPERATOR & MAINT MANUAL*

*ISX15 - ENGLISH*

6380841 2024 X15 MANUAL - EN 1

**3Y00-D30-AAE 5.5LB FIRE EXTINGUISHER - MTD ON**

*5.5LB FIRE EXTINGUISHER - MTD ON*

*PASSENGER SEAT BASE RH*

S86-6000 EXTINGUISHER-FIRE,5.5 LB 1

S34-6003-0619RXL0B Torx Screw (M6 x 1.00 x 19mm), Black 4

S63-1016 PAD-ISOLATOR FOAM 1

*S97-1349-110 INSTL-COMPONENTS, TOOLBOX*

**3Y00-D30-DAD WARNING TRIANGULAR REFLECTOR KIT**

*WARNING TRIANGULAR REFLECTOR KIT*

S74-1008 REFLECTOR - KIT, WITH HOL 1

**3Y00-D60-AAD ROUTING LAYOUT DWGS**

*ROUTING LAYOUT DWGS*

