3195 D Airport Loop

Costa Mesa, CA 92626 Tel. 714-556-8818 Fax. 714-656-1520

www.ktihydraulics.com

# KTI DC POWER UNIT TROUBLE SHOOTING GUIDE

# **General Instructions for 12V DC Systems**

- 1) Check battery voltage. If voltage is 9 Volt or less, do not operate power unit. Change battery to 12 Volts
- 2) Check to see that the motor is wired correctly to starter switch and all other contact wires have light connections
- 3) Check ground wire for good connection
- 4) Check reservoir oil level
- 5) Do not tamper with relief valve. Factory preset to specified pressure and wired. Cutting this wire voids warranty

### **SYMPTOMS**

- 1) Unit will not start (see causes 1,2,7)
- 2) Unit drifts when power is off (see causes 3,4,5)
- 3) Slow Cylinder travel (see causes 1,2,4,5)
- 4) Unit will not lower (see causes 2,3)

## PROBABLE CAUSE

- 1) Improper voltage motor (see solutions A,D,E)
- 2) Improper Ground (see solutions A,F,G)
- 3) Improper voltage to calves (see solutions A,F)
- 4) Leakage thru solenoid valves (see solutions C,D)
- 5) Internal leakage at cylinder (see solutions D,E)
- 6) Insufficient oil to pump inlet (see solutions B,C,E)
- 7) Pump seized or locked (see solutions D,E)

# POSSIBLE SOLUTION

- A) Check wiring to insure that all connections are tight
- B) Keep oil reservoir full and clean
- C) Flush and clean cartridge valves and/or hydraulic system
- D) Replace components
- E) Return for necessary repair
- F) Check for clean, tight, metal- to- metal contact on wire connections
- G) Make sure nuts on top of solenoid valve coil is tight to 40 inch/lb maximum

### **FLUIDS**

KTI recommends using top quality hydraulic fluid with AISO VG 22-68(198-74 8 cSt 97-347 SUS at 40\* C) to ensure optimum performance and system life. Fluids should have anti-wear properties rust and oxidation inhibitors. If using synthetic fluids, consult the factory for alternative seal material requirements Fluid Tomnerature Range

Fluid Temperature Range	ISO Viscosity Grade (ISO VG)		
-5* F to +140 *F	22		
-21* C to + 60* C	22		
+5* F to + 170* F	32		
-15* C to + 77 * C	32		
+15* F to + 190*F			
-9*C to + 88* C	46		
+30* F to + 210* F	46		
1*C to + 99*C	68		
	68		

Do not operate Power unit above recommended Fluid Temperature Range. Premium hydraulic oil with proper Viscosity Grade and additives such as Chevron EP, Mobile DTE10, DTE 20 Series or Shell Tellus would be acceptable.

# T ERENCE TI Hydraulics Pump



7	HOSES CONNECTED BACKWARDS	PACKING ON CYLINDER ROD WORN OUT	LOOSE INLET	BAD SEALS IN CYLINDER	COIL NOT ENERGIZING	THERMAL PRESSURE LOCK	DEBRIS IN LOAD HOLDING VALVE	CHECK HAND CONTROL	POOR GROUND CONDITION	LOW BATTERY VOLTAGE	For additional trouble shooting questions, please call KTI Hydraulics at (1)-714-556-8818
											N.
							3019				Not Building Pressure  Motor Not Ruppi
		•			•						Motor Not Running  Cylinder Won't To
			0								- IIII - IIII
100											Cylinder Won't Extend Won't Retract  Exception Hold I
		0					9				inder Won's Strend
										0	W- Ros
			•								
			9		100				0		Aeration - Heat From I
										0	
				1							Aeration of Hydraulic Fluid Reservoir Overflows Struggles To Lift Load
								0	D (	9	
8		0								1	Struggles Onit Not One
98											Struggles To Lift Load  Start Solensia
			9 63			0.51					Start Sol When o
				6						V	Struggles To Lift Load  Start Solenoid Just Clicks-Motor Not  Von't Lift Load (DC Motor Under Load)  Won't Lift Load (DC Motor Not Under Load)
										V	Von:
THE PARTY NAMED IN							0				Lift Load (De Motor Unit
						-	-			+	(OC Motor Not Load)
95				100						1	Sta Clark
	0			0						C	Vlinder Solenoid
										1	Start Solenoid Stays On  Von't Lower  Vlinder Won't Retract (Motor Under Load)
											act (Motor Und
											(der Load)

CHECK FOR ADDITIONAL VALVING ON OR CON-NECTED TO CYLINDER

PUMP NOT PRIMING CLOGGED ORIFICE RUST IN MOTOR BAD DIODE

.

9

.

0

.

.

.

.

0

DIRECTIONAL VALVE NOT SHIFTING PROPERLY

DIRTY CONTACTS IN HAND CONTROL

0

0

.

0

. .

0

0 -

0

8

0

BAD START SOLENOID