



Transport Operations (Road Use Management) Act 1995

TRB Forms Area Form F2872 V01 May 2015



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: TL114

DATE: 4-9-24

HRS _____

KLM _____



DESCRIPTION OF MAINTENANCE:

- Check hydraulics working properly as were very slow at the start.
- Flush air system
- Check bearings

NAME: MARK ALLEN

SIGNATURE: _____

WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: TH 114

DATE: 6/9/24

HRS _____

KLM



DESCRIPTION OF MAINTENANCE:

BACK GUDGE AND RE-WELD CRACKS ALONG BOTH SIDES OF CHASSIS

BACK GUAGE + RE-WELD CORR PLATES ON
HYDRAULIC MOUNTS (ON TUB) -

REMOVE / REPLACE / WELD OUT
DAMAGED SECTION ON HUNGARY BOARD

NAME: 711 29

SIGNATURE:

ENTERED	
DATE 6/11/24	BY DF



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: TH 114

DATE: 6/9/24

HRS _____

KLM _____



DESCRIPTION OF MAINTENANCE:

BACK GUDGE AND REWELD CRACKS ALONG
BOTH SIDES OF CHASSIS

BACK GUDGE + REWELD COMB PLATES ON
HYDRAULIC MOUNTS (ON TUB) -

REMOVE / REPLACE / WELD OUT
DAMAGED SECTION ON HUNGAR BOARD

NAME: FITZY

SIGNATURE: IFy



TRAILER & DOLLY SERVICE SHEET

ENTERED
DATE 6/11/24 BY DF


DATE 9-9-24 START TIME _____ FINISH TIME _____
FLEET NO 12114 KM'S N/A HRS _____

JOB NO _____
REGO YB67ED

Service Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable		A Service	B Service	C Service
Local Trailers	40000km/365 days	7 DAYS	14 DAYS	40000KM
Linehaul Trailers	15000km 10 days 150000km/365days		15000KM	150000KM
1	Check faults noted on daily prestart and repair as necessary			MH
2	Check fleet numbers are serviceable			MH
3	Record Hub meter reading			N/A
4	Lubricate Container Pins			N/A
5	Check operation & condition of all lights/reflectors			MH
6	Apply Air Check for leaks from boosters, valves & air lines			MH
7	Adjust brakes, visually inspect components			MH
8	Check air cells for air leaks and deterioration			MH
9	Drain all air tanks, report if any oil is present in system			MH
10	Grease trailer incl. brake cams, slack adjusters, landing legs, ring feeder & other grease points			MH
11	Check hoist mounting bolts, hoses, coupling			MH
12	Check number plate & rego label security. Check that rego label is current			MH
13	Check condition of front air connections, light plug base & electrical lead			MH
14	Check security of spare wheels & spare wheel carrier/gate rack			N/A
15	Check condition & security of all mudflaps, mudguards, brackets & spray suppression			MH
16	Check landing legs for damage & security			MH
17	Check sub frame & cross members for cracks, damage & security			MH
18	Check condition, position & security of all air hoses			MH

19	Check brake linings & drums for wear. Check hub seals for leakage
20	Check security of height control valves and links & adjust if required
Check skid plate/king pin security & condition, check draw bar/bushes and towing eye NOTE: If draw bar eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be checked for tolerances	
21	checked for tolerances
22	Check wheel nut tensions, check valve stem alignment
23	Check all tyre pressures and refit valve caps (including spare) report abnormal wear
24	Check condition & security of rear marker signs
25	Check ring feeder condition, operation & security
26	Lubricate twist locks & check operation & security of pedestals, straighten handles as required
27	Check condition & security of rope rails, gate pockets, winch rails & straps
28	Check condition & security of floor and associated components
29	Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear
30	Check security & bolt tension of airbag suspension hangers & radius rod arms
31	Raise wheel assembly & check bearings for free play by "feel" only & adjust as required
32	Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted

MH
N/A
MH
MH
MH
MH
N/A
N/A
MH
MH
MH
MH



33	Check brake linings & drums for wear whilst hubs are removed
34	Check hubs for cracks and tapered shoulders for wear
35	Remove bearings and clean/inspect for reuse
36	Replace mudflaps & decals as required
37	Remove s/cam slack adjuster pins and rotate/lubricate
38	Pack bearings with fresh grease & reassemble

MH
MH
N/A
MH
N/A
N/A

Initial if adjusted - Tick if OK

PLEASE COMPLETE PAGE 2



* REPLACE TRAILER PLUG ~~AT~~ FRONT OF TRAILER

* Fit New "DO NOT OVERTAKE" SIGN

[illegible]

MATI H

9-9-24

Date _____

9-9-24



TRAILER & DOLLY SERVICE SHEET

01815


DATE 9-9-24 START TIME _____ FINISH TIME _____
FLEET NO 12114 KM'S N/A HRS _____

JOB NO _____
REGO YB67ED

Service Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable		A Service	B Service	C Service
Local Trailers	40000km/365 days	7 DAYS	14 DAYS	40000KM
Linehaul Trailers	15000km 10 days 150000km/365days		15000KM	150000KM
1	Check faults noted on daily prestart and repair as necessary			MH
2	Check fleet numbers are serviceable			MH
3	Record Hub meter reading			N/A
4	Lubricate Container Pins			N/A
5	Check operation & condition of all lights/reflectors			MH
6	Apply Air Check for leaks from boosters, valves & air lines			MH
7	Adjust brakes , visually inspect components			MH
8	Check air cells for air leaks and deterioration			MH
9	Drain all air tanks, report if any oil is present in system			MH
10	Grease trailer incl. brake cams, slack adjusters, landing legs, ring feeder & other grease points			MH
11	Check hoist mounting bolts, hoses, coupling			MH
12	Check number plate & rego label security. Check that rego label is current			MH
13	Check condition of front air connections, light plug base & electrical lead			MH
14	Check security of spare wheels & spare wheel carrier/gate rack			N/A
15	Check condition & security of all mudflaps, mudguards, brackets & spray suppression			MH
16	Check landing legs for damage & security			MH
17	Check sub frame & cross members for cracks, damage & security			MH
18	Check condition, position & security of all air hoses			MH

19	Check brake linings & drums for wear. Check hub seals for leakage
20	Check security of height control valves and links & adjust if required
Check skid plate/king pin security & condition, check draw bar/bushes and towing eye NOTE: If draw bar eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be checked for tolerances	
21	
22	Check wheel nut tensions, check valve stem alignment
23	Check all tyre pressures and refit valve caps (including spare) report abnormal wear
24	Check condition & security of rear marker signs
25	Check ring feeder condition, operation & security
26	Lubricate twist locks & check operation & security of pedestals, straighten handles as required
27	Check condition & security of rope rails, gate pockets, winch rails & straps
28	Check condition & security of floor and associated components
29	Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear
30	Check security & bolt tension od airbag suspension hangers & radius rod arms
31	Raise wheel assembly & check bearings for free play by "feel" only & adjust as required
32	Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted

	MH
	N/A
	MH
	MH
	MH
	MH
	N/A
	N/A
	MH
	MH
	MH
	MH



33	Check brake linings & drums for wear whilst hubs are removed
34	Check hubs for cracks and tapered shoulders for wear
35	Remove bearings and clean/inspect for reuse
36	Replace mudflaps & decals as required
37	Remove s/cam slack adjuster pins and rotate/lubricate
38	Pack bearings with fresh grease & reassemble

	MH
	MH
	N/A
	MH
	N/A
	N/A

Initial if adjusted - Tick if OK

PLEASE COMPLETE PAGE 2



TRAILER & DOLLY SERVICE SHEET

Work/Repairs carried out

* REPLACE TRAILER PLUG ~~AT~~ FRONT OF TRAILER

* FIT NEW "DO NOT OVERTAKE" SIGN

List any defect found

Part No/Consumables	Qty	Part No/Consumables	Qty

Tradesperson Name	MATT H	Signature	
		Date	9-9-24

PLEASE COMPLETE PAGE 2

[illegible][illegible]

Tradesperson Name	MATT H	Signature	
		Date	10-10-24

ENTERED	
DATE	BY



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: TL114

DATE: 13/1/24

HRS: _____

KLM: _____



DESCRIPTION OF MAINTENANCE:


- * Replace drivers side Front & middle axle spring pack
- * Crack Repairs
- * Replace King pin & bolts

NAME: L Forder

SIGNATURE: [Signature]

[illegible][illegible]


Tradesperson Name	MAT H	Signature	
		Date	



DATE 15-12-24 START TIME _____ FINISH TIME _____ JOB NO _____
FLEET NO DL114 KM'S N/A HRS _____ REGO _____

Service Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable		A Service	B Service	C Service
Local Trailers	40000km/365 days	7 DAYS	14 DAYS	40000KM
Linehaul Trailers	15000km 10 days 150000km/365days		15000KM	150000KM
1	Check faults noted on daily prestart and repair as necessary	MH		
2	Check fleet numbers are serviceable	MH		
3	Record Hub meter reading	N/A		
4	Lubricate Container Pins	N/A		
5	Check operation & condition of all lights/reflectors	MH		
6	Apply Air Check for leaks from boosters, valves & air lines	MH		
7	Adjust brakes , visually inspect components	MH		
8	Check air cells for air leaks and deterioration	MH		
9	Drain all air tanks, report if any oil is present in system	MH		
10	Grease trailer incl. brake cams, slack adjusters, landing legs, ring feeder & other grease points	MH		
11	Check hoist mounting bolts, hoses, coupling	MH		
12	Check number plate & rego label security. Check that rego label is current	MH		
13	Check condition of front air connections, light plug base & electrical lead	MH		
14	Check security of spare wheels & spare wheel carrier/gate rack	N/A		
15	Check condition & security of all mudflaps, mudguards, brackets & spray suppression	MH		
16	Check landing legs for damage & security	MH		
17	Check sub frame & cross members for cracks, damage & security	MH		
18	Check condition, position & security of all air hoses	MH		

19	Check brake linings & drums for wear. Check hub seals for leakage
20	Check security of height control valves and links & adjust if required
21	Check skid plate/king pin security & condition, check draw bar/bushes and towing eye eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be checked for tolerances
22	Check wheel nut tensions, check valve stem alignment
23	Check all tyre pressures and refit valve caps (including spare) report abnormal wear
24	Check condition & security of rear marker signs
25	Check ring feeder condition, operation & security
26	Lubricate twist locks & check operation & security of pedestals, straighten handles as required
27	Check condition & security of rope rails, gate pockets, winch rails & straps
28	Check condition & security of floor and associated components
29	Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear
30	Check security & bolt tension of airbag suspension hangers & radius rod arms
31	Raise wheel assembly & check bearings for free play by "feel" only & adjust as required
32	Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted

[illegible]


33	Check brake linings & drums for wear whilst hubs are removed
34	Check hubs for cracks and tapered shoulders for wear
35	Remove bearings and clean/inspect for reuse
36	Replace mudflaps & decals as required
37	Remove s/cam slack adjuster pins and rotate/lubricate
38	Pack bearings with fresh grease & reassemble

Initial if adjusted - Tick if OK

PLEASE COMPLETE PAGE 2

[illegible][illegible][illegible]

Tradesperson Name		Signature	
		Date	




TRAILER & DOLLY SERVICE SHEET

DATE 21-12-24 START TIME _____ FINISH TIME _____
 FLEET NO 12114 KM'S N/A HRS _____

JOB NO _____
 REGO _____

Service Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable		A Service	B Service	C Service
Local Trailers	40000km/365 days	7 DAYS	14 DAYS	40000KM
Linehaul Trailers	15000km 10 days 150000km/365days		15000KM	150000KM
1	Check faults noted on daily prestart and repair as necessary	MH		
2	Check fleet numbers are serviceable	MH		
3	Record Hub meter reading	N/A		
4	Lubricate Container Pins	N/A		
5	Check operation & condition of all lights/reflectors	MH		
6	Apply Air Check for leaks from boosters, valves & air lines	MH		
7	Adjust brakes, visually inspect components	MH		
8	Check air cells for air leaks and deterioration	MH		
9	Drain all air tanks, report if any oil is present in system	MH		
10	Grease trailer incl. brake cams, slack adjusters, landing legs, ring feeder & other grease points	MH		
11	Check hoist mounting bolts, hoses, coupling	MH		
12	Check number plate & rego label security. Check that rego label is current	MH		
13	Check condition of front air connections, light plug base & electrical lead	MH		
14	Check security of spare wheels & spare wheel carrier/gate rack	N/A		
15	Check condition & security of all mudflaps, mudguards, brackets & spray suppression	MH		
16	Check landing legs for damage & security	MH		
17	Check sub frame & cross members for cracks, damage & security	MH		
18	Check condition, position & security of all air hoses	MH		

19	Check brake linings & drums for wear. Check hub seals for leakage		
20	Check security of height control valves and links & adjust if required		
21	Check skid plate/king pin security & condition, check draw bar/bushes and towing eye eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be checked for tolerances	NOTE: If draw bar	
22	Check wheel nut tensions, check valve stem alignment		
23	Check all tyre pressures and refit valve caps (including spare) report abnormal wear		
24	Check condition & security of rear marker signs		
25	Check ring feeder condition, operation & security		
26	Lubricate twist locks & check operation & security of pedestals, straighten handles as required		
27	Check condition & security of rope rails, gate pockets, winch rails & straps		
28	Check condition & security of floor and associated components		
29	Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear		
30	Check security & bolt tension of airbag suspension hangers & radius rod arms		
31	Raise wheel assembly & check bearings for free play by "feel" only & adjust as required		
32	Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted		



33	Check brake linings & drums for wear whilst hubs are removed	
34	Check hubs for cracks and tapered shoulders for wear	
35	Remove bearings and clean/inspect for reuse	
36	Replace mudflaps & decals as required	
37	Remove s/cam slack adjuster pins and rotate/lubricate	
38	Pack bearings with fresh grease & reassemble	

Initial if adjusted - Tick if OK

PLEASE COMPLETE PAGE 2

