



Check registration status

View results

BPAY Payments

[BPAY payments](#)  take a few business days to reach us, depending on your bank. **Payment will be backdated once received and your registration status will be updated.** We recommend you carry proof of payment.

Need to pay your registration?

If your registration is due, you can [pay your renewal online](#) . We accept Visa and MasterCard credit or debit cards and American Express. A card surcharge applies.

Registration details

Registration number

874VFZ

Vehicle Identification Number (VIN)

6F5000000DA448777

Description

2013 KENWORTH T659 PRIME MOVER

Gross Vehicle Mass (GVM)

26500 kgs

Gross Combination Mass (GCM)

163500 kgs

TARE

10900 kgs

National Heavy Vehicle Charging Code

MC3

Purpose of use

COMMERCIAL

Status

REGISTERED

Expiry

29/11/2025

Certificate of inspection number

SA 40144830

Certificate of inspection due date

01/12/2025



Payment options


[\(#\)](#)

We accept Visa and MasterCard **credit and debit cards** and American Express.

0.49% surcharge will apply

0.49% surcharge will apply


1.40% surcharge will apply

See [example card surcharges](#) .



Notices

[\(#\)](#)

Please check our scheduled [system outages](#) .



Need help?

[\(#\)](#)



Terms of use

[\(#\)](#)

Copyright (<https://www.qld.gov.au/legal/copyright?content=os-footer-copyright>).

Disclaimer (<https://www.qld.gov.au/legal/disclaimer?content=os-footer-disclaimer>).

Privacy (<https://www.qld.gov.au/legal/privacy?content=os-footer-privacy>).

Right to information (<https://www.qld.gov.au/right-to-information?content=os-footer-rti>).

© The State of Queensland 1995–2025

Brisbane Diff & Gearbox Services Pty Ltd



10 Bellrick Street
ACACIA RIDGE QLD 4110
admin@brisbanediff.com.au

Telephone: (07) 3344 4000 Fax: (07) 3344 3944
Established 1982

ABN 82 011 027 419



Tax Invoice 00015452

WORLD WELDING & TRANSPORT
8-10 KOLONGO CRESANT
MT ISA QLD 4825

Ship To:

WORLD WELDING & TRANSPORT
8-10 KOLONGO CRESANT
MT ISA QLD 4825

			YOUR NO	TERMS	DATE	
			26302	Net 7	23/01/2025	
QTY	ITEM NO	DESCRIPTION	PRICE	UNIT	PRICE ex	GST Code
1	D52 190 4.78	D190 DIFF CENTRE	\$8,000.00	each	\$8,000.00	GST
1	128049	NUT 170/190 THRU SHAFT	\$69.55	Each	\$69.55	GST
1	210737	OIL SEAL 170/190 THRU SHAFT	\$110.49	Each	\$110.49	GST
2	382S	BEARING WIDE CUP 20MM	\$82.23	Each	\$164.46	GST
2	385A	BEARING	\$77.92	each	\$155.84	GST
2	387A	BEARING. 170/190 T/S CONE	\$58.56	Each	\$117.12	GST
<div>PLEASE NOTE: All Units are Exchange , unless prior arrangments have been made by mangement</div> <div>For payments into our Bank Account:</div> <div>Bank of Queensland - Sunnybank</div> <div>BSB: 124 032</div> <div>Account No : 1111 0678</div> <div>Acc Name: Brisbane Diff & Gearbox Service Pty Ltd</div>				Sale Amt (ex GST)		\$8,617.46
				GST		\$861.75
				Total Amt (inc GST)		\$9,479.21
				Paid Amount		\$0.00
				BALANCE		\$9,479.21



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: NW25

DATE: 15-1-25

HRS: 41,388

KLM: 102,077



DESCRIPTION OF MAINTENANCE:

* FIND AND REPAIR A/C FAN FAULT

* REPLACE LEAKING BRAKE BOOSTER ON
FRONT AXLE RHS

NAME: Mat H

SIGNATURE: [Signature]

PRIME MOVER SERVICE

JOB#


Date: 5-2-25

Start Time: _____

Finish Time: _____

Fleet No: NW25Klm: 106,651

Hrs: _____

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY			MH	
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE			MH	
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS			MH	
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL			MH	
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES			MH	
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS			MH	
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT			MH	
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS			MH	
9	GREASE VEHICLE & T/TABLE. (RPLC. DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)			MH	
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS. CHECK TERMINALS, CLEAN & LUBRICATE			MH	
11	CHECK FRONT HUBS OIL LEVELS			MH	
B SERVICE (Items 1 - 53)				B	C
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS			MH	
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC			MH	
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED			MH	
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP			MH	
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWC LABEL, DG LABEL ETC			MH	
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES			MH	
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM			MH	
19	CHECK OPERATION OF LOW ENGINE OIL PRESSURE WARNING SYSTEM			MH	
20	CHECK CONDITION OF BRAKE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS			MH	
21	CHECK PARK BRAKE OPERATION			MH	
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR			MH	
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT			MH	
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION			MH	
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED			MH	
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS				
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING			MH	
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS			MH	
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER			MH	
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT			MH	
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS			MH	
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)			MH	
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE			MH	
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE			MH	
35	ADJUST BRAKES (RAISE VEHICLE)			MH	
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM			MH	
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS.			MH	
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED			MH	
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS			MH	
40	CHECK TURNTABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE PLATE SECURITY			MH	
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR			MH	
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY			MH	
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)			MH	
44	CHECK & ADJUST AIR BAG HEIGHT			MH	
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC			MH	
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC			MH	
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED			MH	
48	CHECK FUEL TANK SECURITY, CHECK MOUNTING RACKETS FOR CRACKS			MH	
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER				
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)			MH	
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)			MH	
52	REMOVE & CLEAN CENTRIFUGAL OIL FILTER BOWL (IF FITTED)				
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED			MH	
					

Entered 11/2/25 OF



WORLD WELDING & TRANSPORT SERVICES

Maintenance Report


VEHICLE: NW 25

DATE: 11/2/25

HRS: 41,483

KLM: 106,654

DESCRIPTION OF MAINTENANCE:




* REPLACE BOTH FRONT LEAF
SPRINGS & PINS, U-BOLTS & NUTS

NAME: Matt H

SIGNATURE: [Signature]



WORLD WELDING & TRANSPORT SERVICES

Maintenance ReportVEHICLE: WW 25DATE: 22-3-25HRS: 41,656KLM: 115,159DESCRIPTION OF MAINTENANCE:

* REPLACE STEER TIRES

* REPLACE FAULTY CRUISE CONTROL SWITCH

* REPLACE EXHAUST FLEX PIPE BEFORE
DPF.

NAME: Matt HSIGNATURE: MH

Entered 2/4/25 OF

PRIME MOVER SERVICE

JOB# _____

Date: 29-3-25

Start Time: _____

Finish Time: _____

Fleet No: WW25

Klm: 118,512

Hrs: 41,721

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY			MH	
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE			MH	
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS			MH	
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL			MH	
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES			MH	
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS			MH	
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT			MH	
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS			MH	
9	GREASE VEHICLE & T/TABLE, (RPLC DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)			MH	
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS. CHECK TERMINALS, CLEAN & LUBRICATE			MH	
11	CHECK FRONT HUBS OIL LEVELS			MH	
B SERVICE (Items 1 - 53)				B	C
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS			MH	
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC			MH	
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED			MH	
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP			MH	
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWC LABEL, DG LABEL ETC			MH	
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES			MH	
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM			MH	
19	CHECK OPERATION OF LOWENGINE OIL PRESSURE WARNING SYSTEM			MH	
20	CHECK CONDITION OF BRADE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS			MH	
21	CHECK PARK BRAKE OPERATION			MH	
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR			MH	
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT			MH	
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION			MH	
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED			MH	
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS			MH	
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING			MH	
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS			MH	
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER			MH	
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT			MH	
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS			MH	
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)			MH	
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE			MH	
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE			MH	
35	ADJUST BRAKES (RAISE VEHICLE)			MH	
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM			MH	
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS.			MH	
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED			MH	
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS			MH	
40	CHECK TURNABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE PLATE SECURITY			MH	
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR			MH	
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY			MH	
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)			MH	
44	CHECK & ADJUST AIR BAG HEIGHT			MH	
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC			MH	
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC			MH	
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED			MH	
48	CHECK FUEL TANK SECURIT, CHECK MOUNTING RACKETS FOR CRACKS			MH	
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER			MH	
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)			MH	
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)			MH	
52	REMOVE & CLEAN CENTRIGUGAL OIL FILTER BOWL (IF FITTED)			MH	
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED			MH	

28/02/2013

PRIME MOVER SERVICE

JOB# _____

Date: 16-4-25

Start Time: _____

Finish Time: _____

Fleet No: WW25Klm: 129,110Hrs: 4:19:24

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY	MH			
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE	MH			
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS	MH			
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL	MH			
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES	MH			
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS	MH			
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT	MH			
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS	MH			
9	GREASE VEHICLE & T/TABLE. (RPLC. DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)	MH			
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS. CHECK TERMINALS, CLEAN & LUBRICATE	MH			
11	CHECK FRONT HUBS OIL LEVELS	MH			
B SERVICE (Items 1 - 53)				B	C
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS				
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC				
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED				
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP				
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWC LABEL, DG LABEL ETC				
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES				
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM				
19	CHECK OPERATION OF LOWENGINE OIL PRESSURE WARNING SYSTEM				
20	CHECK CONDITION OF BRAKE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS				
21	CHECK PARK BRAKE OPERATION				
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR.				
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT				
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION				
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED				
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS				
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING				
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS				
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER				
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT				
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS				
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)				
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE				
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE				
35	ADJUST BRAKES (RAISE VEHICLE)				
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM				
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS.				
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED				
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS				
40	CHECK TURNABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE PLATE SECURITY				
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR				
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY				
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)				
44	CHECK & ADJUST AIR BAG HEIGHT				
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC				
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC				
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED				
48	CHECK FUEL TANK SECURIT, CHECK MOUNTING RACKETS FOR CRACKS				
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER				
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)				
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)				
52	REMOVE & CLEAN CENTRIGUGAL OIL FILTER BOWL (IF FITTED)				
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED				

PRIME MOVER SERVICE

JOB# _____

Date: 23/4/25 Start Time: _____ Finish Time: _____
 Fleet No: 1425 Km: 131636 Hrs: 41973

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY				/
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE				/
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS				/
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL				/
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES				/
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS				/
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT				/
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS				/
9	GREASE VEHICLE & T/TABLE. (RPLC. DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)				/
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS. CHECK TERMINALS, CLEAN & LUBRICATE				/
11	CHECK FRONT HUBS OIL LEVELS				/
B SERVICE (Items 1 - 53)				B	C
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS				/
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC				/
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED				/
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP				/
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWC LABEL, DG LABEL ETC				/
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES				/
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM				/
19	CHECK OPERATION OF LOWENGINE OIL PRESSURE WARNING SYSTEM				/
20	CHECK CONDITION OF BRADE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS				/
21	CHECK PARK BRAKE OPERATION				/
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR				/
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT				/
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION				/
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED				NA
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS				/
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING				/
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS				/
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER				/
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT				/
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS				/
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)				/
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE				/
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE				/
35	ADJUST BRAKES (RAISE VEHICLE)				/
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM				/
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS				/
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED				/
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS				/
40	CHECK TURNTABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE PLATE SECURITY				/
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR				/
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY				/
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)				/
44	CHECK & ADJUST AIR BAG HEIGHT				/
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC				/
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC				/
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED				/
48	CHECK FUEL TANK SECURIT, CHECK MOUNTING RACKETS FOR CRACKS				/
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER				/
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)				/
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)				/
52	REMOVE & CLEAN CENTRIGUGAL OIL FILTER BOWL (IF FITTED)				NA
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED				/



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: NW25

DATE: 17-5-25

HRS: 42,204

KLM: 138,334



DESCRIPTION OF MAINTENANCE:

* GROSS TRUCK

* REPLACE LEAKING AIR BAG on
FRONT DIFF LHS

* WASH DOWN ENGINE BAY


NAME: Matt H

SIGNATURE: MA

PRIME MOVER SERVICE

JOB# _____

Date: 25/5/25 Start Time: _____ Finish Time: _____
 Fleet No: 6415 Km: 140154 Hrs: 422 74

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY		/	✓	
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE		/	✓	
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS		/	✓	
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL		/	✓	
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES		/	✓	
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS		/	✓	
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT		/	✓	
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS		/	✓	
9	GREASE VEHICLE & T/TABLE. (RPLC. DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)		/	✓	
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS. CHECK TERMINALS, CLEAN & LUBRICATE		/	✓	
11	CHECK FRONT HUBS OIL LEVELS		/	✓	
B SERVICE (Items 1 - 53)				B	C
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS			✓	
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC			✓	
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED			✓	
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP			✓	
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWC LABEL, DG LABEL ETC			✓	
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES			✓	
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM			✓	
19	CHECK OPERATION OF LOWENGINE OIL PRESSURE WARNING SYSTEM			✓	
20	CHECK CONDITION OF BRADE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS			✓	
21	CHECK PARK BRAKE OPERATION			✓	
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR			✓	
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT			✓	
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION			✓	
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED			✓	
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS			✓	
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING			✓	
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS			✓	
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER			✓	
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT			✓	
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS			✓	
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)			✓	
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE			✓	
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE			✓	
35	ADJUST BRAKES (RAISE VEHICLE)			✓	
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM			✓	
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS			✓	
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED			✓	
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS			✓	
40	CHECK TURNTABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE PLATE SECURITY			✓	
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR			✓	
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY			✓	
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)			✓	
44	CHECK & ADJUST AIR BAG HEIGHT			✓	
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC			✓	
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC			✓	
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED			✓	
48	CHECK FUEL TANK SECURIT, CHECK MOUNTING RACKETS FOR CRACKS			✓	
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER			✓	
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)			✓	
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)			✓	
52	REMOVE & CLEAN CENTRIGUGAL OIL FILTER BOWL (IF FITTED)			✓	
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED			✓	
					

28/02/2013

SIGNATURE:



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: WW 25

DATE: 27/5/25

HRS: 42294


KLM: 140678



DESCRIPTION OF MAINTENANCE:

Per form brake test. - driver
straighten bent guard.
check emergency braking systems
inspect A frame.
inspect Air system
change tyre on front dolly.

NAME: L Fawkes

SIGNATURE: 

PRIME MOVER SERVICE


JOB# _____

Date: 8-6-25

Start Time: _____

Finish Time: _____

Fleet No: 11125Klm: 143,379Hrs: 42,410

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY	MH			
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE	MH			
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS	MH			
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL	MH			
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES	MH			
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS	MH			
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT	MH			
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS	MH			
9	GREASE VEHICLE & T/TABLE. (RPLC. DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)	MH			
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS. CHECK TERMINALS, CLEAN & LUBRICATE	MH			
11	CHECK FRONT HUBS OIL LEVELS	MH			
B SERVICE (Items 1 - 53)			B	C	
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS				
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC				
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED				
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP				
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWC LABEL, DG LABEL ETC				
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES				
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM				
19	CHECK OPERATION OF LOWENGINE OIL PRESSURE WARNING SYSTEM				
20	CHECK CONDITION OF BRADE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS				
21	CHECK PARK BRAKE OPERATION				
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR.				
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT				
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION				
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED				
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS				
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING				
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS				
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER				
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT				
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS				
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)				
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE				
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE				
35	ADJUST BRAKES (RAISE VEHICLE)				
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM				
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS				
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED				
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS				
40	CHECK TURNABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE PLATE SECURITY				
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR				
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY				
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)				
44	CHECK & ADJUST AIR BAG HEIGHT				
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC				
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC				
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED				
48	CHECK FUEL TANK SECURIT, CHECK MOUNTING RACKETS FOR CRACKS				
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER				
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)				
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)				
52	REMOVE & CLEAN CENTRIGUGAL OIL FILTER BOWL (IF FITTED)				
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED				
					

28/02/2013



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: WWTS

DATE: 9-6-25

HRS: 42,411

KLM: 143,380



DESCRIPTION OF MAINTENANCE:

- * REPLACE FRONT CAB MOUNTS
- * REPLACE REAR ENGINE MOUNTS
- * REPAIR WIRING TO REAR LHS TAIL LIGHT
- * REPAIR WIRING TO REAR CLEARANCE LIGHTS
- * REPAIR WIRING TO NUMBER PLATE LIGHT
- * RE-FIT LHS REAR MUD FLAP WITH NEW BOLTS

NAME: Mark H

SIGNATURE: [Signature]



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: NW 25

DATE: 16-6-25

HRS: 42,465

KLM: 144,376



DESCRIPTION OF MAINTENANCE:

* REPLACE CRANKCASE BREATHER FILTER DRAIN PIPE

* REPLACE LEAKING AIR LINE FITTING BULKHEAD FOR SIDETIPPER LID CONTROLS AT BACK OF CAB

* GREASE TRUCK

* REPLACE LHS MIRROR LIGHTS & LENS

* ROTATE STEER TIRES ON RIM


NAME: MAH H

SIGNATURE: MAH

Date: 28/6/25 Start Time: _____ Finish Time: _____
 Fleet No: 4425 Klm: 147 367 Hrs: 42527

PRIME MOVER SERVICE

JOB# _____

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY			/	
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE			/	
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS			/	
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL			/	
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES			/	
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS			/	
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT			/	
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS			/	
9	GREASE VEHICLE & T/TABLE. (RPLC. DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)			/	
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS. CHECK TERMINALS, CLEAN & LUBRICATE			/	
11	CHECK FRONT HUBS OIL LEVELS			/	
B SERVICE (Items 1 - 53)				B	C
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS			/	
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC			/	
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED			/	
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP			/	
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWC LABEL, DG LABEL ETC			/	
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES			/	
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM			/	
19	CHECK OPERATION OF LOW ENGINE OIL PRESSURE WARNING SYSTEM			/	
20	CHECK CONDITION OF BRADE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS			/	
21	CHECK PARK BRAKE OPERATION			/	
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR.			/	
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT			/	
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION			/	
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED			NA	
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS			/	
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING			/	
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS			/	
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER			/	
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT			/	
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS			/	
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)			/	
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE			/	
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE			/	
35	ADJUST BRAKES (RAISE VEHICLE)			/	
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM			/	
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS			/	
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED			/	
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS			/	
40	CHECK TURNTABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE/PLATE SECURITY			/	
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR			/	
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY			/	
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)			/	
44	CHECK & ADJUST AIR BAG HEIGHT			/	
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC			/	
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC			/	
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED			/	
48	CHECK FUEL TANK SECURIT, CHECK MOUNTING RACKETS FOR CRACKS			/	
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER			/	
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)			/	
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)			/	
52	REMOVE & CLEAN CENTRIGUAL OIL FILTER BOWL (IF FITTED)			/	
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED			/	
					

C SERVICE (Items 1 - 69)		C
54	CHECK FULL EXHAUST SYSTEM & MANIFOLDS FOR LEAKS & SECURITY	/
55	CHECK CABIN, TRANSMISSION & ENGINE MOUNTINGS. CHECK BLOT TENSIONS	/
56	CHECK CONDITION OF ALL BRAKE, POWER STEERING, AIR & OIL HOSES & PIPES	/
57	CHECK COOLANT SERVICE STICKERS & REPLACE AS REQUIRED	/
58	PRESSURE TEST COOLING SYSTEM & RADIATOR CAP IF APPLICABLE. REPORT ANY LEAKS OR REPAIR IF POSSIBLE	/
59	CHECK GEAR CABLES, LINKAGES & TOWERS FOR WEAR & SECURITY. REPLACE AS REQUIRED	/
60	CHECK DUAL AIR SYSTEM OPERATION (BY SEPARATELY DRAINING EACH SYSTEM)	/
61	RAISE FRONT OF VEHICLE ON FORWARD CHASSIS CROSS MEMBER. CHECK SUSPENSION & KING PINS FOR MOVEMENT, GREASE SUSPENSION & KING PINS FOR MOVEMENT, GREASE SUSPENSION WHILST VEHICLE IS RAISED	/
62	RAISE REAR OF VEHICLE ON EACH CHASSIS RAIL & CHECK SUSPENSION FOR WEAR. CHECK TRUNNIONS FOR MOVEMENT. GREASE SUSPENSION WHILST VEHICLE IS RAISED (IF APPLICABLE)	/
63	CHECK OPERATION OF ALL SHOCK ABSORBERS	/
64	REMOVE & CLEAN TRANSMISSION & DIFFERENTIAL BREATHERS	/
65	CHANGE OIL (FILTERS IF APPLICABLE) IN TRANSMISSION & BOTH DIFFERENTIALS. CHECK PLUGS FOR METAL & REPORT	/
66	CHECK STEERING TOE-IN. REPORT READINGS	/
67	CHECK OPERATION OF HYDRAULIC JACK, PRESENCE OF WHEEL BRACE / BAR & SAFETY TRIANGLE SET	/
68	CHECK & SERVICE A/C SYSTEM	/
69	CLEAN GREASE MARKS OFF STEERING WHEEL, CABIN FLOOR, SEATS, DOORS, BULLBAR ETC	/
70	CHANGE GEARBOX AND DIFFERENTIAL OIL WHERE APPLICABLE (MINERAL OIL)	/
71	TAKE OIL SAMPLES WHERE APPLICABLE	/
72	TUNE ENGINE	NA
73	CHECK TURBO AND WATER PUMP	/

Fault Report Logs Repaired: (list corresponding fault report log #s)

[illegible]

PRIME MOVER SERVICE

JOB# _____

Date: 6-7-25

Start Time: _____

Finish Time: _____

Fleet No: NW85Klm: 149, 122Hrs: 42 569

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY	MH			
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE	MH			
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS	MH			
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL	MH			
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES	MH			
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS	MH			
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT	MH			
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS	MH			
9	GREASE VEHICLE & T/TABLE. (RPLC. DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)	MH			
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS. CHECK TERMINALS, CLEAN & LUBRICATE	MH			
11	CHECK FRONT HUBS OIL LEVELS	MH			
B SERVICE (Items 1 - 53)				B	C
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS				
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC				
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED				
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP				
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWC LABEL, DG LABEL ETC				
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES				
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM				
19	CHECK OPERATION OF LOWENGINE OIL PRESSURE WARNING SYSTEM				
20	CHECK CONDITION OF BRADE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS				
21	CHECK PARK BRAKE OPERATION				
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR				
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT				
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION				
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED				
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS				
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING				
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS				
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER				
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT				
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS				
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)				
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE				
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE				
35	ADJUST BRAKES (RAISE VEHICLE)				
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM				
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS				
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED				
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS				
40	CHECK TURNTABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE PLATE SECURITY				
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR				
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY				
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)				
44	CHECK & ADJUST AIR BAG HEIGHT				
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC				
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC				
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED				
48	CHECK FUEL TANK SECURIT, CHECK MOUNTING RACKETS FOR CRACKS				
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER				
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)				
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)				
52	REMOVE & CLEAN CENTRIGUGAL OIL FILTER BOWL (IF FITTED)				
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED				

C

- ### Work/Repairs Carried Out

Fault Report Logs Repaired: (list corresponding fault report log #s)

TRADESPERSON'S NAME/S :

Date: 7/7/25

BrakeCheck
=====

www.circuitlink.com.au
Serial No: BRK27176
S/W Version: 3.0.0 GPS

Log memory: 69

Test Performed:
08:38:59 25/08/2025
Timezone: AEST (+1000)

GPS: Degree Minutes
Latitude: -20 39.7111
Longitude: 139 29.7136

Service Brake Test
=====

Front-Back Deceleration
Peak: 57 %g
Average: 44 %g
Left-Right Acceleration
Peak: 4 %g
Vehicle pulls: LEFT
Test Speed: 37 km/h
Stopping Dist: 12.0 m
Brake Efficiency: 44 %

Calibration Ok
Due: 10/09/2026

874 VFZ
Vehicle Registration

SAH PYE
Inspector Name

Signature

Certificate of inspection 16 tonne and over RGVM



**SUPERIOR
MACHINERY
MAINTENANCE**

Certificate No.
1160

Mobile: 0407 646 131

Owner and vehicle details

Vehicle Owner's name and address

WUATIS
10 KOLONGO CRAS
MT ISA QUD Postcode 4825

Plate No.

(if applicable)

State

Unit No.

874 VF2 QUD WW25

VIN/Chassis no.

6F5000000DA448777

Make

Model

KENWORTH T659

Body Shape

Badge (eg. Cargo)

PRIME MOVER

No. of cylinders

Fuel type (if gas, a current gas certificate
is required for registration purposes)

6 DIESEL

Engine number

80033146

Compliance type

Compliance

☒

Import

☐

Give details

Other

☐

Plate

Plate

Date on Plate

Vehicle Colour

Seating capacity

0113

Left or Right hand drive?

Left

☐

Right

☒

Tare

GVM

26500

GCM

☐

Speed limiter fitted?

Yes

☐

No

☐

Not applicable

☐

Results of inspection

Please indicate

Pass

☒

Fail

☒

1st

inspection

Final

inspection

Identification

☒

Modifications

☐

Seats & Restraints

☒

Lights & Electrical Components

☒

Windscreen & Windows

☒

Body & Chassis

☒

Steering & Suspension

☒

Wheels & Tyres

☒

Brakes

☒

Engines & Drivelines

☒

Exhaust Emissions

☒

Road Test

☒

Service Brake Test

☒

Hand Brake Test

☒

Details of other items rejected

RH TOP CAB CLEARANCE LIGHT
MISSING WHEEL NUT INDICATOR
REAL SHOCK RUBBERS

1st Inspection

Result

☒

Inspection date

25/8/25

Inspection time

8:00 am

Odometer reading

151967

Signature of Examiner

S. Pye

Examiner's no.

18904

Final inspection (must not be more than 14 days from date of 1st inspection)

Result

☒

Inspection date

27/8/25

Inspection time

8:00 am

Odometer reading

151969

Signature of Examiner

S. Pye

Examiner's no.

18904

Inspection Station details

Name and location

SUPERIOR MACHINERY MAINTENANCE
27 COMMERCIAL RD Postcode 4825

Approved Inspection Station Number

10588

Certification

Approved examiner - I have inspected the vehicle indicated on this form and found it had no defect that would affect its safe use of the road and it meets the requirements of the Transport Operations (Road Use Management) Act 1995.

Inspected by - Signature of Examiner

S. Pye

Date

27-8-25

Name of Examiner (please print)

SAM PYE

Examiner's no.

18904

BrakeCheck
=====

www.circuitlink.com.au
Serial No: BRK27176
S/W Version: 3.0.0 GPS

Log memory: 69

Test Performed:
08:38:59 25/08/2025
Timezone: AEST (+1000)

GPS: Degree Minutes
Latitude: -20 39.7111
Longitude: 139 29.7136

Service Brake Test
=====

Front-Back Deceleration
Peak: 57 %g
Average: 44 %g
Left-Right Acceleration
Peak: 4 %g
Vehicle pulls: LEFT
Test Speed: 37 km/h
Stopping Dist: 12.0 m
Brake Efficiency: 44 %

Calibration Ok
Due: 10/09/2026

874 VFZ
Vehicle Registration.....

SAN PYE
Inspector Name.....

Signature.....

PRIME MOVER SERVICE


JOB#

Date: 11-9-25

Start Time:

Finish Time:

Fleet No: WIN 25Klm: 154,547Hrs: 42,766

A SERVICE (ITEMS 1 - 11)		Supervisor to circle service required	A	B	C
1	CHECK FAULT REPAIR BOOK & REPAIR AS NECESSARY			MH	
2	CHECK FLEET NUMBER(S) ARE SERVICEABLE			MH	
3	BEFORE GREASING, JACK BOTH FRONT WHEELS OFF GROUND & CHECK WHEEL BEARINGS, KING PINS & ALL STEERING JOINTS			MA	
4	CHECK ENGINE OIL, DIFF OIL AND GEARBOX OIL			MH	
5	CHECK HEADER TANK OR RADIATOR COOLANT LEVEL & CONDITION OF ALL HOSES			MH	
6	CHECK OPERATION OF ALL LIGHTS (INTERIOR & EXTERIOR) & REFLECTORS			MA	
7	RAISE BONNET/CABIN & VISUALLY CHECK ENGINE BAY & COMPONENTS & REPORT			MH	
8	CHECK TENSION & CONDITION OF ALL VEE-BELTS, CHECK COMPONENTS MOUNTINGS AND BEARINGS			MH	
9	GREASE VEHICLE & T/TABLE. (RPLC. DAMAGED OR MISSING NIPPLES & REPORT IF NOT ACCEPTING GREASE)			MA	
10	CHECK BATTERY SECURITY & ELECTROLYTE LEVELS, CHECK TERMINALS, CLEAN & LUBRICATE			MH	
11	CHECK FRONT HUBS OIL LEVELS			MH	
B SERVICE (Items 1 - 53)				B	C
12	CHECK BONNET SECURITY, CHECK CONDITION OF BONNET CLAMPS & HINGE COLLARS			MH	
13	REMOVE ALL NON CONFORMING STICKERS & LABELS eg BUMPER, TRUCKSTOP, RADIO STATION ETC			MH	
14	CHECK WINDSCREEN WIPER & WASHER OPERATION, REPLACE WIPER BLADES IF REQUIRED			MH	
15	REMOVE FAN BELTS & CHECK BEARINGS, ALTERNATOR & WATER PUMP & A/C COMP			MH	
16	CHECK CONDITION OF WINDSCREEN, GLASS, MIRRORS, REGO / RWCL LABEL, DG LABEL ETC			MH	
17	CHECK OPERATION OF ALL GAUGES & ELECTRICAL ACCESSORIES			MH	
18	CHECK OPERATION OF LOW AIR WARNING SYSTEM			MH	
19	CHECK OPERATION OF LOW ENGINE OIL PRESSURE WARNING SYSTEM			MH	
20	CHECK CONDITION OF BRAKE AIR SUPPLY HOSES, FITTINGS & CHECK FOR LEAKS			MH	
21	CHECK PARK BRAKE OPERATION			MH	
22	CHECK ALL TYRE PRESSURES AND REFIT VALVE CAPS (INCLUDING SPARE). REPORT ABNORMAL WEAR.			MH	
23	CHECK WHEEL NUT TENSIONS CHECK VALVE STEM ALIGNMENT			MH	
24	CHECK CONDITION & SECURITY OF ALL MUDFLAPS, MUDGUARDS, BRACKETS & SPRAY SUPPRESSION			MH	
25	CHECK CLUTCH FREE TRAVEL / CLEARANCE AND ADJUST AS REQUIRED			MH	
26	CHECK CABIN TILT SYSTEM FOR OPERATION, RESERVOIR LEVEL, LEAKS & MANUAL LOCKS			N/A	
27	CHECK ALL LUBRICANT LEVELS EG POWER STEERING			MH	
28	CHECK BRAKE SYSTEMS FOR AIR LEAKS			MH	
29	CHECK CONDITION OF FIRE EXTINGUISHER, SECURITY, CURRENT SERVICE TAG & FIT PLASTIC BAG COVER			MH	
30	CHECK AIR CLEANER RESTRICTION INDICATOR OR DATE A/CLEANER WAS FITTED, RPLC & DATE IF BEYOND LIMIT			MH	
31	CHECK AIR INTAKE & AFTERCOOLER SYSTEM DUCTING FOR SECURITY, CHAFING & CRACKS			MH	
32	CHECK HYDRAULIC OIL RESERVOIR LEVEL (IF PTO FITTED TO VEHICLE)			MH	
33	CHECK & REPORT RUST OR MINOR ACCIDENT DAMAGE			MH	
34	CHECK BRAKE LININGS & DRUMS FOR WEAR, CHECK HUB SEALS FOR LEAKAGE			MH	
35	ADJUST BRAKES (RAISE VEHICLE)			MH	
36	DRAIN ALL AIR TANKS. REPORT IF EXCESSIVE OIL IS PRESENT IN SYSTEM			MH	
37	COVER & SEALS, WINDOW MECHANISMS, CABIN STEPS, EPG HOLDERS & CARDS & DAILY CHECK CARDS.			MH	
38	CHECK AIR COMPRESSOR INTAKE FOR SECURITY, CHAFING & CRACKS, CLEAN FILTER SPONGE AS REQUIRED			MH	
39	CHECK CONDITION & SECURITY OF RADIATOR, AFTERCOOLER & ALL MOUNTS			MH	
40	CHECK TURNTABLE ADJUSTMENT, MOUNTING PINS / BUSHES CONDITION & BASE PLATE SECURITY			MH	
41	CHECK STEERING BOX, JOINT & LINK DAMAGE, SECURITY & WEAR			MH	
42	BEAMS & RADIUS ROD BUSHES & U-BOLTS FOR WEAR, MOVEMENT & SECURITY			MH	
43	CHECK REAR SUSPENSION TRUNNIONS FOR OIL LEAKS (CHECK LEVELS & REPORTING IF ANY LEAKS APPARENT)			MH	
44	CHECK & ADJUST AIR BAG HEIGHT			MH	
45	CHECK CHASSIS, CROSS MEMBERS & RELATED COMPONENTS FOR CRACKS, LOOSE BOLTS ETC			MH	
46	CHECK CONDITION OF DRIVE-LINE, CENTRE BEARINGS, UNI-JOINTS, FLANGE BOLTS ETC			MH	
47	CHECK PINIONS, THRU-SHAFT & OUTPUT SHAFTS FOR MOVEMENT OR SEAL LEAKAGE & ADJUST IF REQUIRED			MH	
48	CHECK FUEL TANK SECURIT, CHECK MOUNTING RACKETS FOR CRACKS			MH	
49	PERFORM COOLANT INHIBITOR TEST, ADJUST CONCENTRATION OR REPLACE COOLANT FILTER			MH	
50	CHANGE FUEL FILTERS (DATE NEW FILTERS WITH MARKER PEN)			N/A	
51	CHANGE ENGINE OIL & FILTERS (DATE NEW FILTERS WITH MARKER PEN)			MH	
52	REMOVE & CLEAN CENTRIFUGAL OIL FILTER BOWL (IF FITTED)			N/A	
53	INDICATE ON BELOW DRAWING WHEEL BEARINGS THAT ARE REPLACED, CHECKED AND OR ADJUSTED			MH	
					

28/02/2013