

| VEHICLE: | 71-21 | | | DATE: | 5-2- | 45 |
|------------------|---------------|-------|------|-------|----------------|----------|
| | | | - | | 34 5 | 1. |
| HRS | HO | | | | \triangle | |
| KLM | NO LIG ME | efre. | 0.00 | 1 H | | H 2 |
| A 2 2 | | 14.1 | | 3 H | | |
| DESCRIPTION OF N | //AINTENANCE: | | | 5 | | . 6 |
| | | | | * | | |
| Pouls | itd Hya | Wille | 1.05 | es , | nd | , |
| Mapa | 1 | | 100 | | 1. 6 - | - 44 24- |
| FIMI | ng and | made | 00 5 | OPPO! | Pora | in ex |
| | | | | | - | |
| | | | | | | 6 |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | - | | |
| | | | | | | _0_ |
| | 10 | | | | | |
| | 2. | | 19. | | | *: |
| | - 12 | | 29 | | | 2 |
| | | | | | # ₄ | |
| | | | | | | |
| | | | | | | |
| 140 | | | | | | |
| | | | | - | | <u>_</u> |
| 1 | 00 | | | | | (f) |
| NAME: | 02 | | 10 | | 30 | |
| 5.7 | da | | | | | |
| GNATURE: | 1/20 | | | | | |



| VEHICLE: | 7621 | | DATE: 6-7 | -23 |
|-------------------|-------------|----------|------------|---------|
| 7,000 | | - 5 | E 10 | |
| HRS | 6 1 . 1 | / | - | |
| KLM/ | vo hub mer | ter | 3 | H 2 H 4 |
| DESCRIPTION OF MA | AINTENANCE: | | 5 H | H 6 |
| Dei | placed fer | ande l | valet is n | 1 |
| 10/ | Julie Ferr | 101 (11 | un pry. | - R 1- |
| | | | | |
| | | | | - 1 |
| | | | ¥1 | |
| | | | | |
| | | | | _ |
| | | | | |
| | | | | |
| 7 | | | | - |
| | * 4) | | | + |
| | 300 | | -6 | |
| | 74 | | 泰 栽 | |
| | | | | |
| 11, | | | | |
| 134 | | | | |
| , F | | | 31 | •2 |
| NAME: | OR | | | 39 |
| × - | di | | S# | |
| GNATURE: | 111 | | | |



| DATE 18-2.23 | START TIME | FINISH TIME | JOB NO |
|----------------|------------|-------------|--------|
| FLEET NO 72 21 | KM'S | HRS | REGO |

| | | NEGO | | |
|----|--|-----------|-----------|-----------|
| | Service Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable | A Service | B Service | C Service |
| | Local Trailers 40000km/365 days | 7 DAYS | 14 DAYS | 40000KM |
| | Linehaul Trailers 15000km 10 days 150000km/365days | | 15000KM | 150000KM |
| 1 | Check faults noted on daily prestart and repair as necessary | MH | | |
| 2 | Check fleet numbers are serviceable | mH | | |
| 3 | Record Hub meter reading | mH | | |
| 4 | Lubricate Container Pins | NIA | | |
| 5 | Check operation & condition of all lights/reflectors | mH | | |
| 6 | Apply Air Check for leaks from boosters, valves & air lines | mit | | |
| 7 | Adjust brakes , visually inspect components | MH | | |
| 8 | Check air cells for air leaks and deterioration | MH | | |
| 9 | Drain all air tanks, report if any oil is present in system | mH | | |
| 10 | Grease trailer incl. brake cams, slack adjusters, landing legs, ring feeder & other grease points | MH | | |
| 11 | Check hoist mounting bolts, hoses, coupling | MH | | |
| 12 | Check number plate & rego label security. Check that rego label is current | MH | | |
| 13 | Check condition of front air connections, light plug base & electrical lead | MH | | |
| 14 | Check security of spare wheels & spare wheel carrier/gate rack | mH | | |
| 15 | Check condition & security of all mudflaps, mudguards, brackets & spray suppression | mH | | |
| 16 | Check landing legs for damage & security | MH | | |
| 17 | Check sub frame & cross members for cracks, damage & security | MH | | |
| 18 | Check condition, position & security of all air hoses | mH | | |
| | | | | |
| 19 | Check brake linings & drums for wear. Check hub seals for leakage | | | |
| 20 | Check security of height control valves and links & adjust if required | | | |
| 21 | Check skid plate/king pin security & condition, check draw bar/bushes and towing eye NOTE: If draw bar eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be checked for tolerances | | | |
| 22 | Check wheel nut tensions, check valve stem alignment | | | |
| 23 | Check all tyre pressures and refit valve caps (including spare) report abnormal wear | | | |
| 24 | Check condition & security of rear marker signs | | | |
| 25 | Check ring feeder condition, operation & security | | | |
| 26 | Lubricate twist locks & check operation & security of pedestals, straighten handles as required | | | |
| 27 | Check condition & security of rope rails, gate pockets, winch rails & straps | | | |
| 28 | Check condition & security of floor and associated components | | | |
| 29 | Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear | | | |
| 30 | Check security & bolt tension od airbag suspension hangers & radius rod arms | | | |
| 31 | Raise wheel assembly & check bearings for free play by "feel" only & adjust as required | | | |
| 32 | Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted | | | |
| | front | f | | |
| | | 1 | | |
| L | 33 Check brake linings & drums for wear whilst hubs are removed | | | |
| | 34 Check hubs for cracks and tapered shoulders for wear | | | |
| | 35 Remove bearings and clean/inspect for reuse | | | |
| | 26 Paplace mudflane & decale as required | | | |

rear

37 Remove s/cam slack adjuster pins and rotate/lubricate
38 Pack bearings with fresh grease & reassemble



| ork/Repairs carried o | ut | | |
|-----------------------|----------|------------------------|---------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | III | | |
| | 19 | | |
| | | | |
| | 11/1 | | |
| | - 1.W. | | |
| | | | |
| | | | |
| | | | |
| ist any defect found | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| new Na /Canaumables | Qty | Part No/Consumables | Qty |
| art No/Consumables | αιγ | r are two/ consumables | GGY |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | <u></u> |
| Tradesperson Name | MATT H | Signature | 18-3-22 |
| Tradesperson Name | 11/11/11 | 3.0 | 168 22 |



| VEHICLE: | TZ21 | | DATE: 10-4 | - 23 |
|----------------|--------------|-------|------------|---------|
| | NA | | 1 H | 2 |
| DESCRIPTION OF | MAINTENANCE: | | 5 11 |] ''[•] |
| REI | FIT AXLE | 4 NEW | TIRES | 70 |
| | | | - | |
| | | | | |
| | | | | |
| | | | DATE | BY |
| | | | | |
| | | | | |
| NAME: | MATT H | 1 | | |
| SIGNATURE: | ma | | | |



| VEHICLE: TL | 21 | | | DATE: 17,04,23 |
|-------------|---------|----|-------|----------------|
| HRS:KLM: | | | | 3 + 4 |
| | | | | |
| CHANGE | REAR | LH | INNER | TYRE |
| | | | | |
| | | | | |
| | | | | |
| - | | | | |
| | | | | DATE BY |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| NAME: K | BURGESS | | | |
| SIGNATURE: | 7 | | | |



| DATE 18-6-23 | START TIME | FINISH TIME | JOB NO |
|---------------|------------|-------------|--------|
| FLEET NO 7221 | KM'S NA | HRS | REGO |

| Service Items | - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable | A Service | B Service | C Service |
|-----------------------------------|--|-----------|-----------|-----------|
| Local Trailers | 40000km/365 days | 7 DAYS | 14 DAYS | 40000KM |
| Linehaul Trailers | 15000km 10 days 150000km/365days | | 15000KM | 150000KM |
| 1 Check faults noted on daily | prestart and repair as necessary | | MH | |
| 2 Check fleet numbers are se | viceable | | MH | |
| 3 Record Hub meter reading | | | NA | |
| 4 Lubricate Container Pins | | | NA | |
| 5 Check operation & conditio | n of all lights/reflectors | | MH | |
| 6 Apply Air Check for leaks fro | om boosters, valves & air lines | | MH | |
| 7 Adjust brakes , visually insp | ect components | | MH | |
| 8 Check air cells for air leaks a | nd deterioration | | MH | |
| 9 Drain all air tanks, report if | any oil is present in system | | MH | |
| .0 Grease trailer incl. brake ca | ms, slack adjusters, landing legs, ring feeder & other grease points | | MH | |
| 1 Check hoist mounting bolts | hoses, coupling | | MH | |
| 2 Check number plate & rego | label security. Check that rego label is current | | MH | |
| Check condition of front air | connections, light plug base & electrical lead | | MH | |
| L4 Check security of spare whe | els & spare wheel carrier/gate rack | | MH | |
| Check condition & security | of all mudflaps, mudguards, brackets & spray suppression | | mH | |
| 6 Check landing legs for dama | ge & security | | mH | |
| Check sub frame & cross me | embers for cracks, damage & security | | MH | |
| 8 Check condition, position & | security of all air hoses | | MH | |

| 19 Check brake linings & drums for wear. Check hub seals for leakage | MH |
|---|----|
| 20 Check security of height control valves and links & adjust if required | m |
| Check skid plate/king pin security & condition, check draw bar/bushes and towing eye eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be checked for tolerances | MH |
| 22 Check wheel nut tensions, check valve stem alignment | MH |
| 23 Check all tyre pressures and refit valve caps (including spare) report abnormal wear | MH |
| 24 Check condition & security of rear marker signs | MH |
| 25 Check ring feeder condition, operation & security | MH |
| 26 Lubricate twist locks & check operation & security of pedestals, straighten handles as required | NA |
| 27 Check condition & security of rope rails, gate pockets, winch rails & straps | NA |
| 28 Check condition & security of floor and associated components | MH |
| 29 Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear | MH |
| 30 Check security & bolt tension od airbag suspension hangers & radius rod arms | MH |
| Raise wheel assembly & check bearings for free play by "feel" only & adjust as required | MH |
| 32 Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted | MH |



| 33 | Check brake linings & drums for wear whilst hubs are removed | |
|----|--|--|
| 34 | Check hubs for cracks and tapered shoulders for wear | |
| 35 | Remove bearings and clean/inspect for reuse | |
| 36 | Replace mudflaps & decals as required | |
| 37 | Remove s/cam slack adjuster pins and rotate/lubricate | |
| 20 | Pack hearings with fresh grosse & reassamble | |



| " Pr | 0, 115 | 2011 | 5 / 1 | r w | 5-0005 0- |
|--------------------|------------|----------|-------------|-----------|-----------|
| RODA | IVIE | Both | C.DES | AND | MIDDLE |
| AVIE | 1-H5 | 0-111 | 3/00- | | 111111 |
| 77.00 | | | | | |
| | 201-1 | | | | |
| * RE | PAIRS | CAGU (| ED 0617 | 70 | 210 |
| | | | | | |
| | AMERICA EL | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| t any defect found | | | | | |
| | | | | | ti. |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| rt No/Consumables | Otv | | Part No/Co | nsumables | Otv |
| rt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| ırt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| ırt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| ırt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| ırt No/Consumables | Qty | | Part No/Cor | nsumables | Qty: |
| irt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| art No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| ort No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| rt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| rt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| rt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| irt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| art No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| art No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| rt No/Consumables | Qty | | Part No/Cor | nsumables | Qty |
| art No/Consumables | Qty | <i>H</i> | Part No/Cor | nsumables | Qty Qty |



| VEHICLE: TL21 | DATE: 23-7-23 |
|--|-------------------------|
| KLM NO his b metter DESCRIPTION OF MAINTENANCE: | 1 H 2 3 H 4 5 H 6 |
| seal hinges | |
| | |
| | |
| NAME: OX/Sterphen. | |
| SIGNATURE: | |





| VEHICLE: | 7221 | | DATE: | 7-23 |
|----------|---------------|---------|-------------|-------------------|
| HRSKLM | MAINTENANCE: | | 1 H 3 H 5 H | H 2 H 4 H 6 |
| R | eplace ose | High | pressure | |
| | | | | |
| | | | | |
| | | | | |
| | -A 1 | | | |
| NAME: | Mgs_ | <u></u> | | |



DATE 31-8-2 START TO

TRAILER & DOLLY SERVICE SHEET

| DATE DI | START TIME FINISH TIME | JOB NO | | |
|--------------------|--|-----------|-----------|-----------|
| FLEET NO T | KM'S O · HRS | REGO | | |
| | A 29 . 34 L AC | | | |
| Servic | e Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable | A Service | B Service | C Service |
| Local Trailers | 40000km/365 days | 7 DAYS | 14 DAYS | 40000KN |
| Linehaul Trailers | 15000km 10 days 150000km/365days | | 15000KM | 150000K |
| Check faults not | ed on daily prestart and repair as necessary | 1 1 | | - |
| Check fleet num | bers are serviceable | OX | | |
| Record Hub met | er reading | OX | | |
| Lubricate Contai | | | | |
| Check operation | & condition of all lights/reflectors | OX | | |
| Apply Air Check | for leaks from boosters, valves & air lines | OX | | |
| Adjust brakes , v | isually inspect components | OX | | |
| Check air cells fo | r air leaks and deterioration | OX | | |
| Drain all air tank | s, report if any oil is present in system | OX | | |
| Grease trailer in | cl. brake cams, slack adjusters, landing legs, ring feeder & other grease points | OX | | |
| Check hoist mou | nting bolts, hoses, coupling | OX | | |
| Check number p | late & rego label security. Check that rego label is current | OX | | |
| Check condition | of front air connections, light plug base & electrical lead | OX | | |
| Check security o | f spare wheels & spare wheel carrier/gate rack | OX | | |
| Check condition | & security of all mudflaps, mudguards, brackets & spray suppression | OX | | |
| Check landing le | gs for damage & security | OX | | |
| Check sub frame | & cross members for cracks, damage & security | OX | | |
| Check condition, | position & security of all air hoses | OX | | |
| | | | | |
| Check brake linir | ngs & drums for wear. Check hub seals for leakage | | | |
| Check security o | f height control valves and links & adjust if required | | | 100 |
| | king pin security & condition, check draw bar/bushes and towing eye NOTE: If | | | |
| | It is found loose, it is not to be retorqued and must be removed and replaced and draw bar | | | |
| | necked for tolerances | | | |
| | tensions, check valve stem alignment | | | |
| | essures and refit valve caps (including spare) report abnormal wear | | | |
| | & security of rear marker signs | | - | |
| | r condition, operation & security | | - | |
| | ocks & check operation & security of pedestals, straighten handles as required | | | |
| | & security of rope rails, gate pockets, winch rails & straps | 1 | | |
| | & security of floor and associated components | | | |
| | ear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear | | | |
| Check security & | bolt tension od airbag suspension hangers & radius rod arms | | | |
| Raise wheel asse | mbly & check bearings for free play by "feel" only & adjust as required | | | |
| Indicate on belov | w drawing wheel bearings that are replaced, checked and/or adjusted | | | |
| front | | | | |
| 1 | | 1 | 1 | |
| X | 33 Check brake linings & drums for wear whilst hubs are removed | | | |
| | 34 Check hubs for cracks and tapered shoulders for wear | | | |
| X | 35 Remove bearings and clean/inspect for reuse | | | |
| | 36 Replace mudflaps & decals as required | | | |

37 Remove s/cam slack adjuster pins and rotate/lubricate
38 Pack bearings with fresh grease & reassemble

Townsville Workshop: 74-76 Northern Link Cct, Shaw (Bohle) Q 4818

Cloncurry Workshop: Lot 2, Hensley Drive, Cloncurry Q 4824

Postal Address: PO Box 766, Deeragun Q 4818 Phone: 07 4789 4888 - Email: fds@bigpond.net.au

www.fabbrodiesel.com.au ABN: 75 617 303 527



CUSTOMER JOB NO. 32432

Site: 311QZH Order No.: TBA

Cassandra Pascoe World Welding & Transport Services PO Box 1808 MOUNT ISA QLD 4825

Description

Work requested: Inspection

Hours: NA Kilometres: NA

3/11/23

Carried out inspection as per customer's request. Defects found:

- POS 3- pad and shock U/S
- POS 4- Shock U/S
- King pin worn
- Number plate light doesn't work.

| Item | Quantity | Unit Price | Total |
|------------------------------|----------|------------|----------|
| Consumables | 1.00 | \$25.00 | \$25.00 |
| Labour - Townsville Workshop | 1.5 | \$120.00 | \$180.00 |

| Sub-Total ex GST | \$205.00 |
|------------------|----------|
| GST | \$20.50 |
| Total inc GST | \$225.50 |

Townsville Workshop: 74-76 Northern Link Cct, Shaw (Bohle) Q 4818

Cloncurry Workshop: Lot 2, Hensley Drive, Cloncurry Q 4824

Postal Address: PO Box 766, Deeragun Q 4818 Phone: 07 4789 4888 - Email: fds@bigpond.net.au

www.fabbrodiesel.com.au ABN: 75 617 303 527



PLEASE PAY BY AMOUNT INVOICE DATE **08/12/2023** \$225.50 **08/11/2023**

311QZH

24519

Site: Order No.:

TAX INVOICE NO. 721821

Cassandra Pascoe World Welding & Transport Services PO Box 1808 MOUNT ISA QLD 4825

Description

Work requested: Inspection

Hours: NA Kilometres: NA

3/11/23

Carried out inspection as per customer's request.

Defects found:

• POS 3- pad and shock U/S

- POS 4- Shock U/S
- King pin worn
- Number plate light doesn't work.

| Item | Quantity | Unit Price | Total |
|------------------------------|----------|------------|----------|
| Consumables | 1.00 | \$25.00 | \$25.00 |
| Labour - Townsville Workshop | 1.50 hrs | \$120.00 | \$180.00 |

| Asset Register - Trailer | | | | | | |
|--------------------------|-------------|---------|-------------|-------------|------|-------------------------|
| VIN | Rego Number | Make | Model | Unit Number | Year | Engine Serial Number |
| 6T9T25NT0D2N UM091 | 311QZH | Tristar | 9m Tri Axle | TL21 | 2013 | |

| PAYMENT PREFERRED BY EFT: | Sub-Total ex GST | \$205.00 |
|--|------------------|----------|
| | GST | \$20.50 |
| Account Name: Fabbro Diesel Services | Total inc GST | \$225.50 |
| BSB: 064834 - Account: 10581652 | Amount Applied | \$0.00 |
| Please email remittance to info@fabbrodiesel.com.au. | Balance Due | \$225.50 |
| | | |

Credit card also accepted in person or over the phone.



FABBRO DIESEL SERVICES WARRANTY On externally purchased parts

In light of more frequent parts failures from majority of local suppliers; Fabbro Diesel Services will be unable to supply replacement labour on any parts supplied by customers from local suppliers. Most mainstream equipment manufactures, and aftermarket parts suppliers will predominately not supply any compensation for Fabbro Diesel Services' fitting labour even though their component was at fault. For over a decade FDS has written this lose off as FDS Policy. Unfortunately, this is a cost that FDS is no longer able to absorb moving forward. **Example:**

Customer supplies a recon head – fitting takes 25 hours. Component fails and customer is given recon head and gasket to complete repair at FDS by the manufacture/parts supplier. FDS completes repair, sends customer second labour bill which will need to be taken up with original parts supplier.

Please note all parts purchased through FDS direct are exempt from this procedure and are covered if conditions fall under FDS warranty policy.

Fabbro Diesel Services or any of its subsidiaries, warrants the following products sold be it to be free from defects in material and workmanship:

- New parts and assembled components
- Reman parts, assembled components

Responsibilities

If a defect in material or workmanship is found during the warranty period, FDS will, during normal working hours and at a place of business of an FDS workshop or elsewhere approved by Russell Fabbro:

Provide (at FDS choice) New reman parts or FDS approved repaired parts, assembled components, needed to correct the
defect.

NOTE: New remanufactured, or FDS approved repaired parts or assembled components provided under the terms of this warranty are warranted for the remainder of the warranty period applicable to the parts or assembled components being replaced as if such parts or assembled components were the original parts or assembled components. Items replaced under this warranty become the property of FDS.

Replaced lubricating oil, filters, antifreeze, and other service items made unusable by the defect.

For all other products covered by this warranty: Provide reasonable and customary repair labour needed to correct the defect if product found to be defective and its replacement are both installed by FDS or other source approved by Russell Fabbro; excluding labour to disconnect and reconnect generator sets, engines, or transmissions to attached equipment or mounting and support systems not sold by FDS.

User Responsibilities

The user is responsible for:

- Providing proof of sale date to the first user
- Providing proof of date of installation
- Transportation costs
- Premium or overtime labour costs
- Parts shipping charges in excess of those that are usual and customary
- Costs to investigate complaints, unless the problem is caused by a defect in FDS material or workmanship
- Giving timely notice of a warrantable failure and promptly making the product available for repair
- Performance of the required maintenance (including use of proper fuel, oil, lubricants, and coolant) and replacement of items
 due to normal wear and tear.
- · Allowing FDS access to all electronically stored data

Limitations

FDS is not responsible for:

- · Failures resulting from any use or installation that FDS judges improper
- Failures resulting from attachments accessory items, and parts not sold by FDS
- Failures resulting from abuse, neglect, and/or improper storage or repair, including installation of parts and assembled components in contaminated systems
- Failures resulting from user's delay in making the product available after being notified of a potential product problem

Failures resulting from unauthorized repair or adjustments and unauthorized fuel-setting changes not performed by FDS.

APENDIX A

Warranty period – 6 months or 1000kms for PARTS Warranty period on workmanship – 6 months for LABOUR

APENDIX B

Equipment that is serviced and maintained for 80% of its working life of Agreed Contract Maintenance may be subject to 12 months or 200 hours parts and labour warranty upon request.



| VEHICLE: | 16 22 | 7/ 2 | 1 .0 | |
|----------|------------|---------|----------|-------------|
| HRS | 1000 | -712 | DATE: 29 | (1,23 |
| KLM | AAINITTALA | | 1 H | 2 - 4 |
| | isy del | ects. | 5 | H 6 |
| | 0 , | 20 W. I | | |
| | | | | |
| | | N | | - |
| | | | | 5 32 |
| Tig. 1 | 00 | | | |
| | 1 | | | |
| 940 | | | | 10 10 1 |
| - A | | 4 | | |
| 1 | | | | |
| NAME: | Than 1 | 2 | | |
| GNATURE: | 6 | 4 | | 2 |





| VEHICLE: SI CLE TIAPERS | DATE: 30-11-73 |
|-----------------------------|----------------|
| HRS 1221,23,25 | |
| KLM | |
| DESCRIPTION OF MAINTENANCE: | 5 + 6 |
| Look up after | machinerys. |
| 10st run diag | nose fault. |
| and orger parts | |
| | |
| | |
| | |
| 1 18 | * * |
| M / | |
| | |
| | |
| | |
| | |
| | |
| NAME: | |
| SIGNATURE: | |



Certificate of Inspection

Transport Operations (Road Use Management) Act 1995



Date of Issue: 27/11/2023 Certificate Number: ST 38763087

Motor Vehicle Details

Plate Number : 311QZH 1

Make : TRISTAR Body Shape : SEMI TRAILER

VIN Number : 6T9T25NTOD2NUM091 Engine No :

ATM (Kg) : 47000 Reg Category: HEAVY TRAILER

GTM (Kg) :

Registered Operator/s Details

WORLD WELDING AND TRANSPORT SERVICE PTY LTD 8-10 KOLONGO CRESCENT MOUNT ISA QLD 4825

Certification

This is to certify that the vehicle, particulars of which are set out in this certificate, was inspected in accordance with the provisions of the above mentioned Act and departmental guidelines on the issue date stated in this certificate and has no evident defect that would affect its safe use on the road.

This certificate is in force until the expiry date specified unless it is suspended or cancelled, or the registration of the vehicle is cancelled under the provisions of the said Act.

Inspector's Authority No: Q581

District : VIDTOWNSVI

Inspector's Signature

Note - Vehicle inspections undertaken by the Department of Transport and Main Roads are carried out to prescribed safety standards. The Department recommends an independent comprehensive assessment of the vehicle's condition prior to purchase.

