



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: 7223

DATE: 1-1-25

HRS: _____

KLM: 208,623



DESCRIPTION OF MAINTENANCE:

* REPLACE WHEEL HUB ASSY ON
FRONT AXLE LHS WITH A REBUILT ONE
WITH NEW BRAKE ROTOR

* REPLACE BRAKE CALIPER ON FRONT
AXLE LHS WITH A REBUILT ONE & FIT
NEW BRAKE PADS

* REPLACE TIRES ON FRONT AXLE LHS
WITH 8 RUN-OUTS

NAME: Max H

SIGNATURE: [Signature]



TRAILER & DOLLY SERVICE SHEET

DATE 5-2-25 START TIME _____ FINISH TIME _____ JOB NO _____
FLEET NO 1223 KM'S 237,062 HRS _____ REGO _____

Service Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable		A Service	B Service	C Service
Local Trailers	40000km/365 days	7 DAYS	14 DAYS	40000KM
Linehaul Trailers	15000km 10 days 150000km/365days		15000KM	150000KM
1	Check faults noted on daily prestart and repair as necessary		MH	
2	Check fleet numbers are serviceable		MH	
3	Record Hub meter reading		MH	
4	Lubricate Container Pins		N/A	
5	Check operation & condition of all lights/reflectors		MH	
6	Apply Air Check for leaks from boosters, valves & air lines		MH	
7	Adjust brakes , visually inspect components		MH	
8	Check air cells for air leaks and deterioration		MH	
9	Drain all air tanks, report if any oil is present in system		MH	
10	Grease trailer incl. brake cams, slack adjusters, landing legs, ring feeder & other grease points		MH	
11	Check hoist mounting bolts, hoses, coupling		MH	
12	Check number plate & rego label security. Check that rego label is current		MH	
13	Check condition of front air connections, light plug base & electrical lead		MH	
14	Check security of spare wheels & spare wheel carrier/gate rack		MH	
15	Check condition & security of all mudflaps, mudguards, brackets & spray suppression		MH	
16	Check landing legs for damage & security		MH	
17	Check sub frame & cross members for cracks, damage & security		MH	
18	Check condition, position & security of all air hoses		MH	

19	Check brake linings & drums for wear. Check hub seals for leakage
20	Check security of height control valves and links & adjust if required
	Check skid plate/king pin security & condition, check draw bar/bushes and towing eye NOTE: If draw bar eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be
21	checked for tolerances
22	Check wheel nut tensions, check valve stem alignment
23	Check all tyre pressures and refit valve caps (including spare) report abnormal wear
24	Check condition & security of rear marker signs
25	Check ring feeder condition, operation & security
26	Lubricate twist locks & check operation & security of pedestals, straighten handles as required
27	Check condition & security of rope rails, gate pockets, winch rails & straps
28	Check condition & security of floor and associated components
29	Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear
30	Check security & bolt tension of airbag suspension hangers & radius rod arms
31	Raise wheel assembly & check bearings for free play by "feel" only & adjust as required
32	Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted

MH	
MH	
MH	
MH	
MH	
MH	
N/A	
N/A	
MH	
MH	
MH	
MH	



33	Check brake linings & drums for wear whilst hubs are removed
34	Check hubs for cracks and tapered shoulders for wear
35	Remove bearings and clean/inspect for reuse
36	Replace mudflaps & decals as required
37	Remove s/cam slack adjuster pins and rotate/lubricate
38	Pack bearings with fresh grease & reassemble

Initial if adjusted - Tick if OK

PLEASE COMPLETE PAGE 2



TRAILER & DOLLY SERVICE SHEET

DATE 24-3-25

START TIME _____ FINISH TIME _____


JOB NO _____

FLEET NO 1223 KM'S 246720 HRS

REGO _____

Service Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable		A Service	B Service	C Service
Local Trailers	40000km/365 days	7 DAYS	14 DAYS	40000KM
Linehaul Trailers	15000km 10 days 150000km/365days		15000KM	150000KM
1	Check faults noted on daily prestart and repair as necessary	MH		
2	Check fleet numbers are serviceable	MH		
3	Record Hub meter reading	MH		
4	Lubricate Container Pins	N/A		
5	Check operation & condition of all lights/reflectors	MH		
6	Apply Air Check for leaks from boosters, valves & air lines	MH		
7	Adjust brakes , visually inspect components	MH		
8	Check air cells for air leaks and deterioration	MH		
9	Drain all air tanks, report if any oil is present in system	MH		
10	Grease trailer incl. brake cams, slack adjusters, landing legs, ring feeder & other grease points	MH		
11	Check hoist mounting bolts, hoses, coupling	MH		
12	Check number plate & rego label security. Check that rego label is current	MH		
13	Check condition of front air connections, light plug base & electrical lead	MH		
14	Check security of spare wheels & spare wheel carrier/gate rack	MH		
15	Check condition & security of all mudflaps, mudguards, brackets & spray suppression	MH		
16	Check landing legs for damage & security	MH		
17	Check sub frame & cross members for cracks, damage & security	MH		
18	Check condition, position & security of all air hoses	MH		

19	Check brake linings & drums for wear. Check hub seals for leakage
20	Check security of height control valves and links & adjust if required
21	Check skid plate/king pin security & condition, check draw bar/bushes and towing eye eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be checked for tolerances
22	Check wheel nut tensions, check valve stem alignment
23	Check all tyre pressures and refit valve caps (including spare) report abnormal wear
24	Check condition & security of rear marker signs
25	Check ring feeder condition, operation & security
26	Lubricate twist locks & check operation & security of pedestals, straighten handles as required
27	Check condition & security of rope rails, gate pockets, winch rails & straps
28	Check condition & security of floor and associated components
29	Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear
30	Check security & bolt tension of airbag suspension hangers & radius rod arms
31	Raise wheel assembly & check bearings for free play by "feel" only & adjust as required
32	Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted

[illegible]

front

rear

- 33 Check brake linings & drums for wear whilst hubs are removed
- 34 Check hubs for cracks and tapered shoulders for wear
- 35 Remove bearings and clean/inspect for reuse
- 36 Replace mudflaps & decals as required
- 37 Remove s/cam slack adjuster pins and rotate/lubricate
- 38 Pack bearings with fresh grease & reassemble

Initial if adjusted - Tick if OK

PLEASE COMPLETE PAGE 2



TRAILER & DOLLY SERVICE SHEET

Work/Repairs carried out

* REPLACE FLAT TIRE ON MIDDLE AXLE
LHS INNER WITH A RUN-OUT

A SPLIT UP AND GREASE KING PIN


List any defect found

Part No/Consumables	Qty	Part No/Consumables	Qty

Tradesperson Name	MATT H	Signature	
		Date	24-3-25



WORLD WELDING & TRANSPORT SERVICES

Maintenance ReportVEHICLE: TL 23DATE: 12-4-25HRS: —KLM: 256,355DESCRIPTION OF MAINTENANCE:

* NEW TIRES FITTED TO FRONT AXLE RHS
AND REAR AXLE LHS (TR668)

* NEW BRAKE PADS FITTED TO FRONT AXLE
RHS.

* REPLACE TIRES ON MIDDLE AXLE RHS WITH
Run-outs.

NAME: Pat HSIGNATURE: [Signature]




WORLD WELDING & TRANSPORT SERVICES

Maintenance Report

VEHICLE: TL 23DATE: 4-5-25

HRS: _____

KLM: 265545DESCRIPTION OF MAINTENANCE:

* REPLACE TIRES WITH Run-outs on
MIDDLE AXLE LHS AND FIT NEW BRAKE PADS

NAME: Mat HSIGNATURE: [Signature]



WORLD WELDING & TRANSPORT SERVICES

Maintenance Report


VEHICLE: TL 23

DATE: 25/5/25

HRS: _____

KLM: _____

DESCRIPTION OF MAINTENANCE:



Repair Rubber mud guard

NAME: L. Fuchs

SIGNATURE: [Signature]



TRAILER & DOLLY SERVICE SHEET

DATE 14-7-25 START TIME _____ FINISH TIME _____
FLEET NO 7283 KM'S 281,859 HRS _____

JOB NO _____
REGO 313QZH

Service Items - Mechanic/Fitters to complete Initial = OK, X Repair, NA = Not Applicable		A Service	B Service	C Service
Local Trailers	40000km/365 days	7 DAYS	14 DAYS	40000KM
Linehaul Trailers	15000km 10 days 150000km/365days		15000KM	150000KM
1	Check faults noted on daily prestart and repair as necessary		MH	
2	Check fleet numbers are serviceable		MH	
3	Record Hub meter reading		MH	
4	Lubricate Container Pins		N/A	
5	Check operation & condition of all lights/reflectors		MA	
6	Apply Air Check for leaks from boosters, valves & air lines		MH	
7	Adjust brakes , visually inspect components		MH	
8	Check air cells for air leaks and deterioration		MH	
9	Drain all air tanks, report if any oil is present in system		MH	
10	Grease trailer incl. brake cams, slack adjusters, landing legs, ring feeder & other grease points		MH	
11	Check hoist mounting bolts, hoses, coupling		MH	
12	Check number plate & rego label security. Check that rego label is current		MH	
13	Check condition of front air connections, light plug base & electrical lead		MH	
14	Check security of spare wheels & spare wheel carrier/gate rack		MH	
15	Check condition & security of all mudflaps, mudguards, brackets & spray suppression		MH	
16	Check landing legs for damage & security		MH	
17	Check sub frame & cross members for cracks, damage & security		MH	
18	Check condition, position & security of all air hoses		MH	

19	Check brake linings & drums for wear. Check hub seals for leakage
20	Check security of height control valves and links & adjust if required
21	Check skid plate/king pin security & condition, check draw bar/bushes and towing eye eye bolt is found loose, it is not to be retorqued and must be removed and replaced and draw bar eye boss to be checked for tolerances
22	Check wheel nut tensions, check valve stem alignment
23	Check all tyre pressures and refit valve caps (including spare) report abnormal wear
24	Check condition & security of rear marker signs
25	Check ring feeder condition, operation & security
26	Lubricate twist locks & check operation & security of pedestals, straighten handles as required
27	Check condition & security of rope rails, gate pockets, winch rails & straps
28	Check condition & security of floor and associated components
29	Raise trailer by rear frame & individually inspect rocker/radius bushes, wear pads, air cells for wear
30	Check security & bolt tension of airbag suspension hangers & radius rod arms
31	Raise wheel assembly & check bearings for free play by "feel" only & adjust as required
32	Indicate on below drawing wheel bearings that are replaced, checked and/or adjusted

MH	
MH	
MH	
MH	
MH	
MH	
MH	
N/A	
N/A	
MH	
MH	
MH	
MA	
MT	




33	Check brake linings & drums for wear whilst hubs are removed
34	Check hubs for cracks and tapered shoulders for wear
35	Remove bearings and clean/inspect for reuse
36	Replace mudflaps & decals as required
37	Remove s/cam slack adjuster pins and rotate/lubricate
38	Pack bearings with fresh grease & reassemble

Initial if adjusted - Tick if OK

PLEASE COMPLETE PAGE 2

[illegible][illegible]

Tradesperson Name	MATI H	Signature	
		Date	14-7-25



WORLD WELDING & TRANSPORT SERVICES


Maintenance Report

VEHICLE: TL 9223

DATE: 21/2/25

HRS: _____

KLM: 285159



DESCRIPTION OF MAINTENANCE:

Replace Rideberg ll valves

NAME: L. Korb

SIGNATURE: [Signature]

Certificate of inspection
Trailers & Dollies over 750kg



Ph 0417 600 249
ABN 97 108 243 714

**SUPERIOR
MACHINERY
MAINTENANCE**

Owner and vehicle details
Vehicle Owner's name and address

WWATIS
10 KOLONGO CRES
MT ISA QLD Postcode 4825

Plate No.
(if applicable) 313 QZH State QLD Unit No. TL23

VIN/Chassis no.
6T9T25NT0D2NUM092

Make Model
TRISMA SEMI TRAILER
Body Shape Badge (eg. Cargo)
SEMI TRAILER

Compliance type
Compliance Plate ☒ Import Plate ☐ Other ☐
Date on Plate Vehicle Colour
2013 YELLOW/BLACK

Left or Right hand drive?
Tare GVM 47000 GCM

Results of inspection
Please indicate Pass ☒ Fail ☒

	1st inspection	Final inspection
Identification	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Modifications	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Lights & Electrical Components	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Body & Chassis	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Suspension	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Wheels & Tyres	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Brakes	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Tow Coupling	<input checked="" type="checkbox"/>	<input type="checkbox"/>
1st Axle	SB <input checked="" type="checkbox"/> HB <input checked="" type="checkbox"/>	SB <input type="checkbox"/> HB <input type="checkbox"/>
2nd Axle	SB <input checked="" type="checkbox"/> HB <input checked="" type="checkbox"/>	SB <input type="checkbox"/> HB <input type="checkbox"/>
3rd Axle	SB <input checked="" type="checkbox"/> HB <input checked="" type="checkbox"/>	SB <input type="checkbox"/> HB <input type="checkbox"/>
4th Axle	SB <input type="checkbox"/> HB <input type="checkbox"/>	SB <input type="checkbox"/> HB <input type="checkbox"/>

Details of other items rejected
WHEEL NUT INDICATORS

1st Inspection
Result ☒
Inspection date 25/8/25 Inspection time 8:00 am
Odometer reading
Signature of Examiner S-PY Examiner's no. 18904

Final inspection (must not be more than 14 days from date of 1st inspection)
Result ☒
Inspection date 27/8/25 Inspection time 8:00 am
Odometer reading
Signature of Examiner S-PY Examiner's no. 18904

Inspection Station details
Name and location
SUPERIOR MACHINERY MAINTENANCE
27 COMMERCIAL RD Postcode 4825

Approved Inspection Station Number
10588

Certification
Approved examiner - I have inspected the vehicle indicated on this form and found it had no defect that would affect its safe use of the road and it meets the requirements of the Transport Operations (Road Use Management) Act 1995.
Inspected by - Signature of Examiner Date
S-PY 27-8-25
Name of Examiner (please print) Examiner's no.
SAM PYLE 18904